



View this document in HTML
crestron.com/docs/9045



Product Manual

DM NAX[®]

Audio-over-IP Distribution Platform

Original Instructions

The U.S. English version of this document is the original instructions.

All other languages are a translation of the original instructions.

Regulatory Model: M1845004

Crestron product development software is licensed to Crestron dealers and Crestron Service Providers (CSPs) under a limited nonexclusive, nontransferable Software Development Tools License Agreement. Crestron product operating system software is licensed to Crestron dealers, CSPs, and end-users under a separate End-User License Agreement. Both of these Agreements can be found on the Crestron website at www.crestron.com/legal/software_license_agreement.

The product warranty can be found at www.crestron.com/warranty.

The specific patents that cover Crestron products are listed at www.crestron.com/legal/patents.

Certain Crestron products contain open source software. For specific information, visit www.crestron.com/opensource.

Crestron, the Crestron logo, Crestron Toolbox, DM, DM NAX, DM NVX and XiO Cloud are either trademarks or registered trademarks of Crestron Electronics, Inc. in the United States and/or other countries. Apple, AirPlay, and macOS are either trademarks or registered trademarks of Apple Inc., registered in the U.S. and other countries. Bluetooth is either a trademark or registered trademark of Bluetooth SIG, Inc. in the United States and/or other countries. Dante is either a trademark or registered trademark of Audinate Pty Ltd. in the United States and/or other countries. Deezer is either a trademark or registered trademark of Deezer société anonyme (sa) in the United States and/or other countries. SOUNDMACHINE is either a trademark or registered trademark of Easy Tempo, Inc. in the United States and/or other countries. RACO is either a trademark or registered trademark of Hubbell Incorporated in the United States and/or other countries. Active Directory and Windows are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries. Pandora is either a trademark or registered trademark of Pandora Media, Inc. in the United States and/or other countries. Roon and Roon Core are either trademarks or registered trademarks of Roon Labs LLC in the United States and/or other countries. SiriusXM is either a trademark or registered trademark of Sirius XM Radio Inc. in the United States and/or other countries. Spotify is either a trademark or registered trademark of Spotify Inc. in the United States and/or other countries. TIDAL is either a trademark or registered trademark of Tidal Music as Corporation Norway in the United States and/or other countries. TOSLINK is either a trademark or registered trademark of Toshiba Electronics Devices & Storage Corporation in the United States and/or other countries. USB-C is either a trademark or registered trademark of USB Implementers Forum, Inc. in the United States and/or other countries. Qobuz is either a trademark or registered trademark of Xandrie société anonyme (sa) in the United States and/or other countries. Other trademarks, registered trademarks, and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Crestron disclaims any proprietary interest in the marks and names of others. Crestron is not responsible for errors in typography or photography.

©2024 Crestron Electronics, Inc.

Contents

Overview	1
Features	1
Products	1
DM-NAX-2XLRI-1G	2
DM-NAX-8ZSA	4
Physical Description	4
Applications	8
DM-NAX-16AIN	15
Physical Description	15
Application	18
DM-NAX-4ZSA-50	19
DM-NAX-4ZSP	21
Physical Description	21
DM-NAX-AMP-X300	25
DM-NAX-AUD-IO	27
DM-NAX-AUD-USB	28
DM-NAX-BTIO-1G	30
Specifications	32
DM-NAX-2XLRI-1G Specifications	32
Specifications	32
Dimension Drawing	35
DM-NAX-8ZSA Specifications	36
Specifications	36
Dimension Drawing	39
DM-NAX-4ZSA-50 Specifications	40
Specifications	40
Dimension Drawing	43
DM-NAX-4ZSP Specifications	44
Specifications	44
Dimension Drawing	47
DM-NAX-16AIN Specifications	48
Specifications	48
Dimension Drawing	50
DM-NAX-AMP-X300 Specifications	51
Specifications	51
Dimension Drawings	54
DM-NAX-AUD-IO Specifications	55
Specifications	55
Dimension Drawing	57
DM-NAX-AUD-USB Specifications	58
Specifications	58

Dimension Drawing	60
DM-NAX-BTIO-1G Specifications	61
Specifications	61
Dimension Drawing	63
Installation	64
DM-NAX-2XLRI-1G Installation	65
In the Box	65
Mounting the Device	65
Connect the Device	68
Reset the Device	69
DM-NAX-8ZSA Installation	71
In the Box	71
Install the Device	72
Connect the Device	73
Apple® AirPlay® Setup	77
Spotify® Connect Setup	78
Observe the LED Indicators	78
Reset the Device	80
DM-NAX-4ZSA-50 Installation	81
In the Box	81
Install the Device	82
Connect the Device	85
Speaker Connections	87
Spotify® Setup	87
Observe the LED Indicators	88
Reset the Device	88
DM-NAX-4ZSP Installation	90
In the Box	90
Install the Device	91
Connect the Device	92
Apple® AirPlay® Setup	94
Spotify® Connect Setup	95
Observe the LED Indicators	96
Reset the Device	97
DM-NAX-16AIN Installation	98
In the Box	98
Install the Device	99
Connect the Device	101
Observe the LED Indicators	103
Reset the Device	104
DM-NAX-AMP-X300 Installation	105
In the Box	106
Install the Device	107
Connect the Device	111
Speaker Mode Selection Switch	111

Lo-Z Modes Selection Switch	112
Observe the LED Indicators	112
Reset the Device	113
Output Wiring Options	114
DM-NAX-AUD-IO Installation	117
In the Box	117
Mount the Device	117
Connect the Device	121
Reset the Device	123
DM-NAX-AUD-USB Installation	125
In the Box	125
Mount the Device	125
Connect the Device	129
Reset the Device	131
DM-NAX-BTIO-1G Installation	132
In the Box	132
Mount the Device	132
Connect the Device	134
Reset the Device	135
Configuration	136
DM-NAX-2XLRI-1G	137
Web Interface Configuration	137
Action	139
Status	143
Settings	145
Security	177
802.1x Configuration	186
Access the Web Interface With the Crestron Toolbox™ Application	188
DM-NAX-8ZSA	189
Web Interface Configuration	189
Action	192
Status	201
Settings	204
Security	244
802.1x Configuration	253
Access the Web Interface With the Crestron Toolbox™ Application	255
DM-NAX-4ZSA-50	256
Web Interface Configuration	256
Action	258
Status	265
Settings	267
Security	302
802.1x Configuration	311
Access the Web Interface With the Crestron Toolbox™ Application	313
DM-NAX-4ZSP	314

Web Interface Configuration	314
Action	317
Status	325
Settings	328
Security	363
802.1x Configuration	372
Access the Web Interface With the Crestron Toolbox™ Application	374
DM-NAX-16AIN	375
Web Interface Configuration	375
Action	378
Status	384
Settings	387
Security	395
802.1x Configuration	404
Access the Web Interface With the Crestron Toolbox™ Application	406
DM-NAX-AMP-X300	407
Web Interface Configuration	407
Action	409
Status	413
Settings	417
Security	463
802.1x Configuration	471
Access the Web Interface With the Crestron Toolbox™ Application	472
DM-NAX-AUD-IO	473
Web Interface Configuration	473
Action	475
Status	479
Settings	481
Security	517
802.1x Configuration	526
Access the Web Interface With the Crestron Toolbox™ Application	528
DM-NAX-AUD-USB	529
Web Interface Configuration	529
Action	531
Status	535
Settings	537
Security	573
802.1x Configuration	582
Access the Web Interface With the Crestron Toolbox™ Application	584
DM-NAX-BTIO-1G	585
Web Interface Configuration	585
Action	587
Status	591
Settings	593
Security	629

802.1x Configuration	638
Access the Web Interface With the Crestron Toolbox™ Application	640
Resources	641
Crestron Support and Training	641
Programmer and Developer Resources	641
Product Certificates	641

Overview

DM NAX® Audio-over-IP (AoIP) solutions are built on AES67 standards with the additional ease of configuration via a web interface, SIMPL, C#, and/or a RESTful API. It is compatible with DM NVX® endpoints through an AES67 secondary audio stream, and also with third-party AES67 solutions, including Dante® devices.

Features

- **Scalability:** DM NAX systems can scale to meet any demand. DM NAX supports up to 32 DM NAX devices in sync. In addition, DM NAX can support any combination of units for additional input-output requirements.
- **Flexibility:** Multiple input-output options are supported. Built-in streaming services and an expanding hardware lineup are available for a broad range of applications.
- **Interoperability:** DM NAX is built on AES67 AoIP standards and is compatible with any third-party AES67 solution


Products

The following products are described in this product manual:

- [DM-NAX-2XLRI-1G on page 2](#)
- [DM-NAX-8ZSA on page 4](#)
- [DM-NAX-16AIN on page 15](#)
- [DM-NAX-4ZSA-50 on page 19](#)
- [DM-NAX-4ZSP on page 21](#)
- [DM-NAX-AMP-X300 on page 25](#)
- [DM-NAX-AUD-IO on page 27](#)
- [DM-NAX-AUD-USB on page 28](#)
- [DM-NAX-BTIO-1G on page 30](#)

DM-NAX-2XLRI-1G

The DM-NAX-2XLRI-1G provides a single-gang wall mount for (2) XLR inputs. The rear of the wall plate features an Ethernet connection for power and DM NAX® audio-over-IP (AOIP) networking. The rear panel also features a five-pin line-level audio output for transmitting an audio signal to a Crestron media wall plate (MP-WP-2XLRO-1G and MP-WP-2RCAO-1G).



- Two XLR input connectors
- Two rear-panel line-level audio outputs
- Single-gang U.S. wall box installation
- Power over Ethernet (PoE) network powered
- Mountable in a standard US electrical box or on a rack rail via included hardware
- Connects directly to a managed network to route to or from other DM NAX® and DM NVX® devices
- Interoperable with Dante® audio networking devices via AES67 compatibility
- Streamlined configuration through a web interface
- Seamless Crestron system integration with SIMPL Windows programming

Audio-over-IP

DM NAX takes audio distribution to a whole new level by putting it on the network. The DM-NAX-2XLRI-1G sends and receives DM NAX and AES67 encoded audio over a standard IP network. A single DM NAX system can handle audio distribution between 32 DM NAX devices and supports up to 256 audio output zones. DM NAX devices can seamlessly pull and distribute the audio from DM NVX sources.

Line Level and Microphone Level Support

The front panel XLR connectors of the DM-NAX-2XLRI-1G can be configured for either line level or microphone level input. Each XLR input can be configured to send a +48V phantom power signal to power a connected condenser microphone.

Digital Signal Processing (DSP)

DSP capabilities such as a 5-band EQ per XLR input and level control of all input and output signal types are available to configure via the web user interface.

Encoder and Decoder Functionality

The DM-NAX-2XLRI-1G can operate as a network AV encoder and decoder. The local input sources on one amplifier can be sent as AoIP streams to DM NAX, Dante, or AES67 capable devices.

Simultaneously, the DM-NAX-2XLRI-1G can receive AoIP streams from these same devices and decode them for local output.

DM-NAX-8ZSA

The Crestron DM-NAX-8ZSA is a next generation DM NAX® Audio-over-IP (AoIP) amplifier that puts Crestron multiroom audio distribution on the network. It provides eight amplified stereo zone (16-channel) outputs. Four stereo line-level outputs mirror speaker zone outputs 1-4.

A dedicated streaming service player for each of the eight zones enables complete freedom to stream different content in every zone. Full DSP capabilities are available on the line and speaker outputs.

Voltage triggers corresponding to the 4 stereo line-level analog outputs can be used to power connected external amplifiers on and off.

The DM-NAX-8ZSA supports [Amazon Connected Speakers](#).


For installation information, refer to the [DM-NAX-8ZSA Quick Start](#).

Physical Description

The following sections provide information about the connectors, controls, and indicators that are available on the DM-NAX-8ZSA device.

Front Panel


The following illustration shows the front panel of the DM-NAX-8ZSA.



- ① **PWR:** (1) LED, indicates operating power is supplied; illuminates amber while booting, white when powered on, red when in standby (no audio or LAN connection), and off when no power is supplied.
- ② **LAN:** (1) LED, illuminates white when the amplifier is connected to a network with a valid IP address, and off when the device is not connected to a network or the IP address is invalid.
- ③ **NAX:** (1) LED, illuminates white when the AoIP is ready to pass and the unit's PTP clock is synced, and off when there is no AoIP is passing to or from an amplifier and/or PTP is not synced.
- ④ **SOURCE:** (8) LEDs, illuminates white when a signal is detected on the specified input/source, red when there is clipping on an analog input or bitstream audio detected on a digital input, and off when there is no signal detected on the specified input/source.
- ⑤ **ZONE:** (8) LEDs, illuminates white when there is audio output on the indicated zone, red when clipping or a fault is detected on the zone output due to overcurrent, over temperature, or low voltage.

Rear Panel

The following illustration shows the rear panel of the DM-NAX-8ZSA.




- 1 DIGITAL INPUTS:** (2) JIS F05 female TOSLINK® optical fiber connectors, S/PDIF optical digital audio inputs;
 (2) RCA female; S/PDIF coaxial digital audio inputs; Input Impedance: 75 Ω
- 2 ANALOG INPUTS:** (8) RCA female comprising (4) unbalanced stereo line-level audio inputs; Input Impedance: 10000 Ω ;
 Maximum Input Level: 2 Vrms
- 3 SPEAKER OUTPUTS:** (16) 2-pin 7.62 mm detachable terminal block;
 Balanced/unbalanced stereo line-level audio outputs,
 Output Impedance: 4 Ω /8 Ω ;
 Maximum Output Level: 150 W single-ended at 8 Ω , 300 W single-ended at 4 Ω ,
 with zones bridgeable up to 500 W at 8 Ω .
- 4 LINE OUTPUTS:** (8) RCA connectors, female; Comprise (4) unbalanced line-level stereo audio outputs (mirror corresponding speaker outputs pair 1 – 4);
 Output Impedance: 100 Ω ; Maximum Output Level: 2 Vrms;
 (2) 5-pin 3.5mm detachable terminal blocks; Balanced stereo line-level audio outputs (mirror corresponding unbalanced RCA output pairs 1 – 2);
 Output Impedance: 150 Ω ; Maximum Output Level: 4 Vrms
- 5 I/O Port:** (1) single 5-pin Phoenix block that comprises four I/O ports, and a shared ground
- 6 TRIGGER:** (2) 4-pin Phoenix connectors for all outputs;
 The triggers correspond to the respective LINE OUTPUTS 1-4 and will send a +10V signal to an external amplifier whenever an audio signal is routed to the respective line output.
- 7 Ethernet 1:** (1) 8-pin RJ-45 connector, female;
 100BASE-TX/1000BASE-T Ethernet port;
 Green LED indicates Ethernet link status;
 Flashing amber LED indicates Ethernet activity

Ethernet 2: (1) 8-pin RJ-45 connector, female;
100BASE-TX/1000BASE-T Ethernet port;
Green LED indicates Ethernet link status;
Flashing amber LED indicates Ethernet activity

- 8 **SETUP:** (1) Push button: Pressing and holding the **SETUP** button for 15 seconds with power supplied clears network settings and restores the default DHCP mode;
Pressing and holding the **SETUP** button with power disconnected, then connecting the power supply and continuing to hold **SETUP** button for 30 seconds performs a factory restore;
(1) LED, illuminates red when the button is pressed, flashes red when reset has been initiated
- 9 **CONSOLE:** (1) Standard USB 2.0 Type B connector, female
- 10 **GROUND:** 6-32 screw, chassis ground lug
- 11 **10A Fuse:** 10 A Fuse
- 12 **POWER OUTLET:** (1) 100-240V~50/60Hz Universal AC; IEC 60320 C14 Main power inlet, mates with removable power cord (included)

Applications

This section shows DM-NAX-8ZSA device in multizone applications.




1. Phono sources require the addition of a line-level phono preamp.

NOTES:

- DM NAX devices generate multicast traffic on the network. Even a single DM NAX device connected to an unmanaged network can cause communication issues with other devices connected to the same network. For information on system installation, refer to the [DM NAX® Audio-over-IP System Design Guide](#).
- If DM NAX devices must be set up before configuring network settings on a managed switch, use the [Port Selection on page 242](#) functionality on the DM NAX device to isolate the AoIP traffic to the secondary Ethernet port. For example, when connecting the DM NAX to a control system or authenticating streaming service accounts. This ensures that during setup, the primary Management port of the device does not receive AoIP traffic.


This application diagram shows the following setup:

- Up to eight zones of amplification and audio distribution
- Local line level input
- Local line level output to an Audio Video Receiver (AVR) mirroring a zone of amplification
- Available DM NVX audio streams to route audio from video sources to non-video zones
- Available music streaming services on up to eight DM NAX zones



This application diagram shows the following setup:

- Up to eight zones of amplification and audio distribution
- Local line level input
- Local line level output to an AVR mirroring a zone of amplification
- Available music streaming services on up to eight DM NAX zones
- The DM-NAX-16AIN is used to transmit audio from the DM chassis' video sources onto the DM NAX network for routing to the non-video zones on the DM-NAX-8ZSA



This application diagram shows different 2.1 configurations and how they affect the zone count of an DM-NAX-8ZSA. By default, a zone comprises two speaker outputs (a left and a right).

- The 2.1 configuration at the left of the diagram comprises two speaker outputs, with an additional line output that feeds the subwoofer.

NOTE: This configuration is only applicable for zones with an available line output (1 through 4).


- The middle configuration (2.1 bridged sub) comprises four speaker outputs - two left and right and two for the bridged sub.

NOTE: This configuration is only applicable when enough subsequently numbered zones are available on the amplifier. For example, the 2.1 bridged sub cannot be used on zone 8 as there is no speaker output pair 9.

- The right configuration (bridged 2.1) comprises six speaker outputs - two for the bridged left, two for the bridged right, and two for the bridged sub.

NOTE: This configuration is only applicable when enough subsequently numbered zones are available on the amplifier. For example, the 2.1 bridged sub cannot be used on zone 7 or 8 as there is no speaker output pair 9 or 10.

Having higher output-count zone configurations on a single DM-NAX-8ZSA will affect the total available zone count on a given box. For example, if you have a single bridged 2.1 configuration on an DM-NAX-8ZSA, it will lower the maximum zone count to six, as the bridged 2.1 consumes three zones worth of speaker outputs on its own.




This application diagram shows the following setup:

- Mirrored zones (Zone 1 and Zone 2 each have two rooms receiving the same audio signal)
- Parallel wiring of low impedance speakers in two Locker Room areas


NOTE: This is a parallel wiring of 8 Ω speakers for a total supported load of 4 Ω per channel. Parallel wiring lowers the effective impedance of the connected loads, so make sure the speakers impedance matches the supported impedance levels from the DM-NAX-8ZSA.

- Using the line outputs of the DM-NAX-8ZSA to feed high-impedance amplifiers (AMP-X300s and AMP-4600) for long speaker runs

- Bussing to multiple zones to feed a large group of low-impedance speakers with the same signal and shared controls



This application diagram shows a commercial setup using casting service streaming applications. For example, in a hotel, each room can receive a cast from a third-party device. The Lobby and Pool zones can exist on another DM-NAX-8ZSA unit that is on the same LAN or on a separate VLAN or WAP to cast to/control those zones.



This application diagram shows zones using only the line outputs. Line outputs 1 and 2 feed high impedance amplifiers driving speakers for large outdoor spaces and speaker zone outputs 5-8 feed low-impedance indoor spaces without overlap of signals. The LAN cloud shows that any individual applications can exist as part of a large DM NAX system.

DM-NAX-16AIN

The Crestron DM NAX® Audio-over-IP (AoIP) encoder (DM-NAX-16AIN) provides 16 local stereo audio inputs to a DM NAX Crestron multiroom audio distribution network. It provides 8 digital inputs comprised of 4 SPDIF TOSLINK® connectors and 4 SPDIF coaxial connectors. Each digital input supports 2-channel PCM audio. The DM-NAX-16AIN also provides 8 analog stereo inputs. Inputs 1-4 offer balanced 5-pin terminal block connectors in parallel with unbalanced RCA connectors, and inputs 5-8 offer RCA connectors.


For installation information, refer to the [DM-NAX-16AIN Quick Start](#).

Physical Description

The following sections provide information about the connectors, controls, and indicators that are available on the DM-NAX-16AIN device.

Front Panel


The following illustration shows the front panel of the DM-NAX-16AIN.



- ❶ **PWR:** (1) LED, indicates operating power is supplied; illuminates amber while booting, white when powered on, red when in standby (no audio or LAN connection), and off when no power is supplied.
- ❷ **LAN:** (1) LED, illuminates white when the device is connected to a network with a valid IP address, and off when the device is not connected to a network or the IP address is invalid.
- ❸ **NAX:** (1) LED, illuminates white when the AoIP is ready to pass and the unit's PTP clock is synced, and off when there is no AoIP is passing to or from the device and/or PTP is not synced.
- ❹ **ANALOG SOURCE:** (8) LEDs, illuminates white when a signal is detected on the specified input/source, red when there is clipping on an analog input and off when there is no signal detected on the specified input/source.
- ❺ **DIGITAL SOURCE:** (8) LEDs, illuminates white when a signal is detected on the specified input/source, red when there is bitstream audio detected on a digital input, and off when there is no signal detected on the specified input/source.

Rear Panel

The following illustration shows the rear panel of the DM-NAX-16AIN.




- 1 ANALOG INPUTS:** (8) RCA female comprising (4) unbalanced stereo line-level audio inputs;
 (4) 5-pin phoenix balanced connector;
 Input Impedance: 10000 Ω ;
 Maximum Input Level: 2 Vrms
- 2 DIGITAL INPUTS:** (4) JIS F05 female TOSLINK® optical fiber connectors, S/PDIF optical digital audio inputs;
 (4) RCA female; S/PDIF coaxial digital audio inputs;
 Input Impedance: 75 Ω
- 3 Ethernet 1:** (1) 8-pin RJ-45 connector, female;
 100BASE-TX/1000BASE-T Ethernet port;
 Green LED indicates Ethernet link status;
 Flashing amber LED indicates Ethernet activity

Ethernet 2: (1) 8-pin RJ-45 connector, female;
 100BASE-TX/1000BASE-T Ethernet port;
 Green LED indicates Ethernet link status;
 Flashing amber LED indicates Ethernet activity
- 4 SETUP:** (1) Push button: Pressing and holding the **SETUP** button for 15 seconds with power supplied clears network settings and restores the default DHCP mode; Pressing and holding the **SETUP** button with power disconnected, then connecting the power supply and continuing to hold **SETUP** button for 30 seconds performs a factory restore;
 (1) LED, illuminates red when the button is pressed, flashes red when reset has been initiated
- 5 CONSOLE:** (1) Standard USB 2.0 Type B connector, female
- 6 POWER INLET:** (1) 100-240V~50/60Hz Universal AC; IEC 60320 C14 Main power inlet, mates with removable power cord (included)

- 7 **GROUND:** 6-32 screw, chassis ground lug

Application

This section shows DM-NAX-16AIN device in a multizone application.



This application diagram shows the following setup:

- Up to eight zones of amplification and audio distribution
- Local line level input
- Local line level output to an AVR mirroring a zone of amplification
- Available music streaming services on up to eight DM NAX zones
- The DM-NAX-16AIN is used to transmit audio from the DM chassis' video sources onto the DM NAX network for routing to the non-video zones on the DM-NAX-8ZSA

DM-NAX-4ZSA-50

The Crestron DM-NAX-4ZSA-50 is a next generation DM NAX® Audio-over-IP (AoIP) amplifier that puts Crestron multiroom audio distribution on the network. It provides four amplified stereo zone (8-channel) outputs and an independent line level zone (2-channel) output.

A dedicated streaming service player for each of the four zones enables complete freedom to stream different content in every zone. Full DSP capabilities are available on the speaker outputs.



- Audio-over-IP (AoIP) amplifier
- Built-in streaming services support
- Full DSP capabilities
- Gallium Nitride (GaN) Class D amplification
- 50 W of output power per channel
- Provides four amplified output zones and one additional line-level output zone
- 1 RU high, half-rack width modular form factor
- Interoperable with Dante® audio networking devices via AES67 compatibility
- Built-in chime support
- Streamlined configuration through a web interface
- Seamless Crestron system integration with SIMPL Windows programming

The DM-NAX-4ZSA-50 supports [Amazon Connected Speakers](#).

Audio-over-IP

The DM-NAX-4ZSA-50 sends and receives DM NAX and AES67 encoded audio over a standard IP network. A single DM NAX system can handle audio distribution between 32 DM NAX devices and supports up to 256 audio output zones. DM NAX devices can seamlessly pull and distribute the audio from DM NVX sources.

Streaming and Casting Services

A dedicated streaming service player is built-in for each zone, supporting AirPlay® 2, Internet Radio, Spotify Connect™, Pandora®, SiriusXM®, TIDAL™, Deezer®, Qobuz®, Podcasts and more. The DM-NAX-4ZSA-50 delivers streaming, routing, distribution, and amplification in a single device. Streams can be routed to other non-streaming AoIP devices.

Chimes

A library of chimes is built into the unit. Chimes can be assigned to different zones to help identify them. Whenever a chime is triggered, the zone audio will duck or pause, so the chime can be clearly heard over active media until the chime concludes.

Digital Signal Processing (DSP)

DSP capabilities such as bass and treble boost and cut, loudness, adjustable delay, speaker protection and limiting, tone profiles, a full 10-band EQ per output, and an option to have line output as a fixed or variable level with or without DSP applied are available. Speaker profiles for first and third party speaker models are built in to simplify output DSP tuning.

Encoder and Decoder Functionality

The DM-NAX-4ZSA-50 can operate as a network AoIP encoder and decoder. The local input sources on one amplifier can be sent as AoIP streams to DM NAX, Dante, or AES67 capable devices. Simultaneously, the DM-NAX-4ZSA-50 can receive AoIP streams from these same devices and decode them for local output.

Modular Design

The DM-NAX-4ZSA-50 is housed in a half-width rack-mountable form factor that can be installed individually or ganged together in a single rack space. The amplifier is high-density stackable with other Crestron DM NAX or X-Series amplifiers, allowing multiple units to be installed vertically in an equipment rack without needing extra ventilation space. Rack mount parts are included, so no additional mounting accessories or rack shelves are required.

Whether mounting in a rack or placing on a shelf, it is easy to combine two amplifiers into a single, full rack-width assembly.

Gallium Nitride (GaN) Amplification

The DM-NAX-4ZSA-50 is the first Crestron amplifier to feature GaN Class D technology. GaN amplification allows higher output power to fit into small form factors without sacrificing efficiency or audio performance. The DM-NAX-4ZSA-50 is capable of 50 W per channel of amplifier output power in a half-width 1RU housing that matches the depth of the [DM-NAX-AMP-X300](#).

DM-NAX-4ZSP

The Crestron DM-NAX-4ZSP is a next generation Audio-over-IP (AoIP) preamplifier that puts Crestron multiroom audio distribution on the network. It provides four stereo zone (8-channel) line-level outputs. A dedicated streaming service player enables streaming different content in each of the four zones.

The DM NAX® platform is built on AES67 standards with additional ease of configuration via a web interface, SIMPL Windows, C#, and/or a RESTful API. It is compatible with the following:

- DM NVX® platform through the AES67 secondary audio stream
- Third-party AES67 solutions
- Dante® devices via the compatibility mode enabled through Dante Controller

Full DSP capabilities are available on the line and speaker outputs. Voltage triggers corresponding to the four stereo line-level analog outputs can be used to power connected external amplifiers on and off.


For installation information, refer to the [DM-NAX-4ZSP Quick Start](#).

Physical Description

The following sections provide information about the connectors, controls, and indicators that are available on the DM-NAX-4ZSP device.

Front Panel


The following illustration shows the front panel of the DM-NAX-4ZSP.



- ① **PWR:** (1) LED, indicates operating power is supplied; illuminates white when powered on, red when in standby (no audio or LAN connection), and off when no power is supplied.
- ② **LAN:** (1) LED, illuminates white when the device is connected to a network with a valid IP address, and off when the device is not connected to a network or the IP address is invalid.
- ③ **NAX:** (1) LED, illuminates white when the AoIP is ready to pass and the unit's PTP clock is synced, and off when there is no AoIP is passing to or from an amplifier and/or PTP is not synced.
- ④ **SOURCE:** (4) LEDs, illuminates white when a signal is detected on the specified input/source, red when there is clipping on an analog input or bitstream audio detected on a digital input, and off when there is no signal detected on the specified input/source.
- ⑤ **ZONE:** (4) LEDs, illuminates white when there is audio output on the indicated zone, red when clipping is detected on the output audio.

Rear Panel

The following illustration shows the rear panel of the DM-NAX-4ZSP.



- 1 DIGITAL INPUTS:** (2) JIS F05 female TOSLINK® optical fiber connectors, S/PDIF optical digital audio inputs;
(2) RCA female; S/PDIF coaxial digital audio inputs; Input Impedance: 75 Ω
- 2 ANALOG INPUTS:** (8) RCA female comprising (4) unbalanced stereo line-level audio inputs; Input Impedance: 10000 Ω ;
Maximum Input Level: 2 Vrms
- 3 LINE OUTPUTS:** (4) RCA connectors, female; Comprise (4) unbalanced line-level stereo audio outputs;
Output Impedance: 100 Ω ; Maximum Output Level: 2 Vrms;
(2) 5-pin 3.5mm detachable terminal blocks; Balanced stereo line-level audio outputs (mirror corresponding unbalanced RCA output pairs 1 – 2);
Output Impedance: 150 Ω ; Maximum Output Level: 4 Vrms
- 4 I/O Port:** (1) single 5-pin Phoenix block that comprises four I/O ports, and a shared ground
- 5 TRIGGER:** (2) 4-pin Phoenix connectors for all outputs;
The triggers correspond to the respective LINE OUTPUTS 1-4 and will send a +10V signal to an external amplifier whenever a signal is routed to the respective line output.
- 6 Ethernet 1:** (1) 8-pin RJ-45 connector, female;
100BASE-TX/1000BASE-T Ethernet port;
Green LED indicates Ethernet link status;
Flashing amber LED indicates Ethernet activity

Ethernet 2: (1) 8-pin RJ-45 connector, female;
100BASE-TX/1000BASE-T Ethernet port;
Green LED indicates Ethernet link status;
Flashing amber LED indicates Ethernet activity

- 7 **SETUP:** (1) Push button: Pressing and holding the **SETUP** button for 15 seconds with power supplied clears network settings and restores the default DHCP mode; Pressing and holding the **SETUP** button with power disconnected, then connecting the power supply and continuing to hold **SETUP** button for 30 seconds performs a factory restore;
(1) LED, illuminates red when the button is pressed, flashes red when reset has been initiated
- 8 **CONSOLE:** (1) Standard USB 2.0 Type B connector, female
- 9 **POWER OUTLET:** (1) 100-240V~50/60Hz Universal AC; IEC 60320 C14 Main power inlet, mates with removable power cord (included)
- 10 **GROUND:** 6-32 screw, chassis ground lug

DM-NAX-AMP-X300

The DM-NAX-AMP-X300 is a high performance, space saving, energy efficient, professional grade Audio-over-IP (AoIP) amplifier. Supporting DM NAX, Dante, AES67, and local inputs, all with full DSP capabilities, this multichannel amplifier is suitable for both residential and commercial configurations.



- Audio-over-IP (AoIP) amplifier
- Native Dante® mode
- Full DSP capabilities
- Streamlined configuration through a web interface
- ENERGY STAR® certified power amplifier
- 1 RU high, half-rack width form factor supports surface and rack mounting
- Configurable for Lo-Z ($4/8\ \Omega$) or Hi-Z (70V or 100V) operation
- Configurable for 4 x up to 75 W output, 2 x up to 150 W output, 1 x up to 300 W (bridged) output, and 2 x up to 75 W + 1 x up to 150 W (bridged) output
- Matrix mixing of any input to any output
- Always On feature allows constant on connection with very low power consumption
- Connects directly to a managed network to route to or from DM NAX/DM NVX®, AES67, or Dante devices
- Supports mic/line level analog inputs and balanced/unbalanced line level outputs
- Individual zone power control and global standby
- Seamless Crestron system integration with Crestron Home® OS and SIMPL Windows programming

Audio-over-IP

DM NAX takes audio distribution to a whole new level by putting it on the network. The DM-NAX-AMP-X300 sends and receives DM NAX, Dante, and AES67 encoded audio over a standard IP network. A single DM NAX system can handle audio distribution between 32 DM NAX devices and

supports up to 256 audio output zones. DM NAX devices can seamlessly pull and distribute the audio from DM NVX sources.

Digital Signal Processing (DSP)

The DM-NAX-AMP-X300 has two DSP modes. Residential mode enables the quick and easy configuration of layout, speaker protection output limits, and speaker profiles for each zone. In Commercial mode, make full use of the DM-NAX-AMP-X300's true mixing matrix as well as advanced options for equalization and dynamics processing on each individual speaker, line, and network channel.

Encoder and Decoder Functionality

The DM-NAX-AMP-X300 can operate as a network AV encoder and decoder. The local input sources on one amplifier can be sent as AoIP streams to DM NAX, Dante, or AES67 capable devices. Simultaneously, the DM-NAX-AMP-X300 can receive AoIP streams from these same devices and decode them for local output.

Lo-Z (4/8 Ω) and Hi-Z (70V or 100V) Output

The DM-NAX-AMP-X300 is a 4-channel amplifier (up to 75 W per channel) which can also be configured for 3-channel bridged operation (up to 75 W per single ended channel and up to 150 W for the bridged channel), 2-channel bridged operation (up to 150 W per channel), or 1 channel bridged operation (up to 300 W). A choice of Lo-Z outputs to drive 4- or 8- Ω speakers, or Hi-Z outputs to drive a distributed speaker system (70V or 100V) can be used. Balanced/Unbalanced inputs are provided for connection to two stereo or four mono sources through detachable terminal blocks.

ENERGY STAR® Certified

An energy-efficient design enables the DM-NAX-AMP-X300 to meet demanding ENERGY STAR requirements. In addition to its high efficiency under operation, the amplifier draws no added inrush current during power-up, thereby reducing AC circuit requirements and allowing multiple amplifiers to be connected to a single switched circuit. To reduce energy usage further, the DM-NAX-AMP-X300 can be configured to enter a low-power standby state if no input signal is detected on either channel for 25 minutes. Signal detection sensitivity has been optimized to improve response time when triggering the amplifier to the on state, allowing it to return to full operation within a half-second. The REMOTE input can be connected to a contact closure to place the amplifier outputs in controlled standby mode.

Modular Design

The DM-NAX-AMP-X300 is housed in a half-width rack-mountable form factor that can be installed individually or ganged together in a single rack space. The amplifier is high-density stackable with other Crestron modular amps, allowing multiple units to be installed vertically in an equipment rack without needing extra ventilation space. Rack and surface mount parts are included, so no additional mounting accessories or rack shelves are required.


Whether mounting in a rack, attaching to a flat surface, or placing on a shelf, it is easy to combine two amplifiers into a single, full rack-width assembly.

Fully Protected

The DM-NAX-AMP-X300 features protection against overheating, shorted or overloaded speaker lines, excessive input signals, and other faults. In the case of a shorted speaker line or overheating condition, paired outputs mute automatically until the fault condition is resolved. In the event of a prolonged fault, all outputs mute and the amplifier shuts down.

DM-NAX-AUD-IO

The DM-NAX-AUD-IO is a DM NAX® encoder and decoder with support for analog line-level audio input and output. The device is housed in a versatile form factor that can be mounted in a single-gang standard electrical box, under a table, or on a rack rail. An additional polycarbonate label is included with rotated text to make the front panel more legible in electrical box installations. The rear panel of the device features an Ethernet connection for PoE, Audio over IP (AoIP), and control.



- Line-level, balanced/unbalanced analog audio input and output via detachable terminal block connectors
- Power over Ethernet (PoE) network powered
- Mountable in a standard US electrical box, under a table, or on a rack rail via included hardware
- Connects directly to a managed network to route to or from other DM NAX® and DM NVX® devices
- Interoperable with Dante® audio networking devices via AES67 compatibility
- Streamlined configuration through a web interface
- Seamless Crestron system integration with SIMPL Windows programming

Audio-over-IP

DM NAX takes audio distribution to a whole new level by putting it on the network. The DM-NAX-AUD-IO sends and receives DM NAX and AES67 encoded audio over a standard IP network. A single DM NAX system can handle audio distribution between 32 DM NAX devices and supports up to 256 audio output zones. DM NAX devices can seamlessly pull and distribute the audio from DM NVX sources.

Digital Signal Processing (DSP)

DSP capabilities such as bass and treble boost and cut, loudness, adjustable delay, tone profiles, and a full 10-band EQ per output are available on each output channel of the DM-NAX-AUD-IO.

Encoder and Decoder Functionality

The DM-NAX-AUD-IO can operate as a network AV encoder and decoder. The local input sources on the adapter can be sent as AoIP streams to DM NAX, Dante, or AES67 capable devices. Simultaneously, the DM-NAX-AUD-IO can receive AoIP streams from these same devices and decode them for local output.

DM-NAX-AUD-USB

The DM-NAX-AUD-USB is a DM NAX® encoder and decoder with support for USB audio and analog line-level audio input and output. The device is housed in a versatile form factor that can be mounted in a single-gang standard electrical box, under a table, or on a rack rail. An additional polycarbonate label is included with rotated text to make the front panel more legible in electrical box installations. Two 1/8 in. (3.5 mm) TRS connectors for analog line-level audio input and output are also included on the front panel. The rear panel of the device features an Ethernet connection for PoE, Audio over IP (AoIP), and control.



- USB Audio Class 1 (UAC1) device with bidirectional stereo USB audio support
- Power over Ethernet (PoE) network powered
- Line-level, unbalanced analog audio input and output via 1/8 in. (3.5 mm) TRS connectors
- Mountable in a standard US electrical box, under a table, or on a rack rail via included hardware
- Connects directly to a managed network to route to or from other DM NAX® and DM NVX® devices
- Interoperable with Dante® audio networking devices via AES67 compatibility
- Streamlined configuration through a web interface
- Seamless Crestron system integration with SIMPL Windows programming

USB Audio

A USB-C® connector is built-in to the front panel of the DM-NAX-AUD-USB, allowing for bidirectional stereo USB audio transfer at rates up to 24-bit/48 kHz. This stereo signal can be output as a DM NAX AoIP stream onto the network or as an unbalanced line-level analog signal from the local 1/8 in. (3.5 mm) audio output connector.

Audio-over-IP

DM NAX takes audio distribution to a whole new level by putting it on the network. The DM-NAX-AUD-USB sends and receives DM NAX and AES67 encoded audio over a standard IP network. A single DM NAX system can handle audio distribution between 32 DM NAX devices and supports up to 256 audio output zones. DM NAX devices can seamlessly pull and distribute the audio from DM NVX sources.

Digital Signal Processing (DSP)


DSP capabilities such as bass and treble boost and cut, loudness, adjustable delay, tone profiles, and a full 10-band EQ per output are available on each output channel of the DM-NAX-AUD-USB.

Encoder and Decoder Functionality

The DM-NAX-AUD-USB can operate as a network AV encoder and decoder. The local input sources on the adapter can be sent as AoIP streams to DM NAX, Dante, or AES67 capable devices. Simultaneously, the DM-NAX-AUD-USB can receive AoIP streams from these same devices and decode them for local output.

DM-NAX-BTIO-1G

The DM-NAX-BTIO-1G is a DM NAX® encoder and decoder with support for Bluetooth® wireless and analog line-level wired audio input and output, housed in a single-gang wall plate form factor. The front panel features an OLED display and four buttons for device pairing and menu navigation. Two 1/8 in. (3.5 mm) TRS connectors for stereo unbalanced analog line-level audio input and output are concealed under a front panel door. The rear panel of the wall plate features an Ethernet connection for PoE, Audio over IP (AoIP), and control.



- Built-in Bluetooth® wireless audio input support
- Front panel OLED display provides metadata readout and device setup menus
- Single-gang U.S. wall box installation
- Power over Ethernet (PoE) network powered
- Stereo unbalanced analog line-level audio input and output via 3.5 mm TRS connectors
- Mountable in a standard US electrical box or on a rack rail via included hardware
- Connects directly to a managed network to route to or from other DM NAX® and DM NVX® devices
- Interoperable with Dante® audio networking devices via AES67 compatibility
- Streamlined configuration through front panel push buttons and a web interface
- Seamless Crestron system integration with SIMPL Windows programming

Bluetooth® Wireless Connectivity

Bluetooth wireless audio support is built-in to the DM-NAX-BTIO-1G, allowing a stereo audio signal to be transmitted from a smart phone or other source device to the wall plate. This stereo signal can be output as a DM NAX AoIP stream onto the network or as an unbalanced line-level analog signal from the local 3.5 mm audio output connector. Metadata for the Bluetooth audio stream can be displayed on the front panel, and up to seven previous source device connections can be recalled.

Audio-over-IP

DM NAX takes audio distribution to a whole new level by putting it on the network. The DM-NAX-BTIO-1G sends and receives DM NAX and AES67 encoded audio over a standard IP network. A single DM NAX system can handle audio distribution between 32 DM NAX devices and supports up to 256 audio output zones. DM NAX devices can seamlessly pull and distribute the audio from DM NVX sources.

Encoder and Decoder Functionality

The DM-NAX-BTIO-1G can operate as a network AV encoder and decoder. The local input sources on the wall plate can be sent as AoIP streams to DM NAX, Dante, or AES67 capable devices. Simultaneously, the DM-NAX-BTIO-1G can receive AoIP streams from these same devices and decode them for local output.

Front Panel Controls and Display

The DM-NAX-BTIO-1G features four front panel push buttons and a 128 x 64 dot matrix OLED display. The push buttons allow local volume control and Bluetooth pairing, with volume feedback and pairing status reflected in real time on the display. Metadata for Bluetooth media and basic configuration menus are also shown on the display.

Both the display and push buttons can be disabled via the configuration web interface or programming for applications where a more discreet or secure installation is required.

Specifications

Refer to the following sections for more information on the specifications for various DM NAX devices.

- [DM-NAX-2XLRI-1G](#)
- [DM-NAX-8ZSA](#)
- [DM-NAX-4ZSA-50](#)
- [DM-NAX-4ZSP](#)
- [DM-NAX-16AIN](#)
- [DM-NAX-AMP-X300](#)
- [DM-NAX-AUD-IO](#)
- [DM-NAX-AUD-USB](#)
- [DM-NAX-BTIO-1G](#)

DM-NAX-2XLRI-1G Specifications

Product specifications for the DM-NAX-2XLRI-1G are provided below.

Specifications

Audio

Input Signal Types	Balanced/unbalanced analog line/mic-level; DM NAX/AES67 audio-over-IP
Output Signal Types	Balanced/unbalanced analog line-level; DM NAX/AES67 audio-over-IP
Source Compensation	±10.0 dB per input
Input Monitoring	Source Signal Detect
Frequency Response (at line-level output)	From mic-level input: 20 Hz to 20 kHz ±1.0 dB; From line-level input: 20 Hz to 20 kHz +0.1/-1.0 dB
THD+N (at line-level output)	From mic-level input: 0.3% @ 1 kHz, max output From line-level input: 0.005% @ 1 kHz, max output
S/N Ratio (at line-level output)	From analog input: 105 dB, 20 Hz to 20 kHz, A-weighted; From digital input: 111 dB, 20 Hz to 20 kHz, A-weighted
Balance Control	Left/right adjustable
EQ Filter Types	EQ, High Pass, Low Pass, Treble Shelf, Bass Shelf, Notch
EQ Center Frequency	10 Hz to 20 kHz per band
EQ Gain	+20/-40 dB per band
EQ Bandwidth	0.1 to 4.0 octaves per band

Connectors

INPUTS 1-2	(2) Balanced XLR input ports Line or microphone-level audio inputs; Mic-level maximum gain: 60 dB Mic-level maximum signal level: 2Vrms; Mic-level channel separation: 70 dB @ 60 dB gain @ 1 kHz; Line-level maximum signal level: +21 dBu (8.7Vrms) Impedance: >10 k Ω ; +48V phantom power is available when used as mic-level inputs
OUTPUT L-R	(1) 5-pin 3.5 mm screw terminal block; Balanced line-level audio output; Pins 1-2: Left channel output; Pin 3: Shared ground; Pins 4-5: Right channel output; Maximum signal level: +14.7 dBu (4.2Vrms) Impedance: 200 Ω ; Channel separation: 100 dB @ 1 kHz
G	(1) 6-32 screw; Chassis ground lug
ETHERNET PoE	(1) 8-pin RJ-45 connector, female; 100BASE-TX/1000BASE-T Ethernet port

Controls and Indicators

ETHERNET PoE	Left amber LED indicates 1000 Mb link status; Left green LED indicates 100 Mb link status; Flashing right amber LED indicates Ethernet activity
SETUP	(1) Push button: Used for factory reset procedures; (1) LED, illuminates red when the button is pressed, flashes red when reset has been initiated

Power

PoE	IEEE 802.3af Class 0 (12.95 W) compliant; Compatible with IEEE 802.3af compliant Ethernet switch or third-party PoE compliant PSE
Power Consumption	2.9 W

Environmental

Temperature	32° to 95° F (0° to 35° C)
Humidity	10% to 95% RH (noncondensing)
Heat Dissipation	9.9 BTU/hr

Construction

Chassis	Metal, black and silver finish, vented sides
Mounting	Mountable on the following: 1-gang U.S. electrical box or plaster ring (not included), 3.5 in. (26 mm) electrical box depth recommended; Rack rail

Dimensions

Height	4.12 in. (105 mm)
Width	1.72 in. (44 mm)
Depth	2.14 in. (55 mm)

Weight


6 oz. (170 g)

Compliance

Regulatory Model: M1845004

IC, FCC Part 15 Class B digital device

Dimension Drawing



DM-NAX-8ZSA Specifications

Product specifications for the DM-NAX-8ZSA are provided below.

Specifications

Audio

Input Signal Types	4 stereo analog (RCA); 4 digital S/PDIF (2 TOSLINK® and 2 Coaxial)
Output Signal Types	4 stereo analog outputs (mirrors speaker zone outputs 1-4), Outputs 1 and 2 have a balanced 5-pin stereo Phoenix connection and an unbalanced RCA connection
Sampling Rates and Bit Depths	Digital Input (Coaxial): Up to 192 kHz, 24-bit; Digital Input (Optical): Up to 96 kHz, 24-bit; Media Players: Up to 192 kHz, 24-bit
Source Compensation	±10.0 dB per input
Input Monitoring	Source Signal Detect
Output Power	150 Watts per channel at 8 Ohms; 300 Watts per channel at 4 Ohms; 500 Watts per channel at 8 Ohms bridged
Amplifier Monitoring	Over Current, Over/Under Voltage, Over Temperature, DC Offset, Clipping
Frequency Response	20 Hz to 20 kHz ±0.6 dB
THD	0.006%
S/N Ratio	110 dB digital in, 108 dB analog in
Stereo Separation	85 dB @ 1 kHz, 8 ohm; 80 dB @ 1 kHz, 4 ohm
Zone Separation	100 dB @ 1 kHz, 8 ohm; 95 dB @ 1 kHz, 4 ohm
Zone Volume Level Control	-80.0 to +20.0 dB, adjustable from 0% to 100% plus mute
Bass Control	±12.0 dB
Treble Control	±12.0 dB
Loudness Compensation	On/Off
Dynamic Range Control	Off/Low/Medium/High
Balance Control	Left/right adjustable
Zone Configuration	Stereo Single Ended, Mono Single Ended, Stereo Bridged, Mono Bridged, Bridged 2.1, and Bridged 2.1 with Bridged Sub
Power Limiting	Configurable 5 to 150 Watts @ 8 Ohms; 5 to 300 Watts @ 4 Ohms; 5 to 500 Watts @ 8 Ohms bridged
Tone Profiles	Flat, Classical, Jazz, Pop, Rock, Spoken Word

EQ Filter Types	EQ, High Pass, Low Pass, Treble Shelf, Bass Shelf, Notch
EQ Center Frequency	10 to 20,000 Hz per band
EQ Gain	+20/-40 dB per band
EQ Bandwidth	0.1 to 4.0 octaves per band
Bus Volume Offset	±12.0 dB per zone for output bussing

Communications

Ethernet	For control, AoIP, and or console, 100/1000 Mbps, auto-switching, auto-negotiating, auto-discovery, full/half duplex, DHCP
USB	For configuration management

Connectors

SPDIF SOURCES 1 – 2	(2) JIS F05 female (TOSLINK) optical fiber connector; S/PDIF optical digital audio input
SPDIF SOURCES 3 – 4	(2) RCA female; S/PDIF coaxial digital audio inputs; Input Impedance: 75 Ohms
ANALOG SOURCES L/R 5 – 8	(8) RCA female comprising (4) unbalanced stereo line-level audio inputs; Input Impedance: 10k Ohms; Maximum Input Level: 2 Vrms
ANALOG OUT L/R 1 – 4	(8) RCA connectors, female; Comprises (4) unbalanced line-level stereo audio outputs (mirror corresponding amplified output pairs 1 – 4); Output Impedance: 100 Ohms; Maximum Output Level: 2 Vrms
ANALOG OUT L/R 1 – 2	(2) 5-pin 3.5mm detachable terminal blocks; Balanced stereo line-level audio outputs (mirror corresponding unbalanced output pairs 1 – 2); Output Impedance: 150 Ohms; Maximum Output Level: 4 Vrms
Ethernet 1	(1) 8-wire RJ45 female; 100Base-T/1000Base-TX Ethernet port
Ethernet 2	(1) 8-wire RJ45 female; 100Base-T/1000Base-TX Ethernet port
USB	(1) USB Type B connector, female; USB computer console port (cable included); For setup only
100-240V~50/60Hz Universal AC	(1) IEC 60320 C14 main power inlet, mates with removable power cord (included)
G	6-32 screw, chassis ground lug
SPEAKER OUTPUTS L/R 1 – 8	(16) 2-pin 7.62mm 15A detachable terminal blocks; Power amplifier outputs; Wire Size: Terminals accept up to 12AWG

Controls and Indicators

PWR	(1) LED. Amber indicates that the device is booting. White indicates that the device is switched on with audio passing. Red indicates that the device is in standby mode. Off indicates that there is no power from the power supply.
LAN	(1) LED. White indicates that the device is switched on and has a valid IP address. Off indicates that the device is not connected to a network or the IP address is invalid.
NAX	(1) LED. White indicates that AoIP is ready to pass and the unit's PTP clock is synced. Off indicates that no AoIP is passing to or from and/or PTP is not synced.
SOURCE 1-8	(8) LEDs. White indicates signal presence on the specified input/source. Red indicates there is a clipping on an analog input or a bitstream issue on a digital input. Off indicates that there is no signal detected on the specified input/source.
ZONE 1-8	(8) LEDs. White indicates there is audio output on the indicated zone. Red indicates a fault due to clipping, over current, over temperature, or low voltage.
SETUP	(1) LED. Blinking red indicates that a network reset or factory restore has been initiated via the adjacent SETUP button.

Power

Power Consumption	240 W (All channels driven at 1/8th power, 8 ohms)
-------------------	--

Environmental

Temperature	32° to 104°F (0° to 40°C)
Humidity	10% to 90% RH (non-condensing)
Heat Dissipation	450 BTU/hr

Construction

Chassis	Metal, black and silver finish, vented sides
Mounting	2 RU rack-mountable

Dimensions

Height	3.50 in. (89 mm)
Width	19 in. (482 mm) 17.28 in. (439 mm) without rack ears
Depth	14.52 in. (369 mm)

Weight


28 lb (12.70 kg)

Compliance

Regulatory Model: M1845004

FCC Part 15 Class B digital device, IC Class B, CE, ETL listed

Dimension Drawing



DM-NAX-4ZSA-50 Specifications

Product specifications for the DM-NAX-4ZSA-50 are provided below.

Specifications

Audio

Input Signal Types	2 stereo analog (RCA); 2 digital S/PDIF (1 TOSLINK® connection and 1 coaxial connection, PCM only)
Output Signal Types	4 stereo speaker-level amplified outputs; 1 stereo analog line-level output
Sampling Rates and Bit Depths	Digital Input (Coaxial): Up to 192 kHz, 24-bit; Digital Input (Optical): Up to 192 kHz, 24-bit; Media Players: Up to 192 kHz, 24-bit
Source Compensation	±10.0 dB per input
Input Monitoring	Source Signal Detect
Output Power	50 W per channel at 4 or 8 Ohms
Amplifier Monitoring	Over Current, Over/Under Voltage, Over Temperature, DC Offset, Clipping
Frequency Response	20 Hz to 20 kHz ±0.5 dB
THD	0.006%
S/N Ratio	110 dB digital in; 108 dB analog in
Stereo Separation	95 dB @ 1 kHz, 8 Ohm; 90 dB @ 1 kHz, 4 Ohm
Zone Separation	100 dB @ 1 kHz, 8 Ohm; 95 dB @ 1 kHz, 4 Ohm
Zone Volume Level Control	-80.0 to +20.0 dB, adjustable from 0% to 100% plus mute
Bass Control	±12.0 dB
Treble Control	±12.0 dB
Loudness Compensation	On/Off
Dynamic Range Control	Off/Low/Medium/High
Balance Control	Left/right adjustable
Zone Configuration	Stereo Single Ended; Mono Single Ended
Power Limiting	Configurable 5 to 50 W @ 4 or 8 Ohms
Tone Profiles	Flat, Classical, Jazz, Pop, Rock, Spoken Word
EQ Filter Types	EQ, High Pass, Low Pass, Treble Shelf, Bass Shelf, Notch
EQ Center Frequency	10 Hz to 20 kHz per band
EQ Gain	-40.0 to +20.0 dB per band
EQ Bandwidth	0.1 to 4.0 octaves per band
Bus Volume Offset	±12.0 dB per zone for output bussing

Communications

Ethernet	For control, AoIP, and/or console; 100/1000 Mbps, auto-switching, auto-negotiating, auto-discovery, full/half duplex, DHCP
-----------------	---

Connectors

SPEAKER ZONES 1-4	(4) 4-pin 5.08 mm detachable terminal blocks; Stereo speaker-level audio outputs; Maximum Wire Size: 12 AWG
LINE OUT 5	(2) RCA female comprising (1) unbalanced stereo line-level audio output; Output Impedance: 100 Ohms; Maximum Output Level: 2Vrms
DIGITAL INPUT 1	(1) RCA female; S/PDIF coaxial digital audio input; Input Impedance: 75 Ohms
DIGITAL INPUT 2	(1) JIS F05 female TOSLINK® optical fiber connector; S/PDIF optical digital audio input
ANALOG INPUTS 3-4	(4) RCA female comprising (2) unbalanced stereo line-level audio inputs; Input Impedance: 10 kOhms; Maximum Input Level: 2Vrms
ETHERNET 1-2	(2) 8-pin RJ-45 connectors, female; 100BASE-TX/1000BASE-T Ethernet port; Green LED indicates Ethernet link status; Flashing amber LED indicates Ethernet activity
100-240 VAC 1.0-0.4A 50/60HZ	(1) 100-240V~50/60Hz Universal AC; IEC 60320 C14 main power inlet, mates with removable power cord (included)

Controls and Indicators

PWR	(1) LED; Amber indicates that the device is booting; White indicates that the device is switched on with audio passing; Red indicates that the device is in standby mode
LAN	(1) White LED; Indicates that the device has a valid IP address
NAX	(1) White LED; White indicates that audio-over-IP traffic is passing in or out of the DM NAX unit
SOURCE 1-4	(4) LEDs; White indicates signal presence on the specified input/source; Red indicates there is clipping on the specified input/source
ZONE 1-5	(5) LEDs; White indicates there is audio output on the indicated zone; Red indicates a fault due to clipping, over current, over temperature, or low voltage

SETUP

(1) Push button: Pressing and holding the **SETUP** button for 15 seconds with power supplied clears network settings and restores the default DHCP mode;
To perform a factory restore, press and hold the **SETUP** button with power disconnected, then connect the power supply and continue to hold the **SETUP** button for 30 seconds;
(1) LED, illuminates red when the button is pressed, flashes red when reset has been initiated

Power

Main Power	1.0-0.4A @ 100-240VAC, 50/60 Hz
Power Consumption	50 W (all channels driven at 1/8 output power, 8 Ohms)

Environmental

Temperature	32° to 104°F (0° to 40°C)
Humidity	10% to 90% RH (non-condensing)
Heat Dissipation	85 BTU/hr (all channels driven at 1/8 output power, 4 Ohms)

Construction

Chassis	Metal, black and silver finish, vented front and rear panels
Mounting	1 RU rack-mountable

Dimensions

Height	1.72 in. (44 mm)
Width	8.66 in. (220 mm)
Depth	10.97 in. (279 mm)

Weight


4.15 lb (1.88 kg)

Compliance

Regulatory Model: M1845004

Intertek® Listed for US & Canada, CE, IC, FCC Part 15 Class B digital device

Dimension Drawing



DM-NAX-4ZSP Specifications

Product specifications for the DM-NAX-4ZSP are provided below.

Specifications

Audio

Input Signal Types	4 stereo analog (RCA); 4 digital S/PDIF (2 TOSLINK® and 2 Coaxial)
Output Signal Types	4 stereo analog outputs, Outputs 1 and 2 have a balanced 5-pin stereo Phoenix connection and an unbalanced RCA connection
Sampling Rates and Bit Depths	Digital Input (Coaxial): Up to 192 kHz, 24-bit; Digital Input (Optical): Up to 96 kHz, 24-bit; Media Players: Up to 192 kHz, 24-bit
Source Compensation	±10.0 dB per input
Input Monitoring	Source Signal Detect
Frequency Response	20 Hz to 20 kHz ±0.2 dB
THD	0.006%
S/N Ratio	110 dB digital in, 108 dB analog in
Zone Volume Level Control	-80.0 to +20.0 dB, adjustable from 0% to 100% plus mute
Bass Control	±12.0 dB
Treble Control	±12.0 dB
Loudness Compensation	On/Off
Dynamic Range Control	Off/Low/Medium/High
Balance Control	Left/right adjustable
Tone Profiles	Flat, Classical, Jazz, Pop, Rock, Spoken Word
EQ Filter Types	EQ, High Pass, Low Pass, Treble Shelf, Bass Shelf, Notch
EQ Center Frequency	10 to 20,000 Hz per band
EQ Gain	+20/-40 dB per band
EQ Bandwidth	0.1 to 4.0 octaves per band
Bus Volume Offset	±12.0 dB per zone for output bussing

Communications

Ethernet	For control, AoIP, and or console, 100/1000 Mbps, auto-switching, auto-negotiating, auto-discovery, full/half duplex, DHCP
USB	For configuration management

Connectors

SPDIF SOURCES 1 – 2	(2) JIS F05 female (TOSLINK) optical fiber connector; S/PDIF optical digital audio input
SPDIF SOURCES 3 – 4	(2) RCA female; S/PDIF coaxial digital audio inputs; Input Impedance: 75 Ohms
ANALOG SOURCES L/R 5 – 8	(8) RCA female comprising (4) unbalanced stereo line-level audio inputs; Input Impedance: 10k Ohms; Maximum Input Level: 2 Vrms
ANALOG OUT L/R 1 – 4	(8) RCA connectors, female; Comprises (4) unbalanced line-level stereo audio outputs (mirror corresponding amplified output pairs 1 – 4); Output Impedance: 100 Ohms; Maximum Output Level: 2 Vrms
ANALOG OUT L/R 1 – 2	(2) 5-pin 3.5mm detachable terminal blocks; Balanced stereo line-level audio outputs (mirror corresponding unbalanced output pairs 1 – 2); Output Impedance: 150 Ohms; Maximum Output Level: 4 Vrms
Ethernet 1	(1) 8-wire RJ45 female; 100Base-T/1000Base-TX Ethernet port
Ethernet 2	(1) 8-wire RJ45 female; 100Base-T/1000Base-TX Ethernet port
USB	(1) USB Type B connector, female; USB computer console port (cable included); For setup only
100-240V~50/60Hz Universal AC	(1) IEC 60320 C14 main power inlet, mates with removable power cord (included)
G	6-32 screw, chassis ground lug

Controls and Indicators

PWR	(1) LED. White indicates that the device is switched on with audio passing. Red indicates that the device is in standby mode. Off indicates that there is no power from the power supply.
LAN	(1) LED. White indicates that the device is switched on and has a valid IP address. Off indicates that the device is not connected to a network or the IP address is invalid.
NAX	(1) LED. White indicates that AoIP is ready to pass and the unit's PTP clock is synced. Off indicates that no AoIP is passing to or from and/or PTP is not synced.
SOURCE 1-8	(8) LEDs. White indicates signal presence on the specified input/source. Red indicates there is a clipping on an analog input or a bitstream issue on a digital input. Off indicates that there is no signal detected on the specified input/source.
ZONE 1-4	(4) LEDs. White indicates there is audio output on the indicated zone. Red indicates clipping is detected on the output audio.
SETUP	(1) LED. Blinking red indicates that a network reset or factory restore has been initiated via the adjacent SETUP button.

Power

Power Consumption	15.9 W
--------------------------	--------

Environmental

Temperature	32° to 104°F (0° to 40°C)
Humidity	10% to 90% RH (non-condensing)
Heat Dissipation	57 BTU/hr

Construction

Chassis	Metal, black and silver finish, vented sides
Mounting	1 RU rack-mountable

Dimensions

Height	1.73 in. (44 mm)
Width	19 in. (482 mm) 17.28 in. (439 mm) without rack ears
Depth	14.50 in. (368 mm)

Weight


8.06 lb (3.65 kg)

Compliance

Regulatory Model: M1845004

FCC Part 15 Class B digital device, IC Class B, CE, ETL listed

Dimension Drawing



DM-NAX-16AIN Specifications

Product specifications for the DM-NAX-16AIN are provided below.

Specifications

Audio

Input Signal Types	8 stereo unbalanced analog (RCA) includes (4) 5-pin phoenix balanced connector; 8 digital SPDIF (4 TOSLINK® and 4 Coaxial)
Source Compensation	±10.0 dB per input
Input Monitoring	Source Signal Detect
THD	0.002%
S/N Ratio	110 dB digital in, 108 dB analog in
Frequency Response	20 Hz to 20 kHz (±0.6 dB)
Supported Sample Rates	Coaxial: Up to 192 kHz; Optical: 192 kHz

Communications

Ethernet	For control, AoIP, and or console, 100/1000 Mbps, auto-switching, auto-negotiating, auto-discovery, full/half duplex, DHCP
USB	For configuration management

Connectors

ANALOG SOURCES L/R 1 – 8	(8) RCA female comprising (4) unbalanced stereo line-level audio inputs; (4) 5-pin phoenix balanced connector Input Impedance: 10k Ohms; Maximum Input Level: 2 Vrms
SPDIF SOURCES 9 – 12	(4) JIS F05 female (TOSLINK) optical fiber connector; S/PDIF optical digital audio input
SPDIF SOURCES 13 – 16	(4) RCA female; S/PDIF coaxial digital audio inputs; Input Impedance: 75 Ohms
Ethernet 1	(1) 8-wire RJ45 female; 100Base-T/1000Base-TX Ethernet port
Ethernet 2	(1) 8-wire RJ45 female; 100Base-T/1000Base-TX Ethernet port
USB	(1) USB Type B connector, female; USB computer console port (cable included); For setup only
100-240V~50/60Hz Universal AC	(1) IEC 60320 C14 main power inlet, mates with removable power cord (included)
G	6-32 screw, chassis ground lug

Controls and Indicators

PWR	(1) LED. Amber indicates that the device is booting. White indicates that the device is switched on with audio passing. Red indicates that the device is in standby mode. Off indicates that there is no power from the power supply.
LAN	(1) LED. White indicates that the device is switched on and has a valid IP address. Off indicates that the device is not connected to a network or the IP address is invalid.
NAX	(1) LED. White indicates that AoIP is ready to pass and the unit's PTP clock is synced. Off indicates that no AoIP is passing to or from and/or PTP is not synced.
SOURCE 1-16	(16) LEDs. White indicates signal presence on the specified input/source. Red indicates there is a clipping on an analog input or a bitstream issue on a digital input. Off indicates that there is no signal detected on the specified input/source.
SETUP	(1) LED. Blinking red indicates that a network reset or factory restore has been initiated via the adjacent SETUP button.

Power

Power Consumption	20 Watts
-------------------	----------

Environmental

Temperature	32° to 104°F (0° to 40°C)
Humidity	10% to 90% RH (non-condensing)
Heat Dissipation	70 BTU/hr

Construction

Chassis	Metal, black and silver finish, vented sides
Mounting	1 RU rack-mountable

Dimensions

Height	1.25 in. (32 mm)
Width	19 in. (483 mm); 17.28 in. (439 mm) without rack ears
Depth	14.46 in. (368 mm)

Weight


7.39 lb (3.35 kg)

Compliance

Regulatory Model: M1845004

FCC Part 15 Class B digital device, CE, ETL listed

Dimension Drawing



DM-NAX-AMP-X300 Specifications

Product specifications for the DM-NAX-AMP-X300 are provided below.

Specifications

Audio

Input Signal Types	Balanced/unbalanced analog line/mic-level and AoIP streams.
Balanced Analog Input	Maximum signal level: +21 dBu (8.7 Vrms) Impedance: >10k Ohms <i>f</i> Response: 20 Hz to 20 kHz±0.5 dB THD+N: <0.005% @ 1 KHz S/N Ratio: 105 dB A-weight Channel Separation: 100 dB @ 1 KHz
Mic Input	Maximum gain: 60 dB Impedance: >10k Ohms <i>f</i> Response: 20 Hz to 20 kHz±0.5 dB THD+N: <0.005% @ 1 KHz @ 60 dB gain S/N Ratio: 71 dB @ 60 dB gain A-weight Channel Separation: 69 dB @ 60 dB gain @ 1 KHz
Balanced Analog Output	Maximum signal level: +21 dBu (8.7 Vrms) Impedance: 200 Ohms <i>f</i> Response: 20 Hz to 20 kHz ±0.5 dB THD+N: 0.005% @ 1 kHz at max output S/N Ratio: 113 dB digital in, 105 dB analog in, 20 Hz -20 kHz, A-weight Channel Separation: 100 dB @ 1 KHz
Speaker Output	<i>f</i> Response: 20 Hz to 20 kHz ±0.5 dB at 1 W High-Pass Filter (70V and 100V operation only): -3 dB @ 80 Hz, -12 dB/octave THD+N: <0.1% at 1 kHz @ -3 dB full rated output power S/N Ratio: >103 dB, 20 Hz to 20 kHz, balanced Crosstalk: -75 dB at 1 kHz Gain: 29 dB @ 8 Ω Protection: Over current, under voltage, over temperature, DC offset, extreme high frequency Go to Sleep Time: 25 minutes with no signal present (when set to POWER SAVER) Wake Time: 0.5 s typical

Output Power Per Channel

Mode	1 Channel Driven	2 Channels Driven	3 Channels Driven	4 Channels Driven
Lo-Z, 8 Ω (single ended)	150 W	150 W	75 W ¹	75 W
Lo-Z, 4 Ω (single ended)	200 W	150 W	75 W ¹	75 W
Lo-Z, 8 Ω Bridged	300 W	150 W	150 W ¹	N/A
Hi-Z 70V	300 W	150 W	N/A	N/A
Hi-Z 100V	300 W	150 W	N/A	N/A

NOTES:

- Total output power from all channels combined (simultaneously) is up to 300 W.
- Each mode will output power in watts up to the value listed in the table.

Connectors

CH1-CH4	(2) 4-pin 5.08 mm pitch, 12A plug with screw locking retainers; Power amplifier output; Terminals accept up to 12 AWG (3.31 mm)
	NOTE: Output is direct-coupled, not transformer isolated.
IN1-IN4	(4) 3-pin 3.5 mm detachable terminal block; Balanced/unbalanced line or mic-level audio inputs; Maximum Input Level: 8.7 Vrms, +21 dBu; Input Impedance: 10k Ω Wake threshold is -65 dBu; Phantom power is available when used as mic-level inputs
OUT1-OUT4	(4) 3-pin 3.5 mm detachable terminal block; Balanced/unbalanced line-level audio outputs; Maximum Output Level: 8.7 Vrms, +21 dBu
REMOTE	(1) 2-pin 3.5 mm detachable terminal block; Connect to dry contact closure to place amplifier in standby mode
G	(1) 6-32 screw; Chassis ground lug
100-240V~ 1.2-0.6A 50/60 Hz	(1) IEC 60320 C14 main power inlet; Mates with removable power cord, included
Ethernet 1	(1) 8-wire RJ45 female; 100Base-T/1000Base-TX Ethernet port
Ethernet 2	(1) 8-wire RJ45 female; 100Base-T/1000Base-TX Ethernet port

Controls and Indicators

PWR	(1) LED; White indicates amplifier is on and ready for use; Amber indicates the amplifier is booting; Red indicates amplifier is in standby
-----	--

HI-Z	(1) White LED; Indicates when Hi-Z mode is enabled (70V or 100V)
LAN	(1) White LED; Indicates that the device has a valid IP address
AoIP	(1) White LED; Indicates an active AoIP stream
FAULT	(4) Red LEDs (one per speaker output); Indicates that the input channel has a fault or is clipping
SIGNAL	(4) White LEDs (one per speaker output); Indicates an active input signal
LOCKOUT	(1) Red LED; Indicates that rear panel slide switches are being overridden by programmatic or web UI control
Lo-Z MODES	(2) Slide switches, one switch controlling channels 1 and 2, and one switch controlling channels 3 and 4; Selects stereo, summed, or bridged operation: <ul style="list-style-type: none"> STEREO: The input signal received on each channel is sent to its respectively numbered speaker, line, and network output for use in applications where left and right channel separation is required. SUM: The input signals received on a pair of line inputs (1 + 2 or 3 + 4) are each routed to both channels of their respectively numbered speaker, line, and network output pair. BRIDGE: The input signals received on a pair of line inputs (1 + 2 or 3 + 4) are summed and sent to a bridged output (1 + 2 or 3 + 4) for use in high power applications.
Operations Mode	(1) Slide switch; Sets the amplifier for Lo-Z (4 or 8 Ω) or Hi-Z operation (70V or 100V)
Power Mode	(1) Slide switch; Selects Power Saver or Always On operation
SETUP	(1) Red LED and push button; Utilized in some restore procedures

Power

Main Power	1.2-0.6A @ 100-240VAC, 50/60 Hz
Power Consumption	75 W (All channels driven at 1/8th power, 8 ohms)

Environmental

Temperature	41 to 104°F (5° to 40°C)
Humidity	10% to 90% RH (non-condensing)
Heat Dissipation	130 BTU/hr

Dimensions

Height	1.74 in. (44 mm)
Width	9.38 in. (238 mm)

Depth 11.03 in. (280 mm)

Weight

5.3 lb (2.4 kg)

Compliance


Regulatory Model: M1845004

UL® Listed for US & Canada, CE, IC, FCC Part 15 Class B digital device

Note:

1. 3 channel operation requires two single ended loads and one bridged load.

Dimension Drawings



DM-NAX-AUD-IO Specifications

Product specifications for the DM-NAX-AUD-IO are provided below.

Specifications

Audio

Input Signal Types	Balanced/unbalanced stereo analog line-level; DM NAX/AES67 audio-over-IP
Output Signal Types	Balanced/unbalanced stereo analog line-level; DM NAX/AES67 audio-over-IP
Source Compensation	±10.0 dB per input
Input Monitoring	Source Signal Detect
Frequency Response (at line-level output)	20 Hz to 20 kHz ±0.5 dB
THD+N (at line-level output)	0.005% @ 1 kHz, max output
S/N Ratio (at line-level output)	From line-level input: 110 dB, 20 Hz to 20 kHz, A-weighted; From digital input: 113 dB, 20 Hz to 20 kHz, A-weighted
Balance Control	Left/right adjustable
EQ Filter Types	EQ, High Pass, Low Pass, Treble Shelf, Bass Shelf, Notch
EQ Center Frequency	10 to 20,000 Hz per band
EQ Gain	+20/-40 dB per band
EQ Bandwidth	0.1 to 4.0 octaves per band

Communications

Ethernet	For control and PoE, AoIP, and/or console, 100/1000 Mbps, auto-switching, auto-negotiating, auto-discovery, full/half duplex, DHCP
-----------------	--

Connectors

INPUTS	(1) 5-pin 3.5 mm detachable terminal block; Balanced/unbalanced line-level audio inputs; Maximum Input Level: +21 dBu (8.7Vrms); Input Impedance: 10 k Ω
OUTPUTS	(1) 5-pin 3.5 mm detachable terminal block; Balanced/unbalanced line-level audio outputs; Maximum Output Level: +21 dBu (8.7Vrms); Channel separation: 100 dB @ 1 kHz; Output Impedance: 400 Ω
G	(1) 6-32 screw; Chassis ground lug

ETHERNET PoE	(1) 8-pin RJ-45 connector, female; 100BASE-TX/1000BASE-T Ethernet port;
--------------	--

Controls and Indicators

ETHERNET PoE	Left amber LED indicates 1000 Mb link status; Left green LED indicates 100 Mb link status; Flashing right amber LED indicates Ethernet activity
SETUP	(1) Push button: Used for factory reset procedures; (1) LED, illuminates red when the button is pressed, flashes red when reset has been initiated

Power

PoE	IEEE 802.3af Class 0 (12.95 W) compliant; Compatible with IEEE 802.3af compliant Ethernet switch or third-party PoE compliant PSE
Power Consumption	5 W

Environmental

Temperature	32° to 104° F (0° to 40° C)
Humidity	10% to 95% RH (noncondensing)
Heat Dissipation	17 BTU/hr

Construction

Chassis	Metal, black and silver finish
Mounting	Mountable on the following via included hardware: 1-gang U.S. electrical box or plaster ring (not included), 3.5 in. (26 mm) electrical box depth recommended; Rack rail; Surface mount

Dimensions

Height	1.59 in. (41 mm)
Width	2.60 in. (66 mm)
Depth	2.11 in. (54 mm)




Weight

7 oz. (199 g)

Compliance

Regulatory Model: M1845004
IC, FCC Part 15 Class B digital device

Dimension Drawing



DM-NAX-AUD-USB Specifications

Product specifications for the DM-NAX-AUD-USB are provided below.

Specifications

Audio

Input Signal Types	USB stereo; Unbalanced stereo analog line-level; DM NAX/AES67 audio-over-IP
Output Signal Types	USB stereo; Unbalanced stereo analog line-level; DM NAX/AES67 audio-over-IP
Source Compensation	±10.0 dB per input
Input Monitoring	Source Signal Detect
Frequency Response (at line-level output)	20 Hz to 20 kHz ±0.5 dB
THD+N (at line-level output)	0.005% @ 1 kHz, max output
S/N Ratio (at line-level output)	From line-level input: 108 dB, 20 Hz to 20 kHz, A-weighted; From digital input: 111 dB, 20 Hz to 20 kHz, A-weighted
Balance Control	Left/right adjustable
EQ Filter Types	EQ, High Pass, Low Pass, Treble Shelf, Bass Shelf, Notch
EQ Center Frequency	10 to 20,000 Hz per band
EQ Gain	+20/-40 dB per band
EQ Bandwidth	0.1 to 4.0 octaves per band

Communications

Ethernet	For control and PoE, AoIP, and/or console, 100/1000 Mbps, auto-switching, auto-negotiating, auto-discovery, full/half duplex, DHCP
USB	Bidirectional USB Audio Class 1 (UAC1) device connection, up to 24-bit/48 kHz stereo audio transfer

Connectors

USB	(1) USB Type-C connector, female; UAC1 audio support; Enumerates as a Non-AEC Enabled Speakerphone
INPUT	(1) 1/8 in. 3.5 mm connector, female TRS; Unbalanced line-level audio input; Maximum input level: 2Vrms; Input Impedance: 10 kΩ

OUTPUT	(1) 1/8 in. 3.5 mm connector, female TRS; Unbalanced line-level audio output; Maximum output level: 2Vrms; Channel separation: 100 dB @ 1 kHz; Output impedance: 100 Ω
G	(1) 6-32 screw; Chassis ground lug
ETHERNET PoE	(1) 8-pin RJ-45 connector, female; 100BASE-TX/1000BASE-T Ethernet port

Controls and Indicators

ETHERNET PoE	Left amber LED indicates 1000 Mb link status; Left green LED indicates 100 Mb link status; Flashing right amber LED indicates Ethernet activity
SETUP	(1) Push button: Used for factory reset procedures; (1) LED, illuminates red when the button is pressed, flashes red when reset has been initiated

Power

PoE	IEEE 802.3af Class 0 (12.95 W) compliant; Compatible with IEEE 802.3af compliant Ethernet switch or third-party PoE compliant PSE
Power Consumption	5 W

Environmental

Temperature	32° to 104° F (0° to 40° C)
Humidity	10% to 95% RH (noncondensing)
Heat Dissipation	17 BTU/hr

Construction

Chassis	Metal, black and silver finish
Mounting	Mountable on the following via included hardware: 1-gang U.S. electrical box or plaster ring (not included), 3.5 in. (26 mm) electrical box depth recommended; Rack rail; Surface mount

Dimensions

Height	1.59 in. (41 mm)
Width	2.60 in. (66 mm)
Depth	2.11 in. (54 mm)

Weight


7 oz. (199 g)

Compliance

Regulatory Model: M1845004

IC, FCC Part 15 Class B digital device

Dimension Drawing



DM-NAX-BTIO-1G Specifications

Product specifications for the DM-NAX-BTIO-1G are provided below.

Specifications

Audio

Input Signal Types	Unbalanced stereo analog line-level; Stereo Bluetooth wireless; DM NAX/AES67 audio-over-IP
Output Signal Types	Unbalanced stereo analog line-level; DM NAX/AES67 audio-over-IP
Source Compensation	±10.0 dB per input
Input Monitoring	Source Signal Detect
Frequency Response (at line-level output)	20 Hz to 20 kHz ±0.5 dB
THD+N	Line-level: 0.005% @ 1 kHz, max output; Bluetooth: 0.05% @ 1 kHz, max output
S/N Ratio (at line-level output)	From line-level input: 108 dB, 20 Hz to 20 kHz, A-weighted; From digital input: 111 dB, 20 Hz to 20 kHz, A-weighted
Balance Control	Left/right adjustable

Communications

Ethernet	For control and PoE, AoIP, and/or console, 100/1000 Mbps, auto-switching, auto-negotiating, auto-discovery, full/half duplex, DHCP
Bluetooth	For audio input, Bluetooth 5.3 sink device, recalls up to seven previously paired devices, persistent or non persistent pairing, exclusive or interrupting connection modes

Connectors

IN	(1) 3.5 mm connector, female TRS; Unbalanced line-level audio input; Maximum input level: 2Vrms; Input Impedance: 10 kΩ
OUT	(1) 3.5 mm connector, female TRS; Unbalanced line-level audio output; Maximum output level: 2Vrms; Channel separation: 80 dB @ 1 kHz; Output Impedance: 100 Ω
G	(1) 6-32 screw; Chassis ground lug
ETHERNET PoE	(1) 8-pin RJ-45 connector, female; 100BASE-TX/1000BASE-T Ethernet port

Controls and Indicators

Front Panel Display	(1) OLED screen, 128 x 64 dot matrix Height (active area): 0.43 in. (11 mm) Width (active area): 0.86 in. (22 mm) Displays metadata, menus, and volume feedback
Menu	(1) Push button Used to enter the front panel menu and select menu items
Bluetooth	(1) Push button Used to initiate Bluetooth pairing
UP and DOWN Arrows	(2) Push buttons Used to navigate menus and control volume
ETHERNET PoE	Left amber LED indicates 1000 Mb link status; Left green LED indicates 100 Mb link status; Flashing right amber LED indicates Ethernet activity
SETUP	(1) Push button: Used for factory reset procedures; (1) LED, illuminates red when the button is pressed, flashes red when reset has been initiated

Power

PoE	IEEE 802.3af Class 0 (12.95 W) compliant; Compatible with IEEE 802.3af compliant Ethernet switch or third-party PoE compliant PSE
Power Consumption	3.5 W

Environmental

Temperature	32° to 95° F (0° to 35° C)
Humidity	10% to 95% RH (noncondensing)
Heat Dissipation	11.95 BTU/hr

Construction

Chassis	Metal, black and silver finish, vented sides
Mounting	Mountable on the following: 1-gang U.S. electrical box or plaster ring (not included), 3.5 in. (26 mm) electrical box depth recommended; Rack rail

Dimensions

Height	4.12 in. (105 mm)
Width	1.76 in. (45 mm)
Depth	2.25 in. (57 mm)

Weight




4.8 oz. (136 g)

Compliance

Regulatory Model: M1845004

IC, FCC Part 15 Class B digital device

Dimension Drawing



Installation

Refer to the following sections for instructions on how to install the various DM NAX devices.

- [DM-NAX-2XLRI-1G](#)
- [DM-NAX-8ZSA](#)
- [DM-NAX-4ZSA-50](#)
- [DM-NAX-4ZSP](#)
- [DM-NAX-16AIN](#)
- [DM-NAX-AMP-X300](#)
- [DM-NAX-AUD-IO](#)
- [DM-NAX-AUD-USB](#)
- [DM-NAX-BTIO-1G](#)

DM-NAX-2XLRI-1G Installation

Refer to the following sections to install the DM-NAX-2XLRI-1G.

- [In the Box on page 65](#)
- [Mounting the Device on page 65](#)
- [Connect the Device on page 68](#)
- [Reset the Device on page 69](#)

In the Box

Qty.	Description
1	DM-NAX-2XLRI

Additional Items

2	Screw, 06-32, 3/4 in., Truss Head, Combo (2009211)
---	--

Mounting the Device

The DM-NAX-2XLRI-1G can be mounted into a 1-gang electrical box or onto a rack rail.


Mounting into a 1-Gang Electrical Box

NOTES:

- The DM-NAX-2XLRI-1G should only be mounted with a RACO® 3 in. x 2 in. x 2 in. gangable metal switch box with eight 0.5 in. knockouts and plaster ears (catalog ID #420), as it was designed to fit the box dimensions and knockout placements. Alternative metal switch boxes should not be used as they may have different knockout placements, which can lead to issues running the PoE connection to the unit due to cable bend radius restrictions.
- For thermal performance reasons, fully enclosed plastic back boxes should not be used with the DM-NAX-2XLRI-1G. In installations where an enclosed back box is not required, the DM-NAX-2XLRI-1G can be installed into most single gang metal or plastic mud rings.
- Connector boots should not be used on CAT5e (or greater) cables being connected to the DM-NAX-2XLRI-1G to avoid cable bend radius issues.

To mount the wall plate into a 1-gang electrical box, follow the instructions below.

1. Make connections to the rear of the device. For details, refer to [Top Panel on page 69](#).
2. Using a Phillips screwdriver and the two included 6-32 x 3/4 in. truss head screws, attach the wall plate to the electrical box.




3. Using a Phillips screwdriver and two 6-32 x 1/4 in., flat head screws (not included), attach a FP-G1 decorator style faceplate (sold separately) to the wall plate.

Mounting onto a Rack Rail

To mount the wall plate onto a rack rail, follow the instructions below.

1. Position the wall plate horizontally so that the holes in the left or right mounting flange align with the holes in the rack rail.

2. Secure the wall plate to the rack rail using two mounting screws (not included).




Mounting to a Flat Surface

To mount the wall plate to a flat surface, follow the instructions below.

1. Position the wall plate so that the holes in the mounting flange align with the mounting bracket (not included).

2. Connect the wall plate to the mounting bracket using a Phillips screwdriver and two SEMS screws 6-32 x 1/4 in. (not included).




3. Secure the mounting bracket to a flat surface using the appropriate mounting screws (not included).


Connect the Device

Make connections to the front and top of the DM-NAX-2XLRI-1G as described below.

Front Panel



Top Panel



NOTE: PoE is a PoE powered device (PD) port. In order for the port to receive PoE, it must be connected to a PoE compliant Ethernet switch.

Connect a PoE capable network switch to the **PoE** port.

Connect a balanced or unbalanced line level sink device (such as the [MP-WP-2RCAO-1G](#) or [MP-WP-2XLRO-1G](#), sold separately) to the **OUTPUT** port

Connect XLR sources to the front panel XLR connections.

Reset the Device

A network reset or factory restore may be performed when troubleshooting.

CAUTION: These procedures should only be performed as a last resort to recover an unresponsive device. Both the Network Reset and Factory Restore procedure will clear certain device settings that cannot be recovered once the procedure is complete. Before performing these procedures, please contact Crestron True Blue Support via phone, email or chat as described at www.crestron.com/support.

Network Reset

1. Ensure the device is powered on.
2. Press and hold the **SETUP** button for up to 15 seconds until the **SETUP** LED flashes red.

The device will reboot, and the default network settings will be reset. The device will be reverted to its default hostname, with DHCP enabled, and no static IP set.

Factory Restore

1. Turn off the device by disconnecting the power cable from the device.
2. Press and hold the **SETUP** button and then reconnect the power cable while still holding the **SETUP** button. Continue holding the **SETUP** button for up to 30 seconds until the **SETUP** LED flashes.

The device will reboot, and all the factory default settings will be restored, such as audio settings, multicast addressing, etc.


CAUTION: Performing a factory restore will clear all settings from the device configuration.

DM-NAX-8ZSA Installation

Refer to the following sections to install the DM-NAX-8ZSA.

- [In the Box on page 71](#)
- [Install the Device on page 72](#)
- [Connect the Device on page 73](#)
- [Apple® AirPlay® Setup on page 77](#)
- [Spotify® Connect Setup on page 78](#)
- [Observe the LED Indicators on page 78](#)
- [Reset the Device on page 80](#)

Front Panel



In the Box

Qty. Description

Qty.	Description
1	DM-NAX-8ZSA

Additional Items

- | | |
|----|--|
| 2 | Bracket, Rack Ear, 2 RU (2053799) |
| 1 | Power Cord, approx. 6.5 ft (2 m) (2014835) |
| 1 | Cable, CAT6, RJ45-to-RJ-45, approx. 5 ft (1.5 m) (2036196) |
| 16 | Connector, 2-Pin (2012361) |
| 2 | Connector, 4-Pin (2003576) |
| 3 | Connector, 5-Pin (2003577) |
| 6 | Screw, 4B x 1/4 in., Pan Head, Phillips (2007195) |

Install the Device

Refer to the [Safety Instructions](#) (Doc. 6607) prior to installation.

The device can be placed on a table or installed in a rack.

Place on a Table


Place the device on a table or stack on top of another device.

Rack Installation

This device occupies 2 RU of rack space.

To install the included rack ears:

1. Use a #1 Phillips screwdriver to remove the three screws from each side of the front of the device as shown in the illustration.
2. Use the screwdriver and the six included 1/4 in. Phillips Pan Head screws to attach the included rack ears to the device.



3. Mount the device into the rack using four rack mounting screws (not included).

Rack Mounting Safety Precautions

Elevated Operating Ambient Temperature: If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient temperature. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (T_{ma}) specified by the manufacturer.

Reduced Airflow: Installation of the equipment in a rack should be such that the amount of airflow required for safe operation of the equipment is not compromised.

Mechanical Loading: Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.

Circuit Overloading: Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.

Reliable Earthing: Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g., use of power strips).

Connect the Device

Make the necessary connections as called out in the following illustration. Connect power last.


CAUTION:

- Keep the device unplugged until all of the input, network, output, and speaker wiring is complete.
- Check the speaker cables for shorts and frayed wiring around the SPEAKER OUTPUTS connectors.

NOTE:


- Ensure that the unit is properly grounded by connecting the chassis ground lug to an earth ground (building steel).
- To prevent overheating, do not operate this product in an area that exceeds the environmental temperature range listed in the product specifications.
- Do not bundle power cords together with connection cables. Doing so can result in noise.

Rear Panel



Digital Inputs


Refer to the following illustration when connecting digital audio sources.



NOTE: 2-channel PCM digital audio is the only supported digital input format.

Analog Inputs

Refer to the following illustration when connecting analog audio sources.




Speaker Connections

The speaker outputs can be wired conventionally or bridged together to deliver higher output power.

NOTE: The Line Outputs 1-4 mirror their respective Speaker Outputs 1-4. These outputs can feed another amplifier or an active subwoofer.

Conventional Wiring

Connect speakers to the DM-NAX-8ZSA as shown in the following illustration.




Bridged Wiring

Connect speaker outputs as shown in the following illustration to deliver more power to the speakers (8 ohm speakers only).

NOTE:


- Before wiring the speakers for bridging, ensure that the device is configured for bridging using web UI, Crestron Home™ software, or a Crestron SIMPL program running on a control system.
- Bridging can only be done between a left and a right output within the labeled zone.



Balanced/Unbalanced Audio Output

Refer to the following table and illustration for analog audio output pin assignments and connection information.

Signal Name	Balanced Audio Output	Unbalanced Audio Output
+	L+	L+ Out
-	L-	Open
G	Shield/ground	Open
+	R+	R+ Out
-	R-	Open



Apple® AirPlay® Setup

The DM-NAX-8ZSA supports AirPlay 2 and requires iOS 11.4 or later.

AirPlay can be enabled on any of the built-in media players on the DM-NAX-8ZSA.

To stream media from an iOS device to a speaker zone in your distributed audio system:

1. Ensure that the iOS device and DM-NAX-8ZSA are on the same network.
2. On the DM-NAX-8ZSA, enable AirPlay for the built-in media player you would like to stream to, either using the web UI or programming.

NOTE: If the control/media and Audio-over-IP network traffic is isolated between two network ports on the DM-NAX-8ZSA, AirPlay will use the port specified for the Control/Media traffic.

3. On your iOS device:
 - a. Enable AirPlay
 - b. From the list of available AirPlay destinations, select the DM-NAX-8ZSA zone you would like to stream to.

The media player will play back audio to the selected zone(s).

Once AirPlay streaming begins, you will be able to control the volume of the streaming DM-NAX-8ZSA speaker zones directly from your iOS device.

NOTE: By default, media players 1 - 8 route the audio signals to their corresponding speaker zones when Airplay streaming begins. If the user has not already specified a destination speaker zone for the media player when streaming begins, the media player will automatically route to its default speaker zone. For example, if a user streams Airplay to media player 3, the audio will be routed to speaker zone 3.

Spotify® Connect Setup

The DM-NAX-8ZSA supports Spotify Connect.

To configure Spotify, use your phone, tablet or computer as a remote control for Spotify. Go to spotify.com/connect to learn how.

Spotify Connect can be enabled on any of the built-in media players on the DM-NAX-8ZSA.

To stream media from a device to a speaker zone in your distributed audio system:

1. Ensure that the device and DM-NAX-8ZSA are on the same network.
2. On the DM-NAX-8ZSA, enable Spotify Connect for the built-in media player you would like to stream to, either using the web UI or programming.

NOTE: If the control/media and Audio-over-IP network traffic is isolated between two network ports on the DM-NAX-8ZSA, Spotify will use the port specified for the Control/Media traffic.

3. On your device:
 - a. Open the Spotify application or web client.
 - b. From the list of available Spotify destinations, select the DM-NAX-8ZSA zone you would like to stream to.

The media player will play back audio to the selected zone(s).

Once Spotify Connect streaming begins, you will be able to control the volume of the streaming DM-NAX-8ZSA speaker zones directly from your device.

NOTE: By default, media players 1 - 8 route the audio signals to their corresponding speaker zones when Spotify Connect streaming begins. If the user has not already specified a destination speaker zone when streaming begins, the media player will automatically route to its default speaker zone. For example, if a user streams Spotify Connect to media player 3, the audio will be routed to speaker zone 3.

Observe the LED Indicators

Refer to the following table for information about the LED indicators on the device.

LED Indicator	Color	Meaning
PWR	Amber	Power is being applied to the device. The device is booting.
	White	Device is powered on with audio passing.
	Red	Device is in standby mode.

LED Indicator	Color	Meaning
LAN	White	The device is powered on and has a valid IP address.
	Off	Device is not connected to a network or the IP address is invalid.
NAX	White	AoIP is ready to pass and the unit's PTP clock is synced.
	Off	No AoIP is passing to or from and/or PTP is not synced.
SOURCE 1-8	White	Signal is detected on the specified input/source.
	Red	There is clipping on an analog input or bitstream audio detected on a digital input.
	Off	There is no signal detected on the specified input/source.
ZONE 1-8	White	There is audio output on the indicated zone.
	Red	Clipping or a fault is detected on the zone output due to over current, over temperature, or low voltage.
SETUP	Solid Red	The SETUP button is pressed.
	Blinking Red	A network reset or factory restore has been initiated via the adjacent SETUP button.

Reset the Device

A network reset or factory restore may be performed when troubleshooting.

CAUTION: These procedures should only be performed as a last resort to recover an unresponsive device. Both the Network Reset and Factory Restore procedure will clear certain device settings that cannot be recovered once the procedure is complete. Before performing these procedures, please contact Crestron True Blue Support via phone, email or chat as described at www.crestron.com/support.

Network Reset

1. Ensure the device is powered on.
2. Press and hold the **SETUP** button for up to 15 seconds until the **SETUP** LED flashes red.

The device will reboot, and the default network settings will be reset. The device will be reverted to its default hostname, with DHCP enabled, and no static IP set.

Factory Restore

1. Turn off the device by disconnecting the power cable from the device.
2. Press and hold the **SETUP** button and then reconnect the power cable while still holding the **SETUP** button. Continue holding the **SETUP** button for up to 30 seconds until the **SETUP** LED flashes.

The device will reboot, and all the factory default settings will be restored, such as Zone settings, streaming service accounts, multicast addressing, etc.

CAUTION: Performing a factory restore will clear all settings from the device configuration.

DM-NAX-4ZSA-50 Installation

Refer to the following sections to install the DM-NAX-4ZSA-50.

- [In the Box on page 81](#)
- [Install the Device on page 82](#)
- [Connect the Device on page 85](#)
- [Spotify® Setup on page 87](#)
- [Reset the Device on page 88](#)
- [Observe the LED Indicators on page 88](#)

In the Box

Qty. Description

1	DM-NAX-4ZSA-50
---	----------------

Additional Items

- | | |
|---|---|
| 1 | Power Cord, approx. 6.5 ft (2m) (2001134) |
| 2 | Bracket, rack ear, quarter-wide (2057495) |
| 4 | Joining plate (2056313) |
| 4 | Speaker Connector, 4-Pin (2057001) |
| 4 | Screw, 6-32 x 5/16 in., Flat Head, Phillips (2007223) |
| 8 | Screw, 8-32 x 5/16 in., Phillips (2056985) |
| 4 | Adhesive feet (2002389) |

Install the Device

Refer to the [Safety Instructions](#) (Doc. 6607) prior to installation.

The device can be placed on a table or installed in a rack.

Place on a Table


Attach the four adhesive feet to the bottom of the device. Place the device on a table or stack on top of another device.

Rack Installation

This device occupies 1/2 RU of rack space.

To install the included rack ears:

1. Use a #1 Phillips screwdriver and the included 6-32 5/16 in. Phillips screws to attach the included rack ears to the device.




2. Mount the device into the rack using four rack mounting screws (not included).


Double Mount

To rack-mount two Crestron 1/2 RU units together:

1. On a flat surface, place the devices upside-down and adjacent to each other.
2. Using a Philips screwdriver and the eight included 8-32 x 5/16 in. screws, gang the devices together with two of the joining plates.



3. Turn the device assembly over and, using six 6-32 x 5/16 in. screws, attach the rack ears to each side.



4. Mount the assembly into the rack using four rack mounting screws (not included).

Rack Mounting Safety Precautions

Elevated Operating Ambient Temperature: If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient temperature. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (T_{ma}) specified by the manufacturer.

Reduced Airflow: Installation of the equipment in a rack should be such that the amount of airflow required for safe operation of the equipment is not compromised.

Mechanical Loading: Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.

Circuit Overloading: Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.

Reliable Earthing: Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g., use of power strips).

Connect the Device

Make the necessary connections as called out in the following illustration. Connect power last.


CAUTION:

- Keep the device unplugged until all of the input, network, output, and speaker wiring is complete.
- Check the speaker cables for shorts and frayed wiring around the SPEAKER ZONES connectors.

NOTE:


- Ensure that the unit is properly grounded by connecting the chassis ground lug to an earth ground (building steel).
- To prevent overheating, do not operate this product in an area that exceeds the environmental temperature range listed in the product specifications.
- Do not bundle power cords together with connection cables. Doing so can result in noise.

Rear Panel



Digital Inputs


Refer to the following illustration when connecting digital audio sources.



NOTE: Only 2-channel PCM digital audio is supported at the digital inputs.


Analog Inputs

Refer to the following illustration when connecting analog audio sources.



Speaker Connections

Connect speakers to the DM-NAX-4ZSA-50 as shown in the following illustration.



Spotify® Setup

The DM-NAX-4ZSA-50 supports Spotify.

To configure Spotify, use your phone, tablet or computer as a remote control for Spotify. Go to spotify.com/connect to learn how.

Spotify can be enabled on any of the built-in media players on the DM-NAX-4ZSA-50.

To stream media from a device to a speaker zone in your distributed audio system:

1. Ensure that the device and DM-NAX-4ZSA-50 are on the same network.
2. On the DM-NAX-4ZSA-50, enable Spotify for the built-in media player you would like to stream to, either using the web UI or programming.

NOTE: If the control/media and Audio-over-IP network traffic is isolated between two network ports on the DM-NAX-4ZSA-50, Spotify will use the port specified for the Control/Media traffic.

3. On your device:
 - a. Enable Spotify
 - b. From the list of available Spotify destinations, select the DM-NAX-4ZSA-50 zone you would like to stream to.

The media player will play back audio to the selected zone(s).

NOTE: By default, media players 1 - 5 route the audio signals to their respectively numbered speaker zones 1 - 5. If the user has not specified the speaker zone when Spotify streaming begins, the media player will automatically route to its default speaker zone. For example, the audio from the media player 3 will be routed to speaker zone 3.

After the Spotify streaming begins, you will be able to control the volume of the streaming DM-NAX-4ZSA-50 speaker zones directly from your device.

Observe the LED Indicators

Refer to the following table for information about the LED indicators on the device.

LED Indicator	Color	Meaning
PWR	Amber	Power is being applied to the device. The device is booting.
	White	Device is powered on with audio passing.
	Red	Device is in standby mode.
Ethernet 1 and 2	White	The device is powered on and has a valid IP address.
	Off	Device is not connected to a network or the IP address is invalid.
SOURCE 1-4	White	Signal is detected on the specified input/source.
	Red	There is clipping on an analog input or bitstream audio detected on a digital input.
	Off	There is no signal detected on the specified input/source.
ZONE 1-4	White	There is audio output on the indicated zone.
	Red	Clipping or a fault is detected on the zone output due to over current, over temperature, or low voltage.
ZONE 5	White	There is audio output on the indicated zone.
	Red	Clipping is detected on the zone output due to over current, over temperature, or low voltage.
SETUP	Solid Red	The SETUP button is pressed.
	Blinking Red	A network reset or factory restore has been initiated via the adjacent SETUP button.

Reset the Device

A network reset or factory restore may be performed when troubleshooting.

CAUTION: These procedures should only be performed as a last resort to recover an unresponsive device. Both the Network Reset and Factory Restore procedure will clear certain device settings that cannot be recovered once the procedure is complete. Before performing these procedures, please contact Crestron True Blue Support via phone, email or chat as described at www.crestron.com/support.

Network Reset

1. Ensure the device is powered on.
2. Press and hold the **SETUP** button for up to 15 seconds until the **SETUP** LED flashes red.

The device will reboot, and the default network settings will be reset. The device will be reverted to its default hostname, with DHCP enabled, and no static IP set.

Factory Restore

1. Turn off the device by disconnecting the power cable from the device.
2. Press and hold the **SETUP** button and then reconnect the power cable while still holding the **SETUP** button. Continue holding the **SETUP** button for up to 30 seconds until the **SETUP** LED flashes.

The device will reboot, and all the factory default settings will be restored, such as Zone settings, streaming service accounts, multicast addressing, etc.


CAUTION: Performing a factory restore will clear all settings from the device configuration.

DM-NAX-4ZSP Installation

Refer to the following sections to install the DM-NAX-4ZSP.

- [In the Box on page 90](#)
- [Install the Device on page 91](#)
- [Connect the Device on page 92](#)
- [Observe the LED Indicators on page 96](#)
- [Apple® AirPlay® Setup on page 94](#)
- [Spotify® Connect Setup on page 95](#)
- [Reset the Device on page 97](#)

Front Panel



In the Box

Qty. Description

1	DM-NAX-4ZSP
---	-------------

Additional Items

- | | |
|---|--|
| 2 | Bracket, Rack Ear, 2 RU (2032122) |
| 1 | Power Cord, approx. 6.5 ft (2 m) (2001134) |
| 2 | Connector, 4-Pin (2003576) |
| 3 | Connector, 5-Pin (2003577) |
| 4 | Feet, Adhesive (2002389) |

Install the Device

Refer to the [Safety Instructions](#) (Doc. 6607) prior to installation.

The device can be placed on a table or installed in a rack.


Place on a Flat Surface

Place the device on a flat surface such as a table.

Install in a Rack

This device occupies 1U of rack space.

1. Use a Phillips screwdriver (not included) to remove the three screws from each side of the device as shown in the illustration.
2. Use the screwdriver and the six screws (removed earlier) to attach the included rack ears to the device.



3. Mount the device into the rack using four rack mounting screws (not included).

Rack Mounting Safety Precautions

Elevated Operating Ambient Temperature: If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than the room ambient temperature. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (T_{ma}) specified by the manufacturer.

Reduced Airflow: Installation of the equipment in a rack should be such that the amount of airflow required for safe operation of the equipment is not compromised.

Mechanical Loading: Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.

Circuit Overloading: Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.

Reliable Earthing: Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g., use of power strips).

Connect the Device

Make the necessary connections as called out in the following illustration. Connect power last.


CAUTION:

- Keep the device unplugged until all of the input, network, output, and speaker wiring is complete.

NOTES:


- Ensure that the unit is properly grounded by connecting the chassis ground lug to an earth ground (building steel).
- To prevent overheating, do not operate this product in an area that exceeds the environmental temperature range of 32° to 104°F (0° to 40°C).
- Do not bundle power cords together with connection cables. Doing so can result in noise.

Rear Panel



Digital Inputs


Refer to the following illustration when connecting digital audio sources.



NOTE: 2-channel PCM digital audio is the only supported digital input format.

Analog Inputs


Refer to the following illustration when connecting analog audio sources.



Balanced/Unbalanced Audio Output

Refer to the following table and illustration for analog audio output pin assignments and connection information.

Signal Name	Balanced Audio Output	Unbalanced Audio Output
+	L+	L+
-	L-	L Shield
G	Shield/ground	G, L Shield, and R Shield
+	R+	R+
-	R-	R Shield



Apple® AirPlay® Setup

The DM-NAX-4ZSP supports AirPlay 2 and requires iOS 11.4 or later.

AirPlay can be enabled on any of the built-in media players on the DM-NAX-4ZSP.

To stream media from an iOS device to an output zone in your distributed audio system:

1. Ensure that the iOS device and DM-NAX-4ZSP are on the same network.
2. On the DM-NAX-4ZSP, enable AirPlay for the built-in media player you would like to stream to, either using the web UI or programming.

NOTE: If the control/media and Audio-over-IP network traffic is isolated between two network ports on the DM-NAX-4ZSP, AirPlay will use the port specified for the Control/Media traffic.

3. On your iOS device:
 - a. Enable AirPlay
 - b. From the list of available AirPlay destinations, select the DM-NAX-4ZSP zone you would like to stream to.

The media player will play back audio to the selected zone(s).

Once AirPlay streaming begins, you will be able to control the volume of the streaming DM-NAX-4ZSP output zones directly from your iOS device.

NOTE: By default, media players 1 - 4 route the audio signals to their corresponding output zones when Airplay streaming begins. If the user has not already specified a destination output zone for the media player when streaming begins, the media player will automatically route to its default output zone. For example, if a user streams Airplay to media player 3, the audio will be routed to output zone 3.

Spotify® Connect Setup

The DM-NAX-4ZSP supports Spotify Connect.

To configure Spotify, use your phone, tablet or computer as a remote control for Spotify. Go to spotify.com/connect to learn how.

Spotify Connect can be enabled on any of the built-in media players on the DM-NAX-4ZSP.

To stream media from a device to a output zone in your distributed audio system:

1. Ensure that the device and DM-NAX-4ZSP are on the same network.
2. On the DM-NAX-4ZSP, enable Spotify Connect for the built-in media player you would like to stream to, either using the web UI or programming.

NOTE: If the control/media and Audio-over-IP network traffic is isolated between two network ports on the DM-NAX-4ZSP, Spotify will use the port specified for the Control/Media traffic.

3. On your device:
 - a. Open the Spotify application or web client.
 - b. From the list of available Spotify destinations, select the DM-NAX-4ZSP zone you would like to stream to.

The media player will play back audio to the selected zone(s).

Once Spotify Connect streaming begins, you will be able to control the volume of the streaming DM-NAX-4ZSP output zones directly from your device.

NOTE: By default, media players 1 - 4 route the audio signals to their corresponding output zones when Spotify Connect streaming begins. If the user has not already specified a destination output zone when streaming begins, the media player will automatically route to its default output zone. For example, if a user streams Spotify Connect to media player 3, the audio will be routed to output zone 3.

Observe the LED Indicators

Refer to the following table for information about the LED indicators on the device.

LED Indicator	Color	Meaning
PWR	White	Device is powered on with audio passing.
	Red	Device is in standby mode.
	Off	Device is not powered on.
LAN	White	The device is powered on and has a valid IP address.
	Off	Device is not connected to a network or the IP address is invalid.
NAX	White	AoIP is ready to pass and the unit's PTP clock is synced.
	Off	No AoIP is passing to or from the unit and/or PTP is not synced.
SOURCE 1-8	White	Signal is detected on the specified input/source.
	Red	There is clipping on an analog input or bitstream audio detected on a digital input.
	Off	There is no signal detected on the specified input/source.
ZONE 1-4	White	There is audio output on the indicated zone.
	Red	Clipping is detected on the output audio.
SETUP	Solid Red	The SETUP button is pressed.
	Blinking Red	A network reset or factory restore has been initiated via the adjacent SETUP button.

Reset the Device

A network reset or factory restore may be performed when troubleshooting.

CAUTION: These procedures should only be performed as a last resort to recover an unresponsive device. Both the Network Reset and Factory Restore procedure will clear certain device settings that cannot be recovered once the procedure is complete. Before performing these procedures, please contact Crestron True Blue Support via phone, email or chat as described at www.crestron.com/support.

Network Reset

1. Ensure the device is powered on.
2. Press and hold the **SETUP** button for up to 15 seconds until the **SETUP** LED flashes red.

The device will reboot, and the default network settings will be reset. The device will be reverted to its default hostname, with DHCP enabled, and no static IP set.

Factory Restore

1. Turn off the device by disconnecting the power cable from the device.
2. Press and hold the **SETUP** button and then reconnect the power cable while still holding the **SETUP** button. Continue holding the **SETUP** button for up to 30 seconds until the **SETUP** LED flashes.

The device will reboot, and all the factory default settings will be restored, such as Zone settings, streaming service accounts, multicast addressing, etc.


CAUTION: Performing a factory restore will clear all settings from the device configuration.

DM-NAX-16AIN Installation

Refer to the following sections to install the DM-NAX-16AIN.

- [In the Box on page 98](#)
- [Install the Device on page 99](#)
- [Connect the Device on page 101](#)
- [Observe the LED Indicators on page 103](#)
- [Reset the Device on page 104](#)

Front Panel



In the Box

Qty. Description

1	DM-NAX-16AIN
---	--------------

Additional Items

- | | |
|---|--|
| 2 | Bracket, Rack Ear, 1U (2032122) |
| 4 | Connector, 5-Pin (2003577) |
| 1 | Power Cord, 6 ft 7 in. (2 m) (2001134) |

Install the Device

Refer to the [Safety Instructions](#) (Doc. 6607) prior to installation.

The device can be placed on a flat surface or installed in a rack.


Place on a Flat Surface

Place the device on a flat surface such as a table.

Install in a Rack

This device occupies 1U of rack space.

1. Use a Phillips screwdriver (not included) to remove the three screws from each side of the device as shown in the illustration.
2. Use the screwdriver and the six screws (removed earlier) to attach the included rack ears to the device.



3. Mount the device into the rack using four rack mounting screws (not included).

Rack Mounting Safety Precautions

Elevated Operating Ambient Temperature: If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than the room ambient temperature. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (T_{ma}) specified by the manufacturer.

Reduced Airflow: Installation of the equipment in a rack should be such that the amount of airflow required for safe operation of the equipment is not compromised.

Mechanical Loading: Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.

Circuit Overloading: Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.

Reliable Earthing: Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g., use of power strips).

Connect the Device

Make the necessary connections as called out in the following illustration. Connect power last.


CAUTION:

- Keep the device unplugged until all of the input wiring is complete.
- Check the connections for shorts and frayed wiring at all the input connectors.

NOTES:

- Ensure that the unit is properly grounded by connecting the chassis ground lug to an earth ground (building steel).
- To prevent overheating, do not operate this product in an area that exceeds the environmental temperature range of 32° to 104°F (0° to 40°C).
- Do not bundle power cords together with connection cables. Doing so can result in noise.

Rear Panel



Digital Inputs

Refer to the following illustration when connecting digital audio sources.



NOTE: 2-channel PCM digital audio is the only supported digital input format.

Analog Inputs


Refer to the following illustration when connecting analog audio sources.



Balanced/Unbalanced Audio Input

Refer to the following table and illustration for analog audio input pin assignments and connection information.

Signal Name	Balanced Audio Input	Unbalanced Audio Input
+	L+	L+
-	L-	Open
G	Shield/ground	Open
+	R+	R+
-	R-	Open



Observe the LED Indicators

Refer to the following table for information about the LED indicators on the device.

LED Indicator	Color	Meaning
PWR	Amber	Power is being applied to the device. The device is booting.
	White	Device is powered on with audio passing.
	Red	Device is in standby mode.
LAN	White	The device is powered on and has a valid IP address.
	Off	Device is not connected to a network or the IP address is invalid.
NAX	White	AoIP is ready to pass and the unit's PTP clock is synced.
	Off	No AoIP is passing to or from and/or PTP is not synced.
SOURCE 1-16	White	Signal is detected on the specified input/source.
	Red	There is clipping on an analog input or bitstream audio detected on a digital input.
	Off	There is no signal detected on the specified input/source.

LED Indicator	Color	Meaning
SETUP	Solid Red	The SETUP button is pressed.
	Blinking Red	A network reset or factory restore has been initiated via the adjacent SETUP button.

Reset the Device

A network reset or factory restore may be performed when troubleshooting.

CAUTION: These procedures should only be performed as a last resort to recover an unresponsive device. Both the Network Reset and Factory Restore procedure will clear certain device settings that cannot be recovered once the procedure is complete. Before performing these procedures, please contact Crestron True Blue Support via phone, email or chat as described at www.crestron.com/support.

Network Reset

1. Ensure the device is powered on.
2. Press and hold the **SETUP** button for up to 15 seconds until the **SETUP** LED flashes red.

The device will reboot, and the default network settings will be reset. The device will be reverted to its default hostname, with DHCP enabled, and no static IP set.

Factory Restore

1. Turn off the device by disconnecting the power cable from the device.
2. Press and hold the **SETUP** button and then reconnect the power cable while still holding the **SETUP** button. Continue holding the **SETUP** button for up to 30 seconds until the **SETUP** LED flashes.

The device will reboot, and all the factory default settings will be restored, such as Zone settings, names, multicast addressing, etc.

CAUTION: Performing a factory restore will clear all settings from the device configuration.

DM-NAX-AMP-X300 Installation

Refer to the following sections to install the DM-NAX-AMP-X300.

- [In the Box on page 106](#)
- [Install the Device on page 107](#)
- [Connect the Device on page 111](#)
- [Speaker Mode Selection Switch on page 111](#)
- [Lo-Z Modes Selection Switch on page 112](#)
- [Observe the LED Indicators on page 112](#)
- [Reset the Device on page 113](#)

In the Box

Qty. Description

1 DM-NAX-AMP-X300

Additional Items

4 Plate, Joining (2055198)

8 Screw, 8-32 x 5/16 in., Flat Head, Philips, Black (2055195)

4 Screw, 6-32 x 3/8 in., Undercut Head, Philips (2055196)

4 Foot, Adhesive, Black (2055200)

2 Rack Ear Assembly, 1U, Quarter-width (2055197), includes Bracket, Rack Ear, 1U (2055199)

2 Connector, Speaker (2055026)

8 Connector, input, output (2055207)

1 Connector, 2-Pin (2003574)


1 Power cord (2055205)

Install the Device

The DM-NAX-AMP-X300 can be placed or mounted on a flat surface or installed in a rack.

Place on a Flat Surface


Place the DM-NAX-AMP-X300 on a table or other flat surface. Attach the four adhesive feet as shown below.




Mount on a Flat Surface

To mount the DM-NAX-AMP-X300 on a flat surface:

1. Use the eight included 8-32 x 5/16 in. screws to attach the four joining plates to the underside of the device as shown in the illustration.



2. Position the device as desired and use screws (not included) and anchors (not included) to mount it.




Rack Installation

The DM-NAX-AMP-X300 occupies one half of 1RU of rack space. Two DM-NAX-AMP-X300 units can be placed together and only occupy 1 RU of rack space.

Single Amp

To install the included rack ears on a single DM-NAX-AMP-X300:

1. Use a #1 Philips screwdriver to remove the three screws from each side of the front of the device.
2. Use the screwdriver and the four included 1/4 in. Philips Pan Head screws to attach the included rack ears to the device.




3. Mount the device into the rack using four rack mounting screws (not included).


Double Amp

To rack-mount two DM-NAX-AMP-X300 units together:


1. On a flat surface, place the amplifiers upside-down and adjacent to each other.
2. Using a Philips screwdriver and the eight included 8-32 x 5/16 in. screws, gang the amplifiers together with two of the joining plates.



3. Use a wrench or M5.5 socket to remove the nuts from the rack ears.



4. Turn the amplifier assembly over and, using six 6-32 x 3/8 in. screws, attach the rack ears to each side.



5. Mount the assembly into the rack using four rack mounting screws (not included).

NOTE: Observe the following rack mount installation guidelines.

Elevated Operating Ambient Temperature: If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient

temperature. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (Tma) specified by the manufacturer.

Reduced Airflow: Installation of the equipment in a rack should be such that the amount of airflow required for safe operation of the equipment is not compromised.

Mechanical Loading: Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.

Circuit Overloading: Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.

Reliable Earthing: Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g., use of power strips).

WARNING: To prevent bodily injury when mounting or servicing the unit in a rack:

- When mounting the unit into a partially filled rack, load the rack from the bottom to the top with the heaviest component at the bottom of the rack.
- If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the unit in the rack.

Connect the Device


Make the necessary connections as called out in the following illustration. For details on wiring, refer to [Output Wiring Options on page 114](#).

CAUTION:

- Keep the device unplugged until all of the input, network, output, and speaker wiring is complete.
- Check the speaker cables for shorts and frayed wiring around the speaker output connectors.

NOTES:

- Ensure that the unit is properly grounded by connecting the chassis ground lug to an earth ground (building steel).
- To prevent overheating, do not operate this product in an area that exceeds the environmental temperature range listed in the table of specifications.
- Ensure that both the Ethernet ports are not connected to the same network or switch.



Speaker Mode Selection Switch

The DM-NAX-AMP-X300 can be configured to work with 4 Ω and 8 Ω (low impedance or Lo-Z) loads or a distributed audio (high impedance or Hi-Z) 70/100V system.

- **Lo-Z:** Set the switch to LoZ to use the amplifier with 4 Ω or 8 Ω low impedance loudspeakers.
- **70V:** Set the switch to 70V to use the amplifier in a 70V distributed audio system.
- **100V:** Set the switch to 100V to use the amplifier in a 100V distributed audio system.

Lo-Z Modes Selection Switch

When operating in Lo-Z mode, the DM-NAX-AMP-X300 outputs can operate in stereo, as summed outputs or as bridged outputs. Set the **Lo-Z Modes** selection switch to the desired setting and connect the outputs as required.


Select stereo, summed, or bridged operation:

- **STEREO:** The input signal received on each channel is sent to its respective output for use in applications where left and right channel separation is required.
- **SUM:** The input signals sent to a channel pair (1 + 2 or 3 + 4) are summed and sent to their respective individual outputs.
- **BRIDGE:** The input signals sent to a channel pair (1 + 2 or 3 + 4) are summed and sent to a bridged output (1 + 2 or 3 + 4) for use in high power applications.

NOTE:

- If the Rear Panel Lockout indicator is enabled, the web user interface settings will override the both switch selections.

Observe the LED Indicators



The LEDs provide the following information:

LED Indicator	Color	Meaning
PWR	White	The device is operating normally.
	Amber	The device is booting.
	Red	The device has entered Standby (Power Saver) mode.
Hi-Z	White	Hi-Z mode is enabled (70V or 100V); Channels 1-2 and 3-4 are bridged and set to 70V or 100V operation.
LAN	White	The device has a valid IP address.
AoIP	White	The device has is handling an AoIP stream.
FAULT	Red	There is a fault on the indicated channel.
SIGNAL	White	An audio signal is present on the indicated speaker channel.
	Red	Clipping is detecting on the indicated speaker channel.

Reset the Device

A network reset or factory restore may be performed when troubleshooting.

CAUTION: These procedures should only be performed as a last resort to recover an unresponsive device. Both the Network Reset and Factory Restore procedure will clear certain device settings that cannot be recovered once the procedure is complete. Before performing these procedures, please contact Crestron True Blue Support via phone, email or chat as described at www.crestron.com/support.

Network Reset

1. Ensure the device is powered on.
2. Press and hold the **SETUP** button for up to 15 seconds until the **SETUP** LED flashes red.

Factory Restore

To restore all settings to factory default, perform the following steps:

1. Turn off the device by disconnecting the power cable from the device.
2. Press and hold the **SETUP** button and then reconnect the power cable while still holding the **SETUP** button. Continue holding the **SETUP** button for up to 30 seconds until the **SETUP** LED flashes.


The device will reboot, and all the factory default settings will be restored, such as Zone settings, names, multicast addressing, etc.

CAUTION: Performing a factory restore will clear all settings from the device configuration.


Output Wiring Options

The DM-NAX-AMP-X300 can be configured for low impedance (LoZ) stereo operation over two or four channels and high impedance (70 V or 100 V) operation over two channels. Refer to the following diagrams for details.


Four Channels up to 75 W (Lo-Z)




Two Channels up to 150 W (Lo-Z)




Two Channels up to 75 W and One Channel up to 150 W (Lo-Z)




One Channel up to 300 W (Lo-Z)



Two Runs up to 150 W (Hi-Z)



One Run up to 300 W (Hi-Z)



DM-NAX-AUD-IO Installation

Refer to the following sections to install the DM-NAX-AUD-IO.

- [In the Box on page 117](#)
- [Mount the Device on page 117](#)
- [Connect the Device on page 121](#)
- [Reset the Device on page 123](#)

In the Box

Qty.	Description
------	-------------

1	DM-NAX-AUD-IO
---	---------------

Additional Items

- | | |
|---|--|
| 1 | Single gang electrical box adapter bracket, galvanized metal (2059673) |
| 2 | Surface mount bracket, aluminum (2059674) |
| 2 | Connector, 5-pin (2003577) |
| 2 | Screws, M3 x 6 mm, Flat Head, Phillips (2062526) |
| 4 | Screws, M3 x 0.5 x 6 mm, Pan Head, Phillips (2058870) |
| 1 | Polycarbonate front panel label (4536923) |

Mount the Device


The DM-NAX-AUD-IO can be mounted under a table, into a 1-gang electrical box, or onto a rack rail.

Mounting under a Table

To mount the device under a table:

1. Using a Phillips screwdriver, remove the four flat head screws from the left and right panels of the device.
2. Align the two included right angle surface mount brackets with the left and right panels of the device. For mounting under a table, keep the flanged surface of the brackets flush with the top panel of the device. For mounting to a surface, keep the flanged surface of the brackets flush with the bottom panel of the device.

- Using a Phillips screwdriver and the four included M3 pan head screws, attach the mounting brackets to the device.



- Secure the device to a surface or under a table using the appropriate mounting screws (not included).

Mounting into a 1-Gang Electrical Box


NOTES:

- The DM-NAX-AUD-IO should only be mounted with a RACO® 3 in. x 2 in. x 2 in. gangable metal switch box with eight 0.5 in. knockouts and plaster ears (catalog ID #420), as it was designed to fit the box dimensions and knockout placements. Alternative metal switch boxes should not be used as they may have different knockout placements, which can lead to issues running the PoE connection to the unit due to cable bend radius restrictions.
- For thermal performance reasons, fully enclosed plastic back boxes should not be used with the DM-NAX-AUD-IO. In installations where an enclosed back box is not required, the DM-NAX-AUD-IO can be installed into most single gang metal or plastic mud rings.
- Connector boots should not be used on CAT5e (or greater) cables being connected to the DM-NAX-AUD-IO to avoid cable bend radius issues.

To mount the device into a 1-gang electrical box:

- Using a Phillips screwdriver, remove the two screws from the top and bottom panels nearer to the front panel of the device.
- Align the included polycarbonate front panel label with the front panel of the device so the holes in the label line up with the 5-pin connectors.

- Using a Phillips screwdriver and the included M3 flat head screws, secure the included single gang electrical box adapter bracket to the top and bottom panels of the device.




- Using a Phillips screwdriver and two 6-32 x 3/4 in., truss head screws (not included), attach the wall plate adapter bracket to the electrical box.
- Using a Phillips screwdriver and two 6-32 x 1/4 in., flat head screws (not included), attach a [FP-G1](#) decorator style faceplate (sold separately) to the wall plate.

Mounting onto a Rack Rail


To mount the device onto a rack rail:

- Using a Phillips screwdriver, remove the two screws from the top and bottom panels nearer to the front panel of the device.

3. Position the wall plate horizontally so that the holes in the left or right mounting flange align with the holes in the rack rail.




4. Secure the wall plate to the rack rail using two mounting screws (not included).



Connect the Device

Make connections to the front and rear panels of the DM-NAX-AUD-IO as described below.


Rear Panel



NOTE: PoE is a PoE powered device (PD) port. In order for the port to receive PoE, it must be connected to a PoE compliant Ethernet switch.

Connect a PoE capable network switch to the **PoE** port.

Front Panel




Connect a balanced or unbalanced line-level audio source signal to the **INPUTS** 5-pin terminal block.

Connect a balanced or unbalanced line-level audio sink device to the **OUTPUTS** 5-pin terminal block.

Balanced/Unbalanced Audio Input

Refer to the following table and illustration for analog audio input pin assignments and connection information.

Signal Name	Balanced Audio Input	Unbalanced Audio Input
+	L+	L+
-	L-	Open
G	Shield/ground	Open
+	R+	R+
-	R-	Open



Reset the Device

A network reset or factory restore may be performed when troubleshooting.

CAUTION: These procedures should only be performed as a last resort to recover an unresponsive device. Both the Network Reset and Factory Restore procedure will clear certain device settings that cannot be recovered once the procedure is complete. Before performing these procedures, please contact Crestron True Blue Support via phone, email or chat as described at www.crestron.com/support.

Network Reset

1. Ensure the device is powered on.
2. Press and hold the **SETUP** button for up to 15 seconds until the **SETUP** LED flashes red.

The device will reboot, and the default network settings will be reset. The device will be reverted to its default hostname, with DHCP enabled, and no static IP set.

Factory Restore

1. Turn off the device by disconnecting the power cable from the device.
2. Press and hold the **SETUP** button and then reconnect the power cable while still holding the **SETUP** button. Continue holding the **SETUP** button for up to 30 seconds until the **SETUP** LED flashes.

The device will reboot, and all the factory default settings will be restored, such as audio settings, multicast addressing, etc.

CAUTION: Performing a factory restore will clear all settings from the device configuration.

DM-NAX-AUD-USB Installation

Refer to the following sections to install the DM-NAX-AUD-USB.

- [In the Box on page 125](#)
- [Mount the Device on page 125](#)
- [Connect the Device on page 129](#)
- [Reset the Device on page 131](#)

In the Box

Qty.	Description
------	-------------

1	DM-NAX-AUD-USB
---	----------------

Additional Items

- | | |
|---|--|
| 1 | Single gang electrical box adapter bracket, galvanized metal (2059673) |
| 2 | Surface mount bracket, aluminum (2059674) |
| 2 | Screws, M3 x 6 mm, Flat Head, Phillips (2062526) |
| 4 | Screws, M3 x 0.5 x 6 mm, Pan Head, Phillips (2058870) |
| 1 | Polycarbonate front panel label (4536924) |

Mount the Device


The DM-NAX-AUD-USB can be mounted under a table, into a 1-gang electrical box, or onto a rack rail.

Mounting under a Table

To mount the device under a table:

1. Using a Phillips screwdriver, remove the four flat head screws from the left and right panels of the device.
2. Align the two included right angle surface mount brackets with the left and right panels of the device. For mounting under a table, keep the flanged surface of the brackets flush with the top panel of the device. For mounting to a surface, keep the flanged surface of the brackets flush with the bottom panel of the device.

3. Using a Phillips screwdriver and the four included M3 pan head screws, attach the mounting brackets to the device.



4. Secure the device to a surface or under a table using the appropriate mounting screws (not included).

Mounting into a 1-Gang Electrical Box


NOTES:

- The DM-NAX-AUD-USB should only be mounted with a RACO® 3 in. x 2 in. x 2 in. gangable metal switch box with eight 0.5 in. knockouts and plaster ears (catalog ID #420), as it was designed to fit the box dimensions and knockout placements. Alternative metal switch boxes should not be used as they may have different knockout placements, which can lead to issues running the PoE connection to the unit due to cable bend radius restrictions.
- For thermal performance reasons, fully enclosed plastic back boxes should not be used with the DM-NAX-AUD-USB. In installations where an enclosed back box is not required, the DM-NAX-AUD-USB can be installed into most single gang metal or plastic mud rings.
- Connector boots should not be used on CAT5e (or greater) cables being connected to the DM-NAX-AUD-USB to avoid cable bend radius issues.

To mount the device into a 1-gang electrical box:

1. Using a Phillips screwdriver, remove the two screws from the top and bottom panels nearer to the front panel of the device.
2. Align the included polycarbonate front panel label with the front panel of the device so the holes in the label line up with the 5-pin connectors.

- Using a Phillips screwdriver and the included M3 flat head screws, secure the included single gang electrical box adapter bracket to the top and bottom panels of the device.




- Using a Phillips screwdriver and two 6-32 x 3/4 in., truss head screws (not included), attach the wall plate adapter bracket to the electrical box.
- Using a Phillips screwdriver and two 6-32 x 1/4 in., flat head screws (not included), attach a [FP-G1](#) decorator style faceplate (sold separately) to the wall plate.

Mounting onto a Rack Rail


To mount the device onto a rack rail:

- Using a Phillips screwdriver, remove the two screws from the top and bottom panels nearer to the front panel of the device.

3. Position the wall plate horizontally so that the holes in the left or right mounting flange align with the holes in the rack rail.




4. Secure the wall plate to the rack rail using two mounting screws (not included).



Connect the Device

Make connections to the front and rear panels of the DM-NAX-AUD-USB as described below.


Rear Panel



NOTE: PoE is a PoE powered device (PD) port. In order for the port to receive PoE, it must be connected to a PoE compliant Ethernet switch.

Connect a PoE capable network switch to the **PoE** port.

Front Panel



Connect a USB audio source to the **USB** port using a USB Type-C male connector .

Connect an unbalanced line-level audio source to the **INPUT** TRS port.

Connect an unbalanced line-level audio sink device to the **OUTPUT** TRS port.

Reset the Device

A network reset or factory restore may be performed when troubleshooting.

CAUTION: These procedures should only be performed as a last resort to recover an unresponsive device. Both the Network Reset and Factory Restore procedure will clear certain device settings that cannot be recovered once the procedure is complete. Before performing these procedures, please contact Crestron True Blue Support via phone, email or chat as described at www.crestron.com/support.

Network Reset

1. Ensure the device is powered on.
2. Press and hold the **SETUP** button for up to 15 seconds until the **SETUP** LED flashes red.

The device will reboot, and the default network settings will be reset. The device will be reverted to its default hostname, with DHCP enabled, and no static IP set.

Factory Restore

1. Turn off the device by disconnecting the power cable from the device.
2. Press and hold the **SETUP** button and then reconnect the power cable while still holding the **SETUP** button. Continue holding the **SETUP** button for up to 30 seconds until the **SETUP** LED flashes.

The device will reboot, and all the factory default settings will be restored, such as audio settings, multicast addressing, etc.

CAUTION: Performing a factory restore will clear all settings from the device configuration.

DM-NAX-BTIO-1G Installation

Refer to the following sections to install the DM-NAX-BTIO-1G.

- [In the Box on page 132](#)
- [Mount the Device on page 132](#)
- [Connect the Device on page 134](#)
- [Reset the Device on page 135](#)

In the Box

Qty.	Description
------	-------------

1	DM-NAX-BTIO-1G
---	----------------

Additional Items

- | | |
|---|---|
| 1 | Metal mounting bracket, steel (2016054) |
| 2 | Screw, 06-32, 1/4 in., Pan Head, Phillips (2007218) |
| 2 | Screws, 6-32 x 3/4 in., Truss Head, Combo (2009211) |


Mount the Device

The DM-NAX-BTIO-1G can be mounted under a table or into a 1-gang electrical box.

Mounting under a Table

To mount the device under a table:

1. Align the included right angle surface mount bracket with the front panel of the device.
2. Using a Phillips screwdriver and the two included 6-32 x 1/4 in. pan head screws, attach the mounting bracket to the device.



3. Secure the device to the underside of a table using the appropriate mounting screws (not included).

Mounting into a 1-Gang Electrical Box


NOTES:

- The DM-NAX-BTIO-1G should only be mounted with a RACO® 3 in. x 2 in. x 2 in. gangable metal switch box with eight 0.5 in. knockouts and plaster ears (catalog ID #420), as it was designed to fit the box dimensions and knockout placements. Alternative metal switch boxes should not be used as they may have different knockout placements, which can lead to issues running the PoE connection to the unit due to cable bend radius restrictions.
- For thermal performance reasons, fully enclosed plastic back boxes should not be used with the DM-NAX-BTIO-1G. In installations where an enclosed back box is not required, the DM-NAX-BTIO-1G can be installed into most single gang metal or plastic mud rings.
- Connector boots should not be used on CAT5e (or greater) cables being connected to the DM-NAX-BTIO-1G to avoid cable bend radius issues.

To mount the wall plate into a 1-gang electrical box:

1. Using a Phillips screwdriver and two 6-32 x 3/4 in., truss head screws, attach the wall plate to the electrical box.


2. Using a Phillips screwdriver and two 6-32 x 1/4 in., flat head screws (not included), attach a [FP-G1](#) decorator style faceplate (sold separately) to the wall plate.



Connect the Device

Make connections to the front and top panels of the DM-NAX-BTIO-1G as described below.

Top Panel



NOTE: **PoE** is a PoE powered device (PD) port. In order for the port to receive PoE, it must be connected to a PoE compliant Ethernet switch.

Connect a PoE capable network switch to the **PoE** port.

Front Panel

Connect an unbalanced line-level audio input to the **INPUT** TRS port.

Connect an unbalanced line-level audio output to the **OUTPUT** TRS port.

Reset the Device

A network reset or factory restore may be performed when troubleshooting.

CAUTION: These procedures should only be performed as a last resort to recover an unresponsive device. Both the Network Reset and Factory Restore procedure will clear certain device settings that cannot be recovered once the procedure is complete. Before performing these procedures, please contact Crestron True Blue Support via phone, email or chat as described at www.crestron.com/support.

Network Reset

1. Ensure the device is powered on.
2. Press and hold the **SETUP** button for up to 15 seconds until the **SETUP** LED flashes red.

The device will reboot, and the default network settings will be reset. The device will be reverted to its default hostname, with DHCP enabled, and no static IP set.

Factory Restore

1. Turn off the device by disconnecting the power cable from the device.
2. Press and hold the **SETUP** button and then reconnect the power cable while still holding the **SETUP** button. Continue holding the **SETUP** button for up to 30 seconds until the **SETUP** LED flashes.

The device will reboot, and all the factory default settings will be restored, such as audio settings, multicast addressing, etc.

CAUTION: Performing a factory restore will clear all settings from the device configuration.

Configuration

The following products can be configured:

- [DM-NAX-2XLRI-1G on page 137](#)
- [DM-NAX-8ZSA on page 189](#)
- [DM-NAX-16AIN on page 375](#)
- [DM-NAX-4ZSA-50 on page 256](#)
- [DM-NAX-4ZSP on page 314](#)
- [DM-NAX-AMP-X300 on page 407](#)
- [DM-NAX-AUD-IO on page 473](#)
- [DM-NAX-AUD-USB on page 529](#)
- [DM-NAX-BTIO-1G on page 585](#)

DM-NAX-2XLRI-1G

This section describes how to configure the DM-NAX-2XLRI-1G.

Web Interface Configuration

The DM-NAX-2XLRI-1G web interface allows you to view status information and configure network and device settings.

Access the Web Interface

To access the web interface, do either of the following:

- [Access the Web Interface with a Web Browser on page 138](#)
- [Access the Web Interface With the Crestron Toolbox™ Application on page 188](#)

The web interface is accessed from a web browser. The following table lists operating systems and their corresponding supported web browsers.

Operating System and Supported Web Browsers


OPERATING SYSTEM	SUPPORTED WEB BROWSERS
Windows® operating system	Chrome™ web browser, version 31 and later
	Firefox® web browser, version 31 and later
	Internet Explorer web browser, version 11 and later
	Microsoft Edge web browser
macOS® operating system	Safari® web browser, version 6 and later
	Chrome web browser, version 31 and later
	Firefox web browser, version 31 and later

Access the Web Interface with a Web Browser

1. Enter the IP address of the DM-NAX-2XLRI-1G into a web browser.


NOTE: To obtain the IP address, use the **Device Discovery Tool** option in Crestron Toolbox™ application or an IP scanner application.

2. If you are creating a user account for the first time, do the following; otherwise, skip to step 3.
 - a. Enter a username in the **Username** field.
 - b. Enter a password in the **Password** field.
 - c. Re-enter the same password in the **Confirm Password** field.



The screenshot shows the Crestron logo at the top left. Below it, a yellow warning triangle icon is followed by the text "DEVICE FIRST BOOT". In the center, there is a white box titled "Device Administration". Inside this box, there are three input fields: "Username", "Password", and "Confirm Password". Below these fields is a green button with a white plus sign and the text "Create User". At the bottom of the white box, there is small text: "© 2021 Crestron Electronics, Inc.", "Privacy Statement", and "Crestron Software End-User License Agreement".

- d. Click **Create User**. The Device Administration page appears.




The screenshot shows the same Crestron logo at the top left. Below it, the "DEVICE FIRST BOOT" message is no longer present. The white box titled "Device Administration" still contains the "Username" and "Password" input fields. Below these fields is a blue button with a white magnifying glass icon and the text "Sign In". At the bottom of the white box, the same small text is present: "© 2021 Crestron Electronics, Inc.", "Privacy Statement", and "Crestron Software End-User License Agreement".

3. Enter the username in the **Username** field.
4. Enter the password in the **Password** field.
5. Click **Sign In**.

Action

The **Action** drop-down menu is displayed at the top right side of the interface and provides quick access to common device functions:

- Save Changes
- Revert
- Reboot
- Restore
- Update Firmware
- Download Logs
- Manage Certificates



Save Changes

Click **Save Changes** to save any changes made to the configuration settings.


Revert

Click **Revert** to revert the device back to the last saved configuration settings.

Reboot the DM-NAX-2XLRI-1G

Certain changes to the settings may require the DM-NAX-2XLRI-1G to be rebooted to take effect. To reboot the device, do the following:

1. Click **Reboot** in the **Actions** drop-down menu. The **Confirmation** message box appears.




2. Click **Yes, Reboot Now** to reboot the device. The **Reboot** message box appears. Wait for the device reboot to complete before attempting to reconnect to the device.

Restore to Factory Default Settings

1. Click **Restore** in the **Actions** drop-down menu to restore the settings of the DM-NAX-2XLRI-1G to factory defaults.

NOTE: When settings are restored, all settings, including the network settings, will revert to the factory default. If a static IP address is set, restoring the device to factory default settings will revert the IP address to the default DHCP mode.




2. Click **Yes** in the **Confirmation** dialog to restore the DM-NAX-2XLRI-1G to factory settings. Click **No** to cancel the restore operation.

A dialog is displayed again, indicating that the restore process was successful and that the device rebooted.

You can also restore to factory settings by pressing and holding the **SETUP** button on the rear panel of the device with power disconnected then connect the power supply and continue to hold **SETUP** button for 30 seconds.

Update Firmware

1. Click **Update Firmware** in the **Actions** drop-down menu.
2. In the **Firmware Upgrade** dialog, click **+ Browse**.



3. Locate and select the desired firmware file, and then click **Open**. The selected firmware file name is displayed in the **Firmware Upgrade** dialog.
4. Click **Load** and wait for the progress bar to complete and for the **OK** button in the message to become clickable.
5. Click **OK**. The device with new firmware can now be accessed.


Download Logs

1. Click **Download Logs** in the **Actions** drop-down menu to download the device message logs for diagnostic purposes.

The log file is downloaded to the Downloads folder of the PC.

Manage Certificates

Use the **Manage Certificates** dialog to add, remove, and manage certificates used in 802.1x and other protected networks.



1. Click **Manage Certificates** in the **Actions** drop-down menu. The following certificate tabs are displayed:
 - **Root:** The Root certificate is used by the DM-NAX-2XLRI-1G to validate the network's authentication server. The DM-NAX-2XLRI-1G has a variety of Root certificates, self-signed by trusted CAs (Certificate Authorities) preloaded into the device. Root certificates must be self-signed.
 - **Intermediate:** The Intermediate store holds non self-signed certificates that are used to validate the authentication server. These certificates will be provided by the network administrator if the network does not use self-signed Root certificates.
 - **Machine:** The machine certificate is an encrypted PFX file that is used by the authentication server to validate the identity of the DM-NAX-2XLRI-1G. The machine certificate will be provided by the network administrator, along with the certificate password. For 802.1x, only one machine certificate can reside on the device.
 - **Web Server:** The Web Server certificate is a digital file that contains information about the identity of the web server.

To Add Certificates

1. Click the corresponding certificate tab.
2. Click the **Add Root Certificate** button.
3. Click the **+ Browse** button.
4. Locate and select the file, and then click the **Open** button.

NOTE: If the certificate is a Machine Certificate, enter the password provided by the network administrator.

5. Click **OK**. This will add the certificate to the list box, displaying the file name and expiration date.
The certificate is now available for selection and can be loaded to the device.


To Delete Certificates

1. Click the corresponding certificate tab.
2. Click the trashcan button (🗑️) in the **Actions** column to delete the certificate.
3. Click **Yes** when prompted to delete the certificate or **No** to cancel the deletion.

Status

The **Status** tab is the first page displayed when opening the interface of the DM-NAX-2XLRI-1G. It displays general information about the DM-NAX-2XLRI-1G (such as Model Name, Firmware Version, and Serial Number), current network settings (such as Host Name and IP Address, etc.), and input and output ports' current status.

The Status tab can be accessed at any time by clicking the **Status** tab of the DM-NAX-2XLRI-1G interface.



Information displayed on the **Status** tab is organized into different sections.

Device

The **Device** section displays the **Model**, **Firmware Version**, and **Serial Number** of the DM-NAX-2XLRI-1G.

Device

Model

DM-NAX-BTIO-1G

Firmware Version

1.0.0033.11191

Serial Number

2346CRX00386

+ More Details

Click **+ More Details** to review additional information about the DM-NAX-2XLRI-1G.

More Details

DM-NAX-BTIO-1G

1.0.0033.11191

Build

Feb 13 2024 (531246)

Updater

1.0.0033.11191

Bootloader

1.00.00

CCUI Version

1.1327.1

XIOSDK

3.8.2

IoTSDK

1.11.0

Build time

11:19:07

Product ID

0x7A09

Revision ID

0x0200

HDCP2X-SKE

HDCP2X-SKE [v9.0000.00000,#FFFFFFFFF]

PRE-BOOT

[v9.0000.00000]

BOOTLOADER

[v9.0000.00000]

ctrl-extclkin-pps

Driver v1.1

ctrl-prod-info

Driver v3.0

ctrl-io-bt

FW v2.0.98

PUF

1.0.0033.11191

Forced Auth Mode

True

Network


The **Network** section displays network-related information about the DM-NAX-2XLRI-1G, including the Hostname, Domain Name, and DNS Servers.

- [Commercial Mode on page 146](#)
- [Residential Mode on page 163](#)

Commercial Mode

This section provides the following information:

- [System Setup on page 146](#)
- [Commissioning on page 151](#)
- [Output Channels on page 152](#)
- [Input Channels on page 156](#)
- [DM NAX Streams on page 158](#)
- [Mixing on page 162](#)



System Setup

The **System Setup** section contains settings for **Date/Time**, **Auto Update**, **Network**, and **Control System**.

System Setup

Date/Time Auto Update Network Control System Cloud Settings Device Modes

— Date/Time

Synchronization

Time Synchronization ☒

[Synchronize Now](#)

NTP Time Servers

<input type="checkbox"/>	Address	Port	Authentication Method	Authentication Key	Key ID
<input type="checkbox"/>	pool.ntp.org	123	None	*****	0

[+ Add](#) [- Remove](#)

Configuration

Time Zone (UTC-05:00) Eastern Time (US & Can)

Date 02/27/2024

Time 17:14

Date/Time

Use the **Date/Time** tab to configure the date and time settings of the DM-NAX-2XLRI-1G.

— Date/Time

Synchronization

Time Synchronization ☒

[Synchronize Now](#)

NTP Time Servers

<input type="checkbox"/>	Address	Port	Authentication Method	Authentication Key	Key ID
<input type="checkbox"/>	pool.ntp.org	123	None	*****	0

[+ Add](#) [- Remove](#)

Configuration

Time Zone (UTC-05:00) Eastern Time (US & Can)

Date 02/21/2024

Time 12:40

Time Synchronization

1. Set the **Time Synchronization** toggle to the right position to enable or left position to disable time synchronization. By default, time synchronization is enabled.
2. In the **NTP Time Servers** table, enter the URL of a NTP (Network Time Protocol) or SNTP (Simple Network Time Protocol) server. Up to three time servers can be added on a device.
3. Click **Synchronize Now** to perform time synchronization between the device's internal clock and the time server.

Time Configuration

1. Click on the **Time Zone** drop-down menu to select the applicable time zone.
2. In the **Date** field, enter the current date.
3. In the **Time (24hr Format)** field, enter the current time in 24-hour format.

Click the **Save Changes** button to save the settings.

Click **Revert** from the **Actions** drop-down menu to revert to the previous settings without saving.

Auto Update

The DM-NAX-2XLRI-1G can automatically check for and install firmware updates at scheduled intervals via the Auto Update feature.

Auto Update

Auto Update ☐

Custom URL ☐

Custom URL Path

Schedule

Day of Week

Time of Day

Poll Interval Minutes

Update Now

1. Set the **Auto Update** toggle to the right position to enable Auto Update.
2. Define the URL to download the updates by doing either of the following:
 - a. Use the default URL to download the updates from the Crestron server.
 - b. Use a custom URL. Set the **Custom URL** toggle to the right position to enable a custom URL. In the **Custom URL Path** text box, enter the path to a custom manifest file in the FTP or SFTP URL format. Use the Crestron Auto Update Tool to generate a custom manifest file, then store the file on an FTP (File Transfer Protocol) or SFTP (Secure File Transfer Protocol) server.
3. Set a schedule for the automatic firmware update by doing either of the following:
 - a. Select the desired **Day of Week** and **Time of Day** (24-hour format) values.
 - b. Set the **Poll Interval** by entering a value from **60** to **65535** minutes. A value of **0** disables the Poll Interval.
4. Click **Save Changes**.

Clicking **Update Now** causes the device to check for a firmware update immediately. If a schedule was set in step 4 above, that schedule still remains in effect.

Network

The **Network** tab contains network-related settings for the DM-NAX-2XLRI-1G, including the Hostname, Domain, Primary Static DNS, and Secondary Static DNS.

Network

Adapter 1

Hostname *

DM-NAX-2XLRI-1G-C442683FB8AC

Domain

lan

Primary Static DNS

192.168.1.1(DHCP)

Secondary Static DNS

DHCP Enabled

☒

IP Address

192.168.1.231

Subnet Mask

255.255.255.0

Default Gateway

192.168.1.1

NOTE: By default, the hostname of the DM-NAX-2XLRI-1G consists of the model name followed by the MAC address of the device. For example, DM-NAX-2XLRI-1G-00107FB58088.

Adapter 1

The Adapter 1 subheading contains settings for DHCP, IP Address, Subnet Mask, and Default Gateway of Ethernet adapter 1 on the rear panel of the device.

NOTE: DM NAX devices' internal processes use IP addresses in the 10.10.10.xxx range. This IP range should be avoided when addressing DM NAX devices to prevent conflicts.

Set the **DHCP** toggle to enabled (right) or disabled (left) to specify whether the IP address of the DM-NAX-2XLRI-1G is to be assigned by a DHCP (Dynamic Host Configuration Protocol) server.

- **Enabled:** When DHCP is enabled (default setting), the IP address of the DM-NAX-2XLRI-1G is automatically assigned by a DHCP server on the local area network (LAN).
- **Disabled:** When DHCP is disabled, manually enter information in the following fields:
 - **Primary Static DNS:** Enter a primary DNS IP address.
 - **Secondary Static DNS:** Enter a secondary DNS IP address.
 - **IP Address:** Enter a unique IP address for the DM-NAX-2XLRI-1G.
 - **Subnet Mask:** Enter the subnet mask that is set on the network.
 - **Default Gateway:** Enter the IP address that is to be used as the network's gateway.

To save any new network entries, click **Save Changes**.

Control System

Control System

Control System Username

chdevice

Control System Password

Encrypt Connection

IP Table

<input type="checkbox"/>	IP ID	IP Address/Hostname	Room Id
<input type="checkbox"/>	C	DIN-AP4-R-C442681A3F36	Room Id

+ Add

× Remove

1. Click the **Encrypt Connection** button to navigate to the **Security** tab to configure encryption settings.
2. Enter the username in the **Control System Username** field.
3. Enter the password in the **Control System Password** field.
4. Enter the Room ID in the **Room ID** field.
5. Enter the IP ID of the DM-NAX-2XLRI-1G in the **IP ID** field.
6. Enter the IP address or hostname of the control system in the **IP Address/Hostname** field.
7. Click the **Save Changes** button to save the new entries. The Control System Save message box appears, indicating that the control system settings were saved successfully. Click the **Revert** button to revert to the previous settings without saving.

Cloud Settings

Date/Time

Auto Update

Network

Control System

Cloud Settings

Device Modes

Cloud Settings

Cloud Configuration Service Connection

Set the **Cloud Settings** toggle to enabled (right) or disabled (left) to specify whether the DM-NAX-2XLRI-1G can communicate with the XiO Cloud® platform.

Device Modes

Use the **Device Modes** tab to configure the **Application Mode** of the DM-NAX-2XLRI-1G.

Date/Time

Auto Update

Network

Control System

Cloud Settings

Device Modes


Device Modes (Autosaved)

Application Mode

Commercial (Advanced)

The Application Mode determines which options and controls are available.

- Select **Residential (Standard)** or **Commercial (Advanced)**. A **Reboot** confirmation message box appears.




- Click **Yes, Reboot Now** to reboot the device into the selected mode. The **Reboot** message box appears.
- Wait for the device reboot to complete before attempting to reconnect to the device.

By default, the DM-NAX-2XLRI-1G is set to **Commercial (Advanced)** mode.

Commissioning

The **Commissioning** section provides a quick way to automatically assign multicast addresses to the device's internal audio-over-IP stream transmitters.

A screenshot of the 'Commissioning' section in a web interface. It has a light blue header with a dropdown arrow and the text 'Commissioning'. Below the header, there are two labels: 'Starting Multicast Address' and 'Last Used Multicast Address'. The 'Starting Multicast Address' is followed by a text input field containing '239.8.0.0'. The 'Last Used Multicast Address' is followed by the text '239.8.0.8'. At the bottom right, there is a blue button labeled 'Assign Addresses'.

Click **Assign Addresses** to give each DM NAX transmitter in the DM-NAX-2XLRI-1G a unique multicast address beginning with the specified **Starting Multicast Address**. The valid range for **Starting Multicast Address** is 239.8.0.0 to 239.255.255.254.

NOTE: This will begin transmitting multicast traffic on your network, refer to the [DM NAX Audio-over-IP System Design Guide](#) document for details.

The **Zones** section contains the **Volume** and **Mute** settings for all zone outputs of the device, as well as an **Edit** option for more advanced settings within each zone.

Signal Presence indicates whether or not an audio signal is detected in that zone.

- **Nominal:** The signal level is within normal operating bounds and below the clipping threshold.
- **Clipping:** The signal level is clipping or above the -3 dB warning threshold and in danger of clipping.

To configure the zone volume, do one of the following:


- Move the **Volume** slider up to increase or down to decrease the zone volume.
- Click the % arrows to increase or decrease the zone volume. Values range from 0 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Volume** field.

To mute all audio output from a zone, click its respective **Mute** button. To unmute the zone, click the **Muted** button.

Click **Edit** to view additional **Zone** and **Output** options.


Zone Settings

To configure the settings for an output channel, click the **Edit** button. The **Edit Zone** window appears.



Zone

Click **Zone** to access the settings for **Delay**.



Delay

To set the delay, do one of the following:

- Move the **Delay Time(ms)** slider to the right to increase or to the left to decrease the delay time.
- Click the **ms** arrows to increase or decrease the delay. Values range from 0 ms to 85 ms, adjustable in increments of 1 ms.
- Manually enter a value in the **Delay Time(ms)** field.

NOTE: The Delay feature is only available on the line level output channels.

Output

Click **Output** to access the settings for **Minimum/Maximum Volume** and **Signal**.

The screenshot shows the 'Output' settings panel. It has a light blue header with a dropdown arrow and the text 'Output'. Below the header, there are two sections separated by green lines. The first section is titled 'Minimum / Maximum (Autosaved)' and contains three sliders: 'Minimum' (set to 0%), 'Maximum' (set to 100%), and 'Default' (set to 30%). Each slider has a blue knob and a corresponding numerical value in a box with up/down arrows. The second section is titled 'Signal (Autosaved)' and contains two labels: 'Signal' with the value 'Not Present' in red, and 'Clipping' with the value 'None' in green.

Minimum/Maximum Volume

This screenshot shows the 'Minimum / Maximum (Autosaved)' section of the settings panel. It contains three sliders: 'Minimum' (set to 0%), 'Maximum' (set to 100%), and 'Default' (set to 30%). Each slider has a blue knob and a corresponding numerical value in a box with up/down arrows.

1. To set the minimum volume of the zone, do one of the following:
 - Move the **Minimum** slider to the right to increase or to the left to decrease the minimum volume.
 - Click the **%** arrows to increase or decrease the minimum volume. Values range from 0 to 50%, adjustable in increments of 1%.
 - Manually enter a value in the **Minimum** field.

2. To set the maximum volume of the zone, do one of the following:

- Move the **Maximum** slider to the right to increase or to the left to decrease the maximum volume.
- Click the **%** arrows to increase or decrease the maximum volume. Values range from 70 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Maximum** field.

NOTE: When a **Minimum** and **Maximum** volume are set, the 1-100% range represented by the **Zone** and **Default** volume controls are scaled to the range set. For example, if a **Minimum** of 10% and a **Maximum** of 80% are set for a zone, the 1-100% range of the **Zone** volume control is scaled to the 10%-80% range set as the **Minimum** and **Maximum**.

3. To set the default volume of the zone, do one of the following:

- Move the **Default** slider to the right to increase or to the left to decrease the default volume.
- Click the **%** arrows to increase or decrease the default volume. Values range from 0 to 50%, adjustable in increments of 1%.
- Manually enter a value in the **Default** field.

NOTE: The **Default** volume is applied as the **Zone** volume any time the zone receives a source route and no source was previously routed to that zone.

Signal

— Signal (Autosaved)	
Signal	Not Present
Clipping	None

The **Signal** section is a read-only field that displays the **Signal** and **Clipping** status of the zone output.

- If an output signal is present but not clipping, **Signal** will display **Present** in green and **Clipping** will display **None** in green.
- If an output signal is present and clipping, **Signal** will display **Present** in green and **Clipping** will display **Present** in red.
- If no output signal is detected, **Signal** will display **Not Present** in red and **Clipping** will display **None** in green.

Input Channels

The **Input Channels** section is used to configure the **Name**, **Compensation**, and **Mute** attributes of the front panel XLR inputs on the DM-NAX-2XLRI-1G.

Input Channels

— Analog Inputs (Autosaved)

Name	XLR1	XLR2	StreamIn1Ch1	StreamIn1Ch2
Analog Gain (db)	17	17		
Compensation (db)				
Signal Present				
Signal Level				
Mode	Line	Line		
Phantom Power	<input type="checkbox"/>	<input type="checkbox"/>		
Mute	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Action	Edit	Edit	Edit	Edit

Configure Inputs

1. If needed, enter a friendly name for each input in its **Name** field.
2. To set an analog gain value for a given input, click the **db** arrows to increase or decrease the compensation. Values range from 0 dB to 60 dB, adjustable in increments of 1 dB.
3. To set a level compensation adjustment for a given input, do one of the following:
 - Move the **Compensation** slider up to increase or down to decrease the level compensation. Compensation increases or decreases the level of the incoming audio signal on any of the physical inputs on the device's rear panel.
 - Click the **db** arrows to increase or decrease the compensation. Values range from -10 dB to 10 dB, adjustable in increments of 1 dB.
 - Manually enter a value in the **Compensation** field.

4. To switch between microphone level and line level input signals, expand the **Mode** drop-down and select the desired input signal level. By default, the XLR inputs are both set to **Line** level.
5. Set a channel's **Phantom Power** toggle to the right to enable +48V phantom power. Set the channel's **Phantom Power** toggle to the left to disable phantom power. By default, **Phantom Power** is disabled, and can only be enabled while the **Mode** of the channel is set to **Mic**.
6. To mute the signal from the corresponding input, set the **Mute** toggle to the right. To disable the mute, set the **Mute** toggle to the left. By default, **Mute** is disabled.

Monitor the device's input signals using the text indicators in the **Signal Present** and **Clipping Detected** columns:

- **Signal Presence** indicates whether or not a signal is detected in that zone.
- **Clipping Detected** indicates if the signal is **Clipping** or **Nominal** (non-clipping).

Click **Edit** to open the equalizer for a given input channel.

Equalizer Settings

DM-NAX-2XLRI-1G-C442683FB8AC > Analog Inputs
XLR1

Input

Equalizer Settings (Autosaved)

Band	Band01	Band02	Band03	Band04	Band05
Gain	<div><div></div></div> <div>0</div>	<div><div></div></div> <div>0</div>	<div><div></div></div> <div>0</div>	<div><div></div></div> <div>0</div>	<div><div></div></div> <div>0</div>
Type	EQ	EQ	EQ	EQ	EQ
Frequency	32	64	125	250	500
Bandwidth	0.33	0.33	0.33	0.33	0.33
Bypass	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Actions	Reset	Reset	Reset	Reset	Reset

Each XLR input channel of the DM-NAX-2XLRI-1G has a dedicated five-band equalizer that can be fully customized to tune the input signal to the needs of an install. Each band can have a discrete gain, filter type, center frequency, and bandwidth set, and can also be bypassed.

Do the following to configure a given equalizer band:

1. To set a band's gain, do one of the following:
 - Move the **Gain** slider up to increase or down to decrease the gain.
 - Click the arrows to increase or decrease the gain. Values range from -40 dB to 20 dB, adjustable in increments of 0.1 dB.
 - Manually enter a value in the **Gain** field.
2. Select a filter type from the **Type** drop-down menu. By default, all bands are set to the **EQ** filter type. Some filter types will disable other settings in their respective band while enabled. For example, selecting the **LowPass** filter type for a band will disable that band's **Gain** and **Bandwidth** settings, since the **LowPass** filter applies a fixed roll-off slope at a set frequency. The available filter types are:
 - **EQ**: a fully parametric filter that can boost or cut a range of frequencies.
 - **Notch**: a parametric filter designed to more precisely cut a frequency or range of frequencies. A notch filter can achieve a narrower bandwidth than the standard **EQ** parametric filter type.
 - **TrebleShelf**: a filter that boosts or cuts all frequencies above a set frequency by a set gain.
 - **BassShelf**: a filter that boosts or cuts all frequencies below a set frequency by a set gain.
 - **LowPass**: a filter that fully cuts all frequencies above a set frequency using a fixed roll-off slope of -12 dB per octave.
 - **HighPass**: a filter that fully cuts all frequencies below a set frequency using a fixed roll-off slope of -12 dB per octave.
3. Set a center frequency for the equalizer band to tune a specific portion of the audible frequency spectrum. To set the center frequency, do one of the following:
 - Click the arrows to increase or decrease the frequency. Values range from 20 Hz to 20 kHz, adjustable in increments of 1 Hz. Each band has a default center frequency that will be applied if the **Reset** button at the bottom of the band is clicked.
 - Manually enter a value in the **Frequency** field.
4. Set a bandwidth to determine how wide of a frequency range is effected by the equalizer band. To set the bandwidth, do one of the following:
 - Click the arrows to increase or decrease the bandwidth. Values range from 0.1 octaves to 4.0 octaves, adjustable in increments of 0.1 octave.
 - Manually enter a value in the **Bandwidth** field.
5. The individual Bypass controls allow you to bypass a single band of equalization at a time for more granular A/B testing of a single filter. Set a band's **Bypass** toggle to the right position to bypass that band. Set the toggle to the left position to disable the bypass. By default, **Bypass** is disabled.
6. Each equalizer band has a **Reset** button that will reapply the default settings for that band.

Click **Done** to return to the **Settings** tab of the web user interface.

DM NAX Streams


The local inputs of the DM-NAX-2XLRI-1G can be made available as a DM NAX audio-over-IP stream. This single two channel stream will encode XLR input 1 as the left channel, and XLR input 2 as the right channel.

Click **NAX Streams** to expand the tab and display the following information.

Configure Transmitters

To configure the DM NAX transmit stream, do the following.

1. Enter a valid multicast address in the **NAX Stream Address** field.
2. Enter a name in the **NAX Stream Name** field by which the stream can be identified. This stream name is associated with the DM NAX stream's multicast address by other DM NAX or AES67 devices, like a device hostname that resolves to a given IP address.
3. **Status** indicates whether a stream is transmitting or not. When the stream has started or stopped, the **Status** column will update accordingly.
4. Click the configure button (⚙️) in the **Actions** column. The **Configure** dialog appears:




5. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled for a given stream, the stream will begin transmitting automatically and will be available as a multicast stream on your network at the specified multicast address.
 - If **Auto Initiation** is disabled for the input, the stream will not begin transmitting until it is manually initiated.
6. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number for DM NAX streams is 5004.
7. Click **OK** to save or click **Cancel** to cancel the changes.

Configure Receivers

1. Enter the multicast address of a transmitting stream in the **Requested Stream Address** field to subscribe the receiver to the stream.

2. Click the configure button (⚙️) in the **Actions** column. The **Configure** dialog appears:




3. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled, the stream will begin automatically when the receiver subscribes to the transmitter.
 - If **Auto Initiation** is disabled, the stream will not begin until it is manually initiated.
4. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number is 5004.
5. Click **OK** to save or click **Cancel** to cancel the changes.

Mixing

The **Mixing** matrix is used to route a local input or AES67 stream to an output on the DM-NAX-2XLRI-1G.

NOTE: To receive an AES67 stream from Dante devices, see [OLH 1001151](#).




To route inputs to outputs on the device:

- Click the cells corresponding to the desired output that are to be paired for routing. Once a route is made, appears. The input that you have selected for a given row will route to the output corresponding to that row in the matrix.
- To break a given route click or .

Each output can have any number of inputs routed to it. To adjust the mix setting for a route, click the **dB** value of the cell, then do one of the following:


- Move the slider up to increase or down to decrease the mix level.
- Click the arrows to increase or decrease the mix level.
- Manually enter a value in the field.



Residential Mode

This section provides the following information:

- [System Setup on page 164](#)
- [Commissioning on page 168](#)
- [Output Channels on page 169](#)
- [Inputs on page 174](#)
- [NAX Streams on page 175](#)
- [Routing on page 177](#)




System Setup

The **System Setup** section displays information about the Date/Time, Auto Update, Network, Control System, Cloud Settings, and Device Modes.

Date/Time

Use the **Date/Time** section to configure the date and time settings of the DM-NAX-2XLRI-1G.



Time Synchronization

1. Set the **Time Synchronization** toggle to the right position to enable or left position to disable time synchronization. By default, time synchronization is enabled.

2. In the **NTP Time Servers** table, enter the URL of a NTP (Network Time Protocol) or SNTP (Simple Network Time Protocol) server. Up to three time servers can be added on a device.
3. Click **Synchronize Now** to perform time synchronization between the device's internal clock and the time server.

Time Configuration

1. Click on the **Time Zone** drop-down menu to select the applicable time zone.
2. In the **Date** field, enter the current date.
3. In the **Time (24hr Format)** field, enter the current time in 24-hour format.

Click the **Save Changes** button to save the settings.

Click **Revert** from the **Actions** drop-down menu to revert to the previous settings without saving.

Auto Update

The DM-NAX-2XLRI-1G can automatically check for and install firmware updates at scheduled intervals via the Auto Update feature.

The screenshot shows the 'System Setup' menu with 'Auto Update' selected. The 'Auto Update' toggle is turned on. The 'Custom URL' toggle is turned off. The 'Custom URL Path' text box contains the URL 'https://crestrondevicefiles.blob.core.win'. The 'Schedule' section is visible on the left. The 'Day of Week' dropdown is set to 'Daily'. The 'Time of Day' text box contains '02:25'. The 'Poll Interval' text box contains '0' with a 'Minutes' label. An 'Update Now' button is at the bottom right.

1. Set the **Auto Update** toggle to the right position to enable Auto Update.
2. Define the URL to download the updates by doing either of the following:
 - a. Use the default URL to download the updates from the Crestron server.
 - b. Use a custom URL. Set the **Custom URL** toggle to the right position to enable a custom URL. In the **Custom URL Path** text box, enter the path to a custom manifest file in the FTP or SFTP URL format. Use the Crestron Auto Update Tool to generate a custom manifest file, then store the file on an FTP (File Transfer Protocol) or SFTP (Secure File Transfer Protocol) server.
3. Set a schedule for the automatic firmware update by doing either of the following:

- a. Select the desired **Day of Week** and **Time of Day** (24-hour format) values.
 - b. Set the **Poll Interval** by entering a value from **60** to **65535** minutes. A value of **0** disables the Poll Interval.
4. Click **Save Changes**.

Clicking **Update Now** causes the device to check for a firmware update immediately. If a schedule was set in step 4 above, that schedule still remains in effect.

Network

The **Network** section contains network-related settings for the DM-NAX-2XLRI-1G, including the Hostname, Domain, Primary Static DNS, and Secondary Static DNS.

The screenshot shows the 'Network' configuration page. On the left, there is a subheading 'Adapter 1'. To the right, there are several configuration fields:

- Hostname ***: DM-NAX-2XLRI-1G-C442683FB8AC
- Domain**: lan
- Primary Static DNS**: 192.168.1.1(DHCP)
- Secondary Static DNS**: (empty field)
- DHCP Enabled**: A toggle switch is turned on (blue).
- IP Address**: 192.168.1.231
- Subnet Mask**: 255.255.255.0
- Default Gateway**: 192.168.1.1

NOTE: By default, the host name of the DM-NAX-2XLRI-1G consists of the model name followed by the MAC address of the device. For example, DM-NAX-2XLRI-1G-00107FB58088.

Adapter 1

The Adapter 1 subheading contains settings for DHCP, IP Address, Subnet Mask, and Default Gateway of Ethernet adapter 1 on the rear panel of the device.

NOTE: DM NAX devices' internal processes use IP addresses in the 10.10.10.xxx range. This IP range should be avoided when addressing DM NAX devices to prevent conflicts.

Set the **DHCP** toggle to enabled (right) or disabled (left) to specify whether the IP address of the DM-NAX-2XLRI-1G is to be assigned by a DHCP (Dynamic Host Configuration Protocol) server.

- **Enabled:** When DHCP is enabled (default setting), the IP address of the DM-NAX-2XLRI-1G is automatically assigned by a DHCP server on the local area network (LAN).
- **Disabled:** When DHCP is disabled, manually enter information in the following fields:

- **Primary Static DNS:** Enter a primary DNS IP address.
- **Secondary Static DNS:** Enter a secondary DNS IP address.
- **IP Address:** Enter a unique IP address for the DM-NAX-2XLRI-1G.
- **Subnet Mask:** Enter the subnet mask that is set on the network.
- **Default Gateway:** Enter the IP address that is to be used as the network's gateway.

To save any new network entries, click **Save Changes**.

Control System

1. Click the **Encrypt Connection** button to navigate to the **Security** tab to configure encryption settings.
2. Enter the username in the **Control System Username** field.
3. Enter the password in the **Control System Password** field.
4. Enter the Room ID in the **Room ID** field.
5. Enter the IP ID of the DM-NAX-2XLRI-1G in the **IP ID** field.
6. Enter the IP address or hostname of the control system in the **IP Address/Hostname** field.
7. Click the **Save Changes** button to save the new entries. The Control System Save message box appears, indicating that the control system settings were saved successfully. Click the **Revert** button to revert to the previous settings without saving.

Cloud Settings

Set the **Cloud Settings** toggle to enabled (right) or disabled (left) to specify whether the DM-NAX-2XLRI-1G can communicate with the XiO Cloud® platform.

Device Modes

Use the **Device Modes** section to configure the **Application Mode**.

- **Application Mode:** The Application Mode determines which options and controls are available.
 - Select **Residential (Standard)** or **Commercial (Advanced)**. A **Reboot** confirmation message box appears.

- Click **Yes, Reboot Now** to reboot the device into the selected mode. The **Reboot** message box appears.
- Wait for the device reboot to complete before attempting to reconnect to the device.

Commissioning


The **Commissioning** section provides a quick way to automatically assign multicast addresses to the device's internal audio-over-IP stream transmitters.

Click **Assign Addresses** to give each DM NAX transmitter in the DM-NAX-2XLRI-1G a unique multicast address beginning with the specified **Starting Multicast Address**. The valid range for **Starting Multicast Address** is 239.8.0.0 to 239.127.255.254.

NOTE: This will begin transmitting multicast traffic on your network, refer to the [General Network Requirements](#) document for details.

Output Channels

The **Output Channels** section contains the **Volume** and **Mute** settings for all zone outputs of the device, as well as a Configure option for more advanced settings within each zone.




Give each zone a friendly name using the **Name** column of the **Zones** table. If the device is paired with a control system, these names may be overwritten by the control system's program.

To configure the zone volume, do one of the following:

- Move the **Volume** slider to the right to increase or to the left to decrease the zone volume.
- Click the % arrows to increase or decrease the zone volume. Values range from 0 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Volume** field.


To mute all audio output from a zone, click its respective **Mute** button. To unmute the zone, click the **Muted** button.

Zone Settings

To configure zone settings, click the **Configure** button (). The **Edit Zone** window appears.

Zone

Click **Zone** to access the settings for **Balance**, and **Delay**.



Balance

To adjust the left/right balance of the stereo output signal, do one of the following:

- Move the **Balance** slider to the right to shift the stereo balance to the right channel or to the left to shift the balance to the left.
- Click the arrows to adjust the balance left or right. The up arrow shifts the balance to the right while the down arrow shifts the balance to the left.

- Manually enter a value in the **Balance** field. Values range from -50 to 50, adjustable in increments of 1. Positive values shift the balance to the right while negative values shift the balance to the left.

Delay

To set the delay, do one of the following:

- Move the **Delay Time(ms)** slider to the right to increase or to the left to decrease the delay time.
- Click the **ms** arrows to increase or decrease the delay. Values range from 0 ms to 85 ms, adjustable in increments of 1 ms.
- Manually enter a value in the **Delay Time(ms)** field.

Output

Click **Output** to access the settings for **Minimum/Maximum Volume**, **Stereo/Mono**, **Signal**, **Bussing Volume Offset**, and **Signal Generator**.

Output

Minimum / Maximum (Autosaved)

Minimum

0 %

Maximum

100 %

Default

30 %

Stereo / Mono (Autosaved)

Stereo / Mono

Stereo

Mono

Zone Configuration

Standard

Signal (Autosaved)

Signal

Not Present

Clipping

None

Minimum/Maximum Volume

Minimum / Maximum (Autosaved)

Minimum

0 %

Maximum

100 %

Default

30 %


1. To set the minimum volume of the zone, do one of the following:
 - Move the **Minimum** slider to the right to increase or to the left to decrease the minimum volume.
 - Click the **%** arrows to increase or decrease the minimum volume. Values range from 0 to 50%, adjustable in increments of 1%.
 - Manually enter a value in the **Minimum** field.
2. To set the maximum volume of the zone, do one of the following:
 - Move the **Maximum** slider to the right to increase or to the left to decrease the maximum volume.
 - Click the **%** arrows to increase or decrease the maximum volume. Values range from 70 to 100%, adjustable in increments of 1%.
 - Manually enter a value in the **Maximum** field.

NOTE: When a **Minimum** and **Maximum** volume are set, the 1-100% range represented by the **Zone** and **Default** volume controls are scaled to the range set. For example, if a **Minimum** of 10% and a **Maximum** of 80% are set for a zone, the 1-100% range of the **Zone** volume control is scaled to the 10%-80% range set as the **Minimum** and **Maximum**.

3. To set the default volume of the zone, do one of the following:
 - Move the **Default** slider to the right to increase or to the left to decrease the default volume.
 - Click the **%** arrows to increase or decrease the default volume. Values range from 0 to 50%, adjustable in increments of 1%.
 - Manually enter a value in the **Default** field.


NOTE: The **Default** volume is applied as the **Zone** volume any time the zone receives a source route and no source was previously routed to that zone.

Stereo/Mono



Select either **Stereo** or **Mono** from the **Stereo/Mono** radio buttons. If **Stereo** is selected, both output channels can have independent audio content. If **Mono** is selected, both output channels receive the same audio content.

Signal



— Signal (Autosaved)


Signal	Not Present
Clipping	None

The interface shows a title bar 'Signal (Autosaved)' and a table with two rows. The first row has 'Signal' and 'Not Present'. The second row has 'Clipping' and 'None'.

The **Signal** section is a read-only field that displays the **Signal** and **Clipping** status of the zone output.

- If an output signal is present but not clipping, **Signal** will display **Present** in green and **Clipping** will display **None** in green.
- If an output signal is present and clipping, **Signal** will display **Present** in green and **Clipping** will display **Present** in red.
- If no output signal is detected, **Signal** will display **Not Present** in red and **Clipping** will display **None** in green.

Bussing Volume Offset



— Bussing Volume Offset (Autosaved)

Bussing Volume Offset

0 db

The interface shows a title bar 'Bussing Volume Offset (Autosaved)'. Below the title bar is a slider control labeled 'Bussing Volume Offset'. The slider has a blue handle and a range from -12 to 12. To the right of the slider is a numeric input field showing '0' and a 'db' unit label.

Bussing Volume Offset is an additional level compensation applied to the zone relative to any other zones it is grouped with via the **Bussing** feature.

To set the bussing volume offset, do one of the following:

- Move the **Bussing Volume Offset** slider to the right to increase or to the left to decrease the offset.
- Click the **db** arrows to increase or decrease the offset. Values range from -12 dB to 12 dB, adjustable in increments of 1 dB.
- Manually enter a value in the **Bussing Volume Offset** field.

Signal Generator

The screenshot shows two sections of a web interface. The top section, titled "Signal Generator (Autosaved)", contains a button labeled "Signal Generator" with a speaker icon and the word "Inactive" next to it. Below this is a "Signal Generator Volume" control consisting of a horizontal slider with a blue knob, and a numeric input field showing "30" with up and down arrows and a percent sign. The bottom section, titled "Advanced Signal Generator (Autosaved)", contains three controls: "Left Channel" and "Right Channel" each with a blue toggle switch in the "on" position, and a "Signal Type" dropdown menu currently set to "Tone".

The DM-NAX-2XLRI-1G has a built-in signal generator that allows an integrator to send an audio signal to the output for testing purposes.

1. To route the signal generator to the zone output, click the **Signal Generator** button so that it displays **Active** and is highlighted in blue. To unroute the signal generator on the zone output, click the **Signal Generator** button so that it displays **Inactive** and is highlighted in grey. By default, the signal generator is not routed to the zone output.
2. To adjust the signal generator's volume, do one of the following:
 - Move the **Signal Generator Volume** slider right to increase or left to decrease the volume.
 - Click the arrows to increase or decrease the signal generator volume. Values range from 0 to 100, adjustable in increments of 1.
 - Manually enter a value in the **Signal Generator Volume** field.

Advanced Signal Generator

The advanced signal generator settings control the signal type of the signal generator, and allow the left and right channel to be enabled or disabled independently of one another.

1. Set the **Left Channel** toggle to the right position to enable the left channel of the signal. Set the toggle to the left position to disable the left channel. By default, **Left Channel** is enabled.
2. Set the **Right Channel** toggle to the right position to enable the right channel of the signal. Set the toggle to the left position to disable the right channel. By default, **Right Channel** is enabled.
3. Select an audio test signal type from the **Signal Type** drop-down menu. The available signal types are:
 - **Tone:** Generates a 1 kHz sine wave tone.
 - **Pink Noise:** Generates pink noise.
 - **White Noise:** Generates white noise.

Click **Done** to return to the **Settings** tab of the web user interface.

Inputs

The **Inputs** section is used to configure the **Name**, **Compensation**, and **Mute** attributes of the available analog, digital, and media streaming inputs on the DM-NAX-2XLRI-1G.

Name	Gain (db)	Signal Present	Clipping Detected	Mute	Action
XLR1-2	<div><div></div><div>0</div><div>db</div></div>		<div><div></div><div>Nominal</div></div>	<div><div></div></div>	<div><div>Edit</div></div>

Configure Inputs

1. If needed, enter a friendly name for each input in its **Name** field.
2. To set a level compensation adjustment for a given input, do one of the following:
 - Move the **Compensation** slider up to increase or down to decrease the level compensation. Compensation increases or decreases the level of the incoming audio signal on any of the physical inputs on the device's rear panel.
 - Click the **db** arrows to increase or decrease the compensation. Values range from -10 dB to 10 dB, adjustable in increments of 1 dB.
 - Manually enter a value in the **Compensation** field.
3. To mute the signal from the corresponding input, set the **Mute** toggle to the right. To disable the mute, set the **Mute** toggle to the left. By default, **Mute** is disabled.

Monitor the device's input signals using the text indicators in the **Signal Present** and **Clipping Detected** columns:

- **Signal Presence** indicates whether or not a signal is detected in that zone.
- **Clipping Detected** indicates if the signal is **Clipping** or **Nominal** (non-clipping).

NAX Streams

The local inputs of the DM-NAX-2XLRI-1G can be made available as a DM NAX audio-over-IP stream. This single two channel stream will encode XLR input 1 as the left channel, and XLR input 2 as the right channel.

Click **NAX Streams** to expand the tab and display the following information.

NAX Streams

This Device is the Leader PTP Clock SourceNo

PTP Clock Leader MAC Address00:10:7f9c:1fe9

PTP Priority254

Transmitters (Autosaved)

Audio Source	Stream	Nax Stream Address	Nax Stream Name	Status	Actions
StreamOut1Ch1	Stream01	0.0.0.0	Stream01c4.42.68.3fb8.ac	Stream Stopped	

Receivers (Autosaved)

Zone Name	Stream	Current Stream Address	Requested Stream Address	Status	Actions
StreamIn1Ch1	Stream01	0.0.0.0	0.0.0.0	Stream Stopped	

- **Device is Master PTP Clock Source** indicates whether the device is the master for PTP on the network. **Yes** will be displayed in green when the local DM-NAX-2XLRI-1G is the PTP clock master and **No** will be displayed in red when another PTP clock on the network is operating as the master clock.
- **Master Clock Status** displays the Master Clock ID of the device on the network that acts as the Master Clock.
- **PTP Priority**: This sets the priority of the local DM NAX device's PTP clock relative to other clocks on the network. The default setting is 254 (one increment higher than the lowest possible value) so that the DM-NAX-2XLRI-1G will only operate as clock master if no other PTP master is present on the network. Valid values range from 1 to 255.

Configure Transmitters

Transmitters (Autosaved)

Audio Source	Stream	Nax Stream Address	Nax Stream Name	Status	Actions
IN1-IN2	Stream01	239.8.0.2	Stream01c4.42.68.18.54.47	Stream Started	
IN3-IN4	Stream02	239.8.0.3	Stream02c4.42.68.18.54.47	Stream Started	

To configure a DM NAX transmit stream, do the following.

1. Enter a valid multicast address in the **NAX Stream Address** field.
2. Enter a name in the **NAX Stream Name** field by which the stream can be identified. This stream name is associated with the DM NAX stream's multicast address by other DM NAX or AES67 devices, like a device hostname that resolves to a given IP address.
3. **Status** indicates whether a stream is transmitting or not. When the stream has started or stopped, the **Status** column will update accordingly.
4. Click the configure button () in the **Actions** column. The **Configure** dialog appears:

The image shows a 'Configure' dialog box with a blue header and a close button. Inside, there is an 'Auto Initiation' toggle switch currently in the off position. Below it is a 'Port' field with the value '5004' and up/down arrows. At the bottom are 'OK' and 'CANCEL' buttons.

5. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled for a given stream, the stream will begin transmitting automatically and will be available as a multicast stream on your network at the specified multicast address.
 - If **Auto Initiation** is disabled for the input, the stream will not begin transmitting until it is manually initiated.
6. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number for DM NAX streams is 5004.
7. Click **OK** to save or click **Cancel** to cancel the changes.

Configure Receivers

Receivers (Autosaved)					
Zone Name	Stream	Current Stream Address	Requested Stream Address	Status	Actions
Zone_Amp1	Stream01	0.0.0.0	0.0.0.0	Stream Stopped	
Zone_Amp2	Stream02	0.0.0.0	0.0.0.0	Stream Stopped	

1. Enter the multicast address of a transmitting stream in the **Requested Stream Address** field to subscribe the receiver to the stream.
2. Click the configure button () in the **Actions** column. The **Configure** dialog appears:


This is a duplicate of the 'Configure' dialog box shown at the top of the page, featuring the 'Auto Initiation' toggle and the 'Port' field set to 5004.

3. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled, the stream will begin automatically when the receiver subscribes to the transmitter.
 - If **Auto Initiation** is disabled, the stream will not begin until it is manually initiated.
4. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number is 5004.
5. Click **OK** to save or click **Cancel** to cancel the changes.

Routing

The **Routing** section is used to route a local input or AES67 stream to a Zone on the DM-NAX-2XLRI-1G.

NOTE: To receive an AES67 stream from Dante devices, see [OLH 1001151](#).



To route an input to a zone, click the box in the routing matrix where the zone's row overlaps the corresponding input's column. Once a route is made, appears. To break a given route click or . To route a single input to all zones, click on the under the input's name.

Security

Click the **Security** tab to configure security for users and groups and to allow different levels of access to the DM-NAX-2XLRI-1G functions. By default, security is disabled.

✓ Status

⚙ Settings

🔒 Security

⚙ 802.1x Configuration

▼ Security

SSL Mode

Encrypt

▼

SSL Authentication

Username *

chdevice

Password *

Confirm Password *

Current User

Users

Groups

Name

admin

Access Level

Administrator

Active Directory User

No

Groups

Administrators

Change Current User Password

Select **Encrypt and Validate**, **Encrypt**, or **OFF** in the **SSL Mode** drop-down menu, to specify whether to use encryption. By default, SSL Mode is set to **OFF**.

Current User

Click the **Current User** tab to view read-only information or to change the password for the current user.

Current User

Users

Groups

Name

admin

Access Level

Administrator

Active Directory User

No

Groups

Administrators

Change Current User Password

1. Click the **Change Current User Password** button to provide a new password for the current user.
2. In the **Change Password** dialog, enter the current password in the **Current Password** field, the new password in the **Password** field, and then re-enter the same new password in the **Confirm Password** field.

Change Password

Current Password

.....

Password

.....

Confirm Password

.....|


✓ OK

✕ Cancel

3. Click **OK** to save or click **Cancel** to cancel the changes.

Users

Click the **Users** tab to view and edit user settings. The **Users** tab can be used to add or remove local and Active Directory users and preview information about users.



Use the **Search Users** field to enter search term(s) and display users that match the search criteria.

If users listed in the **Users** table span across multiple pages, navigate through the list of users by clicking a page number or by using the left or right arrows at the bottom of the **Users** pane to move forward or backward through the pages.

Each page can be set to display 5, 10, or 20 users by using the drop-down menu to the right of the navigation arrows.

Information about existing users is displayed in table format and the following details are provided for each user.


- **Username:** Displays the name of the user.
- **AD User:** Displays whether the user requires authentication using Active Directory.

Click the corresponding button in the Actions column to view detailed user information or to delete the user.

To create a new user, click the **Create User** button.

Create a New Local User

1. Click the **Create User** button in the User tab.
2. In the **Create User** dialog, enter the following:



The screenshot shows a 'Create User' dialog box. The 'Name' field contains the text 'test'. The 'Active Directory User' toggle switch is turned off. The 'Password' and 'Confirm Password' fields are both filled with dots, indicating they are masked. The 'Groups' dropdown menu is set to 'Administrators'. At the bottom right, there are two buttons: 'OK' and 'Cancel'.

- a. Enter a user name in the **Name** field. A valid user name can consist of alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
- c. Assign the access level by selecting one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is disabled.

3. Click **OK** to save or click **Cancel** to cancel the changes.


Add an Active Directory User

Users cannot be created or removed from the Active Directory server, but access can be granted to an existing user in the Active Directory server.

To grant access to an Active Directory user, you can either add the user to a local group on the DM-NAX-2XLRI-1G, or add the Active Directory group(s) that they are a member of to the DM-NAX-2XLRI-1G.

To add an Active Directory user.

1. Click the **Create User** button.
2. In the **Create User** dialog, enter the following.




The screenshot shows a 'Create User' dialog box with a blue header. It contains three main fields: 'Name' with the text 'Connects\test', 'Active Directory User' with a blue toggle switch turned on, and 'Groups' with a dropdown menu showing 'Connects'. At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'x' icon.

- a. Enter a user name in the **Name** field in the format "Domain\UserName", for example "crestronlabs.com\JohnSmith". Valid user names can contain alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Select one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is set to enabled.


3. Click **OK** to save or click **Cancel** to cancel the changes.

Delete User


Click the trashcan button () in the **Actions** column to delete the user. Click **Yes** when prompted to delete the user or **No** to cancel the deletion.

After a user is removed from a group, they lose any access rights associated with that group. Note that the user account is not deleted by the delete user operation.

View User Details

Click the information button () in the **Actions** column to view information for the selected user. The **User Details** dialog displays the following information for the selected user.


- **Name:** Displays the name of the selected user.
- **Active Directory User:** Displays whether the user is an Active Directory user.
- **Group:** Displays group(s) the selected user is part of.




The **User Details** dialog box has a blue title bar with the text "User Details" and a close button (X). The main area is white and contains three rows of information: "Name" with the value "admin1", "Active Directory User" with the value "No", and "Groups" with the value "Administrators". At the bottom right, there is a blue button with a checkmark and the text "OK".

Click **OK** to close the **User Details** dialog and to return to the **Users** tab.

Update User Details



The **Update User** dialog box has a blue title bar with the text "Update User" and a close button (X). The main area is white and contains several fields: "Name" with the value "admin1", "Active Directory User" with a toggle switch that is currently off, "Password" and "Confirm Password" fields with masked text (dots), and a "Groups" drop-down menu with "Administrators" selected. At the bottom right, there are two blue buttons: "OK" with a checkmark and "Cancel" with an X.

1. Click the edit button () in the **Actions** column to update information for the selected user.
2. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
3. Select one or more groups to assign the user to from the **Groups** drop-down list.
4. Click **OK** to save or click **Cancel** to cancel the changes.

The **Update User** dialog also displays the following read-only information for the selected user.

- **Name:** Displays the name of the user.
- **Active Directory User:** Displays whether the user is an Active Directory user.











Groups

Click the **Groups** tab to view and edit group settings. The **Groups** tab can be used to add local and Active Directory groups, remove local and Active Directory groups, and preview information about a group.

Use the **Search Groups** field to enter search term(s) and display groups that match the search criteria.

Current UserUsersGroups

Search...

Group Name	AD Group	Access Level	Actions
Administrators	No	Administrator	 
Connects	No	Connect	 
Operators	No	Operator	 
Programmers	No	Programmer	 
Users	No	User	 

<<<1>>>

10



Create Group

If groups listed in the **Groups** table span across multiple pages, navigate through the groups by clicking a page number or by using the left or right arrows at the bottom of the Groups pane to move forward or backward through the pages.

Additionally, each page can be set to display 5, 10, or 20 groups by using the drop-down menu to the right of the navigation arrows.


Existing groups are displayed in a table and the following information is provided for each group:

- **Group Name:** Displays the name of the group.
- **AD Group:** Displays whether the group requires authentication using Active Directory.
- **Access Level:** Displays the predefined access level assigned to the group (Administrator, Programmer, Operator, User, or Connect).

Click the corresponding button in the **Actions** column to view detailed group information () or to delete () selected group.

Click on the **Create Group** button in the **Groups** tab to create new group.

Create Local Group

The 'Create Group' dialog box has a blue title bar with the text 'Create Group' and a close button. It contains three fields: 'Name' with the value 'test12', 'Access Level' with a dropdown menu showing 'Programmer', and 'Active Directory Group' with a toggle switch that is turned off. At the bottom right are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'x' icon.


1. Click the **Create Group** button.
2. In the **Create Group** dialog, enter the following:
 - a. Enter the group name in the **Name** field.
 - b. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is disabled.

3. Click **OK** to save. Click **Cancel** to cancel the changes.

Add Active Directory Group

A group cannot be created or removed from the Active Directory server, but access can be granted to an existing group in Active Directory.

The 'Create Group' dialog box has a blue title bar with the text 'Create Group' and a close button. It contains three fields: 'Name' with the value 'test', 'Access Level' with a dropdown menu showing 'Administrator', and 'Active Directory Group' with a toggle switch that is turned on. At the bottom right are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'x' icon.

Once the group is added, all members of that group will have access to the DM-NAX-2XLRI-1G.


1. Click the **Create Group** button.
2. In the **Create Group** dialog enter the following:
 - a. Enter the group name in the **Name** field, for example "Engineering Group". Note that group names are case sensitive; a space is a valid character that can be used in group names.

3. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is enabled.


4. Click **OK** to save. Click **Cancel** to cancel the changes.


Delete a Group

Click the trashcan button () in the **Actions** column to delete a group. Click **Yes** when prompted to delete the group or **No** to cancel the deletion.

When a group is deleted, users in the group are not removed from the device or Active Directory server. However, because a user's access level is inherited from a group(s), users within the deleted group will lose access rights associated with the group.

View Group Details

Click the information button () in the **Actions** column to view information for the selected group. The **Group Details** dialog lists the following information for the selected group.



The Group Details dialog box displays the following information:

Name	Administrators
Access Level	Administrator
Active Directory Group	No

At the bottom right, there is a blue button with a checkmark and the text **OK**.

- **Name:** Displays the name of the group.
- **Access Level:** Displays the access level of the group and its users.
- **Active Directory Group:** Displays whether the group is an Active Directory group.

Click **OK** to close the **Group Details** dialog and to return to the Groups tab.

802.1x Configuration

The DM-NAX-2XLRI-1G has built-in support for the 802.1X standard (an IEEE network standard designed to enhance the security of wireless and Ethernet LANs. The standard relies on the exchange of messages between the device and the network's host, or authentication server), allowing communication with the authentication server and access to protected corporate networks.

StatusSettingsSecurity802.1x Configuration

802.1x Configuration

IEEE 802.1x Authentication

Authentication Method

EAP MSCHAP V2- password

Domain

secure12

Username

admin

Password

Enable Authentication Server Validation

Select Trusted Certificate Authorities

Q

☒ AAA Certificate Services

☐ AC RAIZ FNMT-RCM

☐ ACCVRAIZ1

☐ Actalis Authentication Root CA

☒ AffirmTrust Commercial

☐ AffirmTrust Networking

☐ AffirmTrust Premium ECC

☒ AffirmTrust Premium

☐ Amazon Root CA 1

☐ Amazon Root CA 2

☒ Amazon Root CA 3

☐ Amazon Root CA 4

☐ Atos TrustedRoot 2011

☐ Autoridad de Certificacion Firmaprofesional CIF A62634068

☐ Baltimore CyberTrust Root

To Configure DM-NAX-2XLRI-1G for 802.1X Authentication

1. Set the **IEEE 802.1X Authentication** toggle to enabled. This will enable all options on the 802.1X dialog.
2. Select the **Authentication method: EAP-TLS Certificate** or **EAP-MSCHAP V2 Password** according to the network administrator's requirement.
3. Do either one of the following:
 - Select **EAP-TLS Certificate**, click **Action/Manage Certificates** to upload the required machine certificate. The machine certificate is an encrypted file that will be supplied by the network administrator, along with the certificate password.
 - Select **EAP-MSCHAP V2 Password**, enter the username and password supplied by the network administrator into the **Username** and **Password** fields. This method does not require the use of a machine certificate, only the user name and password credentials.
4. If you enabled the **Enable Authentication Server Validation** option, this will enable the **Select Trusted Certificate Authority(ies)** list box which contains signed Trusted Certificate Authorities (CAs) preloaded into the DM-NAX-2XLRI-1G.

Select the check box next to each CA whose certificate can be used for server validation, as specified by the network administrator.

If the network does not use any of the listed certificates, the network administrator must provide a certificate, which must be uploaded manually via the **Manage Certificates** functionality.
5. If required, type the domain name of the network in the **Domain** field.
6. When the 802.1X settings are configured as desired, click **Save Changes** to save the changes to the device and reboot it. Click **Revert** to cancel any changes.

Access the Web Interface With the Crestron Toolbox™ Application

To access the web interface by opening a web browser within the Crestron Toolbox™ application, do the following:

1. Open the Crestron Toolbox application.
2. From the **Tools** menu, select **Device Discovery Tool**. You can also access the Device Discovery Tool by clicking the Device Discovery Tool button () in the Crestron Toolbox toolbar. The DM-NAX-8ZSA is discovered and listed in the device list on the left side of the screen. The associated host name, IP address, and firmware version are also displayed.

NOTE: If there is security software running on the computer, a security alert might be displayed when the Crestron Toolbox application attempts to connect to the network. Make sure to allow the connection, so that the Device Discovery Tool can be used.

3. In the Device Discovery Tool list, double-click your device.
4. Enter your credentials in the **Authentication Required** dialog that opens, and then click **Log In**.
5. Click the **Web Configuration** button in the Configuration page displayed on the left side of the Device Discovery Tool.

DM-NAX-8ZSA

This section describes how to configure the DM-NAX-8ZSA.

Web Interface Configuration

The DM-NAX-8ZSA web interface allows you to view status information and configure network and device settings.

Access the Web Interface

To access the web interface, do either of the following:

- [Access the Web Interface with a Web Browser on page 190](#)
- [Access the Web Interface With the Crestron Toolbox™ Application on page 255](#)

The web interface is accessed from a web browser. The following table lists operating systems and their corresponding supported web browsers.

Operating System and Supported Web Browsers


OPERATING SYSTEM	SUPPORTED WEB BROWSERS
Windows® operating system	Chrome™ web browser, version 31 and later
	Firefox® web browser, version 31 and later
	Internet Explorer web browser, version 11 and later
	Microsoft Edge web browser
macOS® operating system	Safari® web browser, version 6 and later
	Chrome web browser, version 31 and later
	Firefox web browser, version 31 and later

Access the Web Interface with a Web Browser

1. Enter the IP address of the DM-NAX-8ZSA into a web browser.


NOTE: To obtain the IP address, use the **Device Discovery Tool** option in Crestron Toolbox™ application or an IP scanner application.

2. If you are creating a user account for the first time, do the following; otherwise, skip to step 3.
 - a. Enter a username in the **Username** field.
 - b. Enter a password in the **Password** field.
 - c. Re-enter the same password in the **Confirm Password** field.



The screenshot shows the Crestron logo at the top left. Below it, a yellow warning triangle icon is followed by the text "DEVICE FIRST BOOT". In the center, there is a white box titled "Device Administration". Inside this box, there are three input fields: "Username", "Password", and "Confirm Password". Below these fields is a green button with a white plus icon and the text "Create User". At the bottom of the white box, there is small text: "© 2021 Crestron Electronics, Inc.", "Privacy Statement", and "Crestron Software End-User License Agreement".

- d. Click **Create User**. The Device Administration page appears.




The screenshot shows the same Crestron logo at the top left. Below it, the "DEVICE FIRST BOOT" message is no longer present. The white box titled "Device Administration" still contains the "Username" and "Password" input fields. Below these fields is a blue button with a white magnifying glass icon and the text "Sign In". At the bottom of the white box, the same small text is present: "© 2021 Crestron Electronics, Inc.", "Privacy Statement", and "Crestron Software End-User License Agreement".

3. Enter the username in the **Username** field.
4. Enter the password in the **Password** field.
5. Click **Sign In**.

Action

The **Action** drop-down menu is displayed at the top right side of the interface and provides quick access to common device functions:

- Save Changes
- Revert
- Reboot
- Restore
- Update Firmware
- Download Logs
- Manage Certificates
- Manage Audio Profiles
- Download Configuration
- Upload Configuration



Save Changes

Click **Save Changes** to save any changes made to the configuration settings.


Revert

Click **Revert** to revert the device back to the last saved configuration settings.

Reboot the DM-NAX-8ZSA

Certain changes to the settings may require the DM-NAX-8ZSA to be rebooted to take effect. To reboot the device, do the following:

1. Click **Reboot** in the **Actions** drop-down menu. The **Confirmation** message box appears.




2. Click **Yes, Reboot Now** to reboot the device. The **Reboot** message box appears. Wait for the device reboot to complete before attempting to reconnect to the device.

Restore to Factory Default Settings

1. Click **Restore** in the **Actions** drop-down menu to restore the settings of the DM-NAX-8ZSA to factory defaults.

NOTE: When settings are restored, all settings, including the network settings, will revert to the factory default. If a static IP address is set, restoring the device to factory default settings will revert the IP address to the default DHCP mode.




2. Click **Yes** in the **Confirmation** dialog to restore the DM-NAX-8ZSA to factory settings. Click **No** to cancel the restore operation.

A dialog is displayed again, indicating that the restore process was successful and that the device rebooted.

You can also restore to factory settings by pressing and holding the **SETUP** button on the rear panel of the device with power disconnected then connect the power supply and continue to hold **SETUP** button for 30 seconds.

Update Firmware

1. Click **Update Firmware** in the **Actions** drop-down menu.
2. In the **Firmware Upgrade** dialog, click **+ Browse**.



3. Locate and select the desired firmware file, and then click **Open**. The selected firmware file name is displayed in the **Firmware Upgrade** dialog.
4. Click **Load** and wait for the progress bar to complete and for the **OK** button in the message to become clickable.
5. Click **OK**. The device with new firmware can now be accessed.


Download Logs

1. Click **Download Logs** in the **Actions** drop-down menu to download the device message logs for diagnostic purposes.

The log file is downloaded to the Downloads folder of the PC.

Manage Certificates

Use the **Manage Certificates** dialog to add, remove, and manage certificates used in 802.1x and other protected networks.



1. Click **Manage Certificates** in the **Actions** drop-down menu. The following certificate tabs are displayed:
 - **Root:** The Root certificate is used by the DM-NAX-8ZSA to validate the network's authentication server. The DM-NAX-8ZSA has a variety of Root certificates, self-signed by trusted CAs (Certificate Authorities) preloaded into the device. Root certificates must be self-signed.
 - **Intermediate:** The Intermediate store holds non self-signed certificates that are used to validate the authentication server. These certificates will be provided by the network administrator if the network does not use self-signed Root certificates.
 - **Machine:** The machine certificate is an encrypted PFX file that is used by the authentication server to validate the identity of the DM-NAX-8ZSA. The machine certificate will be provided by the network administrator, along with the certificate password. For 802.1x, only one machine certificate can reside on the device.
 - **Web Server:** The Web Server certificate is a digital file that contains information about the identity of the web server.


To Add Certificates

1. Click the corresponding certificate tab.
2. Click the **Add Root Certificate** button.
3. Click the **+ Browse** button.
4. Locate and select the file, and then click the **Open** button.

NOTE: If the certificate is a Machine Certificate, enter the password provided by the network administrator.


5. Click **OK**. This will add the certificate to the list box, displaying the file name and expiration date.
The certificate is now available for selection and can be loaded to the device.

To Delete Certificates

1. Click the corresponding certificate tab.
2. Click the trashcan button () in the **Actions** column to delete the certificate.
3. Click **Yes** when prompted to delete the certificate or **No** to cancel the deletion.

Manage Audio Profiles

Use the **Manage Audio Profiles** dialog to add, remove, and manage the audio profiles of speakers.




Click **Manage Audio Profiles** in the **Actions** drop-down menu. The following audio profiles tabs are displayed, providing information such as **Model**, **Manufacturer**, and **Type** of the speaker profiles:

- **Default Profiles:** Lists the default library of included speaker profiles.
- **User Profiles:** Lists the custom, user loaded profiles, and allows them to be loaded and removed.

In the **Search** field, enter the speaker's profile name to search for the profile. The speaker profile matching the search criteria is displayed.

NOTE: To create a custom speaker profile, see [OLH 1001820](#).


To Add a Speaker Profile



1. Click the **User Profiles** tab.
2. Click the **+ Add Profiles** button.
3. Click the **+ Browse** button.
4. Locate and select the .prof file, and then click the **Open** button.
5. Click the **Upload** button.
6. Click **OK**. This will add the profile to the list box.

The speaker profile is now available for selection and can be applied to the speaker.

To Delete a Speaker Profile



1. Click the **User Profiles** tab.
2. Select the checkbox corresponding to the audio profile that needs to be deleted.
3. Click **Delete Profile** button.

The speaker profile is deleted.

Download Configuration

Click **Download Configuration** to download a TGZ file containing the settings data for the DM NAX device.


NOTE: User accounts for accessing the device, streaming service accounts, multicast addresses, and stream names are not saved in this configuration file.

Upload Configuration


1. Click **Upload Configuration** to upload a TGZ file that will overwrite the current settings of the DM NAX device with a saved configuration.

CAUTION: Be sure to load a TGZ file for the same DM NAX device type while using the Load Configuration feature. For example, if loading a TGZ file to a DM-NAX-8ZSA, be sure that the TGZ file originated from a DM-NAX-8ZSA.


2. Click **Browse** to navigate to the desired TGZ file in your file browser. Double-click the file or highlight it and click **Open**.



3. Click **Upload** to begin the file upload process. A progress bar will indicate the status of the configuration file upload.



4. Once the upload is complete, the device will require a reboot. Click **Yes, Reboot Now** to begin the reboot, or click **No** to return to the web UI.



NOTE: Any changes made after the configuration file upload, but before a device reboot, may be overwritten when the device is rebooted.

Status

The **Status** tab is the first page displayed when opening the interface of the DM-NAX-8ZSA. It displays general information about the DM-NAX-8ZSA (such as Model Name, Firmware Version, and Serial Number), current network settings (such as Host Name and IP Address, etc.), and input and output ports' current status.


The Status tab can be accessed at any time by clicking the **Status** tab of the DM-NAX-8ZSA interface.




Information displayed on the **Status** tab is organized into different sections.

Device

The **Device** section displays the **Model**, **Firmware Version**, and **Serial Number** of the DM-NAX-8ZSA.




Click **+ More Details** to review additional information about the DM-NAX-8ZSA.



Network

The **Network** section displays network-related information about the DM-NAX-8ZSA, including the Hostname, Domain Name, and DNS Servers.




NOTE: By default, the host name of the DM-NAX-8ZSA consists of the model name followed by the MAC address of the device. For example, DM-NAX-8ZSA-00107FB58088.

Click **+ Adapter 1** to display an expanded section that shows additional information. If **+ Adapter 1** is selected, click **- Less** details to collapse the section.

NOTE: The + **Adapter 2** option appears when the dual Ethernet ports on the DM-NAX-8ZSA are set to isolate traffic using the Port Selection feature.

Control System


The **Control System** section displays connection information, consisting of the following:



- **Encrypt Connection:** ON or OFF
- **IP ID:** Reports the currently used IP ID of the DM-NAX-8ZSA
- **IP Address/Hostname:** The IP address of the control system
- **Room ID:** Displays the room ID
- **Status:** OFFLINE or ONLINE

Settings

The **Settings** tab enables you to configure the DM-NAX-8ZSA settings. The Settings page can be accessed at any time by clicking the **Settings** tab of the DM-NAX-8ZSA interface.




Settings available on the **Settings** tab are organized into different sections.

System Setup

The **System Setup** section contains settings for **Date/Time**, **Auto Update**, **Network**, and **Control System**.

Date/Time

Use the **Date/Time** section to configure the date and time settings of the DM-NAX-8ZSA.



Time Synchronization

1. Set the **Time Synchronization** toggle to the right position to enable or left position to disable time synchronization. By default, time synchronization is enabled.
2. In the **NTP Time Servers** table, enter the URL of a NTP (Network Time Protocol) or SNTP (Simple Network Time Protocol) server. Up to three time servers can be added on a device.
3. Click **Synchronize Now** to perform time synchronization between the device's internal clock and the time server.

Time Configuration


1. Click on the **Time Zone** drop-down menu to select the applicable time zone.
2. In the **Date** field, enter the current date.
3. In the **Time (24hr Format)** field, enter the current time in 24-hour format.

Click the **Save Changes** button to save the settings.

Click **Revert** from the **Actions** drop-down menu to revert to the previous settings without saving.

Auto Update

The DM-NAX-8ZSA can automatically check for and install firmware updates at scheduled intervals via the Auto Update feature.



The screenshot shows the Crestron web interface for device DM-NAX-8ZSA-00107FB58088. The 'System Setup' tab is active, and the 'Auto Update' section is expanded. The 'Auto Update' toggle is turned on. The 'Custom URL' toggle is turned off. The 'Custom URL Path' is set to 'https://crestrondevicefiles.blob.core.winc'. The 'Schedule' section shows 'Day of Week' set to 'Daily', 'Time of Day' set to '02:10', and 'Poll Interval' set to '0' minutes. An 'Update Now' button is visible at the bottom of the configuration area.

1. Set the **Auto Update** toggle to the right position to enable Auto Update.
2. Define the URL to download the updates by doing either of the following:
 - a. Use the default URL to download the updates from the Crestron server.
 - b. Use a custom URL. Set the **Custom URL** toggle to the right position to enable a custom URL. In the **Custom URL Path** text box, enter the path to a custom manifest file in the FTP or SFTP URL format. Use the Crestron Auto Update Tool to generate a custom manifest file, then store the file on an FTP (File Transfer Protocol) or SFTP (Secure File Transfer Protocol) server.
3. Set a schedule for the automatic firmware update by doing either of the following:
 - a. Select the desired **Day of Week** and **Time of Day** (24-hour format) values.
 - b. Set the **Poll Interval** by entering a value from **60** to **65535** minutes. A value of **0** disables the Poll Interval.
4. Click **Save Changes**.

Clicking **Update Now** causes the device to check for a firmware update immediately. If a schedule was set in step 4 above, that schedule still remains in effect.

Network

The **Network** section contains network-related settings for the DM-NAX-8ZSA, including the Hostname, Domain, Primary Static DNS, and Secondary Static DNS.

The screenshot shows the Crestron web interface for the DM-NAX-8ZSA-00107FB58088 device. The 'Network' section is expanded, showing the following settings:

- Host Name: DM-NAX-8ZSA-00107FB58088
- Domain: CRESTRON.CRESTRON.com
- Primary Static DNS: 10.88.2.10(DHCP)
- Secondary Static DNS: 192.168.200.134(DHCP)
- Adapter 1:
 - DHCP: Enabled (toggle switch is blue)
 - IP Address: 10.88.105.66
 - Subnet Mask: 255.255.255.0
 - Default Gateway: 10.88.105.1

A 'Save Changes' button is located in the top right corner of the configuration area.

NOTE: By default, the hostname of the DM-NAX-8ZSA consists of the model name followed by the MAC address of the device. For example, DM-NAX-8ZSA-00107FB58088.

Adapter 1

The Adapter 1 subheading contains settings for DHCP, IP Address, Subnet Mask, and Default Gateway of Ethernet adapter 1 on the rear panel of the device.

NOTES:

- An **+ Adapter 2** option only appears when the dual Ethernet ports on the DM-NAX-8ZSA are set to isolate traffic using the Port Selection feature. The settings for Adapter 2 are identical to those available for Adapter 1.
- DM NAX devices' internal processes use IP addresses in the 10.10.10.xxx range. This IP range should be avoided when addressing DM NAX devices to prevent conflicts.

Set the **DHCP** toggle to enabled (right) or disabled (left) to specify whether the IP address of the DM-NAX-8ZSA is to be assigned by a DHCP (Dynamic Host Configuration Protocol) server.

- **Enabled:** When DHCP is enabled (default setting), the IP address of the DM-NAX-8ZSA is automatically assigned by a DHCP server on the local area network (LAN).
- **Disabled:** When DHCP is disabled, manually enter information in the following fields:
 - **Primary Static DNS:** Enter a primary DNS IP address.
 - **Secondary Static DNS:** Enter a secondary DNS IP address.
 - **IP Address:** Enter a unique IP address for the DM-NAX-8ZSA.
 - **Subnet Mask:** Enter the subnet mask that is set on the network.
 - **Default Gateway:** Enter the IP address that is to be used as the network's gateway.

To save any new network entries, click **Save Changes**.

Control System

DM-NAX-8ZSA-00107FB58088 ✓ Action

▼ Status **Settings** Security 802.1x Configuration

▼ System Setup

+ Date/Time

+ Auto Update

+ Network

- Control System

Encrypt Connection ☐

IP Table

IP ID	IP Address/Hostname	Room ID
No records found		

+ Add ✖ Remove

1. Click the **Encrypt Connection** button to navigate to the **Security** tab to configure encryption settings.
2. Enter the username in the **Control System Username** field.
3. Enter the password in the **Control System Password** field.
4. Enter the Room ID in the **Room ID** field.
5. Enter the IP ID of the DM-NAX-8ZSA in the **IP ID** field.
6. Enter the IP address or hostname of the control system in the **IP Address/Hostname** field.
7. Click the **Save Changes** button to save the new entries. The Control System Save message box appears, indicating that the control system settings were saved successfully. Click the **Revert** button to revert to the previous settings without saving.

Commissioning

The **Commissioning** section provides a quick way to automatically assign multicast addresses to all of the device's internal audio-over-IP stream transmitters.

▼ Commissioning

Starting Multicast Address

239.8.3.5

Last Used Multicast Address

239.8.3.36


Assign Addresses

Click **Assign Addresses** to give each DM NAX transmitter in the DM-NAX-8ZSA a unique multicast address beginning with the specified **Starting Multicast Address**. The valid range for **Starting Multicast Address** is 239.8.0.0 to 239.255.255.231.

NOTE: This will begin transmitting multicast traffic on your network, refer to the [DM NAX Audio-over-IP System Design Guide](#) document for details.

Chimes


The **Chimes** section allows the built-in chime files to be assigned to any of the output zones on the device.



For each chime file, click the cells corresponding to the desired Zones for playback of that specific chime sound. You can assign multiple chimes to the same zone. To view all available chimes, use the ▲ or ▼ arrows at the left of the matrix to change pages.

To configure the chime volume of a zone:

1. Click the ⚙ icon corresponding to the zone. A **Configure** window appears.




- To set the volume, do one of the following:
 - Move the **Volume** slider to the right to increase or to the left to decrease the chime volume.
 - Click the % arrows to increase or decrease the chime volume. Values range from 0 to 100%, adjustable in increments of 1%.
 - Manually enter a value in the **Volume** field.

NOTE: The chime volume is independent of the zone volume control.

- Set the **Do Not Disturb** toggle to the right to mute all chimes for the zone. Set the **Do Not Disturb** toggle to the left to unmute the chimes.
- Click **OK** to apply the new settings.

Zones

The **Zones** section contains the **Volume** and **Mute** settings for all zone outputs of the device, as well as a Configure option for more advanced settings within each zone.



Name	Volume	Mute	Action
Screen Porch	30 %	Mute	Configure
Bedroom 1	30 %	Mute	Configure
Bedroom 2	30 %	Mute	Configure
Master Bedroom	30 %	Mute	Configure
Master Bath	30 %	Mute	Configure
Kitchen	30 %	Mute	Configure
Dining Room	30 %	Mute	Configure
Living Room	30 %	Mute	Configure


Give each zone a friendly name using the **Name** column of the **Zones** table. If the device is paired with a control system, these names may be overwritten by the control system's program.


To configure the zone volume, do one of the following:

- Move the **Volume** slider to the right to increase or to the left to decrease the zone volume.
- Click the % arrows to increase or decrease the zone volume. Values range from 0 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Volume** field.

To mute all audio output from a zone, click its respective **Mute** button. To unmute the zone, click the **Muted** button.


Zone Settings

To configure zone settings, click the **Configure** button ( **Configure**). The **Edit Zone** window appears.




Zone

Click **Zone** to access the settings for **Tone**, **Balance**, and **Delay**.



Tone




The **Tone** section provides adjustments for the **Tone Profile**, **Bass**, **Treble**, **Loudness**, and **Night Mode** settings of the zone output.

NOTE: The Tone Profile, Bass, Treble, and Loudness settings in the Tone section are all applied separately from the Equalizer Settings for the zone. This means that any adjustments made in the Tone section will stack with those made in the Equalizer Settings section.

1. To select a tone profile preset for the zone, select an option from the **Tone Profile** drop-down menu. The available options are **Off**, **Classical**, **Jazz**, **Pop**, **Rock**, and **Spoken Word**. By default, **Off** is selected.

2. **Bass:** To adjust the bass, do one of the following:
 - Move the **Bass** slider to the right to increase or to the left to decrease the bass.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of 1 db.
 - Manually enter a value in the **Bass** field.
3. **Treble:** To adjust the treble, do one of the following:
 - Move the **Treble** slider to the right to increase or to the left to decrease the treble.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of 1 db.
 - Manually enter a value in the **Treble** field.
4. To enable the loudness setting on the zone output, slide the **Loudness** switch to the right. To disable loudness, slide the **Loudness** switch to the left.
5. The **Night Mode** feature applies subtle processing to restrict the dynamic range of the zone audio, to allow for lower listening levels at night or in rooms where higher listening levels would be disruptive. To select a dynamics processing level, select an option from the **Night Mode** drop-down menu. The available options are **Off**, **Low**, **Medium**, and **High**. By default, **Off** is selected.


Balance



To adjust the left/right balance of the stereo output signal, do one of the following:

- Move the **Balance** slider to the right to shift the stereo balance to the right channel or to the left to shift the balance to the left.
- Click the arrows to adjust the balance left or right. The up arrow shifts the balance to the right while the down arrow shifts the balance to the left.
- Manually enter a value in the **Balance** field. Values range from -50 to 50, adjustable in increments of 1. Positive values shift the balance to the right while negative values shift the balance to the left.

Delay



To set the delay, do one of the following:

- Move the **Delay Time(ms)** slider to the right to increase or to the left to decrease the delay time.
- Click the **ms** arrows to increase or decrease the delay. Values range from 0 ms to 250 ms, adjustable in increments of 1 ms.
- Manually enter a value in the **Delay Time(ms)** field.

Output

Click **Output** to access the settings for **Minimum/Maximum Volume**, **Stereo/Mono**, **Signal**, **Bussing**, **Volume Offset**, **Configure Speaker Profile**, **Speaker Configuration**, **Casting**, **Speaker/Faults**, **Line Out**, **Signal Generator**, **Advanced Signal Generator**, and **Equalizer Settings**.

The screenshot shows the 'Output' settings panel. It contains three sections: 'Minimum / Maximum (Autosaved)', 'Stereo / Mono (Autosaved)', and 'Signal (Autosaved)'. The 'Minimum / Maximum' section has three sliders: 'Minimum' (0%), 'Maximum' (100%), and 'Default' (30%). The 'Stereo / Mono' section has radio buttons for 'Stereo' (selected) and 'Mono', and a 'Zone Configuration' dropdown set to 'Standard'. The 'Signal' section shows 'Signal' as 'Not Present'.

Minimum/Maximum Volume

The screenshot shows the 'Minimum / Maximum (Autosaved)' settings panel. It contains three sliders: 'Minimum' (14%), 'Maximum' (86%), and 'Default' (27%). Each slider has a corresponding percentage value displayed next to it.

1. To set the minimum volume of the zone, do one of the following:
 - Move the **Minimum** slider to the right to increase or to the left to decrease the minimum volume.
 - Click the **%** arrows to increase or decrease the minimum volume. Values range from 0 to 50%, adjustable in increments of 1%.
 - Manually enter a value in the **Minimum** field.
2. To set the maximum volume of the zone, do one of the following:
 - Move the **Maximum** slider to the right to increase or to the left to decrease the maximum volume.
 - Click the **%** arrows to increase or decrease the maximum volume. Values range from 70 to 100%, adjustable in increments of 1%.
 - Manually enter a value in the **Maximum** field.


NOTE: When a **Minimum** and **Maximum** volume are set, the 1-100% range represented by the **Zone** and **Default** volume controls are scaled to the range set. For example, if a **Minimum** of 10% and a **Maximum** of 80% are set for a zone, the 1-100% range of the **Zone** volume control is scaled to the 10%-80% range set as the **Minimum** and **Maximum**.

3. To set the default volume of the zone, do one of the following:

- Move the **Default** slider to the right to increase or to the left to decrease the default volume.
- Click the **%** arrows to increase or decrease the default volume. Values range from 0 to 50%, adjustable in increments of 1%.
- Manually enter a value in the **Default** field.

NOTE: The **Default** volume is applied as the **Zone** volume any time the zone receives a source route and no source was previously routed to that zone.


Stereo/Mono




1. Select either **Stereo** or **Mono** from the **Stereo/Mono** field.
2. Select the zone configuration from the **Zone Configuration** drop-down menu. The available values are **Standard**, **Bridged**, **Bridged 2.1**, **Bridged Sub 2.1**, and **Bridged Mono**. See the diagrams below for the output signal flow applied in each configuration.

NOTE: The **Stereo/Mono** field is disabled for the Bridged 2.1, Bridged Sub 2.1, and Bridged Mono zone configurations.


Stereo - Standard




Stereo - Bridged




Mono - Standard




Mono - Bridged




Bridged 2.1




Bridged Sub 2.1



Bridged Mono



Signal



The **Signal** section is a read-only field that displays the **Signal** and **Clipping** status of the zone output.

- If an output signal is present but not clipping, **Signal** will display **Present** in green and **Clipping** will display **None** in green.
- If an output signal is present and clipping, **Signal** will display **Present** in green and **Clipping** will display **Present** in red.

- If no output signal is detected, **Signal** will display **Not Present** in red and **Clipping** will display **None** in green.

Bussing Volume Offset



Bussing Volume Offset is an additional level compensation applied to the zone relative to any other zones it is grouped with via the **Bussing** feature.

To set the bussing volume offset, do one of the following:

- Move the **Bussing Volume Offset** slider to the right to increase or to the left to decrease the offset.
- Click the **db** arrows to increase or decrease the offset. Values range from -12 dB to 12 dB, adjustable in increments of 1 dB.
- Manually enter a value in the **Bussing Volume Offset** field.


Configure Speaker Profile



The DM-NAX-8ZSA has a library of built-in speaker profiles that contain equalizer, speaker protection, and impedance settings specific to Crestron and third-party speaker models. Custom speaker profiles can also be generated and loaded to the DM-NAX-8ZSA. The **Configure Speaker Profile** field is used to apply these speaker profiles to a given zone of the DM NAX device.

NOTE: Applying a speaker profile on a zone will overwrite the existing **Speaker Configuration** and **Equalizer** settings for that zone.

Applied Manufacturer Crestron

Applied Model SAROS ICE4

Global Filter 

	Model 	Manufacturer 
<input type="radio"/>	Air LS4	Crestron
<input type="radio"/>	Air LS6	Crestron
<input type="radio"/>	Air SR4	Crestron
<input type="radio"/>	Air SR6	Crestron
<input type="radio"/>	Air SR8	Crestron

1 of 9

Apply

In the **Global Filter** field, enter the speaker's model name to search for its associated profile. Any speaker profiles matching the search criteria are displayed.

To apply a speaker profile:


1. Select the radio button corresponding to the speaker profile.
2. Click **Apply**.

The equalizer, impedance, and speaker protection settings of the zone are updated as per the applied speaker profile.

After applying a speaker profile, the **Speaker Configuration** and **Equalizer** settings for the zone can still be edited. The **Configure Speaker Profile** section will display a notification if these settings were altered after the speaker profile was applied.



Speaker Configuration



Speaker Configuration (Autosaved)


Enable Speaker Protect ☒

Speaker Wattage 40 Watts

Impedance

1. Set the **Enable Speaker Protect** toggle to the right position to enable speaker protection for the zone output. Set the toggle to the left position to disable speaker protection. By default, **Enable Speaker Protect** is set to the left position.
2. To set the maximum output wattage, do one of the following:
 - Move the **Speaker Wattage** slider to the right to increase or to the left to decrease the maximum peak amplifier wattage that can be output to the speaker.
 - Click the **Watts** arrows to increase or decrease the maximum peak amplifier wattage that can be output to the speaker. Values range from 5 W to 150 W, adjustable in increments of 1 W.
 - Manually enter a value in the **Speaker Wattage** field.
3. Select the impedance of the speaker on a selected zone from the **Impedance** drop-down menu. Values are **4 Ohms**, **8 Ohms**, and **Bridged**.

Casting



— Casting (Autosaved)

Maximum Casting Volume 80 %

Casting Name *

AirPlay ☒

Spotify ☒

The Casting section is used to enable or disable the ability of third-party devices to cast audio to the DM NAX output zone, as well as set a maximum casting volume and friendly name for the zone.

To configure Casting:

1. **Maximum Casting Volume** is an alternate value for the **Maximum** volume set in the [Minimum/Maximum Volume on page 214](#) settings, applied to the zone only when a casting service is routed to it. To set the maximum casting volume, do one of the following:

- Move the **Maximum Casting Volume** slider right to increase or left to decrease the maximum volume.
- Click the arrows to increase or decrease the maximum casting volume. Values range from 70% to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Maximum Casting Volume** field.

NOTE: If the **Maximum Casting Volume** value is higher than the regular **Maximum** volume value, the **Maximum** value will be applied instead.

2. A custom casting name (for example, "Living Room") must be entered so that a name for the zone will be displayed in the list of available casting destinations when initiating a stream. Enter this friendly name in the **Casting Name** field.

NOTE: Ensure that the **Casting Name** field is populated as any field with an asterisk (*) is mandatory.

Once AirPlay® and/or Spotify Connect™ are enabled, this name will be displayed as an available destination on the casting device.

To configure Apple AirPlay® casting:

1. Set the **AirPlay** toggle to the right to enable AirPlay casting to the zone's associated media player. Set the **AirPlay** toggle to the left to disable AirPlay casting to the associated media player.

To configure Spotify Connect™ casting:


1. Set the **Spotify** toggle to the right to enable Spotify Connect casting to the zone's associated media player. Set the **Spotify** toggle to the left to disable Spotify Connect casting to the associated media player.

To stream media from an iOS device or Spotify app to a zone in your distributed audio system, refer to the [DM-NAX-8ZSA Quick Start](#).

To stream media from a Roon® streaming device to a zone in your distributed audio system:


1. Enable Apple AirPlay casting for each DM NAX zone.
2. Launch the Roon desktop app.
3. Open the Roon app menu and navigate to the **Settings** submenu, then select **Audio**. A table of discovered network devices that the Roon device can stream to will be displayed. Any devices that previously have been enabled for Roon casting are listed under the **Connected to Core** section, and the rest of the discovered devices are listed under **Other network devices**.
4. Find each of the DM NAX zones in the **Other network devices** list, then click the **Enable** button for each zone to connect it to the Roon Core® for casting.
5. Return to the Roon app home page and click on the speaker icon at the bottom right. Select a DM NAX zone from the list of available casting destinations. With a zone selected, start a media stream, and the Roon device will cast the streaming audio to the zone.

Speaker/Faults



The Speaker/Faults section is a read-only field that displays the status of the **DC Offset Fault**, **Over Current Fault**, **Clipping Detected**, **Over or Under Voltage**, and **Over Temperature** detectors for the zone output. If clipping or a given fault type is detected, then its corresponding readout displays **Fault Detected** in red. Otherwise, it displays **None** in blue.

Line Out




Line Out Volume controls the volume level of the corresponding line-level output on the DM NAX device. This setting is only available on zones 1 through 4 of the DM-NAX-8ZSA, as zones 5 through 8 do not

have a corresponding line-level output. The Line Out Volume is only applied when **Line Out EQ Bypass** is enabled.

1. To set the line out volume, do one of the following:
 - Move the **Line Out Volume** slider to the right to increase or to the left to decrease the line out volume.
 - Click the arrows to increase or decrease the line out volume. Values range from 0 to 100, adjustable in increments of 1. This range in dB is -80 dB to 20 dB.
 - Manually enter a value in the **Line Out Volume** field.
2. Set the **Line Out EQ Bypass** toggle to the right position to have the line-level output signal bypass the zone's equalizer settings. Set the toggle to the left position to have the line-level output signal pass through the zone's equalizer. By default, **Line Out EQ Bypass** is disabled.

NOTE: When the **Line Out EQ Bypass** setting is disabled, the line-level output's level will mirror the speaker output's **Zone** volume control. This allows for a variable signal level in applications where the line-level output is connected to an uncontrolled device such as powered speakers. If the **Line Out EQ Bypass** setting is enabled, the **Line Out Volume** slider can be used to set a fixed level for the line-level output. This level will not be affected by the speaker output **Zone** volume controls, so this configuration is better suited to applications where the line output is connected to a controlled amplifier with its own level adjustment.

Signal Generator



The DM-NAX-8ZSA has a built-in signal generator that allows an integrator to send an audio signal to any number of selected zones to test output functionality.


1. To route the signal generator to the zone output, click the **Signal Generator** button so that it displays **Active** and is highlighted in blue. To unroute the signal generator on the zone output, click the **Signal Generator** button so that it displays **Inactive** and is highlighted in grey. By default, the signal generator is not routed to the zone output.

NOTES:

- There is only one signal generator built-in to the DM NAX device. Each zone has its own button to enable or disable the signal generator from passing signal to that output. Setting the signal generator to **Inactive** on a given zone output only breaks the route for that output and does not stop it from playing back in other zones.
- The **Signal Generator Volume** control is a local control that does not affect the signal generator's volume on other zone outputs. Only the settings under **Advanced Signal Generator** are applied universally to all zones of the DM NAX device.

2. To adjust the signal generator's volume, do one of the following:
 - Move the **Signal Generator Volume** slider right to increase or left to decrease the volume.
 - Click the arrows to increase or decrease the signal generator volume. Values range from 0 to 100, adjustable in increments of 1.
 - Manually enter a value in the **Signal Generator Volume** field.

Advanced Signal Generator



The advanced signal generator settings control the built-in signal generator directly, and are applied universally to all output zones of the DM NAX device. The signal type for the generator can be set, and the left and right channels of the test signal can be individually enabled or disabled.

1. Set the **Left Channel** toggle to the right position to enable the left channel of the signal. Set the toggle to the left position to disable the left channel. By default, **Left Channel** is enabled.
2. Set the **Right Channel** toggle to the right position to enable the right channel of the signal. Set the toggle to the left position to disable the right channel. By default, **Right Channel** is enabled.

3. Select an audio test signal type from the **Signal Type** drop-down menu. The available signal types are:
 - **Tone:** Generates a 1 kHz sine wave tone.
 - **Pink Noise:** Generates pink noise.
 - **White Noise:** Generates white noise.

Equalizer Settings

Equalizer Settings (Autosaved)

Speaker EQ Enabled ☒

Band	Band01	Band02	Band03	Band04	Band05	Band06	Band07	Band08	Band09	Band10
Gain										
	0	0	0	0	0	0	0	0	0	0
Type	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ
Frequency	32	64	125	250	500	1000	2000	4000	8000	16000
Bandwidth	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1
Bypass	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Actions	Reset	Reset	Reset	Reset	Reset	Reset	Reset	Reset	Reset	Reset

Each zone output of the DM-NAX-8ZSA has a dedicated ten-band equalizer that can be fully customized to tune the zone output signal to the needs of an install. Each band can have a discrete gain, filter type, center frequency, and bandwidth set, and can also be bypassed. The equalizer itself can also be bypassed using the **Speaker EQ Enabled** toggle.

1. Set the **Speaker EQ Enabled** toggle to the right position to enable the equalizer. Set the toggle to the left position to bypass the equalizer.

NOTE: When **Speaker EQ Enabled** is disabled, all equalizer bands are bypassed. This is a quick way to perform A/B testing of the entire EQ curve.

2. With the **Speaker EQ Enabled** toggle in the right position, do the following to configure a given equalizer band:
 - a. To set a band's gain, do one of the following:
 - Move the **Gain** slider up to increase or down to decrease the gain.
 - Click the arrows to increase or decrease the gain. Values range from -40 dB to 20 dB, adjustable in increments of 0.1 dB.
 - Manually enter a value in the **Gain** field.

- b. Select a filter type from the **Type** drop-down menu. By default, all bands are set to the **EQ** filter type. Some filter types will disable other settings in their respective band while enabled. For example, selecting the **LowPass** filter type for a band will disable that band's **Gain** and **Bandwidth** settings, since the **LowPass** filter applies a fixed roll-off slope at a set frequency. The available filter types are:
- **EQ:** a fully parametric filter that can boost or cut a range of frequencies.
 - **Notch:** a parametric filter designed to more precisely cut a frequency or range of frequencies. A notch filter can achieve a narrower bandwidth than the standard **EQ** parametric filter type.
 - **TrebleShelf:** a filter that boosts or cuts all frequencies above a set frequency by a set gain.
 - **BassShelf:** a filter that boosts or cuts all frequencies below a set frequency by a set gain.
 - **LowPass:** a filter that fully cuts all frequencies above a set frequency using a fixed roll-off slope of -12 dB per octave.
 - **HighPass:** a filter that fully cuts all frequencies below a set frequency using a fixed roll-off slope of -12 dB per octave.
- c. Set a center frequency for the equalizer band to tune a specific portion of the audible frequency spectrum. To set the center frequency, do one of the following:
- Click the arrows to increase or decrease the frequency. Values range from 20 Hz to 20 kHz, adjustable in increments of 1 Hz. Each band has a default center frequency that will be applied if the **Reset** button at the bottom of the band is clicked.
 - Manually enter a value in the **Frequency** field.
- d. Set a bandwidth to determine how wide of a frequency range is effected by the equalizer band. To set the bandwidth, do one of the following:
- Click the arrows to increase or decrease the bandwidth. Values range from 0.1 octaves to 4.0 octaves, adjustable in increments of 0.1 octave.
 - Manually enter a value in the **Bandwidth** field.
- e. The individual Bypass controls allow you to bypass a single band of equalization at a time for more granular A/B testing of a single filter. Set a band's **Bypass** toggle to the right position to bypass that band. Set the toggle to the left position to disable the bypass. By default, **Bypass** is disabled.
- f. Each equalizer band has a **Reset** button that will reapply the default settings for that band.

Click **Done** to return to the **Settings** tab of the web user interface.

Bussing

The bussing feature on DM NAX devices allows an integrator to assign any number of selected zones to a fixed group of zones (bus). Zones in a bus track the other zones' volume and routing. For example, when the source or volume for one zone in the bus is adjusted, all other zones in that bus receive the same adjustment. You can create up to four buses on the DM-NAX-8ZSA.

DM-NAX-8ZSA-00107FB58088

Action

Status

Settings

Security

802.1x Configuration

System Setup

Commissioning

Chimes

Zones

Bussing

Bussing (Autosaved)

Global Filter

Name	Bus Id	Included Zones
Bus01	1	Choose Zones
Bus02	2	Choose Zones
Bus03	3	Choose Zones
Bus04	4	Choose Zones

Configure Bussing


1. If needed, enter a friendly name for each bus in its **Name** field.
2. Select any number of zones from the **Included Zones** drop-down menu.

NOTE: Each zone can be a member of only one bus. Any zones that are already a member of another bus will not be shown in the **Included Zones** drop-down.

Inputs

The **Inputs** section is used to configure the **Name**, **Compensation**, and **Mute** attributes of the available analog, digital, and media streaming inputs on the DM-NAX-8ZSA.

A total of 16 inputs are available on the DM-NAX-8ZSA, including the 8 physical input connectors on the device's rear panel and the 8 internal media players used for media streaming services.




Name	TOSLINK1	TOSLINK2	S/PDIF1	S/PDIF2	RCA1	RCA2	RCA3	RCA4
Gain (db)								
Signal Present								
Clipping Detected								
Mute								

Configure Inputs

1. If needed, enter a friendly name for each input in its **Name** field.
2. To set a level compensation adjustment for a given input, do one of the following:
 - Move the **Compensation** slider up to increase or down to decrease the compensation. Compensation increases or decreases the level of the incoming audio signal on any of the physical inputs on the device's rear panel. Compensation is not available for any of the internal media players.
 - Click the **db** arrows to increase or decrease the compensation. Values range from -10 dB to 10 dB, adjustable in increments of 1 dB.
 - Manually enter a value in the **Compensation** field.
3. To mute the signal from the corresponding input, click the **Mute** button. To disable the mute, click the **Muted** button. By default, **Mute** is disabled.

Monitor the device's input signals using the text indicators in the **Signal Present** and **Clipping Detected** columns:

- **Signal Presence** indicates whether or not a signal is detected in that zone.
- **Clipping Detected** indicates if the signal is **Clipping** or **Nominal** (non-clipping).

Use the **Global Filter** text field to filter specific inputs by name. Not all of the available inputs are shown on the first page in this section when no **Global Filter** is applied. Use  at the bottom of the table to view the next page of inputs.

DM NAX Streams

Each local input of the DM-NAX-8ZSA can be made available as a DM NAX audio-over-IP stream. This includes the eight physical inputs on the rear panel of the device and the eight internal media players.

The DM-NAX-8ZSA also supports parallel DM NAX streams for each zone output, enabling an additional transmit stream per output to mirror all routes and DSP settings of its respective zone. These parallel

streams enable control of the audio signal to third-party uncontrolled AES67 devices receiving audio from the DM-NAX-8ZSA.

NOTES:

- Under the **Transmitters** section (see [Configure Transmitters](#)), the last four listed transmitters are dedicated to parallel zone outputs.
- To configure the DSP settings, see [Zone Settings](#).

Click **NAX Streams** to expand the tab and display the following information.

The screenshot shows the Crestron configuration interface for a DM-NAX-8ZSA device. The top bar displays the device ID 'DM-NAX-8ZSA-00107FB58088' and an 'Action' button. A sidebar on the left contains a menu with 'Zones', 'Bussing', 'Inputs', and 'NAX Streams' (which is selected and highlighted in blue). The main content area for 'NAX Streams' displays the following settings:

- Device is Master PTP Clock Source:** Yes (indicated by green text)
- Master Clock Status:** 00107f.ffff.b58088
- PTP Priority:** 254 (with a dropdown arrow)
- Transmitters (Autosaved):** A large empty rectangular box.
- Receivers (Autosaved):** A large empty rectangular box.

- **Device is Master PTP Clock Source** indicates whether the DM NAX device's PTP clock is the master clock on the network. **Yes** will be displayed in green when the local DM-NAX-8ZSA's clock is the PTP master clock and **No** will be displayed in red when another PTP clock on the network is operating as the master clock.
- **Master Clock Status** displays the Master Clock ID of the device on the network that is currently acting as the master clock.
- **PTP Priority:** This sets the priority of the local DM NAX device's PTP clock relative to other clocks on the network. The default setting is 254 (one increment higher than the lowest possible value) so that the DM-NAX-8ZSA will only operate as clock master if no other PTP master is present on the network. Valid values range from 1 to 255.

Configure Transmitters

NAX Streams

Device is Master PTP Clock Source No
Master Clock Status 001071ffe.9cc314
PTP Priority 254

Transmitters (Autosaved)

Audio Source	Stream	Nax Stream Address	Nax Stream Name	Status	Actions
Digital Input 1	Stream01	0.0.0.0	TOSLINK1100.10.7fb5.80.88	Stream Stopped	▶ ◻ ⚙
Digital Input 2	Stream02	0.0.0.0	TOSLINK2200.10.7fb5.80.88	Stream Stopped	▶ ◻ ⚙
Digital Input 3	Stream03	239.8.0.32	S/PDIF1300.10.7fb5.80.88	Stream Started	▶ ◻ ⚙
Digital Input 4	Stream04	0.0.0.0	S/PDIF2400.10.7fb5.80.88	Stream Stopped	▶ ◻ ⚙
Analog Input 5	Stream05	0.0.0.0	RCA1500.10.7fb5.80.88	Stream Stopped	▶ ◻ ⚙
Analog Input 6	Stream06	0.0.0.0	RCA2600.10.7fb5.80.88	Stream Stopped	▶ ◻ ⚙
Analog Input 7	Stream07	0.0.0.0	RCA3700.10.7fb5.80.88	Stream Stopped	▶ ◻ ⚙
Analog Input 8	Stream08	0.0.0.0	RCA4800.10.7fb5.80.88	Stream Stopped	▶ ◻ ⚙

NOTE: To configure transmitters not shown on the current page of the table, click the ▶ icon to display the next page of eight transmitters.

To configure a DM NAX transmit stream, do the following.

1. Enter a valid multicast address in the **NAX Stream Address** field.
2. Enter a name in the **NAX Stream Name** field by which the stream can be identified. This stream name is associated with the DM NAX stream's multicast address by other DM NAX or AES67 devices, like a device hostname that resolves to a given IP address.
3. **Status** indicates whether a stream is transmitting or not. When the stream has started or stopped, the **Status** column will update accordingly.
4. Click the configure button (⚙) in the **Actions** column. The **Configure** dialog appears:

Configure

Auto Initiation ☐

Port 5004

OK CANCEL

5. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled for a given stream, the stream will begin transmitting automatically and will be available as a multicast stream on your network at the specified multicast address.
 - If **Auto Initiation** is disabled for the input, the stream will not begin transmitting until it is manually initiated.
6. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number for DM NAX streams is 5004.
7. Click **OK** to save or click **Cancel** to cancel the changes.

Configure Receivers

Receivers (Autosaved)						
Zone Name	Stream	Current Stream Address	Requested Stream Address		Status	Actions
Zone1	Stream01	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Zone2	Stream02	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Zone3	Stream03	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Zone4	Stream04	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Zone5	Stream05	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Zone6	Stream06	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Zone7	Stream07	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Zone8	Stream08	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙

1. Enter the multicast address of a transmitting stream in the **Requested Stream Address** field to subscribe the receiver to the stream.
2. Click the configure button (⚙) in the **Actions** column. The **Configure** dialog appears:

Configure

Auto Initiation

Port

5004

✓ OK


✕ CANCEL





3. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled, the stream will begin automatically when the receiver subscribes to the transmitter.
 - If **Auto Initiation** is disabled, the stream will not begin until it is manually initiated.
4. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number is 5004.
5. Click **OK** to save or click **Cancel** to cancel the changes.



Routing

The **Routing** section is used to route a local input, media player, or AES67 stream to a Zone on the DM-NAX-8ZSA.


NOTE: To receive an AES67 stream from Dante devices, see [OLH 1001151](#).




To route an input to a zone, click the box in the routing matrix where the zone's row overlaps the corresponding input's column. Once a route is made,  appears. To break a given route click  or . To route a single input to all zones, click on the  icon under the input's name.





Use the arrows ( or ) at the top of the matrix to change pages to view all available inputs.



To select a specific DM NAX/AES67 stream when AES67 is selected as the source for a Zone, do the following:

- Click  to display the list of all DM NAX/AES67 streams discovered on the network and click a radio button to select the corresponding stream to be routed to the zone.



	Stream Name	Network Address
<input type="radio"/>	MediaStream6147ff40efe	239.8.0.37
<input type="radio"/>	MediaStream2107ff40efe	239.8.0.41
<input type="radio"/>	RCA2600.10.7ff4.0b.8d	239.8.10.25
<input type="radio"/>	Stream0100.10.7f.9c.9b.06	239.0.14.239
<input type="radio"/>	MediaStream61400.10.7f.b5.f3.24	239.8.0.8
<input type="radio"/>	MediaStream7157ff40efe	239.8.0.38
<input type="radio"/>	MediaStream31100.10.7f.b5.f3.24	239.8.0.2
<input type="radio"/>	RCA1500.10.7ff4.0b.8d	239.8.10.24
<input type="radio"/>	MediaStream71500.10.7f.b5.f3.24	239.8.0.5
<input type="radio"/>	Stream0100.10.7f.05.23.9c	239.57.156.23


Navigation:   1 of 5  

Buttons:  

- Click **OK** to save or click **Cancel** to cancel the changes.


Streaming Services

The DM-NAX-8ZSA features eight built-in media streaming players, each of which can play back a discrete media stream from a cloud-based service or local casting device. User Profiles can be created for each user of the DM NAX device with discrete credentials, enabling multiple users access to media streaming services without interfering with other users' recommendations, favorites, or playlists.




To configure Streaming Services:

1. Click the **+ Add User Profile** button to create a new user profile. Each user profile can contain a unique set of accounts for all supported streaming services.
2. Enter a name in the **Profile Name** field. Click **Save** to create the **User Profile**. Once the profile is created, you have the option to either **Delete** the profile, or add **Services** to it.
3. Click **Services** in the **Action** column and an **Edit Services** window appears.



4. Select from the available Streaming Services: **TIDAL™**, **Deezer®**, **Qobuz®**, **SOUNDMACHINE®**, **SiriusXM®**, **Pandora®**, **Internet Radio**, and **Podcasts**. Click **+** or **🗑️** to add or delete the desired streaming services for each user profile.


User Authentication

User authentication is required for TIDAL, Deezer, Qobuz, SOUNDMACHINE, SiriusXM and Pandora. Click  to authorize the user.

To authenticate SiriusXM streaming:

NOTE: To determine whether to use commercial accounts, refer to the streaming service license agreement or FAQs on their respective portals. For SiriusXM, click [here](#).


Enter the user credentials and click **OK**.



To authenticate TIDAL streaming:

1. Click on the link to log in to the TIDAL portal.

NOTE: The link is valid for one minute. After one minute, the link expires, and the **Authorize URL** is shown as blank. The **Authorize User** dialogue will need to be closed and reopened.




2. Click **DONE** to return to **Streaming Services**.

To authenticate Deezer streaming:

1. Click on the link to log in to the Deezer portal.

NOTE: The link is valid for one minute. After one minute, the link expires, and the **Authorize URL** is shown as blank. The **Authorize User** dialogue will need to be closed and reopened.



2. Click **DONE** to return to **Streaming Services**.

To authenticate Qobuz streaming:

1. Click on the link to log in to the Qobuz portal.


NOTE: The link is valid for one minute. After one minute, the link expires, and the **Authorize URL** is shown as blank. The **Authorize User** dialogue will need to be closed and reopened.



2. Click **DONE** to return to **Streaming Services**.

To authenticate SOUNDMACHINE streaming:

NOTE: To determine whether to use commercial accounts, refer to the streaming service license agreement or FAQs on their respective portals. For SOUNDMACHINE, click [here](#).




1. Click the link to log in to the SOUNDMACHINE portal.


NOTE: The link is valid for one minute. After one minute, the link expires, and the **Authorize URL** is shown as blank. The **Authorize User** dialogue will need to be closed and reopened.


A screenshot of the SOUNDMACHINE login page. At the top is the "SOUNDMACHINE" logo in a multi-colored font. Below the logo is the heading "Login". Underneath the heading are two input fields: the first is labeled "Email" and the second is labeled "Password". Both fields have a red border. Below these fields is a large, light gray button with the text "PLEASE ENTER YOUR CREDENTIALS" in all caps.

2. Log in to the SOUNDMACHINE account.
3. Click **DONE** to return to **Streaming Services**.

To authenticate Pandora streaming:



1. Click the  icon to copy the activation code.
2. Click the link to register the device. The Device Activation page is displayed.




NOTE: The link is valid for one minute. After one minute, the link expires, and the **Authorize URL** and **Enter Code** are shown as blank. The **Authorize User** dialogue will need to be closed and reopened.

3. Paste the activation code in the **Please enter your activation code** field and click **Activate Now**.
4. Log in to the Pandora account.
5. Click **DONE** to return to **Streaming Services**.

Port Selection

The Port Selection feature allows the device's internal network traffic to be managed and segregated based on traffic type. Internal VLANs are used to segment device management and streaming service traffic to a separate physical device Ethernet port than audio-over-IP streaming traffic. With Port Selection enabled on all DM NAX devices on a network, DM NAX and AES67 network traffic can be physically separated from the control network onto a dedicated audio network.

▼ Port Selection

 **Port Selection:** Connecting multiple interfaces to the same switch may cause a network loop

Port Selection ☒

Management

Port1

Audio/NAX

Port2

To configure Port Selection:

1. Set the **Port Selection** toggle to the right position to enable Port Selection. Set the toggle to the left position to disable Port Selection. By default, **Port Selection** is disabled.

NOTE: Ports 1 and 2 correspond to the Ethernet adapters labeled **1** and **2** on the rear panel of the DM-NAX-8ZSA, respectively.

2. With **Port Selection** enabled, select an Ethernet port from the **Management** drop-down menu to designate which Ethernet port on the rear panel of the device will handle network traffic relating to device configuration, streaming services, and the device's connection to a control system.

NOTES:


- To access streaming services, the Management port must be connected to a network with internet access.
- The Management port determines your connection to the web interface. Changing the port value can result in losing your connection to the device via the web interface.

3. With **Port Selection** enabled, select an Ethernet port from the **Audio/NAX** drop-down menu to designate which Ethernet port on the rear panel of the device will handle audio-over-IP streaming network traffic.
4. Click **Save** changes to apply the new settings.

NOTE: Making changes to **Port Selection** settings will require a reboot.

Security


Click the **Security** tab to configure security for users and groups and to allow different levels of access to the DM-NAX-8ZSA functions. By default, security is disabled.



Select **Encrypt and Validate**, **Encrypt**, or **OFF** in the **SSL Mode** drop-down menu, to specify whether to use encryption. By default, SSL Mode is set to **OFF**.

Current User

Click the **Current User** tab to view read-only information or to change the password for the current user.




The screenshot shows a web interface with three tabs: "Current User", "Users", and "Groups". The "Current User" tab is selected. Below the tabs, the following information is displayed:

Name	admin1
Access Level	Administrator
Active Directory User	No
Groups	Administrators

At the bottom left, there is a blue button labeled "Change Current User Password".

1. Click the **Change Current User Password** button to provide a new password for the current user.
2. In the **Change Password** dialog, enter the current password in the **Current Password** field, the new password in the **Password** field, and then re-enter the same new password in the **Confirm Password** field.



The screenshot shows a "Change Password" dialog box with a blue title bar and a close button (X) in the top right corner. The dialog contains three text input fields, each with a password mask (dots):


- Current Password
- Password
- Confirm Password

At the bottom right, there are two buttons: "OK" (with a checkmark icon) and "Cancel" (with an X icon).

3. Click **OK** to save or click **Cancel** to cancel the changes.

Users

Click the **Users** tab to view and edit user settings. The **Users** tab can be used to add or remove local and Active Directory users and preview information about users.



Use the **Search Users** field to enter search term(s) and display users that match the search criteria.

If users listed in the **Users** table span across multiple pages, navigate through the list of users by clicking a page number or by using the left or right arrows at the bottom of the **Users** pane to move forward or backward through the pages.

Each page can be set to display 5, 10, or 20 users by using the drop-down menu to the right of the navigation arrows.

Information about existing users is displayed in table format and the following details are provided for each user.


- **Username:** Displays the name of the user.
- **AD User:** Displays whether the user requires authentication using Active Directory.

Click the corresponding button in the Actions column to view detailed user information or to delete the user.

To create a new user, click the **Create User** button.

Create a New Local User

1. Click the **Create User** button in the User tab.
2. In the **Create User** dialog, enter the following:



The screenshot shows a 'Create User' dialog box. The 'Name' field contains the text 'test'. The 'Active Directory User' toggle switch is turned off. The 'Password' and 'Confirm Password' fields are both filled with dots, indicating they are masked. The 'Groups' dropdown menu is set to 'Administrators'. At the bottom right, there are 'OK' and 'Cancel' buttons.

- a. Enter a user name in the **Name** field. A valid user name can consist of alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
- c. Assign the access level by selecting one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is disabled.

3. Click **OK** to save or click **Cancel** to cancel the changes.


Add an Active Directory User

Users cannot be created or removed from the Active Directory server, but access can be granted to an existing user in the Active Directory server.

To grant access to an Active Directory user, you can either add the user to a local group on the DM-NAX-8ZSA, or add the Active Directory group(s) that they are a member of to the DM-NAX-8ZSA.

To add an Active Directory user.

1. Click the **Create User** button.
2. In the **Create User** dialog, enter the following.




The screenshot shows a 'Create User' dialog box with a blue header. It contains three main fields: 'Name' with the text 'Connects\test', 'Active Directory User' with a blue toggle switch turned on, and 'Groups' with a dropdown menu showing 'Connects'. At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'X' icon.

- a. Enter a user name in the **Name** field in the format "Domain\UserName", for example "crestronlabs.com\JohnSmith". Valid user names can contain alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Select one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is set to enabled.


3. Click **OK** to save or click **Cancel** to cancel the changes.

Delete User


Click the trashcan button () in the **Actions** column to delete the user. Click **Yes** when prompted to delete the user or **No** to cancel the deletion.

After a user is removed from a group, they lose any access rights associated with that group. Note that the user account is not deleted by the delete user operation.

View User Details

Click the information button () in the **Actions** column to view information for the selected user. The **User Details** dialog displays the following information for the selected user.


- **Name:** Displays the name of the selected user.
- **Active Directory User:** Displays whether the user is an Active Directory user.
- **Group:** Displays group(s) the selected user is part of.




The **User Details** dialog box has a blue title bar with the text "User Details" and a close button (X). The main area is white and contains three rows of information: "Name" with the value "admin1", "Active Directory User" with the value "No", and "Groups" with the value "Administrators". At the bottom right, there is a blue button with a checkmark and the text "OK".

Click **OK** to close the **User Details** dialog and to return to the **Users** tab.

Update User Details



The **Update User** dialog box has a blue title bar with the text "Update User" and a close button (X). The main area is white and contains several fields: "Name" with the value "admin1", "Active Directory User" with a toggle switch that is currently off, "Password" and "Confirm Password" fields both containing seven dots, and a "Groups" drop-down menu with "Administrators" selected. At the bottom right, there are two blue buttons: one with a checkmark and "OK", and another with an X and "Cancel".

1. Click the edit button () in the **Actions** column to update information for the selected user.
2. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
3. Select one or more groups to assign the user to from the **Groups** drop-down list.
4. Click **OK** to save or click **Cancel** to cancel the changes.

The **Update User** dialog also displays the following read-only information for the selected user.

- **Name:** Displays the name of the user.
- **Active Directory User:** Displays whether the user is an Active Directory user.











Groups

Click the **Groups** tab to view and edit group settings. The **Groups** tab can be used to add local and Active Directory groups, remove local and Active Directory groups, and preview information about a group.

Use the **Search Groups** field to enter search term(s) and display groups that match the search criteria.

Current UserUsersGroups

Search...

Group Name	AD Group	Access Level	Action
Administrators	No	Administrator	 
Connects	No	Connect	 
Operators	No	Operator	 
Programmers	No	Programmer	 
Users	No	User	 

1

10



Create Group

If groups listed in the **Groups** table span across multiple pages, navigate through the groups by clicking a page number or by using the left or right arrows at the bottom of the Groups pane to move forward or backward through the pages.

Additionally, each page can be set to display 5, 10, or 20 groups by using the drop-down menu to the right of the navigation arrows.


Existing groups are displayed in a table and the following information is provided for each group:

- **Group Name:** Displays the name of the group.
- **AD Group:** Displays whether the group requires authentication using Active Directory.
- **Access Level:** Displays the predefined access level assigned to the group (Administrator, Programmer, Operator, User, or Connect).

Click the corresponding button in the **Actions** column to view detailed group information () or to delete () selected group.

Click on the **Create Group** button in the **Groups** tab to create new group.

Create Local Group

The image shows a 'Create Group' dialog box with a blue header bar containing the title 'Create Group' and a close button. The dialog has three main input areas: a 'Name' field with the text 'test12', an 'Access Level' dropdown menu currently showing 'Programmer', and an 'Active Directory Group' toggle switch which is turned off (grey). At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'X' icon.


1. Click the **Create Group** button.
2. In the **Create Group** dialog, enter the following:
 - a. Enter the group name in the **Name** field.
 - b. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is disabled.

3. Click **OK** to save. Click **Cancel** to cancel the changes.

Add Active Directory Group

A group cannot be created or removed from the Active Directory server, but access can be granted to an existing group in Active Directory.

The image shows a 'Create Group' dialog box with a blue header bar containing the title 'Create Group' and a close button. The dialog has three main input areas: a 'Name' field with the text 'test', an 'Access Level' dropdown menu currently showing 'Administrator', and an 'Active Directory Group' toggle switch which is turned on (blue). At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'X' icon.

Once the group is added, all members of that group will have access to the DM-NAX-8ZSA.


1. Click the **Create Group** button.
2. In the **Create Group** dialog enter the following:
 - a. Enter the group name in the **Name** field, for example "Engineering Group". Note that group names are case sensitive; a space is a valid character that can be used in group names.

3. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is enabled.


4. Click **OK** to save. Click **Cancel** to cancel the changes.


Delete a Group

Click the trashcan button () in the **Actions** column to delete a group. Click **Yes** when prompted to delete the group or **No** to cancel the deletion.

When a group is deleted, users in the group are not removed from the device or Active Directory server. However, because a user's access level is inherited from a group(s), users within the deleted group will lose access rights associated with the group.

View Group Details

Click the information button () in the **Actions** column to view information for the selected group. The **Group Details** dialog lists the following information for the selected group.



The **Group Details** dialog box displays the following information for the selected group:

Name	Administrators
Access Level	Administrator
Active Directory Group	No

At the bottom right, there is a blue button with a checkmark and the text **OK**.

- **Name:** Displays the name of the group.
- **Access Level:** Displays the access level of the group and its users.
- **Active Directory Group:** Displays whether the group is an Active Directory group.

Click **OK** to close the **Group Details** dialog and to return to the Groups tab.

802.1x Configuration

The DM-NAX-8ZSA has built-in support for the 802.1X standard (an IEEE network standard designed to enhance the security of wireless and Ethernet LANs. The standard relies on the exchange of messages between the device and the network's host, or authentication server), allowing communication with the authentication server and access to protected corporate networks.

StatusSettingsSecurity802.1x Configuration

802.1x Configuration

IEEE 802.1x Authentication

Authentication MethodEAP MSCHAP V2- password

Domainsecure12

Usernameadmin

Password*****

Enable Authentication Server Validation

Select Trusted Certificate Authority(s)

☐ AAA Certificate Services

☐ AC RAIZ FNMT-RCM

☐ ACCVRAIZ1

☐ Actalis Authentication Root CA

☒ AffirmTrust Commercial

☐ AffirmTrust Networking

☐ AffirmTrust Premium ECC

☒ AffirmTrust Premium

☐ Amazon Root CA 1

☐ Amazon Root CA 2

☒ Amazon Root CA 3

☐ Amazon Root CA 4

☐ Atos TrustedRoot 2011

☐ Autoridad de Certificacion Firmaprofesional CIF A62634068

☐ Baltimore CyberTrust Root

To Configure DM-NAX-8ZSA for 802.1X Authentication

1. Set the **IEEE 802.1X Authentication** toggle to enabled. This will enable all options on the 802.1X dialog.
2. Select the **Authentication method: EAP-TLS Certificate** or **EAP-MSCHAP V2 Password** according to the network administrator's requirement.
3. Do either one of the following:
 - Select **EAP-TLS Certificate**, click **Action/Manage Certificates** to upload the required machine certificate. The machine certificate is an encrypted file that will be supplied by the network administrator, along with the certificate password.
 - Select **EAP-MSCHAP V2 Password**, enter the username and password supplied by the network administrator into the **Username** and **Password** fields. This method does not require the use of a machine certificate, only the user name and password credentials.
4. If you enabled the **Enable Authentication Server Validation** option, this will enable the **Select Trusted Certificate Authoritie(s)** list box which contains signed Trusted Certificate Authorities (CAs) preloaded into the DM-NAX-8ZSA.

Select the check box next to each CA whose certificate can be used for server validation, as specified by the network administrator.

If the network does not use any of the listed certificates, the network administrator must provide a certificate, which must be uploaded manually via the **Manage Certificates** functionality.

5. If required, type the domain name of the network in the **Domain** field.
6. When the 802.1X settings are configured as desired, click **Save Changes** to save the changes to the device and reboot it. Click **Revert** to cancel any changes.

Access the Web Interface With the Crestron Toolbox™ Application

To access the web interface by opening a web browser within the Crestron Toolbox™ application, do the following:

1. Open the Crestron Toolbox application.
2. From the **Tools** menu, select **Device Discovery Tool**. You can also access the Device Discovery Tool by clicking the Device Discovery Tool button () in the Crestron Toolbox toolbar. The DM-NAX-2XLRI-1G is discovered and listed in the device list on the left side of the screen. The associated host name, IP address, and firmware version are also displayed.

NOTE: If there is security software running on the computer, a security alert might be displayed when the Crestron Toolbox application attempts to connect to the network. Make sure to allow the connection, so that the Device Discovery Tool can be used.

3. In the Device Discovery Tool list, double-click your device.
4. Enter your credentials in the **Authentication Required** dialog that opens, and then click **Log In**.
5. Click the **Web Configuration** button in the Configuration page displayed on the left side of the Device Discovery Tool.

DM-NAX-4ZSA-50

This section describes how to configure the DM-NAX-4ZSA-50.

Web Interface Configuration

The DM-NAX-2XLRI-1G web interface allows you to view status information and configure network and device settings.

Access the Web Interface

To access the web interface, do either of the following:

- [Access the Web Interface with a Web Browser on page 257](#)
- [Access the Web Interface With the Crestron Toolbox™ Application on page 313](#)

The web interface is accessed from a web browser. The following table lists operating systems and their corresponding supported web browsers.

Operating System and Supported Web Browsers


OPERATING SYSTEM	SUPPORTED WEB BROWSERS
Windows® operating system	Chrome™ web browser, version 31 and later
	Firefox® web browser, version 31 and later
	Internet Explorer web browser, version 11 and later
	Microsoft Edge web browser
macOS® operating system	Safari® web browser, version 6 and later
	Chrome web browser, version 31 and later
	Firefox web browser, version 31 and later

Access the Web Interface with a Web Browser

1. Enter the IP address of the DM-NAX-4ZSA-50 into a web browser.


NOTE: To obtain the IP address, use the **Device Discovery Tool** option in Crestron Toolbox™ application or an IP scanner application.

2. If you are creating a user account for the first time, do the following; otherwise, skip to step 3.
 - a. Enter a username in the **Username** field.
 - b. Enter a password in the **Password** field.
 - c. Re-enter the same password in the **Confirm Password** field.



The screenshot shows the Crestron logo at the top left. Below it, a yellow warning triangle icon is followed by the text "DEVICE FIRST BOOT". The main content area is titled "Device Administration". It contains three input fields: "Username", "Password", and "Confirm Password". Below these fields is a green button with a white plus icon and the text "Create User". At the bottom of the form, there is copyright information: "© 2021 Crestron Electronics, Inc.", a link to "Privacy Statement", and a link to "Crestron Software End-User License Agreement".

- d. Click **Create User**. The Device Administration page appears.




The screenshot shows the same Crestron logo at the top left. Below it, the text "DEVICE FIRST BOOT" is no longer present. The main content area is still titled "Device Administration". It now contains two input fields: "Username" and "Password". Below these fields is a blue button with a white magnifying glass icon and the text "Sign In". At the bottom of the form, the same copyright information is present: "© 2021 Crestron Electronics, Inc.", a link to "Privacy Statement", and a link to "Crestron Software End-User License Agreement".

3. Enter the username in the **Username** field.
4. Enter the password in the **Password** field.
5. Click **Sign In**.

Action

The **Action** drop-down menu is displayed at the top right side of the interface and provides quick access to common device functions:

- Save Changes
- Revert
- Reboot
- Restore
- Update Firmware
- Download Logs
- Manage Certificates
- Manage Audio Profiles
- Download Configuration
- Upload Configuration



Save Changes

Click **Save Changes** to save any changes made to the configuration settings.


Revert

Click **Revert** to revert the device back to the last saved configuration settings.

Reboot the DM-NAX-4ZSA-50

Certain changes to the settings may require the DM-NAX-4ZSA-50 to be rebooted to take effect. To reboot the device, do the following:

1. Click **Reboot** in the **Actions** drop-down menu. The **Confirmation** message box appears.




2. Click **Yes, Reboot Now** to reboot the device. The **Reboot** message box appears. Wait for the device reboot to complete before attempting to reconnect to the device.

Restore to Factory Default Settings

1. Click **Restore** in the **Actions** drop-down menu to restore the settings of the DM-NAX-4ZSA-50 to factory defaults.

NOTE: When settings are restored, all settings, including the network settings, will revert to the factory default. If a static IP address is set, restoring the device to factory default settings will revert the IP address to the default DHCP mode.




2. Click **Yes** in the **Confirmation** dialog to restore the DM-NAX-4ZSA-50 to factory settings. Click **No** to cancel the restore operation.

A dialog is displayed again, indicating that the restore process was successful and that the device rebooted.

You can also restore to factory settings by pressing and holding the **SETUP** button on the rear panel of the device with power disconnected then connect the power supply and continue to hold **SETUP** button for 30 seconds.

Update Firmware

1. Click **Update Firmware** in the **Actions** drop-down menu.
2. In the **Firmware Upgrade** dialog, click **+ Browse**.



3. Locate and select the desired firmware file, and then click **Open**. The selected firmware file name is displayed in the **Firmware Upgrade** dialog.
4. Click **Load** and wait for the progress bar to complete and for the **OK** button in the message to become clickable.
5. Click **OK**. The device with new firmware can now be accessed.


Download Logs

1. Click **Download Logs** in the **Actions** drop-down menu to download the device message logs for diagnostic purposes.

The log file is downloaded to the Downloads folder of the PC.

Manage Certificates

Use the **Manage Certificates** dialog to add, remove, and manage certificates used in 802.1x and other protected networks.



1. Click **Manage Certificates** in the **Actions** drop-down menu. The following certificate tabs are displayed:
 - **Root:** The Root certificate is used by the DM-NAX-4ZSA-50 to validate the network's authentication server. The DM-NAX-4ZSA-50 has a variety of Root certificates, self-signed by trusted CAs (Certificate Authorities) preloaded into the device. Root certificates must be self-signed.
 - **Intermediate:** The Intermediate store holds non self-signed certificates that are used to validate the authentication server. These certificates will be provided by the network administrator if the network does not use self-signed Root certificates.
 - **Machine:** The machine certificate is an encrypted PFX file that is used by the authentication server to validate the identity of the DM-NAX-4ZSA-50. The machine certificate will be provided by the network administrator, along with the certificate password. For 802.1x, only one machine certificate can reside on the device.
 - **Web Server:** The Web Server certificate is a digital file that contains information about the identity of the web server.


To Add Certificates

1. Click the corresponding certificate tab.
2. Click the **Add Root Certificate** button.
3. Click the **+ Browse** button.
4. Locate and select the file, and then click the **Open** button.

NOTE: If the certificate is a Machine Certificate, enter the password provided by the network administrator.


5. Click **OK**. This will add the certificate to the list box, displaying the file name and expiration date. The certificate is now available for selection and can be loaded to the device.

To Delete Certificates

1. Click the corresponding certificate tab.
2. Click the trashcan button () in the **Actions** column to delete the certificate.
3. Click **Yes** when prompted to delete the certificate or **No** to cancel the deletion.

Manage Audio Profiles

Use the **Manage Audio Profiles** dialog to add, remove, and manage the audio profiles of speakers.




Click **Manage Audio Profiles** in the **Actions** drop-down menu. The following audio profiles tabs are displayed, providing information such as **Model**, **Manufacturer**, and **Type** of the speaker profiles:

- **Default Profiles:** Lists the default library of included speaker profiles.
- **User Profiles:** Lists the custom, user loaded profiles, and allows them to be loaded and removed.

In the **Search** field, enter the speaker's profile name to search for the profile. The speaker profile matching the search criteria is displayed.

NOTE: To create a custom speaker profile, see [OLH 1001820](#).


To Add a Speaker Profile



1. Click the **User Profiles** tab.
2. Click the **+ Add Profiles** button.
3. Click the **+ Browse** button.
4. Locate and select the .prof file, and then click the **Open** button.
5. Click the **Upload** button.
6. Click **OK**. This will add the profile to the list box.

The speaker profile is now available for selection and can be applied to the speaker.

To Delete a Speaker Profile



1. Click the **User Profiles** tab.
2. Select the checkbox corresponding to the audio profile that needs to be deleted.
3. Click **Delete Profile** button.

The speaker profile is deleted.

Download Configuration

Click **Download Configuration** to download a TGZ file containing the settings data for the DM NAX device.


NOTE: User accounts for accessing the device, streaming service accounts, multicast addresses, and stream names are not saved in this configuration file.

Upload Configuration

1. Click **Upload Configuration** to upload a TGZ file that will overwrite the current settings of the DM NAX device with a saved configuration.


CAUTION: Be sure to load a TGZ file for the same DM NAX device type while using the Load Configuration feature. For example, if loading a TGZ file to a DM-NAX-4ZSA-50, be sure that the TGZ file originated from a DM-NAX-4ZSA-50.

2. Click **Browse** to navigate to the desired TGZ file in your file browser. Double-click the file or highlight it and click **Open**.



3. Click **Upload** to begin the file upload process. A progress bar will indicate the status of the configuration file upload.

- Once the upload is complete, the device will require a reboot. Click **Yes, Reboot Now** to begin the reboot, or click **No** to return to the web UI.




NOTE: Any changes made after the configuration file upload, but before a device reboot, may be overwritten when the device is rebooted.

Status

The **Status** tab is the first page displayed when opening the interface of the DM-NAX-4ZSA-50. It displays general information about the DM-NAX-4ZSA-50 (such as Model Name, Firmware Version, and Serial Number), current network settings (such as Host Name and IP Address, etc.), and input and output ports' current status.

The Status tab can be accessed at any time by clicking the **Status** tab of the DM-NAX-4ZSA-50 interface.



Information displayed on the **Status** tab is organized into different sections.

Device

The **Device** section displays the **Model**, **Firmware Version**, and **Serial Number** of the DM-NAX-4ZSA-50.

Device

Model

DM-NAX-4ZSA-50

Firmware Version

1.0.0111.10448

Serial Number

2402CRX02413

+ More Details

Click **+ More Details** to review additional information about the DM-NAX-4ZSA-50.

More Details

DM-NAX-4ZSA-50

1.0.0111.10448

Build

Feb 16 2024 (531614)

Updater

1.0.0111.10448

Bootloader

02.019.000

CCUI Version

1.1338.557

XIOSDK

3.8.2

IoTSDK

1.10.1

Build time

10:44:52

Product ID

0x7A04

Revision ID

0x0300

HDCP2X-SKE

HDCP2X-SKE [v9.0000.00000, #FFFFFFFF]

PRE-BOOT

[v9.0000.00000]

BOOTLOADER

[v9.0000.00000]

amp0-fpga-4zsa

FW v551.39 Rev.17 (Driver v1.1)

ctrl-audio-dsp-0

FW v19 (Driver v4.00)

ctrl-prod-info

Driver v3.0

PUF

1.0.0111.10448

Forced Auth Mode

True

Network

The **Network** section displays network-related information about the DM-NAX-4ZSA-50, including the Hostname, Domain Name, and DNS Servers.

Network	
Hostname	DM-NAX-4ZSA-50-C442683FE459
Domain Name	6vcrestronqelab.com
DNS Servers	10.253.31.12(DHCP)
Adapter 1	
DHCP	On
IP Address	10.253.38.72
Subnet Mask	255.255.255.0
Default Gateway	10.253.38.1
Link Active	true
MAC Address	c4.42.68.3f.e4.59

NOTE: By default, the host name of the DM-NAX-4ZSA-50 consists of the model name followed by the MAC address of the device. For example, DM-NAX-4ZSA-50-00107FB58088.

Click **+ Adapter 1** to display an expanded section that shows additional information. If **+ Adapter 1** is selected, click **- Less details** to collapse the section.

NOTE: The **+ Adapter 2** option appears when the dual Ethernet ports on the DM-NAX-4ZSA-50 are set to isolate traffic using the Port Selection feature.

Control System

The **Control System** section displays connection information, consisting of the following:

Control System

Encrypt Connection ON


IP Table

IP ID	Room Id	IP Address/Hostname	Type	Server Port	Connection	Status
C		DIN-AP4-R- C442681A3F36	Peer	41796	Gway	ONLINE

- **Encrypt Connection:** ON or OFF
- **IP ID:** Reports the currently used IP ID of the DM-NAX-4ZSA-50
- **IP Address/Hostname:** The IP address of the control system
- **Room ID:** Displays the room ID
- **Status:** OFFLINE or ONLINE

Settings

The **Settings** tab enables you to configure the DM-NAX-4ZSA-50 settings. The Settings page can be accessed at any time by clicking the **Settings** tab of the DM-NAX-4ZSA-50 interface.



Settings available on the **Settings** tab are organized into different sections.

System Setup

The **System Setup** section contains settings for **Date/Time**, **Auto Update**, **Network**, and **Control System**.

Date/Time

Use the **Date/Time** section to configure the date and time settings of the DM-NAX-4ZSA-50.

Date/Time

Synchronization

Time Synchronization

Synchronize Now

NTP Time Servers

	Address	Port	Authentication Method	Authentication Key	Key ID
<input type="checkbox"/>	pool.ntp.org	123	None	*****	0

+ Add

- Remove

Configuration

Time Zone

(UTC-05:00) Eastern Time (US & Can)

Date

02/21/2024

Time

12:40

Time Synchronization

1. Set the **Time Synchronization** toggle to the right position to enable or left position to disable time synchronization. By default, time synchronization is enabled.
2. In the **NTP Time Servers** table, enter the URL of a NTP (Network Time Protocol) or SNTP (Simple Network Time Protocol) server. Up to three time servers can be added on a device.
3. Click **Synchronize Now** to perform time synchronization between the device's internal clock and the time server.

Time Configuration

1. Click on the **Time Zone** drop-down menu to select the applicable time zone.
2. In the **Date** field, enter the current date.
3. In the **Time (24hr Format)** field, enter the current time in 24-hour format.

Click the **Save Changes** button to save the settings.

Click **Revert** from the **Actions** drop-down menu to revert to the previous settings without saving.

Auto Update

The DM-NAX-4ZSA-50 can automatically check for and install firmware updates at scheduled intervals via the Auto Update feature.

Auto Update

Schedule

Auto Update ☐

Custom URL ☐

Custom URL Path

Day of Week

Time of Day

Poll Interval Minutes

Update Now

1. Set the **Auto Update** toggle to the right position to enable Auto Update.
2. Define the URL to download the updates by doing either of the following:
 - a. Use the default URL to download the updates from the Crestron server.
 - b. Use a custom URL. Set the **Custom URL** toggle to the right position to enable a custom URL. In the **Custom URL Path** text box, enter the path to a custom manifest file in the FTP or SFTP URL format. Use the Crestron Auto Update Tool to generate a custom manifest file, then store the file on an FTP (File Transfer Protocol) or SFTP (Secure File Transfer Protocol) server.
3. Set a schedule for the automatic firmware update by doing either of the following:
 - a. Select the desired **Day of Week** and **Time of Day** (24-hour format) values.
 - b. Set the **Poll Interval** by entering a value from **60** to **65535** minutes. A value of **0** disables the Poll Interval.
4. Click **Save Changes**.

Clicking **Update Now** causes the device to check for a firmware update immediately. If a schedule was set in step 4 above, that schedule still remains in effect.

Network

The **Network** section contains network-related settings for the DM-NAX-4ZSA-50, including the Hostname, Domain, Primary Static DNS, and Secondary Static DNS.

Network

Adapter 1

Hostname *

DM-NAX-4ZSA-50-C442683FE459

Domain

6vcrestronqelab.com

Primary Static DNS

10.253.31.12(DHCP)

Secondary Static DNS

DHCP Enabled

☒

IP Address

10.253.38.72

Subnet Mask

255.255.255.0

Default Gateway

10.253.38.1

NOTE: By default, the hostname of the DM-NAX-4ZSA-50 consists of the model name followed by the MAC address of the device. For example, DM-NAX-4ZSA-50-00107FB58088.

Adapter 1

The Adapter 1 subheading contains settings for DHCP, IP Address, Subnet Mask, and Default Gateway of Ethernet adapter 1 on the rear panel of the device.

NOTES:

- An **+ Adapter 2** option only appears when the dual Ethernet ports on the DM-NAX-4ZSA-50 are set to isolate traffic using the Port Selection feature. The settings for Adapter 2 are identical to those available for Adapter 1.
- DM NAX devices' internal processes use IP addresses in the 10.10.10.xxx range. This IP range should be avoided when addressing DM NAX devices to prevent conflicts.

Set the **DHCP** toggle to enabled (right) or disabled (left) to specify whether the IP address of the DM-NAX-4ZSA-50 is to be assigned by a DHCP (Dynamic Host Configuration Protocol) server.

- **Enabled:** When DHCP is enabled (default setting), the IP address of the DM-NAX-4ZSA-50 is automatically assigned by a DHCP server on the local area network (LAN).
- **Disabled:** When DHCP is disabled, manually enter information in the following fields:
 - **Primary Static DNS:** Enter a primary DNS IP address.
 - **Secondary Static DNS:** Enter a secondary DNS IP address.
 - **IP Address:** Enter a unique IP address for the DM-NAX-4ZSA-50.
 - **Subnet Mask:** Enter the subnet mask that is set on the network.
 - **Default Gateway:** Enter the IP address that is to be used as the network's gateway.

To save any new network entries, click **Save Changes**.

Control System

Control System Username:

Control System Password:

IP Table

<input type="checkbox"/>	IP ID	IP Address/Hostname	Room Id
<input type="checkbox"/>	C	DIN-AP4-R-C442681A3F36	<input type="text" value="Room Id"/>

1. Click the **Encrypt Connection** button to navigate to the **Security** tab to configure encryption settings.
2. Enter the username in the **Control System Username** field.
3. Enter the password in the **Control System Password** field.
4. Enter the Room ID in the **Room ID** field.
5. Enter the IP ID of the DM-NAX-4ZSA-50 in the **IP ID** field.
6. Enter the IP address or hostname of the control system in the **IP Address/Hostname** field.
7. Click the **Save Changes** button to save the new entries. The Control System Save message box appears, indicating that the control system settings were saved successfully. Click the **Revert** button to revert to the previous settings without saving.

Commissioning

The **Commissioning** section provides a quick way to automatically assign multicast addresses to all of the device's internal audio-over-IP stream transmitters.

Starting Multicast Address:


Last Used Multicast Address: 239.8.0.8

Click **Assign Addresses** to give each DM NAX transmitter in the DM-NAX-4ZSA-50 a unique multicast address beginning with the specified **Starting Multicast Address**. The valid range for **Starting Multicast Address** is 239.8.0.0 to 239.255.255.247.

NOTE: This will begin transmitting multicast traffic on your network, refer to the [DM NAX Audio-over-IP System Design Guide](#) document for details.


Chimes


The **Chimes** section allows the built-in chime files to be assigned to any of the output zones on the device.



For each chime file, click the cells corresponding to the desired Zones for playback of that specific chime sound. You can assign multiple chimes to the same zone. To view all available chimes, use the ▲ or ▼ arrows at the left of the matrix to change pages.

To configure the chime volume of a zone:

1. Click the  icon corresponding to the zone. A **Configure** window appears.



2. To set the volume, do one of the following:
- Move the **Volume** slider to the right to increase or to the left to decrease the chime volume.
 - Click the % arrows to increase or decrease the chime volume. Values range from 0 to 100%, adjustable in increments of 1%.
 - Manually enter a value in the **Volume** field.

NOTE: The chime volume is independent of the zone volume control.

3. Set the **Do Not Disturb** toggle to the right to mute all chimes for the zone. Set the **Do Not Disturb** toggle to the left to unmute the chimes.
4. Click **OK** to apply the new settings.

Zones

The **Zones** section contains the **Volume** and **Mute** settings for all zone outputs of the device, as well as a Configure option for more advanced settings within each zone.

Zones

Zones (Autosaved)

Global Filter

Name	Volume	Mute	Action
Room 5 (bussed)	<div><div></div><div>0</div><div>%</div></div>	<div><div></div>Mute</div>	<div>Configure</div>
Room 5 (bussed)	<div><div></div><div>0</div><div>%</div></div>	<div><div></div>Mute</div>	<div>Configure</div>
Room 5 (bussed)	<div><div></div><div>0</div><div>%</div></div>	<div><div></div>Mute</div>	<div>Configure</div>
Room 5 (bussed)	<div><div></div><div>0</div><div>%</div></div>	<div><div></div>Mute</div>	<div>Configure</div>
Zone5	<div><div></div><div>30</div><div>%</div></div>	<div><div></div>Mute</div>	<div>Configure</div>


Give each zone a friendly name using the **Name** column of the **Zones** table. If the device is paired with a control system, these names may be overwritten by the control system's program.

To configure the zone volume, do one of the following:

- Move the **Volume** slider to the right to increase or to the left to decrease the zone volume.
- Click the % arrows to increase or decrease the zone volume. Values range from 0 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Volume** field.

To mute all audio output from a zone, click its respective **Mute** button. To unmute the zone, click the **Muted** button.

Zone Settings

To configure zone settings, click the **Configure** button ( **Configure**). The **Edit Zone** window appears.

DM-NAX-4ZSA-50-C442683FE459 > Zones
Room 5 (bussed)

Zone

Tone (Autosaved)

Tone Profile
Off

Bass
0 db

Treble
0 db

Loudness

Night Mode
Off

Balance (Autosaved)

Left / Right
0

Zone

Click **Zone** to access the settings for **Tone**, **Balance**, and **Delay**.

Zone

Tone (Autosaved)

Tone Profile

Bass 0 db

Treble 0 db

Loudness ☐

Night Mode

Balance (Autosaved)

Left / Right 0

Tone

Tone (Autosaved)

Tone Profile

Bass 0 db

Treble 0 db

Loudness ☐

Night Mode

The **Tone** section provides adjustments for the **Tone Profile**, **Bass**, **Treble**, **Loudness**, and **Night Mode** settings of the zone output.

NOTE: The Tone Profile, Bass, Treble, and Loudness settings in the Tone section are all applied separately from the Equalizer Settings for the zone. This means that any adjustments made in the Tone section will stack with those made in the Equalizer Settings section.

1. To select a tone profile preset for the zone, select an option from the **Tone Profile** drop-down menu. The available options are **Off**, **Classical**, **Jazz**, **Pop**, **Rock**, and **Spoken Word**. By default, **Off** is selected.
2. **Bass**: To adjust the bass, do one of the following:
 - Move the **Bass** slider to the right to increase or to the left to decrease the bass.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of 1 db.
 - Manually enter a value in the **Bass** field.
3. **Treble**: To adjust the treble, do one of the following:
 - Move the **Treble** slider to the right to increase or to the left to decrease the treble.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of 1 db.
 - Manually enter a value in the **Treble** field.
4. To enable the loudness setting on the zone output, slide the **Loudness** switch to the right. To disable loudness, slide the **Loudness** switch to the left.
5. The **Night Mode** feature applies subtle processing to restrict the dynamic range of the zone audio, to allow for lower listening levels at night or in rooms where higher listening levels would be disruptive. To select a dynamics processing level, select an option from the **Night Mode** drop-down menu. The available options are **Off**, **Low**, **Medium**, and **High**. By default, **Off** is selected.

Balance




The Balance control interface features a horizontal slider labeled "Left / Right" with a blue knob. To the right of the slider is a numeric input field displaying "0" with up and down arrow buttons. The entire control is enclosed in a green border with the text "Balance (Autosaved)" at the top left.

To adjust the left/right balance of the stereo output signal, do one of the following:

- Move the **Balance** slider to the right to shift the stereo balance to the right channel or to the left to shift the balance to the left.
- Click the arrows to adjust the balance left or right. The up arrow shifts the balance to the right while the down arrow shifts the balance to the left.
- Manually enter a value in the **Balance** field. Values range from -50 to 50, adjustable in increments of 1. Positive values shift the balance to the right while negative values shift the balance to the left.

Delay



The Delay control interface features a horizontal slider labeled "Delay Time(ms)" with a blue knob. To the right of the slider is a numeric input field displaying "0" with up and down arrow buttons and the unit "ms". The entire control is enclosed in a green border with the text "Delay (Autosaved)" at the top left.

To set the delay, do one of the following:

- Move the **Delay Time(ms)** slider to the right to increase or to the left to decrease the delay time.
- Click the **ms** arrows to increase or decrease the delay. Values range from 0 ms to 250 ms, adjustable in increments of 1 ms.
- Manually enter a value in the **Delay Time(ms)** field.

Output

Click **Output** to access the settings for **Minimum/Maximum Volume**, **Stereo/Mono**, **Signal**, **Bussing Volume Offset**, **Configure Speaker Profile**, **Speaker Configuration**, **Casting**, **Speaker/Faults**, **Line Out**, **Signal Generator**, **Advanced Signal Generator**, and **Equalizer Settings**.

Minimum/Maximum Volume

1. To set the minimum volume of the zone, do one of the following:
 - Move the **Minimum** slider to the right to increase or to the left to decrease the minimum volume.
 - Click the **%** arrows to increase or decrease the minimum volume. Values range from 0 to 50%, adjustable in increments of 1%.
 - Manually enter a value in the **Minimum** field.

2. To set the maximum volume of the zone, do one of the following:

- Move the **Maximum** slider to the right to increase or to the left to decrease the maximum volume.
- Click the **%** arrows to increase or decrease the maximum volume. Values range from 70 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Maximum** field.


NOTE: When a **Minimum** and **Maximum** volume are set, the 1-100% range represented by the **Zone** and **Default** volume controls are scaled to the range set. For example, if a **Minimum** of 10% and a **Maximum** of 80% are set for a zone, the 1-100% range of the **Zone** volume control is scaled to the 10%-80% range set as the **Minimum** and **Maximum**.

3. To set the default volume of the zone, do one of the following:

- Move the **Default** slider to the right to increase or to the left to decrease the default volume.
- Click the **%** arrows to increase or decrease the default volume. Values range from 0 to 50%, adjustable in increments of 1%.
- Manually enter a value in the **Default** field.


NOTE: The **Default** volume is applied as the **Zone** volume any time the zone receives a source route and no source was previously routed to that zone.

Stereo/Mono




1. Select either **Stereo** or **Mono** from the **Stereo/Mono** field.

Stereo



Mono



NOTE: The signal flow diagrams above are specifically for the speaker output zones (Zones 1 through 4). The diagrams still apply for Zone 5 with the exception of the amplifiers shown in the path of each output channel.

Signal

— Signal (Autosaved)

Signal	Not Present
Clipping	None

The **Signal** section is a read-only field that displays the **Signal** and **Clipping** status of the zone output.

- If an output signal is present but not clipping, **Signal** will display **Present** in green and **Clipping** will display **None** in green.
- If an output signal is present and clipping, **Signal** will display **Present** in green and **Clipping** will display **Present** in red.
- If no output signal is detected, **Signal** will display **Not Present** in red and **Clipping** will display **None** in green.

Bussing Volume Offset

— Bussing Volume Offset (Autosaved)

Bussing Volume Offset

0 ▲ ▼ db

Bussing Volume Offset is an additional level compensation applied to the zone relative to any other zones it is grouped with via the **Bussing** feature.

To set the bussing volume offset, do one of the following:

- Move the **Bussing Volume Offset** slider to the right to increase or to the left to decrease the offset.
- Click the **db** arrows to increase or decrease the offset. Values range from -12 dB to 12 dB, adjustable in increments of 1 dB.
- Manually enter a value in the **Bussing Volume Offset** field.

Configure Speaker Profile

The DM-NAX-4ZSA-50 has a library of built-in speaker profiles that contain equalizer, speaker protection, and impedance settings specific to Crestron and third-party speaker models. Custom speaker profiles can also be generated and loaded to the DM-NAX-4ZSA-50. The **Configure Speaker Profile** field is used to apply these speaker profiles to a given zone of the DM NAX device.

NOTE: Applying a speaker profile on a zone will overwrite the existing **Speaker Configuration** and **Equalizer** settings for that zone.

Applied Manufacturer		Crestron
Applied Model		SAROS ICE4
Global Filter <input type="text"/>		
	Model	Manufacturer
<input type="radio"/>	Air LS4	Crestron
<input type="radio"/>	Air LS6	Crestron
<input type="radio"/>	Air SR4	Crestron
<input type="radio"/>	Air SR6	Crestron
<input type="radio"/>	Air SR8	Crestron
1 of 9		
Apply		

In the **Global Filter** field, enter the speaker's model name to search for its associated profile. Any speaker profiles matching the search criteria are displayed.

To apply a speaker profile:

1. Select the radio button corresponding to the speaker profile.
2. Click **Apply**.


The equalizer, impedance, and speaker protection settings of the zone are updated as per the applied speaker profile.

NOTE: Zone 5 does not have impedance or speaker protection settings, but speaker profiles can still be applied to the zone output. Only the equalizer settings are effected when a speaker profile is applied to Zone 5.

After applying a speaker profile, the **Speaker Configuration** and **Equalizer** settings for the zone can still be edited. The **Configure Speaker Profile** section will display a notification if these settings were altered after the speaker profile was applied.


 Profile settings have been locally altered

Speaker Configuration (Zones 1 through 4 only)



1. Set the **Enable Speaker Protect** toggle to the right position to enable speaker protection for the zone output. Set the toggle to the left position to disable speaker protection. By default, **Enable Speaker Protect** is set to the left position.
2. To set the maximum output wattage, do one of the following:
 - Move the **Speaker Wattage** slider to the right to increase or to the left to decrease the maximum peak amplifier wattage that can be output to the speaker.
 - Click the **Watts** arrows to increase or decrease the maximum peak amplifier wattage that can be output to the speaker. Values range from 5 W to 150 W, adjustable in increments of 1 W.
 - Manually enter a value in the **Speaker Wattage** field.
3. Select the impedance of the speaker on a selected zone from the **Impedance** drop-down menu. Values are **4 Ohms**, **8 Ohms**, and **Bridged**.

Casting



The Casting section is used to enable or disable the ability of third-party devices to cast audio to the DM NAX output zone, as well as set a maximum casting volume and friendly name for the zone.

To configure Casting:

1. **Maximum Casting Volume** is an alternate value for the **Maximum** volume set in the [Minimum/Maximum Volume on page 278](#) settings, applied to the zone only when a casting service is routed to it. To set the maximum casting volume, do one of the following:

- Move the **Maximum Casting Volume** slider right to increase or left to decrease the maximum volume.
- Click the arrows to increase or decrease the maximum casting volume. Values range from 70% to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Maximum Casting Volume** field.

NOTE: If the **Maximum Casting Volume** value is higher than the regular **Maximum** volume value, the **Maximum** value will be applied instead.

2. A custom casting name (for example, "Living Room") must be entered so that a name for the zone will be displayed in the list of available casting destinations when initiating a stream. Enter this friendly name in the **Casting Name** field.

NOTE: Ensure that the **Casting Name** field is populated as any field with an asterisk (*) is mandatory.

Once Spotify Connect™ is enabled, this name will be displayed as an available destination on the casting device.

The DM-NAX-4ZSA-50 supports Spotify Connect™ casting.

To stream media to a zone on the DM-NAX-4ZSA-50 via Spotify Connect casting:

1. Ensure that the casting device and DM-NAX-4ZSA-50 are on the same network.

NOTE: If Port Selection is enabled on the DM-NAX-4ZSA-50, Spotify Connect will use the port specified for Control/Media traffic.

2. Set the **Spotify Connect** toggle to the right to enable Spotify Connect casting to the zone's associated media player.
3. On the casting device:
 - a. Open the Spotify application.
 - b. Enable Spotify Connect casting.
 - c. From the list of available casting destinations, select the DM-NAX-4ZSA-50 media player you would like to stream to. The device will cast the streaming audio to the selected media player.

NOTE: By default, media players 1-5 route to their respectively numbered output zones 1-5 if they are not already routed to any other zones when casting playback begins. For example, the audio from the media player 5 will be routed to output zone 5 if an AirPlay casting session on media player 5 starts and it is not already routed to another zone.

- d. After the Spotify Connect stream begins, control the volume of the streaming DM-NAX-4ZSA-50 output zone directly from the Spotify application on the casting device.


Set the **Spotify Connect** toggle to the left to disable Spotify Connect casting for a DM-NAX-4ZSA-50 media player.

Speaker/Faults

Speaker / Faults (Autosaved)	
DC Offset Fault	None
Over Current Fault	None
Clipping Detected	None
Over or Under Voltage	None
Over Temperature	None

The Speaker/Faults section is a read-only field that displays the status of the **DC Offset Fault**, **Over Current Fault**, **Clipping Detected**, **Over or Under Voltage**, and **Over Temperature** detectors for the zone output. If clipping or a given fault type is detected, then its corresponding readout displays **Fault Detected** in red. Otherwise, it displays **None** in blue.

Signal Generator



The DM-NAX-4ZSA-50 has a built-in signal generator that allows an integrator to send an audio signal to any number of selected zones to test output functionality.


1. To route the signal generator to the zone output, click the **Signal Generator** button so that it displays **Active** and is highlighted in blue. To unroute the signal generator on the zone output, click the **Signal Generator** button so that it displays **Inactive** and is highlighted in grey. By default, the signal generator is not routed to the zone output.

NOTES:

- There is only one signal generator built-in to the DM NAX device. Each zone has its own button to enable or disable the signal generator from passing signal to that output. Setting the signal generator to **Inactive** on a given zone output only breaks the route for that output and does not stop it from playing back in other zones.
- The **Signal Generator Volume** control is a local control that does not affect the signal generator's volume on other zone outputs. Only the settings under **Advanced Signal Generator** are applied universally to all zones of the DM NAX device.

2. To adjust the signal generator's volume, do one of the following:
 - Move the **Signal Generator Volume** slider right to increase or left to decrease the volume.
 - Click the arrows to increase or decrease the signal generator volume. Values range from 0 to 100, adjustable in increments of 1.
 - Manually enter a value in the **Signal Generator Volume** field.

Advanced Signal Generator



The advanced signal generator settings control the built-in signal generator directly, and are applied universally to all output zones of the DM NAX device. The signal type for the generator can be set, and the left and right channels of the test signal can be individually enabled or disabled.

1. Set the **Left Channel** toggle to the right position to enable the left channel of the signal. Set the toggle to the left position to disable the left channel. By default, **Left Channel** is enabled.
2. Set the **Right Channel** toggle to the right position to enable the right channel of the signal. Set the toggle to the left position to disable the right channel. By default, **Right Channel** is enabled.
3. Select an audio test signal type from the **Signal Type** drop-down menu. The available signal types are:
 - **Tone:** Generates a 1 kHz sine wave tone.
 - **Pink Noise:** Generates pink noise.
 - **White Noise:** Generates white noise.

Equalizer Settings

Equalizer Settings (Autosaved)

Speaker EQ Enabled
☒

Band	Band01	Band02	Band03	Band04	Band05	Band06	Band07	Band08	Band09	Band10
Gain	<input type="text" value="0"/> <input type="button" value="▲"/> <input type="button" value="▼"/>	<input type="text" value="0"/> <input type="button" value="▲"/> <input type="button" value="▼"/>	<input type="text" value="0"/> <input type="button" value="▲"/> <input type="button" value="▼"/>	<input type="text" value="0"/> <input type="button" value="▲"/> <input type="button" value="▼"/>	<input type="text" value="0"/> <input type="button" value="▲"/> <input type="button" value="▼"/>	<input type="text" value="0"/> <input type="button" value="▲"/> <input type="button" value="▼"/>	<input type="text" value="0"/> <input type="button" value="▲"/> <input type="button" value="▼"/>	<input type="text" value="0"/> <input type="button" value="▲"/> <input type="button" value="▼"/>	<input type="text" value="0"/> <input type="button" value="▲"/> <input type="button" value="▼"/>	<input type="text" value="0"/> <input type="button" value="▲"/> <input type="button" value="▼"/>
Type	EQ ▼	EQ ▼	EQ ▼	EQ ▼	EQ ▼	EQ ▼	EQ ▼	EQ ▼	EQ ▼	EQ ▼
Frequency	32 <input type="button" value="▲"/> <input type="button" value="▼"/>	64 <input type="button" value="▲"/> <input type="button" value="▼"/>	125 <input type="button" value="▲"/> <input type="button" value="▼"/>	250 <input type="button" value="▲"/> <input type="button" value="▼"/>	500 <input type="button" value="▲"/> <input type="button" value="▼"/>	1000 <input type="button" value="▲"/> <input type="button" value="▼"/>	2000 <input type="button" value="▲"/> <input type="button" value="▼"/>	4000 <input type="button" value="▲"/> <input type="button" value="▼"/>	8000 <input type="button" value="▲"/> <input type="button" value="▼"/>	16000 <input type="button" value="▲"/> <input type="button" value="▼"/>
Bandwidth	0.33 <input type="button" value="▲"/> <input type="button" value="▼"/>	0.33 <input type="button" value="▲"/> <input type="button" value="▼"/>	0.33 <input type="button" value="▲"/> <input type="button" value="▼"/>	0.33 <input type="button" value="▲"/> <input type="button" value="▼"/>	0.33 <input type="button" value="▲"/> <input type="button" value="▼"/>	0.33 <input type="button" value="▲"/> <input type="button" value="▼"/>	0.33 <input type="button" value="▲"/> <input type="button" value="▼"/>	0.33 <input type="button" value="▲"/> <input type="button" value="▼"/>	0.33 <input type="button" value="▲"/> <input type="button" value="▼"/>	0.33 <input type="button" value="▲"/> <input type="button" value="▼"/>
Bypass	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Actions	<input type="button" value="↶"/> <input type="button" value="Reset"/>	<input type="button" value="↶"/> <input type="button" value="Reset"/>	<input type="button" value="↶"/> <input type="button" value="Reset"/>	<input type="button" value="↶"/> <input type="button" value="Reset"/>	<input type="button" value="↶"/> <input type="button" value="Reset"/>	<input type="button" value="↶"/> <input type="button" value="Reset"/>	<input type="button" value="↶"/> <input type="button" value="Reset"/>	<input type="button" value="↶"/> <input type="button" value="Reset"/>	<input type="button" value="↶"/> <input type="button" value="Reset"/>	<input type="button" value="↶"/> <input type="button" value="Reset"/>

Each zone output of the DM-NAX-4ZSA-50 has a dedicated ten-band equalizer that can be fully customized to tune the zone output signal to the needs of an install. Each band can have a discrete gain, filter type, center frequency, and bandwidth set, and can also be bypassed. The equalizer itself can also be bypassed using the **Speaker EQ Enabled** toggle.

- Set the **Speaker EQ Enabled** toggle to the right position to enable the equalizer. Set the toggle to the left position to bypass the equalizer.

NOTE: When **Speaker EQ Enabled** is disabled, all equalizer bands are bypassed. This is a quick way to perform A/B testing of the entire EQ curve.

- With the **Speaker EQ Enabled** toggle in the right position, do the following to configure a given equalizer band:
 - To set a band's gain, do one of the following:
 - Move the **Gain** slider up to increase or down to decrease the gain.
 - Click the arrows to increase or decrease the gain. Values range from -40 dB to 20 dB, adjustable in increments of 0.1 dB.
 - Manually enter a value in the **Gain** field.

- b. Select a filter type from the **Type** drop-down menu. By default, all bands are set to the **EQ** filter type. Some filter types will disable other settings in their respective band while enabled. For example, selecting the **LowPass** filter type for a band will disable that band's **Gain** and **Bandwidth** settings, since the **LowPass** filter applies a fixed roll-off slope at a set frequency. The available filter types are:
- **EQ:** a fully parametric filter that can boost or cut a range of frequencies.
 - **Notch:** a parametric filter designed to more precisely cut a frequency or range of frequencies. A notch filter can achieve a narrower bandwidth than the standard **EQ** parametric filter type.
 - **TrebleShelf:** a filter that boosts or cuts all frequencies above a set frequency by a set gain.
 - **BassShelf:** a filter that boosts or cuts all frequencies below a set frequency by a set gain.
 - **LowPass:** a filter that fully cuts all frequencies above a set frequency using a fixed roll-off slope of -12 dB per octave.
 - **HighPass:** a filter that fully cuts all frequencies below a set frequency using a fixed roll-off slope of -12 dB per octave.
- c. Set a center frequency for the equalizer band to tune a specific portion of the audible frequency spectrum. To set the center frequency, do one of the following:
- Click the arrows to increase or decrease the frequency. Values range from 20 Hz to 20 kHz, adjustable in increments of 1 Hz. Each band has a default center frequency that will be applied if the **Reset** button at the bottom of the band is clicked.
 - Manually enter a value in the **Frequency** field.
- d. Set a bandwidth to determine how wide of a frequency range is effected by the equalizer band. To set the bandwidth, do one of the following:
- Click the arrows to increase or decrease the bandwidth. Values range from 0.1 octaves to 4.0 octaves, adjustable in increments of 0.1 octave.
 - Manually enter a value in the **Bandwidth** field.
- e. The individual Bypass controls allow you to bypass a single band of equalization at a time for more granular A/B testing of a single filter. Set a band's **Bypass** toggle to the right position to bypass that band. Set the toggle to the left position to disable the bypass. By default, **Bypass** is disabled.
- f. Each equalizer band has a **Reset** button that will reapply the default settings for that band.

Click **Done** to return to the **Settings** tab of the web user interface.

Bussing

The bussing feature on DM NAX devices allows an integrator to assign any number of selected zones to a fixed group of zones (bus). Zones in a bus track the other zones' volume and routing. For example, when the source or volume for one zone in the bus is adjusted, all other zones in that bus receive the same adjustment. You can create up to two buses on the DM-NAX-4ZSA-50.

Bus

Global Filter

Bus01

1

Room 5 (bussed), Room 5 (bussed), Room 5 (bussed), Room 5 (bussed)

Bus02

2

Choose Zones

Configure Bussing

1. If needed, enter a friendly name for each bus in its **Name** field.
2. Select any number of zones from the **Included Zones** drop-down menu.

NOTE: Each zone can be a member of only one bus. Any zones that are already a member of another bus will not be shown in the **Included Zones** drop-down.

Inputs

The **Inputs** section is used to configure the **Name**, **Compensation**, and **Mute** attributes of the available analog and digital inputs on the DM-NAX-4ZSA-50.

A total of 9 inputs are available on the DM-NAX-4ZSA-50, including the 4 physical input connectors on the device's rear panel and the 5 internal media players used for media streaming services. Only the attributes of the 4 physical inputs can be adjusted in the **Inputs** section.

The screenshot shows the 'Inputs' configuration page for the DM-NAX-4ZSA-50. It features a table for configuring four analog inputs. Each input has a 'Name' field, a 'Gain (db)' slider and numeric input, and status indicators for 'Signal Present', 'Clipping Detected', and 'Mute'.

	Office	Office	Office	Analog Input 2
Name	Office	Office	Office	Analog Input 2
Gain (db)				
Signal Present				
Clipping Detected	 Nominal	 Nominal	 Nominal	 Nominal
Mute				

Configure Inputs

1. If needed, enter a friendly name for each input in its **Name** field.
2. To set a level compensation adjustment for a given input, do one of the following:
 - Move the **Gain** slider up to increase or down to decrease the level compensation. Compensation increases or decreases the level of the incoming audio signal on any of the physical inputs on the device's rear panel.
 - Click the **db** arrows to increase or decrease the compensation. Values range from -10 dB to 10 dB, adjustable in increments of 1 dB.
 - Manually enter a value in the **Gain** field.
3. To mute the signal from the corresponding input, click the **Mute** button. To disable the mute, click the **Muted** button. By default, **Mute** is disabled.

Monitor the device's input signals using the text indicators in the **Signal Present** and **Clipping Detected** columns:

- **Signal Presence** indicates whether or not a signal is detected in that zone.
- **Clipping Detected** indicates if the signal is **Clipping** or **Nominal** (non-clipping).

DM NAX Streams

Each local input of the DM-NAX-4ZSA-50 can be made available as a DM NAX audio-over-IP stream. This includes the four physical inputs on the rear panel of the device and the five internal media players.

Click **NAX Streams** to expand the tab and display the following information.

NAX Streams

This Device is the Leader PTP Clock Source
PTP Clock Leader MAC Address 00:10:7f9c:c3:e3
PTP Priority 254

Transmitters (Autosaved)

Audio Source	Stream	Nax Stream Address	Nax Stream Name	Status	Actions
Office	Stream01	239.8.0.24	S/PDIF11c4.42.68.3fe4.59	Stream Started	▶ ■ ⚙️
Office	Stream02	239.8.0.25	TOSLINK12c4.42.68.3fe4.59	Stream Started	▶ ■ ⚙️
Office	Stream03	239.8.0.23	RCA13c4.42.68.3fe4.59	Stream Started	▶ ■ ⚙️
Analog Input 2	Stream04	0.0.0.0	RCA24c4.42.68.3fe4.59	Stream Stopped	▶ ■ ⚙️
MediaStream1	Stream05	239.8.0.18	MediaStream15c4.42.68.3fe4.59	Stream Started	▶ ■ ⚙️

- **Device is Master PTP Clock Source** indicates whether the DM NAX device's PTP clock is the master clock on the network. **Yes** will be displayed in green when the local DM-NAX-4ZSA-50's clock is the PTP master clock and **No** will be displayed in red when another PTP clock on the network is operating as the master clock.
- **Master Clock Status** displays the Master Clock ID of the device on the network that is currently acting as the master clock.
- **PTP Priority:** This sets the priority of the local DM NAX device's PTP clock relative to other clocks on the network. The default setting is 254 (one increment higher than the lowest possible value) so that the DM-NAX-4ZSA-50 will only operate as clock master if no other PTP master is present on the network. Valid values range from 1 to 255.

Configure Transmitters

Transmitters (Autosaved)					
Audio Source	Stream	Nax Stream Address	Nax Stream Name	Status	Actions
Office	Stream01	239.8.0.24	S/PDIF11c4.42.68.3fe4.59	Stream Started	▶ ⚙
Office	Stream02	239.8.0.25	TOSLINK12c4.42.68.3fe4.59	Stream Started	▶ ⚙
Office	Stream03	239.8.0.23	RCA13c4.42.68.3fe4.59	Stream Started	▶ ⚙
Analog Input 2	Stream04	0.0.0.0	RCA24c4.42.68.3fe4.59	Stream Stopped	▶ ⚙
MediaStream1	Stream05	239.8.0.18	MediaStream15c4.42.68.3fe4.59	Stream Started	▶ ⚙
MediaStream2	Stream06	239.8.0.19	MediaStream26c4.42.68.3fe4.59	Stream Started	▶ ⚙
MediaStream3	Stream07	239.8.0.20	MediaStream37c4.42.68.3fe4.59	Stream Started	▶ ⚙
MediaStream4	Stream08	239.8.0.21	MediaStream48c4.42.68.3fe4.59	Stream Started	▶ ⚙

NOTE: To configure transmitters not shown on the current page of the table, click the ▶ icon to display the next page of transmitters.

To configure a DM NAX transmit stream, do the following.

1. Enter a valid multicast address in the **NAX Stream Address** field.
2. Enter a name in the **NAX Stream Name** field by which the stream can be identified. This stream name is associated with the DM NAX stream's multicast address by other DM NAX or AES67 devices, like a device hostname that resolves to a given IP address.
3. **Status** indicates whether a stream is transmitting or not. When the stream has started or stopped, the **Status** column will update accordingly.
4. Click the configure button (⚙) in the **Actions** column. The **Configure** dialog appears:

Configure

Auto Initiation

Port

5004

✓ OK

✕ CANCEL

5. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled for a given stream, the stream will begin transmitting automatically and will be available as a multicast stream on your network at the specified multicast address.
 - If **Auto Initiation** is disabled for the input, the stream will not begin transmitting until it is manually initiated.

6. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number for DM NAX streams is 5004.
7. Click **OK** to save or click **Cancel** to cancel the changes.

Configure Receivers

Receivers (Autosaved)						
Zone Name	Stream	Current Stream Address	Requested Stream Address		Status	Actions
Room 5 (bussed)	Stream01	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Room 5 (bussed)	Stream02	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Room 5 (bussed)	Stream03	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Room 5 (bussed)	Stream04	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Zone5	Stream05	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙

1. Enter the multicast address of a transmitting stream in the **Requested Stream Address** field to subscribe the receiver to the stream.
2. Click the configure button (⚙) in the **Actions** column. The **Configure** dialog appears:

Configure

Auto Initiation

Port

5004

✓ OK


✕ CANCEL





3. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled, the stream will begin automatically when the receiver subscribes to the transmitter.
 - If **Auto Initiation** is disabled, the stream will not begin until it is manually initiated.
4. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number is 5004.
5. Click **OK** to save or click **Cancel** to cancel the changes.



Routing

The **Routing** section is used to route a local input, media player, or AES67 stream to a Zone on the DM-NAX-4ZSA-50.


NOTE: To receive an AES67 stream from Dante devices, see [OLH 1001151](#).



To route an input to a zone, click the box in the routing matrix where the zone's row overlaps the corresponding input's column. Once a route is made,  appears. To break a given route click  or . To route a single input to all zones, click on the  icon under the input's name.

Use the arrows ( or ) at the top of the matrix to change pages to view all available inputs.

To select a specific DM NAX/AES67 stream when AES67 is selected as the source for a Zone, do the following:

- Click  to display the list of all DM NAX/AES67 streams discovered on the network and click a radio button to select the corresponding stream to be routed to the zone.

	Stream Name	Network Address
<input type="radio"/>	MediaStream6147ff40efe	239.8.0.37
<input type="radio"/>	MediaStream2107ff40efe	239.8.0.41
<input type="radio"/>	RCA2600.10.7ff4.0b.8d	239.8.10.25
<input type="radio"/>	Stream0100.10.7f.9c.9b.06	239.0.14.239
<input type="radio"/>	MediaStream61400.10.7f.b5.f3.24	239.8.0.8
<input type="radio"/>	MediaStream7157ff40efe	239.8.0.38
<input type="radio"/>	MediaStream31100.10.7f.b5.f3.24	239.8.0.2
<input type="radio"/>	RCA1500.10.7ff4.0b.8d	239.8.10.24
<input type="radio"/>	MediaStream71500.10.7f.b5.f3.24	239.8.0.5
<input type="radio"/>	Stream0100.10.7f.05.23.9c	239.57.156.23

1 of 5


✓ OK

✕ CANCEL

- Click **OK** to save or click **Cancel** to cancel the changes.


Streaming Services


The DM-NAX-4ZSA-50 features five built-in media streaming players, each of which can play back a discrete media stream from a cloud-based service or local casting device. User Profiles can be created for each user of the DM NAX device with discrete credentials, enabling multiple users access to media streaming services without interfering with other users' recommendations, favorites, or playlists.




To configure Streaming Services:

- 1. Click the **+ Add User Profile** button to create a new user profile. Each user profile can contain a unique set of accounts for all supported streaming services.
- 2. Enter a name in the **Profile Name** field. Click **Save** to create the **User Profile**. Once the profile is created, you have the option to either **Delete** the profile, or add **Services** to it.
- 3. Click **Services** in the **Action** column and an **Edit Services** window appears.



4. Select from the available Streaming Services: **TIDAL™**, **Deezer®**, **Qobuz®**, **SOUNDMACHINE®**, **SiriusXM®**, **Pandora®**, **Internet Radio**, and **Podcasts**. Click  or  to add or delete the desired streaming services for each user profile.


User Authentication

User authentication is required for TIDAL, Deezer, Qobuz, SOUNDMACHINE, SiriusXM and Pandora. Click  to authorize the user.

To authenticate SiriusXM streaming:

NOTE: To determine whether to use commercial accounts, refer to the streaming service license agreement or FAQs on their respective portals. For SiriusXM, click [here](#).


Enter the user credentials and click **OK**.



To authenticate TIDAL streaming:

1. Click on the link to log in to the TIDAL portal.

NOTE: The link is valid for one minute. After one minute, the link expires, and the **Authorize URL** is shown as blank. The **Authorize User** dialogue will need to be closed and reopened.




2. Click **DONE** to return to **Streaming Services**.

To authenticate Deezer streaming:

1. Click on the link to log in to the Deezer portal.

NOTE: The link is valid for one minute. After one minute, the link expires, and the **Authorize URL** is shown as blank. The **Authorize User** dialogue will need to be closed and reopened.



2. Click **DONE** to return to **Streaming Services**.

To authenticate Qobuz streaming:

1. Click on the link to log in to the Qobuz portal.


NOTE: The link is valid for one minute. After one minute, the link expires, and the **Authorize URL** is shown as blank. The **Authorize User** dialogue will need to be closed and reopened.



2. Click **DONE** to return to **Streaming Services**.

To authenticate SOUNDMACHINE streaming:

NOTE: To determine whether to use commercial accounts, refer to the streaming service license agreement or FAQs on their respective portals. For SOUNDMACHINE, click [here](#).




1. Click the link to log in to the SOUNDMACHINE portal.


NOTE: The link is valid for one minute. After one minute, the link expires, and the **Authorize URL** is shown as blank. The **Authorize User** dialogue will need to be closed and reopened.


A screenshot of the SOUNDMACHINE login page. At the top is the "SOUNDMACHINE" logo in a colorful, stylized font. Below the logo is the text "Stream your music everywhere". Underneath that is the word "Login" in a bold, black font. There are two input fields: the first is labeled "Email" and the second is labeled "Password". Both fields have a red border. Below the input fields is a large, light gray button with the text "PLEASE ENTER YOUR CREDENTIALS" in a bold, black font.

2. Log in to the SOUNDMACHINE account.
3. Click **DONE** to return to **Streaming Services**.

To authenticate Pandora streaming:



1. Click the  icon to copy the activation code.
2. Click the link to register the device. The Device Activation page is displayed.




NOTE: The link is valid for one minute. After one minute, the link expires, and the **Authorize URL** and **Enter Code** are shown as blank. The **Authorize User** dialogue will need to be closed and reopened.

3. Paste the activation code in the **Please enter your activation code** field and click **Activate Now**.
4. Log in to the Pandora account.
5. Click **DONE** to return to **Streaming Services**.

Port Selection

The Port Selection feature allows the device's internal network traffic to be managed and segregated based on traffic type. Internal VLANs are used to segment device management and streaming service traffic to a separate physical device Ethernet port than audio-over-IP streaming traffic. With Port Selection enabled on all DM NAX devices on a network, DM NAX and AES67 network traffic can be physically separated from the control network onto a dedicated audio network.



To configure Port Selection:

1. Set the **Port Selection** toggle to the right position to enable Port Selection. Set the toggle to the left position to disable Port Selection. By default, **Port Selection** is disabled.

NOTE: Ports 1 and 2 correspond to the Ethernet adapters labeled **1** and **2** on the rear panel of the DM-NAX-4ZSA-50, respectively.

2. With **Port Selection** enabled, select an Ethernet port from the **Management** drop-down menu to designate which Ethernet port on the rear panel of the device will handle network traffic relating to device configuration, streaming services, and the device's connection to a control system.

NOTES:

- To access streaming services, the Management port must be connected to a network with internet access.
- The Management port determines your connection to the web interface. Changing the port value can result in losing your connection to the device via the web interface.

3. With **Port Selection** enabled, select an Ethernet port from the **Audio/NAX** drop-down menu to designate which Ethernet port on the rear panel of the device will handle audio-over-IP streaming network traffic.
4. Click **Save** changes to apply the new settings.

NOTE: Making changes to **Port Selection** settings will require a reboot.

Security

Click the **Security** tab to configure security for users and groups and to allow different levels of access to the DM-NAX-4ZSA-50 functions. By default, security is disabled.

✓ Status

⚙ Settings

🔒 Security

⚙ 802.1x Configuration

▼ Security

SSL Mode

Encrypt ▼

SSL Authentication

Username *

chdevice

Password *

Confirm Password *

Current User

Users

Groups

Name

admin

Access Level

Administrator

Active Directory User

No

Groups


Administrators

Change Current User Password

Select **Encrypt and Validate**, **Encrypt**, or **OFF** in the **SSL Mode** drop-down menu, to specify whether to use encryption. By default, SSL Mode is set to **OFF**.

Current User

Click the **Current User** tab to view read-only information or to change the password for the current user.




The screenshot shows a web interface with three tabs: 'Current User', 'Users', and 'Groups'. The 'Current User' tab is selected. Below the tabs, there is a table of user information:

Name	admin
Access Level	Administrator
Active Directory User	No
Groups	Administrators

Below the table, there is a blue button labeled 'Change Current User Password'.

1. Click the **Change Current User Password** button to provide a new password for the current user.
2. In the **Change Password** dialog, enter the current password in the **Current Password** field, the new password in the **Password** field, and then re-enter the same new password in the **Confirm Password** field.



The screenshot shows a 'Change Password' dialog box with a blue header and a close button (X) in the top right corner. The dialog contains three text input fields, each with a password mask (dots):


- Current Password
- Password
- Confirm Password

At the bottom right of the dialog, there are two buttons: 'OK' (with a checkmark icon) and 'Cancel' (with an X icon).

3. Click **OK** to save or click **Cancel** to cancel the changes.

Users

Click the **Users** tab to view and edit user settings. The **Users** tab can be used to add or remove local and Active Directory users and preview information about users.



Use the **Search Users** field to enter search term(s) and display users that match the search criteria.

If users listed in the **Users** table span across multiple pages, navigate through the list of users by clicking a page number or by using the left or right arrows at the bottom of the **Users** pane to move forward or backward through the pages.

Each page can be set to display 5, 10, or 20 users by using the drop-down menu to the right of the navigation arrows.

Information about existing users is displayed in table format and the following details are provided for each user.


- **Username:** Displays the name of the user.
- **AD User:** Displays whether the user requires authentication using Active Directory.

Click the corresponding button in the Actions column to view detailed user information or to delete the user.

To create a new user, click the **Create User** button.

Create a New Local User

1. Click the **Create User** button in the User tab.
2. In the **Create User** dialog, enter the following:



The screenshot shows a 'Create User' dialog box. The 'Name' field contains the text 'test'. The 'Active Directory User' toggle switch is turned off. The 'Password' and 'Confirm Password' fields are both filled with dots, indicating they are masked. The 'Groups' dropdown menu is set to 'Administrators'. At the bottom right, there are 'OK' and 'Cancel' buttons.

- a. Enter a user name in the **Name** field. A valid user name can consist of alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
- c. Assign the access level by selecting one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is disabled.

3. Click **OK** to save or click **Cancel** to cancel the changes.


Add an Active Directory User

Users cannot be created or removed from the Active Directory server, but access can be granted to an existing user in the Active Directory server.

To grant access to an Active Directory user, you can either add the user to a local group on the DM-NAX-4ZSA-50, or add the Active Directory group(s) that they are a member of to the DM-NAX-4ZSA-50.

To add an Active Directory user.

1. Click the **Create User** button.
2. In the **Create User** dialog, enter the following.




The screenshot shows a 'Create User' dialog box with a blue header bar. Inside, there is a 'Name' text field with the value 'Connects\test'. Below it is a toggle switch labeled 'Active Directory User' which is currently turned on (blue). Underneath the toggle is a 'Groups' dropdown menu showing 'Connects'. At the bottom right of the dialog are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'X' icon.

- a. Enter a user name in the **Name** field in the format "Domain\UserName", for example "crestronlabs.com\JohnSmith". Valid user names can contain alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Select one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is set to enabled.


3. Click **OK** to save or click **Cancel** to cancel the changes.

Delete User


Click the trashcan button () in the **Actions** column to delete the user. Click **Yes** when prompted to delete the user or **No** to cancel the deletion.

After a user is removed from a group, they lose any access rights associated with that group. Note that the user account is not deleted by the delete user operation.

View User Details

Click the information button () in the **Actions** column to view information for the selected user. The **User Details** dialog displays the following information for the selected user.

- **Name:** Displays the name of the selected user.
- **Active Directory User:** Displays whether the user is an Active Directory user.
- **Group:** Displays group(s) the selected user is part of.




The **User Details** dialog box shows the following information for the selected user:

Name	admin1
Active Directory User	No
Groups	Administrators

At the bottom right, there is a blue button with a checkmark and the text **OK**.

Click **OK** to close the **User Details** dialog and to return to the **Users** tab.


Update User Details



The **Update User** dialog box shows the following information for the selected user:

Name	admin1
Active Directory User	<input type="checkbox"/>
Password	<input type="password"/>
Confirm Password	<input type="password"/>
Groups	Administrators

At the bottom right, there are two blue buttons: one with a checkmark and the text **OK**, and another with an 'X' and the text **Cancel**.

1. Click the edit button () in the **Actions** column to update information for the selected user.
2. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
3. Select one or more groups to assign the user to from the **Groups** drop-down list.
4. Click **OK** to save or click **Cancel** to cancel the changes.

The **Update User** dialog also displays the following read-only information for the selected user.

- **Name:** Displays the name of the user.
- **Active Directory User:** Displays whether the user is an Active Directory user.











Groups

Click the **Groups** tab to view and edit group settings. The **Groups** tab can be used to add local and Active Directory groups, remove local and Active Directory groups, and preview information about a group.

Use the **Search Groups** field to enter search term(s) and display groups that match the search criteria.

Current UserUsersGroups

Search...

Group Name	AD Group	Access Level	Actions
Administrators	No	Administrator	 
Connects	No	Connect	 
Operators	No	Operator	 
Programmers	No	Programmer	 
Users	No	User	 

<<<1>>>

10



Create Group

If groups listed in the **Groups** table span across multiple pages, navigate through the groups by clicking a page number or by using the left or right arrows at the bottom of the Groups pane to move forward or backward through the pages.

Additionally, each page can be set to display 5, 10, or 20 groups by using the drop-down menu to the right of the navigation arrows.


Existing groups are displayed in a table and the following information is provided for each group:

- **Group Name:** Displays the name of the group.
- **AD Group:** Displays whether the group requires authentication using Active Directory.
- **Access Level:** Displays the predefined access level assigned to the group (Administrator, Programmer, Operator, User, or Connect).

Click the corresponding button in the **Actions** column to view detailed group information () or to delete () selected group.

Click on the **Create Group** button in the **Groups** tab to create new group.

Create Local Group



The 'Create Group' dialog box has a blue title bar with a close button. It contains three fields: 'Name' with the text 'test12', 'Access Level' with a dropdown menu showing 'Programmer', and 'Active Directory Group' with a disabled toggle switch. At the bottom right are 'OK' and 'Cancel' buttons.


1. Click the **Create Group** button.
2. In the **Create Group** dialog, enter the following:
 - a. Enter the group name in the **Name** field.
 - b. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is disabled.

3. Click **OK** to save. Click **Cancel** to cancel the changes.

Add Active Directory Group

A group cannot be created or removed from the Active Directory server, but access can be granted to an existing group in Active Directory.



The 'Create Group' dialog box has a blue title bar with a close button. It contains three fields: 'Name' with the text 'test', 'Access Level' with a dropdown menu showing 'Administrator', and 'Active Directory Group' with an enabled toggle switch. At the bottom right are 'OK' and 'Cancel' buttons.

Once the group is added, all members of that group will have access to the DM-NAX-4ZSA-50.


1. Click the **Create Group** button.
2. In the **Create Group** dialog enter the following:
 - a. Enter the group name in the **Name** field, for example "Engineering Group". Note that group names are case sensitive; a space is a valid character that can be used in group names.

3. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is enabled.


4. Click **OK** to save. Click **Cancel** to cancel the changes.


Delete a Group

Click the trashcan button () in the **Actions** column to delete a group. Click **Yes** when prompted to delete the group or **No** to cancel the deletion.

When a group is deleted, users in the group are not removed from the device or Active Directory server. However, because a user's access level is inherited from a group(s), users within the deleted group will lose access rights associated with the group.

View Group Details

Click the information button () in the **Actions** column to view information for the selected group. The **Group Details** dialog lists the following information for the selected group.



The **Group Details** dialog box displays the following information:

Name	Administrators
Access Level	Administrator
Active Directory Group	No

At the bottom right, there is a blue button with a checkmark and the text **OK**.

- **Name:** Displays the name of the group.
- **Access Level:** Displays the access level of the group and its users.
- **Active Directory Group:** Displays whether the group is an Active Directory group.

Click **OK** to close the **Group Details** dialog and to return to the Groups tab.

802.1x Configuration

The DM-NAX-4ZSA-50 has built-in support for the 802.1X standard (an IEEE network standard designed to enhance the security of wireless and Ethernet LANs. The standard relies on the exchange of messages between the device and the network's host, or authentication server), allowing communication with the authentication server and access to protected corporate networks.

StatusSettingsSecurity802.1x Configuration

802.1x Configuration

IEEE 802.1x Authentication

Authentication MethodEAP MSCHAP V2- password

Domainsecure12

Usernameadmin

Password

Enable Authentication Server Validation

Select Trusted Certificate Authority(ies)

☐

AAA Certificate Services

☐

AC RAIZ FNMT-RCM

☐

ACCVRAIZ1

☐

Actalis Authentication Root CA

☒

AffirmTrust Commercial

☐

AffirmTrust Networking

☐

AffirmTrust Premium ECC

☒

AffirmTrust Premium

☐

Amazon Root CA 1

☐

Amazon Root CA 2

☒

Amazon Root CA 3

☐

Amazon Root CA 4

☐

Atos TrustedRoot 2011

☐

Autoridad de Certificacion Firmaprofesional CIF A62634068

☐

Baltimore CyberTrust Root

To Configure DM-NAX-4ZSA-50 for 802.1X Authentication

1. Set the **IEEE 802.1X Authentication** toggle to enabled. This will enable all options on the 802.1X dialog.
2. Select the **Authentication method: EAP-TLS Certificate** or **EAP-MSCHAP V2 Password** according to the network administrator's requirement.
3. Do either one of the following:
 - Select **EAP-TLS Certificate**, click **Action/Manage Certificates** to upload the required machine certificate. The machine certificate is an encrypted file that will be supplied by the network administrator, along with the certificate password.
 - Select **EAP-MSCHAP V2 Password**, enter the username and password supplied by the network administrator into the **Username** and **Password** fields. This method does not require the use of a machine certificate, only the user name and password credentials.
4. If you enabled the **Enable Authentication Server Validation** option, this will enable the **Select Trusted Certificate Authority(ies)** list box which contains signed Trusted Certificate Authorities (CAs) preloaded into the DM-NAX-4ZSA-50.

Select the check box next to each CA whose certificate can be used for server validation, as specified by the network administrator.

If the network does not use any of the listed certificates, the network administrator must provide a certificate, which must be uploaded manually via the **Manage Certificates** functionality.
5. If required, type the domain name of the network in the **Domain** field.
6. When the 802.1X settings are configured as desired, click **Save Changes** to save the changes to the device and reboot it. Click **Revert** to cancel any changes.

Access the Web Interface With the Crestron Toolbox™ Application

To access the web interface by opening a web browser within the Crestron Toolbox™ application, do the following:

1. Open the Crestron Toolbox application.
2. From the **Tools** menu, select **Device Discovery Tool**. You can also access the Device Discovery Tool by clicking the Device Discovery Tool button () in the Crestron Toolbox toolbar. The DM-NAX-4ZSA-50 is discovered and listed in the device list on the left side of the screen. The associated host name, IP address, and firmware version are also displayed.

NOTE: If there is security software running on the computer, a security alert might be displayed when the Crestron Toolbox application attempts to connect to the network. Make sure to allow the connection, so that the Device Discovery Tool can be used.

3. In the Device Discovery Tool list, double-click your device.
4. Enter your credentials in the **Authentication Required** dialog that opens, and then click **Log In**.
5. Click the **Web Configuration** button in the Configuration page displayed on the left side of the Device Discovery Tool.

DM-NAX-4ZSP

This section describes how to configure DM-NAX-4ZSP.

Web Interface Configuration

The DM-NAX-4ZSP web interface allows you to view status information and configure network and device settings.

Access the Web Interface

To access the web interface, do either of the following:

- [Access the Web Interface with a Web Browser on page 315](#)
- [Access the Web Interface With the Crestron Toolbox™ Application on page 374](#)

The web interface is accessed from a web browser. The following table lists operating systems and their corresponding supported web browsers.

Operating System and Supported Web Browsers


OPERATING SYSTEM	SUPPORTED WEB BROWSERS
Windows® operating system	Chrome™ web browser, version 31 and later
	Firefox® web browser, version 31 and later
	Internet Explorer web browser, version 11 and later
	Microsoft Edge web browser
macOS® operating system	Safari® web browser, version 6 and later
	Chrome web browser, version 31 and later
	Firefox web browser, version 31 and later

Access the Web Interface with a Web Browser

1. Enter the IP address of the DM-NAX-4ZSP into a web browser.


NOTE: To obtain the IP address, use the **Device Discovery Tool** option in Crestron Toolbox™ application or an IP scanner application.

2. If you are creating a user account for the first time, do the following; otherwise, skip to step 3.
 - a. Enter a username in the **Username** field.
 - b. Enter a password in the **Password** field.
 - c. Re-enter the same password in the **Confirm Password** field.



The screenshot shows the Crestron logo at the top left. Below it, a yellow warning triangle icon is followed by the text "DEVICE FIRST BOOT". In the center, there is a white box titled "Device Administration". Inside this box, there are three input fields: "Username", "Password", and "Confirm Password". Below these fields is a green button with a white plus icon and the text "Create User". At the bottom of the white box, there is small text: "© 2021 Crestron Electronics, Inc.", "Privacy Statement", and "Crestron Software End-User License Agreement".

- d. Click **Create User**. The Device Administration page appears.




The screenshot shows the same Crestron logo at the top left. Below it, the "DEVICE FIRST BOOT" message is no longer present. The white box titled "Device Administration" still contains the "Username" and "Password" input fields. Below these fields is a blue button with a white magnifying glass icon and the text "Sign In". At the bottom of the white box, the same small text is present: "© 2021 Crestron Electronics, Inc.", "Privacy Statement", and "Crestron Software End-User License Agreement".

3. Enter the username in the **Username** field.
4. Enter the password in the **Password** field.
5. Click **Sign In**.

Action

The **Action** drop-down menu is displayed at the top right side of the interface and provides quick access to common device functions:

- Save Changes
- Revert
- Reboot
- Restore
- Update Firmware
- Download Logs
- Manage Certificates
- Manage Audio Profiles
- Download Configuration
- Upload Configuration



Save Changes

Click **Save Changes** to save any changes made to the configuration settings.


Revert

Click **Revert** to revert the device back to the last saved configuration settings.

Reboot the DM-NAX-4ZSP

Certain changes to the settings may require the DM-NAX-4ZSP to be rebooted to take effect. To reboot the device, do the following:

1. Click **Reboot** in the **Actions** drop-down menu. The **Confirmation** message box appears.




2. Click **Yes, Reboot Now** to reboot the device. The **Reboot** message box appears. Wait for the device reboot to complete before attempting to reconnect to the device.

Restore to Factory Default Settings

1. Click **Restore** in the **Actions** drop-down menu to restore the settings of the DM-NAX-4ZSP to factory defaults.

NOTE: When settings are restored, all settings, including the network settings, will revert to the factory default. If a static IP address is set, restoring the device to factory default settings will revert the IP address to the default DHCP mode.




2. Click **Yes** in the **Confirmation** dialog to restore the DM-NAX-4ZSP to factory settings. Click **No** to cancel the restore operation.

A dialog is displayed again, indicating that the restore process was successful and that the device rebooted.

You can also restore to factory settings by pressing and holding the **SETUP** button on the rear panel of the device with power disconnected then connect the power supply and continue to hold **SETUP** button for 30 seconds.

Update Firmware

1. Click **Update Firmware** in the **Actions** drop-down menu.
2. In the **Firmware Upgrade** dialog, click **+ Browse**.



3. Locate and select the desired firmware file, and then click **Open**. The selected firmware file name is displayed in the **Firmware Upgrade** dialog.
4. Click **Load** and wait for the progress bar to complete and for the **OK** button in the message to become clickable.
5. Click **OK**. The device with new firmware can now be accessed.


Download Logs

1. Click **Download Logs** in the **Actions** drop-down menu to download the device message logs for diagnostic purposes.

The log file is downloaded to the Downloads folder of the PC.

Manage Certificates

Use the **Manage Certificates** dialog to add, remove, and manage certificates used in 802.1x and other protected networks.



1. Click **Manage Certificates** in the **Actions** drop-down menu. The following certificate tabs are displayed:
 - **Root:** The Root certificate is used by the DM-NAX-4ZSP to validate the network's authentication server. The DM-NAX-4ZSP has a variety of Root certificates, self-signed by trusted CAs (Certificate Authorities) preloaded into the device. Root certificates must be self-signed.
 - **Intermediate:** The Intermediate store holds non self-signed certificates that are used to validate the authentication server. These certificates will be provided by the network administrator if the network does not use self-signed Root certificates.
 - **Machine:** The machine certificate is an encrypted PFX file that is used by the authentication server to validate the identity of the DM-NAX-4ZSP. The machine certificate will be provided by the network administrator, along with the certificate password. For 802.1x, only one machine certificate can reside on the device.
 - **Web Server:** The Web Server certificate is a digital file that contains information about the identity of the web server.


To Add Certificates

1. Click the corresponding certificate tab.
2. Click the **Add Root Certificate** button.
3. Click the **+ Browse** button.
4. Locate and select the file, and then click the **Open** button.

NOTE: If the certificate is a Machine Certificate, enter the password provided by the network administrator.


5. Click **OK**. This will add the certificate to the list box, displaying the file name and expiration date. The certificate is now available for selection and can be loaded to the device.

To Delete Certificates

1. Click the corresponding certificate tab.
2. Click the trashcan button () in the **Actions** column to delete the certificate.
3. Click **Yes** when prompted to delete the certificate or **No** to cancel the deletion.

Manage Audio Profiles

Use the **Manage Audio Profiles** dialog to add, remove, and manage the audio profiles of speakers.




Click **Manage Audio Profiles** in the **Actions** drop-down menu. The following audio profiles tabs are displayed, providing information such as **Model**, **Manufacturer**, and **Type** of the speaker profiles:

- **Default Profiles:** Lists the default library of included speaker profiles.
- **User Profiles:** Lists the custom, user loaded profiles, and allows them to be loaded and removed.

In the **Search** field, enter the speaker's profile name to search for the profile. The speaker profile matching the search criteria is displayed.

NOTE: To create a custom speaker profile, see [OLH 1001820](#).


To Add a Speaker Profile



1. Click the **User Profiles** tab.
2. Click the **+ Add Profiles** button.
3. Click the **+ Browse** button.
4. Locate and select the .prof file, and then click the **Open** button.
5. Click the **Upload** button.
6. Click **OK**. This will add the profile to the list box.

The speaker profile is now available for selection and can be applied to the speaker.

To Delete a Speaker Profile



1. Click the **User Profiles** tab.
2. Select the checkbox corresponding to the audio profile that needs to be deleted.
3. Click **Delete Profile** button.

The speaker profile is deleted.

Download Configuration

Click **Download Configuration** to download a TGZ file containing the settings data for the DM NAX device.


NOTE: User accounts for accessing the device, streaming service accounts, multicast addresses, and stream names are not saved in this configuration file.

Upload Configuration


1. Click **Upload Configuration** to upload a TGZ file that will overwrite the current settings of the DM NAX device with a saved configuration.

CAUTION: Be sure to load a TGZ file for the same DM NAX device type while using the Load Configuration feature. For example, if loading a TGZ file to a DM-NAX-16AIN, be sure that the TGZ file originated from a DM-NAX-16AIN.


2. Click **Browse** to navigate to the desired TGZ file in your file browser. Double-click the file or highlight it and click **Open**.



3. Click **Upload** to begin the file upload process. A progress bar will indicate the status of the configuration file upload.



4. Once the upload is complete, the device will require a reboot. Click **Yes, Reboot Now** to begin the reboot, or click **No** to return to the web UI.




NOTE: Any changes made after the configuration file upload, but before a device reboot, may be overwritten when the device is rebooted.

Status

The **Status** tab is the first page displayed when opening the interface of the DM-NAX-4ZSP. It displays general information about the DM-NAX-4ZSP (such as Model Name, Firmware Version, and Serial Number), current network settings (such as Host Name and IP Address, etc.), and input and output ports' current status.


The Status tab can be accessed at any time by clicking the **Status** tab of the DM-NAX-4ZSP interface.



Information displayed on the **Status** tab is organized into different sections.

Device

The **Device** section displays the **Model**, **Firmware Version**, and **Serial Number** of the DM-NAX-4ZSP.



Click **+ More Details** to review additional information about the DM-NAX-4ZSP.

- More Details	
DM-NAX-4ZSP	0.5154.23582
Build	Feb 11 2022 (449289)
Updater	0.5154.23582
Bootloader	0.04.00
CCUI Version	1.602.877345
XIOSDK	3.8.0
IoTSDK	1.6.0
Build time	00:18:24
Product ID	0x7AFF
Revision ID	0x0400
ctrl-audio-dsp-0	FW v38 (Driver v3.9)
ctrl-audio-dsp-1	FW v38 (Driver v3.9)
ctrl-audio-fpga	FW v0.25 (Driver v1.2)
ctrl-sigma-dsp-0	FW v1.00 (Driver v1.1)
ctrl-sigma-dsp-1	FW v1.00 (Driver v1.1)
ctrl-hps-fpga	FW v1.20.2433093 (Driver v2.1)
PUF	Unknown
Forced Auth Mode	True

Network

The **Network** section displays network-related information about the DM-NAX-4ZSP, including the Hostname, Domain Name, and DNS Servers.

▼ Network	
Hostname	DM-NAX-4ZSP-00107FF455C9
Domain Name	crestronqelab.com
Primary Static DNS	10.254.64.12(DHCP)
Secondary Static DNS	192.168.200.133(DHCP)
- Adapter 1	
DHCP	On
IP Address	10.254.68.109
Subnet Mask	255.255.255.0
Default Gateway	10.254.68.1
Link Active	true
MAC Address	00:10:7f:f4:55:c9

NOTE: By default, the host name of the DM-NAX-4ZSP consists of the model name followed by the MAC address of the device. For example, DM-NAX-4ZSP-00107FF455C9.

Click **+ Adapter 1** to display an expanded section that shows additional information. If **+ Adapter 1** is selected, click **- Less** details to collapse the section.

NOTE: The + **Adapter 2** option appears when the dual Ethernet ports on the DM-NAX-4ZSP are set to isolate traffic using the Port Selection feature.

Control System

The **Control System** section displays connection information, consisting of the following:

The screenshot shows the 'Control System' section of a web interface. At the top, there is a toggle for 'Encrypt Connection' set to 'OFF'. Below this is a section titled 'IP Table' which contains a table with the following columns: IP ID, Room ID, IP Address/Hostname, Type, Server Port, Connection, and Status. The table is currently empty, displaying 'No records found'.

IP ID	Room ID	IP Address/Hostname	Type	Server Port	Connection	Status
No records found						

- **Encrypt Connection:** ON or OFF
- **IP ID:** Reports the currently used IP ID of the DM-NAX-4ZSP
- **IP Address/Hostname:** The IP address of the control system
- **Room ID:** Displays the room ID
- **Status:** OFFLINE or ONLINE

Settings

The **Settings** tab enables you to configure the DM-NAX-4ZSP settings. The Settings page can be accessed at any time by clicking the **Settings** tab of the DM-NAX-4ZSP interface.




Settings available on the **Settings** tab are organized into different sections.

System Setup

The **System Setup** section contains settings for **Date/Time**, **Auto Update**, **Network**, and **Control System**.

Date/Time

Use the **Date/Time** section to configure the date and time settings of the DM-NAX-4ZSP.



Time Synchronization

1. Set the **Time Synchronization** toggle to the right position to enable or left position to disable time synchronization. By default, time synchronization is enabled.
2. In the **NTP Time Servers** table, enter the URL of a NTP (Network Time Protocol) or SNTP (Simple Network Time Protocol) server. Up to three time servers can be added on a device.
3. Click **Synchronize Now** to perform time synchronization between the device's internal clock and the time server.

Time Configuration


1. Click on the **Time Zone** drop-down menu to select the applicable time zone.
2. In the **Date** field, enter the current date.
3. In the **Time (24hr Format)** field, enter the current time in 24-hour format.

Click the **Save Changes** button to save the settings.

Click **Revert** from the **Actions** drop-down menu to revert to the previous settings without saving.

Auto Update

The DM-NAX-4ZSP can automatically check for and install firmware updates at scheduled intervals via the Auto Update feature.



The screenshot shows the 'Auto Update' configuration page. At the top left is a minus sign followed by the text 'Auto Update'. The main area contains several settings: 'Auto Update' is a green toggle switch in the 'on' position; 'Custom URL' is a grey toggle switch in the 'off' position; 'Custom URL Path' is a text input field containing 'https://crestrondevicefiles.blob.core.winc'; 'Schedule' is a section header on the left; 'Day of Week' is a dropdown menu set to 'Daily'; 'Time of Day' is a text input field set to '02:29'; 'Poll Interval' is a text input field set to '0' with 'Minutes' to its right; and at the bottom right is a blue button labeled 'Update Now'.

1. Set the **Auto Update** toggle to the right position to enable Auto Update.
2. Define the URL to download the updates by doing either of the following:
 - a. Use the default URL to download the updates from the Crestron server.
 - b. Use a custom URL. Set the **Custom URL** toggle to the right position to enable a custom URL. In the **Custom URL Path** text box, enter the path to a custom manifest file in the FTP or SFTP URL format. Use the Crestron Auto Update Tool to generate a custom manifest file, then store the file on an FTP (File Transfer Protocol) or SFTP (Secure File Transfer Protocol) server.
3. Set a schedule for the automatic firmware update by doing either of the following:
 - a. Select the desired **Day of Week** and **Time of Day** (24-hour format) values.
 - b. Set the **Poll Interval** by entering a value from **60** to **65535** minutes. A value of **0** disables the Poll Interval.
4. Click **Save Changes**.

Clicking **Update Now** causes the device to check for a firmware update immediately. If a schedule was set in step 4 above, that schedule still remains in effect.

Network

The **Network** section contains network-related settings for the DM-NAX-4ZSP, including the Hostname, Domain, Primary Static DNS, and Secondary Static DNS.

▼ Network

Hostname	DM-NAX-4ZSP-00107FF455C9
Domain Name	crestronqelab.com
Primary Static DNS	10.254.64.12(DHCP)
Secondary Static DNS	192.168.200.133(DHCP)

— Adapter 1

DHCP	On
IP Address	10.254.68.109
Subnet Mask	255.255.255.0
Default Gateway	10.254.68.1
Link Active	true
MAC Address	00.10.7f.f4.55.c9

NOTE: By default, the hostname of the DM-NAX-4ZSP consists of the model name followed by the MAC address of the device. For example, DM-NAX-4ZSP-00107FB58088.

Adapter 1

The Adapter 1 subheading contains settings for DHCP, IP Address, Subnet Mask, and Default Gateway of Ethernet adapter 1 on the rear panel of the device.

NOTES:

- An **+ Adapter 2** option only appears when the dual Ethernet ports on the DM-NAX-4ZSP are set to isolate traffic using the Port Selection feature. The settings for Adapter 2 are identical to those available for Adapter 1.
- DM NAX devices' internal processes use IP addresses in the 10.10.10.xxx range. This IP range should be avoided when addressing DM NAX devices to prevent conflicts.

Set the **DHCP** toggle to enabled (right) or disabled (left) to specify whether the IP address of the DM-NAX-4ZSP is to be assigned by a DHCP (Dynamic Host Configuration Protocol) server.

- **Enabled:** When DHCP is enabled (default setting), the IP address of the DM-NAX-4ZSP is automatically assigned by a DHCP server on the local area network (LAN).
- **Disabled:** When DHCP is disabled, manually enter information in the following fields:
 - **Primary Static DNS:** Enter a primary DNS IP address.
 - **Secondary Static DNS:** Enter a secondary DNS IP address.
 - **IP Address:** Enter a unique IP address for the DM-NAX-4ZSP.
 - **Subnet Mask:** Enter the subnet mask that is set on the network.
 - **Default Gateway:** Enter the IP address that is to be used as the network's gateway.

To save any new network entries, click **Save Changes**.

Control System

Control System

Encrypt Connection

IP Table

<input type="checkbox"/>	IP ID	IP Address/Hostname	Room ID
<input type="checkbox"/>	12	10.88.17.15	23
<input type="checkbox"/>	13	10.88.87.13	23
<input type="checkbox"/>	99	10.88.12.17	22
<input type="checkbox"/>	8B	CP4-R-00107FB9E0CC	Room ID

+ Add

✕ Remove

1. Click the **Encrypt Connection** button to navigate to the **Security** tab to configure encryption settings.
2. Enter the username in the **Control System Username** field.
3. Enter the password in the **Control System Password** field.
4. Enter the Room ID in the **Room ID** field.
5. Enter the IP ID of the DM-NAX-4ZSP in the **IP ID** field.
6. Enter the IP address or hostname of the control system in the **IP Address/Hostname** field.
7. Click the **Save Changes** button to save the new entries. The Control System Save message box appears, indicating that the control system settings were saved successfully. Click the **Revert** button to revert to the previous settings without saving.

Commissioning

The **Commissioning** section provides a quick way to automatically assign multicast addresses to all of the device's internal audio-over-IP stream transmitters.

Commissioning

Starting Multicast Address

239.8.3.5

Last Used Multicast Address

239.8.3.36


Assign Addresses

Click **Assign Addresses** to give each DM NAX transmitter in the DM-NAX-4ZSP a unique multicast address beginning with the specified **Starting Multicast Address**. The valid range for **Starting Multicast Address** is 239.8.0.0 to 239.255.255.239.

NOTE: This will begin transmitting multicast traffic on your network, refer to the [DM NAX Audio-over-IP System Design Guide](#) document for details.


Chimes


The **Chimes** section allows the built-in chime files to be assigned to any of the output zones on the device.



For each chime file, click the cells corresponding to the desired Zones for playback of that specific chime sound. You can assign multiple chimes to the same zone. To view all available chimes, use the ▲ or ▼ arrows at the left of the matrix to change pages.

To configure the chime volume of a zone:

1. Click the  icon corresponding to the zone. A **Configure** window appears.















2. To set the volume, do one of the following:
 - Move the **Volume** slider to the right to increase or to the left to decrease the chime volume.
 - Click the % arrows to increase or decrease the chime volume. Values range from 0 to 100%, adjustable in increments of 1%.
 - Manually enter a value in the **Volume** field.

NOTE: The chime volume is independent of the zone volume control.

3. Set the **Do Not Disturb** toggle to the right to mute all chimes for the zone. Set the **Do Not Disturb** toggle to the left to unmute the chimes.
4. Click **OK** to apply the new settings.

Zones

The **Zones** section contains the **Volume** and **Mute** settings for all zone outputs of the device, as well as a Configure option for more advanced settings within each zone.

Zones				
Zones (Autosaved)				
Global Filter <input type="text"/>				
Name	Volume	Mute	Action	
Zone_01	 30 %	 Mute		
Zone_02	 30 %	 Mute		
Zone_03	 30 %	 Mute		
Zone_04	 30 %	 Mute		

Give each zone a friendly name using the **Name** column of the **Zones** table. If the device is paired with a control system, these names may be overwritten by the control system's program.


To configure the zone volume, do one of the following:

- Move the **Volume** slider to the right to increase or to the left to decrease the zone volume.
- Click the % arrows to increase or decrease the zone volume. Values range from 0 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Volume** field.

To mute all audio output from a zone, click its respective **Mute** button. To unmute the zone, click the **Muted** button.


Zone Settings

To configure zone settings, click the **Configure** button ( **Configure**). The **Edit Zone** window appears.




Zone

Click **Zone** to configure **Tone (Autosaved)**, **Balance (Autosaved)**, and **Delay (Autosaved)**.



Tone




The **Tone** section provides adjustments for the **Tone Profile**, **Bass**, **Treble**, **Loudness**, and **Night Mode** settings of the zone output.

NOTE: The Tone Profile, Bass, Treble, and Loudness settings in the Tone section are all applied separately from the Equalizer Settings for the zone. This means that any adjustments made in the Tone section will stack with those made in the Equalizer Settings section.

1. To select a tone profile preset for the zone, select an option from the **Tone Profile** drop-down menu. The available options are **Off**, **Classical**, **Jazz**, **Pop**, **Rock**, and **Spoken Word**. By default, **Off** is selected.
2. **Bass:** To adjust the bass, do one of the following:
 - Move the **Bass** slider to the right to increase or to the left to decrease the bass.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of 1 db.
 - Manually enter a value in the **Bass** field.
3. **Treble:** To adjust the treble, do one of the following:
 - Move the **Treble** slider to the right to increase or to the left to decrease the treble.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of 1 db.
 - Manually enter a value in the **Treble** field.
4. To enable the loudness setting on the zone output, slide the **Loudness** switch to the right. To disable loudness, slide the **Loudness** switch to the left.
5. The **Night Mode** feature applies subtle processing to restrict the dynamic range of the zone audio, to allow for lower listening levels at night or in rooms where higher listening levels would be disruptive. To select a dynamics processing level, select an option from the **Night Mode** drop-down menu. The available options are **Off**, **Low**, **Medium**, and **High**. By default, **Off** is selected.

Balance



To adjust the left/right balance of the stereo output signal, do one of the following:

- Move the **Balance** slider to the right to shift the stereo balance to the right channel or to the left to shift the balance to the left.

- Click the arrows to adjust the balance left or right. The up arrow shifts the balance to the right while the down arrow shifts the balance to the left.
- Manually enter a value in the **Balance** field. Values range from -50 to 50, adjustable in increments of 1. Positive values shift the balance to the right while negative values shift the balance to the left.

Delay

Delay (Autosaved)

Delay Time(ms) ms

To set the delay, do one of the following:

- Move the **Delay Time(ms)** slider to the right to increase or to the left to decrease the delay time.
- Click the **ms** arrows to increase or decrease the delay. Values range from 0 ms to 250 ms, adjustable in increments of 1 ms.
- Manually enter a value in the **Delay Time(ms)** field.

Output

Click **Output** to access the settings for **Minimum/Maximum Volume, Stereo/Mono, Signal, Bussing Volume Offset, Configure Speaker Profile, Speaker Configuration, Casting, Line Out, Signal Generator, Advanced Signal Generator, and Equalizer Settings.**

Output

Minimum / Maximum (Autosaved)

Minimum %

Maximum %

Default %

Stereo / Mono (Autosaved)

Stereo / Mono ☒ Stereo ☐ Mono

Zone Configuration

Signal (Autosaved)

Signal Not Present

Minimum/Maximum Volume

Minimum / Maximum (Autosaved)

Control	Value	Unit
Minimum	14	%
Maximum	86	%
Default	27	%


1. To set the minimum volume of the zone, do one of the following:
 - Move the **Minimum** slider to the right to increase or to the left to decrease the minimum volume.
 - Click the **%** arrows to increase or decrease the minimum volume. Values range from 0 to 50%, adjustable in increments of 1%.
 - Manually enter a value in the **Minimum** field.
2. To set the maximum volume of the zone, do one of the following:
 - Move the **Maximum** slider to the right to increase or to the left to decrease the maximum volume.
 - Click the **%** arrows to increase or decrease the maximum volume. Values range from 70 to 100%, adjustable in increments of 1%.
 - Manually enter a value in the **Maximum** field.

NOTE: When a **Minimum** and **Maximum** volume are set, the 1-100% range represented by the **Zone** and **Default** volume controls are scaled to the range set. For example, if a **Minimum** of 10% and a **Maximum** of 80% are set for a zone, the 1-100% range of the **Zone** volume control is scaled to the 10%-80% range set as the **Minimum** and **Maximum**.

3. To set the default volume of the zone, do one of the following:
 - Move the **Default** slider to the right to increase or to the left to decrease the default volume.
 - Click the **%** arrows to increase or decrease the default volume. Values range from 0 to 50%, adjustable in increments of 1%.
 - Manually enter a value in the **Default** field.

NOTE: The **Default** volume is applied as the **Zone** volume any time the zone receives a source route and no source was previously routed to that zone.

Stereo/Mono

The screenshot shows a control panel for the Stereo/Mono setting. At the top, it says "Stereo / Mono (Autosaved)". Below this, there are two radio buttons: "Stereo" (which is selected) and "Mono". To the right of these is a dropdown menu labeled "Zone Configuration" with "Standard" selected.

1. Select either **Stereo** or **Mono** from the **Stereo/Mono** field.

NOTE: The **Zone Configuration** field is reserved for future use on the DM-NAX-4ZSP. Currently, the only available value is **Standard**.

Signal

The screenshot shows a read-only display for the Signal status. It has two lines of text: "Signal" followed by "Not Present" in red, and "Clipping" followed by "None" in green.

The **Signal** section is a read-only field that displays the **Signal** and **Clipping** status of the zone output.

- If an output signal is present but not clipping, **Signal** will display **Present** in green and **Clipping** will display **None** in green.
- If an output signal is present and clipping, **Signal** will display **Present** in green and **Clipping** will display **Present** in red.
- If no output signal is detected, **Signal** will display **Not Present** in red and **Clipping** will display **None** in green.

Bussing Volume Offset

The screenshot shows a control panel for the Bussing Volume Offset. At the top, it says "Bussing Volume Offset (Autosaved)". Below this is a slider control with a blue knob. To the right of the slider is a numeric field showing "0" and a unit selector with "db" selected.

Bussing Volume Offset is an additional level compensation applied to the zone relative to any other zones it is grouped with via the **Bussing** feature.

To set the bussing volume offset, do one of the following:

- Move the **Bussing Volume Offset** slider to the right to increase or to the left to decrease the offset.
- Click the **db** arrows to increase or decrease the offset. Values range from -12 dB to 12 dB, adjustable in increments of 1 dB.
- Manually enter a value in the **Bussing Volume Offset** field.

Configure Speaker Profile

The DM-NAX-4ZSP has a library of built-in speaker profiles that contain equalizer and maximum output level settings specific to Crestron and third-party speaker models. Custom speaker profiles can also be generated and loaded to the DM-NAX-4ZSP. The **Configure Speaker Profile** field is used to apply these speaker profiles to a given zone of the DM NAX device.

NOTE: Applying a speaker profile on a zone will overwrite the existing **Speaker Configuration** and **Equalizer** settings for that zone.

Applied Manufacturer Crestron

Applied Model SAROS ICE4

Global Filter

	Model	Manufacturer
<input type="radio"/>	Air LS4	Crestron
<input type="radio"/>	Air LS6	Crestron
<input type="radio"/>	Air SR4	Crestron
<input type="radio"/>	Air SR6	Crestron
<input type="radio"/>	Air SR8	Crestron

1 of 9

Apply

In the **Global Filter** field, enter the speaker's model name to search for its associated profile. Any speaker profiles matching the search criteria are displayed.

To apply a speaker profile:


- 1. Select the radio button corresponding to the speaker profile.
- 2. Click **Apply**.

The equalizer, impedance, and speaker protection settings of the zone are updated as per the applied speaker profile.

After applying a speaker profile, the **Speaker Configuration** and **Equalizer** settings for the zone can still be edited. The **Configure Speaker Profile** section will display a notification if these settings were altered after the speaker profile was applied.

 Profile settings have been locally altered

Speaker Configuration



Speaker Configuration (Autosaved)


Enable Speaker Protect ☒

Speaker Wattage 40 Watts

Impedance

1. Set the **Enable Speaker Protect** toggle to the right position to enable speaker protection for the zone output. Set the toggle to the left position to disable speaker protection. By default, **Enable Speaker Protect** is set to the left position.
2. To set the maximum output wattage, do one of the following:
 - Move the **Speaker Wattage** slider to the right to increase or to the left to decrease the maximum peak amplifier wattage that can be output to the speaker.
 - Click the **Watts** arrows to increase or decrease the maximum peak amplifier wattage that can be output to the speaker. Values range from 5 W to 150 W, adjustable in increments of 1 W.
 - Manually enter a value in the **Speaker Wattage** field.
3. Select the impedance of the speaker on a selected zone from the **Impedance** drop-down menu. Values are **4 Ohms**, **8 Ohms**, and **Bridged**.

Casting



— Casting (Autosaved)

Maximum Casting Volume 80 %

Casting Name *

AirPlay ☒

Spotify ☒

The Casting section is used to enable or disable the ability of third-party devices to cast audio to the DM NAX output zone, as well as set a maximum casting volume and friendly name for the zone.

To configure Casting:

1. **Maximum Casting Volume** is an alternate value for the **Maximum** volume set in the [Minimum/Maximum Volume on page 338](#) settings, applied to the zone only when a casting service is routed to it. To set the maximum casting volume, do one of the following:
 - Move the **Maximum Casting Volume** slider right to increase or left to decrease the maximum volume.
 - Click the arrows to increase or decrease the maximum casting volume. Values range from 70% to 100%, adjustable in increments of 1%.
 - Manually enter a value in the **Maximum Casting Volume** field.

NOTE: If the **Maximum Casting Volume** value is higher than the regular **Maximum** volume value, the **Maximum** value will be applied instead.

2. A custom casting name (for example, "Living Room") must be entered so that a name for the zone will be displayed in the list of available casting destinations when initiating a stream. Enter this friendly name in the **Casting Name** field.

NOTE: Ensure that the **Casting Name** field is populated as any field with an asterisk (*) is mandatory.

Once AirPlay® and/or Spotify Connect™ are enabled, this name will be displayed as an available destination on the casting device.

To configure Apple AirPlay® casting:

1. Set the **AirPlay** toggle to the right to enable AirPlay casting to the zone's associated media player. Set the **AirPlay** toggle to the left to disable AirPlay casting to the associated media player.

To configure Spotify Connect™ casting:


1. Set the **Spotify** toggle to the right to enable Spotify Connect casting to the zone's associated media player. Set the **Spotify** toggle to the left to disable Spotify Connect casting to the associated media player.

To stream media from an iOS device or Spotify app to a zone in your distributed audio system, refer to the [DM-NAX-4ZSP Quick Start](#).

To stream media from a Roon® streaming device to a zone in your distributed audio system:

1. Enable Apple AirPlay casting for each DM NAX zone.
2. Launch the Roon desktop app.
3. Open the Roon app menu and navigate to the **Settings** submenu, then select **Audio**. A table of discovered network devices that the Roon device can stream to will be displayed. Any devices that previously have been enabled for Roon casting are listed under the **Connected to Core** section, and the rest of the discovered devices are listed under **Other network devices**.
4. Find each of the DM NAX zones in the **Other network devices** list, then click the **Enable** button for each zone to connect it to the Roon Core® for casting.
5. Return to the Roon app home page and click on the speaker icon at the bottom right. Select a DM NAX zone from the list of available casting destinations. With a zone selected, start a media stream, and the Roon device will cast the streaming audio to the zone.

Line Out




Line Out Volume controls the volume level of the corresponding line-level output on the DM NAX device. The Line Out Volume is only applied when **Line Out EQ Bypass** is enabled.

1. To set the line out volume, do one of the following:
 - Move the **Line Out Volume** slider to the right to increase or to the left to decrease the line out volume.
 - Click the arrows to increase or decrease the line out volume. Values range from 0 to 100, adjustable in increments of 1. This range in dB is -80 dB to 20 dB.
 - Manually enter a value in the **Line Out Volume** field.

2. Set the **Line Out EQ Bypass** toggle to the right position to have the line-level output signal bypass the zone's equalizer settings. Set the toggle to the left position to have the line-level output signal pass through the zone's equalizer. By default, **Line Out EQ Bypass** is disabled.

NOTE: When the **Line Out EQ Bypass** setting is disabled, the line-level output's level will follow the speaker output's **Zone** volume control. This allows for a variable line-level output in applications where the line-level output is connected to an uncontrolled device such as powered speakers. If the **Line Out EQ Bypass** setting is enabled, the **Line Out Volume** slider can be used to set a fixed level for the line-level output. This level will not be affected by the speaker output **Zone** volume controls, which is better suited to applications where the line output is connected to a controlled amplifier with its own level adjustment.

Signal Generator



The DM-NAX-4ZSP has a built-in signal generator that allows an integrator to send an audio signal to any number of selected zones to test output functionality.


1. To route the signal generator to the zone output, click the **Signal Generator** button so that it displays **Active** and is highlighted in blue. To unroute the signal generator on the zone output, click the **Signal Generator** button so that it displays **Inactive** and is highlighted in grey. By default, the signal generator is not routed to the zone output.

NOTES:

- There is only one signal generator built-in to the DM NAX device. Each zone has its own button to enable or disable the signal generator from passing signal to that output. Setting the signal generator to **Inactive** on a given zone output only breaks the route for that output and does not stop it from playing back in other zones.
- The **Signal Generator Volume** control is a local control that does not affect the signal generator's volume on other zone outputs. Only the settings under **Advanced Signal Generator** are applied universally to all zones of the DM NAX device.

2. To adjust the signal generator's volume, do one of the following:
 - Move the **Signal Generator Volume** slider right to increase or left to decrease the volume.
 - Click the arrows to increase or decrease the signal generator volume. Values range from 0 to 100, adjustable in increments of 1.
 - Manually enter a value in the **Signal Generator Volume** field.

Advanced Signal Generator



The advanced signal generator settings control the built-in signal generator directly, and are applied universally to all output zones of the DM NAX device. The signal type for the generator can be set, and the left and right channels of the test signal can be individually enabled or disabled.

1. Set the **Left Channel** toggle to the right position to enable the left channel of the signal. Set the toggle to the left position to disable the left channel. By default, **Left Channel** is enabled.
2. Set the **Right Channel** toggle to the right position to enable the right channel of the signal. Set the toggle to the left position to disable the right channel. By default, **Right Channel** is enabled.

3. Select an audio test signal type from the **Signal Type** drop-down menu. The available signal types are:
 - **Tone:** Generates a 1 kHz sine wave tone.
 - **Pink Noise:** Generates pink noise.
 - **White Noise:** Generates white noise.

Equalizer Settings

Equalizer Settings (Autosaved)

Speaker EQ Enabled ☒

Band	Band01	Band02	Band03	Band04	Band05	Band06	Band07	Band08	Band09	Band10
Gain										
	0	0	0	0	0	0	0	0	0	0
Type	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ
Frequency	32	64	125	250	500	1000	2000	4000	8000	16000
Bandwidth	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1
Bypass	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Actions										

Each zone output of the DM-NAX-4ZSP has a dedicated ten-band equalizer that can be fully customized to tune the zone output signal to the needs of an install. Each band can have a discrete gain, filter type, center frequency, and bandwidth set, and can also be bypassed. The equalizer itself can also be bypassed using the **Speaker EQ Enabled** toggle.

1. Set the **Speaker EQ Enabled** toggle to the right position to enable the equalizer. Set the toggle to the left position to bypass the equalizer.

NOTE: When **Speaker EQ Enabled** is disabled, all equalizer bands are bypassed. This is a quick way to perform A/B testing of the entire EQ curve.

2. With the **Speaker EQ Enabled** toggle in the right position, do the following to configure a given equalizer band:
 - a. To set a band's gain, do one of the following:
 - Move the **Gain** slider up to increase or down to decrease the gain.
 - Click the arrows to increase or decrease the gain. Values range from -40 dB to 20 dB, adjustable in increments of 0.1 dB.
 - Manually enter a value in the **Gain** field.

- b. Select a filter type from the **Type** drop-down menu. By default, all bands are set to the **EQ** filter type. Some filter types will disable other settings in their respective band while enabled. For example, selecting the **LowPass** filter type for a band will disable that band's **Gain** and **Bandwidth** settings, since the **LowPass** filter applies a fixed roll-off slope at a set frequency. The available filter types are:
- **EQ:** a fully parametric filter that can boost or cut a range of frequencies.
 - **Notch:** a parametric filter designed to more precisely cut a frequency or range of frequencies. A notch filter can achieve a narrower bandwidth than the standard **EQ** parametric filter type.
 - **TrebleShelf:** a filter that boosts or cuts all frequencies above a set frequency by a set gain.
 - **BassShelf:** a filter that boosts or cuts all frequencies below a set frequency by a set gain.
 - **LowPass:** a filter that fully cuts all frequencies above a set frequency using a fixed roll-off slope of -12 dB per octave.
 - **HighPass:** a filter that fully cuts all frequencies below a set frequency using a fixed roll-off slope of -12 dB per octave.
- c. Set a center frequency for the equalizer band to tune a specific portion of the audible frequency spectrum. To set the center frequency, do one of the following:
- Click the arrows to increase or decrease the frequency. Values range from 20 Hz to 20 kHz, adjustable in increments of 1 Hz. Each band has a default center frequency that will be applied if the **Reset** button at the bottom of the band is clicked.
 - Manually enter a value in the **Frequency** field.
- d. Set a bandwidth to determine how wide of a frequency range is effected by the equalizer band. To set the bandwidth, do one of the following:
- Click the arrows to increase or decrease the bandwidth. Values range from 0.1 octaves to 4.0 octaves, adjustable in increments of 0.1 octave.
 - Manually enter a value in the **Bandwidth** field.
- e. The individual Bypass controls allow you to bypass a single band of equalization at a time for more granular A/B testing of a single filter. Set a band's **Bypass** toggle to the right position to bypass that band. Set the toggle to the left position to disable the bypass. By default, **Bypass** is disabled.
- f. Each equalizer band has a **Reset** button that will reapply the default settings for that band.

Click **Done** to return to the **Settings** tab of the web user interface.

Bussing

The bussing feature on DM NAX devices allows an integrator to assign any number of selected zones to a fixed group of zones (bus). Zones in a bus track the other zones' volume and routing. For example, when the source or volume for one zone in the bus is adjusted, all other zones in that bus receive the same adjustment. You can create up to two buses on the DM-NAX-4ZSP.

Global Filter <input type="text"/>		
Name	Bus Id	Included Zones
Bus01	1	Choose Zones
Bus02	2	Choose Zones

Configure Bussing

1. If needed, enter a friendly name for each bus in its **Name** field.
2. Select any number of zones from the **Included Zones** drop-down menu.

NOTE: Each zone can be a member of only one bus. Any zones that are already a member of another bus will not be shown in the **Included Zones** drop-down.

Inputs

The **Inputs** menu is used to configure **Name**, **Compensation**, and **Mute** attributes of the available analog, digital, and media streaming inputs on the DM-NAX-4ZSP.

A total of 12 inputs are available on the DM-NAX-4ZSP, including the 8 physical input connectors on the device's rear panel and the 4 internal media players used for media streaming services.


Name	TOSLINK1	TOSLINK2	S/PDIF1	S/PDIF2	RCA1	RCA2	RCA3	RCA4
Gain (db)								
Signal Present								
Clipping Detected								
Mute								

Configure Inputs

1. If needed, enter a friendly name for each input in its **Name** field.
2. To set a level compensation adjustment for a given input, do one of the following:
 - Move the **Compensation** slider up to increase or down to decrease the compensation. Compensation increases or decreases the level of the incoming audio signal on any of the physical inputs on the device's rear panel. Compensation is not available for any of the internal media players.
 - Click the **db** arrows to increase or decrease the compensation. Values range from -10 dB to 10 dB, adjustable in increments of 1 dB.
 - Manually enter a value in the **Compensation** field.
3. To mute the signal from the corresponding input, click the **Mute** button. To disable the mute, click the **Muted** button. By default, **Mute** is disabled.

Monitor the device's input signals using the text indicators in the **Signal Present** and **Clipping Detected** columns:

- **Signal Presence** indicates whether or not a signal is detected in that zone.
- **Clipping Detected** indicates if the signal is **Clipping** or **Nominal** (non-clipping).

Use the **Global Filter** text field to filter specific inputs by name. Not all of the available inputs are shown on the first page in this section when no **Global Filter** is applied. Use  at the bottom of the table to view the next page of inputs.

DM NAX Streams

Each local input of the DM-NAX-4ZSP can be made available as a DM NAX audio-over-IP stream. This includes the eight physical inputs on the rear panel of the device and the four internal media players.

The DM-NAX-4ZSP also supports parallel DM NAX streams for each zone output, enabling an additional transmit stream per output to mirror all routes and DSP settings of its respective zone. These parallel streams enable control of the audio signal to third-party uncontrolled AES67 devices receiving audio from the DM-NAX-4ZSP.

NOTES:

- Under the **Transmitters** section (see [Configure Transmitters](#)), the last four listed transmitters are dedicated to parallel zone outputs.
- To configure the DSP settings, see [Zone Settings](#).

Click **NAX Streams** to expand the tab and display the following information.

The screenshot shows the Crestron configuration interface for device DM-NAX-8ZSA-00107FB58088. The 'NAX Streams' tab is selected and expanded. It displays the following settings:

- Device is Master PTP Clock Source:** Yes (indicated in green)
- Master Clock Status:** 00107f.ffe.b58088
- PTP Priority:** 254 (with a dropdown arrow)
- Transmitters (Autosaved):** A large empty text box for listing transmitters.
- Receivers (Autosaved):** A large empty text box for listing receivers.

- **Device is Master PTP Clock Source** indicates whether the device is the master for PTP on the network. **Yes** will be displayed in green when the local DM-NAX-4ZSP is the PTP clock master and **No** will be displayed in red when another PTP clock on the network is operating as the master clock.
- **Master Clock Status** displays the Master Clock ID of the device on the network that acts as the Master Clock.
- **PTP Priority:** This sets the priority of the local DM NAX device's PTP clock relative to other clocks on the network. The default setting is 254 (one increment higher than the lowest possible value) so that the DM-NAX-4ZSP will only operate as clock master if no other PTP master is present on the network. Valid values range from 1 to 255.

Configure Transmitters

NAX Streams

Device is Master PTP Clock Source

No

Master Clock Status

001071ffe.9cc314

PTP Priority

254

Transmitters (Autosaved)

Audio Source	Stream	Nax Stream Address	Nax Stream Name	Status	Actions
Digital Input 1	Stream01	0.0.0.0	TOSLINK1100.10.7fb5.80.88	Stream Stopped	▶ ◻ ⚙
Digital Input 2	Stream02	0.0.0.0	TOSLINK2200.10.7fb5.80.88	Stream Stopped	▶ ◻ ⚙
Digital Input 3	Stream03	239.8.0.32	S/PDIF1300.10.7fb5.80.88	Stream Started	▶ ◻ ⚙
Digital Input 4	Stream04	0.0.0.0	S/PDIF2400.10.7fb5.80.88	Stream Stopped	▶ ◻ ⚙
Analog Input 5	Stream05	0.0.0.0	RCA1500.10.7fb5.80.88	Stream Stopped	▶ ◻ ⚙
Analog Input 6	Stream06	0.0.0.0	RCA2600.10.7fb5.80.88	Stream Stopped	▶ ◻ ⚙
Analog Input 7	Stream07	0.0.0.0	RCA3700.10.7fb5.80.88	Stream Stopped	▶ ◻ ⚙
Analog Input 8	Stream08	0.0.0.0	RCA4800.10.7fb5.80.88	Stream Stopped	▶ ◻ ⚙

NOTE: To configure transmitters not shown on the current page of the table, click the ▶ icon to display the next page of eight transmitters.

To configure a DM NAX transmit stream, do the following.

1. Enter a valid multicast address in the **NAX Stream Address** field.
2. Enter a name in the **NAX Stream Name** field by which the stream can be identified. This stream name is associated with the DM NAX stream's multicast address by other DM NAX or AES67 devices, like a device hostname that resolves to a given IP address.
3. **Status** indicates whether a stream is transmitting or not. When the stream has started or stopped, the **Status** column will update accordingly.
4. Click the configure button (⚙) in the **Actions** column. The **Configure** dialog appears:

Configure

Auto Initiation

◻

Port

5004

✓ OK

✗ CANCEL

5. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled for a given stream, the stream will begin transmitting automatically and will be available as a multicast stream on your network at the specified multicast address.
 - If **Auto Initiation** is disabled for the input, the stream will not begin transmitting until it is manually initiated.
6. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number for DM NAX streams is 5004.
7. Click **OK** to save or click **Cancel** to cancel the changes.

Configure Receivers

Receivers (Autosaved)						
Zone Name	Stream	Current Stream Address	Requested Stream Address		Status	Actions
Zone1	Stream01	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Zone2	Stream02	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Zone3	Stream03	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Zone4	Stream04	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Zone5	Stream05	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Zone6	Stream06	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Zone7	Stream07	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙
Zone8	Stream08	0.0.0.0	0.0.0.0	Q	Stream Stopped	▶ ■ ⚙

1. Enter the multicast address of a transmitting stream in the **Requested Stream Address** field to subscribe the receiver to the stream.
2. Click the configure button (⚙) in the **Actions** column. The **Configure** dialog appears:

Configure

Auto Initiation

Port

5004

✓ OK


✗ CANCEL

3. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled, the stream will begin automatically when the receiver subscribes to the transmitter.
 - If **Auto Initiation** is disabled, the stream will not begin until it is manually initiated.
4. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number is 5004.
5. Click **OK** to save or click **Cancel** to cancel the changes.

Routing

The **Routing** page is used to route a local input, media player, or AES67 stream to a Zone on the DM-NAX-4ZSP.


NOTE: To receive an AES67 stream from Dante devices, see [OLH 1001151](#).



To route an input to a zone, click the box in the routing matrix where the zone's row overlaps the corresponding input's column. Once a route is made, appears. To break a given route click or . To route a single input to all zones, click on the under the input's name.

Use the arrows (or) at the top of the matrix to change pages to view all available inputs.

To select a specific NAX/AES67 stream when AES67 is selected as the source for a Zone, do the following:

- Click  to display the list of all DM NAX/AES67 streams discovered on the network and click a radio button to select the corresponding stream to be routed to the zone.

	Stream Name	Network Address
<input type="radio"/>	MediaStream6147ff40efe	239.8.0.37
<input type="radio"/>	MediaStream2107ff40efe	239.8.0.41
<input type="radio"/>	RCA2600.10.7ff4.0b.8d	239.8.10.25
<input type="radio"/>	Stream0100.10.7f.9c.9b.06	239.0.14.239
<input type="radio"/>	MediaStream61400.10.7f.b5.f3.24	239.8.0.8
<input type="radio"/>	MediaStream7157ff40efe	239.8.0.38
<input type="radio"/>	MediaStream31100.10.7f.b5.f3.24	239.8.0.2
<input type="radio"/>	RCA1500.10.7ff4.0b.8d	239.8.10.24
<input type="radio"/>	MediaStream71500.10.7f.b5.f3.24	239.8.0.5
<input type="radio"/>	Stream0100.10.7f.05.23.9c	239.57.156.23

1 of 5


✓ OK

✕ CANCEL

- Click **OK** to save or click **Cancel** to cancel the changes.


Streaming Services

The DM-NAX-4ZSP features four built-in media streaming players, each of which can play back a discrete media stream from a cloud-based service or local casting device. User Profiles can be created for each user of the DM NAX device with discrete credentials, enabling multiple users access to media streaming services without interfering with other users' recommendations, favorites, or playlists.




To configure Streaming Services:

- 1. Click the **+ Add User Profile** button to create a new user profile. Each user profile can contain a unique set of accounts for all supported streaming services.
- 2. Enter a name in the **Profile Name** field. Click **Save** to create the **User Profile**. Once the profile is created, you have the option to either **Delete** the profile, or add **Services** to it.
- 3. Click **Services** in the **Action** column and an **Edit Services** window appears.



- 4. Select from the available Streaming Services: **TIDAL™**, **Deezer®**, **Qobuz®**, **SOUNDMACHINE®**, **SiriusXM®**, **Pandora®**, **Internet Radio**, and **Podcasts**. Click **+** or **🗑** to add or delete the desired streaming services for each user profile.


User Authentication

User authentication is required for TIDAL, Deezer, Qobuz, SOUNDMACHINE, SiriusXM and Pandora. Click  to authorize the user.

To authenticate SiriusXM streaming:

NOTE: To determine whether to use commercial accounts, refer to the streaming service license agreement or FAQs on their respective portals. For SiriusXM, click [here](#).


Enter the user credentials and click **OK**.



To authenticate TIDAL streaming:

1. Click on the link to log in to the TIDAL portal.

NOTE: The link is valid for one minute. After one minute, the link expires, and the **Authorize URL** is shown as blank. The **Authorize User** dialogue will need to be closed and reopened.




2. Click **DONE** to return to **Streaming Services**.

To authenticate Deezer streaming:

1. Click on the link to log in to the Deezer portal.

NOTE: The link is valid for one minute. After one minute, the link expires, and the **Authorize URL** is shown as blank. The **Authorize User** dialogue will need to be closed and reopened.



2. Click **DONE** to return to **Streaming Services**.

To authenticate Qobuz streaming:

1. Click on the link to log in to the Qobuz portal.


NOTE: The link is valid for one minute. After one minute, the link expires, and the **Authorize URL** is shown as blank. The **Authorize User** dialogue will need to be closed and reopened.



2. Click **DONE** to return to **Streaming Services**.


To authenticate SOUNDMACHINE streaming:

NOTE: To determine whether to use commercial accounts, refer to the streaming service license agreement or FAQs on their respective portals. For SOUNDMACHINE, click [here](#).



1. Click the link to log in to the SOUNDMACHINE portal.

NOTE: The link is valid for one minute. After one minute, the link expires, and the **Authorize URL** is shown as blank. The **Authorize User** dialogue will need to be closed and reopened.



SOUNDMACHINE

Login


Email


Password


PLEASE ENTER YOUR CREDENTIALS

2. Log in to the SOUNDMACHINE account.
3. Click **DONE** to return to **Streaming Services**.

To authenticate Pandora streaming:



1. Click the  icon to copy the activation code.
2. Click the link to register the device. The Device Activation page is displayed.




NOTE: The link is valid for one minute. After one minute, the link expires, and the **Authorize URL** and **Enter Code** are shown as blank. The **Authorize User** dialogue will need to be closed and reopened.

3. Paste the activation code in the **Please enter your activation code** field and click **Activate Now**.
4. Log in to the Pandora account.
5. Click **DONE** to return to **Streaming Services**.

Port Selection

The Port Selection feature allows the device's internal network traffic to be managed and segregated based on traffic type. Internal VLANs are used to segment device management and streaming service traffic to a separate physical device Ethernet port than audio-over-IP streaming traffic. With Port Selection enabled on all DM NAX devices on a network, DM NAX and AES67 network traffic can be physically separated from the control network onto a dedicated audio network.

▼ Port Selection

 **Port Selection:** Connecting multiple interfaces to the same switch may cause a network loop

Port Selection ☒

Management

Port1

Audio/NAX

Port2

To configure Port Selection:

1. Set the **Port Selection** toggle to the right position to enable Port Selection. Set the toggle to the left position to disable Port Selection. By default, **Port Selection** is disabled.

NOTE: Ports 1 and 2 correspond to the Ethernet adapters labeled **1** and **2** on the rear panel of the DM-NAX-4ZSP, respectively.

2. With **Port Selection** enabled, select an Ethernet port from the **Management** drop-down menu to designate which Ethernet port on the rear panel of the device will handle network traffic relating to device configuration, streaming services, and the device's connection to a control system.

NOTES:


- To access streaming services, the Management port must be connected to a network with internet access.
- The Management port determines your connection to the web interface. Changing the port value can result in losing your connection to the device via the web interface.

3. With **Port Selection** enabled, select an Ethernet port from the **Audio/NAX** drop-down menu to designate which Ethernet port on the rear panel of the device will handle audio-over-IP streaming network traffic.
4. Click **Save** changes to apply the new settings.

NOTE: Making changes to **Port Selection** settings will require a reboot.

Security


Click the **Security** tab to configure security for users and groups and to allow different levels of access to the DM-NAX-4ZSP functions. By default, security is disabled.



Select **Encrypt and Validate**, **Encrypt**, or **OFF** in the **SSL Mode** drop-down menu, to specify whether to use encryption. By default, SSL Mode is set to **OFF**.

Current User

Click the **Current User** tab to view read-only information or to change the password for the current user.




The screenshot shows a web interface with three tabs: "Current User", "Users", and "Groups". The "Current User" tab is active. It displays the following information:

Name	admin1
Access Level	Administrator
Active Directory User	No
Groups	Administrators

Below the information is a blue button labeled "Change Current User Password".

1. Click the **Change Current User Password** button to provide a new password for the current user.
2. In the **Change Password** dialog, enter the current password in the **Current Password** field, the new password in the **Password** field, and then re-enter the same new password in the **Confirm Password** field.



The screenshot shows a "Change Password" dialog box with a blue title bar and a close button (X). It contains three password input fields, each with a label and a masked password (dots):


- Current Password
- Password
- Confirm Password

At the bottom right, there are two buttons: "OK" (with a checkmark icon) and "Cancel" (with an X icon).

3. Click **OK** to save or click **Cancel** to cancel the changes.

Users

Click the **Users** tab to view and edit user settings. The **Users** tab can be used to add or remove local and Active Directory users and preview information about users.



Use the **Search Users** field to enter search term(s) and display users that match the search criteria.

If users listed in the **Users** table span across multiple pages, navigate through the list of users by clicking a page number or by using the left or right arrows at the bottom of the **Users** pane to move forward or backward through the pages.

Each page can be set to display 5, 10, or 20 users by using the drop-down menu to the right of the navigation arrows.

Information about existing users is displayed in table format and the following details are provided for each user.


- **Username:** Displays the name of the user.
- **AD User:** Displays whether the user requires authentication using Active Directory.

Click the corresponding button in the Actions column to view detailed user information or to delete the user.

To create a new user, click the **Create User** button.

Create a New Local User

1. Click the **Create User** button in the User tab.
2. In the **Create User** dialog, enter the following:



The screenshot shows a 'Create User' dialog box. The 'Name' field contains 'test'. The 'Active Directory User' toggle is disabled. The 'Password' and 'Confirm Password' fields are masked with dots. The 'Groups' dropdown is set to 'Administrators'. The 'OK' and 'Cancel' buttons are at the bottom right.

- a. Enter a user name in the **Name** field. A valid user name can consist of alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
- c. Assign the access level by selecting one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is disabled.

3. Click **OK** to save or click **Cancel** to cancel the changes.


Add an Active Directory User

Users cannot be created or removed from the Active Directory server, but access can be granted to an existing user in the Active Directory server.

To grant access to an Active Directory user, you can either add the user to a local group on the DM-NAX-4ZSP, or add the Active Directory group(s) that they are a member of to the DM-NAX-4ZSP.

To add an Active Directory user.

1. Click the **Create User** button.
2. In the **Create User** dialog, enter the following.




The screenshot shows a 'Create User' dialog box with a blue header. It contains three main fields: 'Name' with the text 'Connects\test', 'Active Directory User' with a blue toggle switch turned on, and 'Groups' with a dropdown menu showing 'Connects'. At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'x' icon.

- a. Enter a user name in the **Name** field in the format "Domain\UserName", for example "crestronlabs.com\JohnSmith". Valid user names can contain alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Select one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is set to enabled.


3. Click **OK** to save or click **Cancel** to cancel the changes.

Delete User


Click the trashcan button () in the **Actions** column to delete the user. Click **Yes** when prompted to delete the user or **No** to cancel the deletion.

After a user is removed from a group, they lose any access rights associated with that group. Note that the user account is not deleted by the delete user operation.

View User Details

Click the information button () in the **Actions** column to view information for the selected user. The **User Details** dialog displays the following information for the selected user.


- **Name:** Displays the name of the selected user.
- **Active Directory User:** Displays whether the user is an Active Directory user.
- **Group:** Displays group(s) the selected user is part of.




The **User Details** dialog box has a blue title bar with the text "User Details" and a close button (X). The main area is white and contains three rows of information: "Name" with the value "admin1", "Active Directory User" with the value "No", and "Groups" with the value "Administrators". At the bottom right, there is a blue button with a checkmark and the text "OK".

Click **OK** to close the **User Details** dialog and to return to the **Users** tab.

Update User Details



The **Update User** dialog box has a blue title bar with the text "Update User" and a close button (X). The main area is white and contains several fields: "Name" with the value "admin1", "Active Directory User" with a toggle switch that is currently off, "Password" and "Confirm Password" fields both containing seven dots, and a "Groups" drop-down menu with "Administrators" selected. At the bottom right, there are two blue buttons: one with a checkmark and "OK", and another with an X and "Cancel".

1. Click the edit button () in the **Actions** column to update information for the selected user.
2. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
3. Select one or more groups to assign the user to from the **Groups** drop-down list.
4. Click **OK** to save or click **Cancel** to cancel the changes.

The **Update User** dialog also displays the following read-only information for the selected user.

- **Name:** Displays the name of the user.
- **Active Directory User:** Displays whether the user is an Active Directory user.











Groups

Click the **Groups** tab to view and edit group settings. The **Groups** tab can be used to add local and Active Directory groups, remove local and Active Directory groups, and preview information about a group.

Use the **Search Groups** field to enter search term(s) and display groups that match the search criteria.

Current UserUsersGroups

Search...

Group Name	AD Group	Access Level	Action
Administrators	No	Administrator	 
Connects	No	Connect	 
Operators	No	Operator	 
Programmers	No	Programmer	 
Users	No	User	 

1

10



Create Group

If groups listed in the **Groups** table span across multiple pages, navigate through the groups by clicking a page number or by using the left or right arrows at the bottom of the Groups pane to move forward or backward through the pages.

Additionally, each page can be set to display 5, 10, or 20 groups by using the drop-down menu to the right of the navigation arrows.


Existing groups are displayed in a table and the following information is provided for each group:

- **Group Name:** Displays the name of the group.
- **AD Group:** Displays whether the group requires authentication using Active Directory.
- **Access Level:** Displays the predefined access level assigned to the group (Administrator, Programmer, Operator, User, or Connect).

Click the corresponding button in the **Actions** column to view detailed group information () or to delete () selected group.

Click on the **Create Group** button in the **Groups** tab to create new group.

Create Local Group

A screenshot of the 'Create Group' dialog box. The title bar is blue with the text 'Create Group' and a close button. The dialog has three main sections: 'Name' with a text field containing 'test12', 'Access Level' with a dropdown menu showing 'Programmer', and 'Active Directory Group' with a toggle switch that is turned off. At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'X' icon.


1. Click the **Create Group** button.
2. In the **Create Group** dialog, enter the following:
 - a. Enter the group name in the **Name** field.
 - b. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is disabled.

3. Click **OK** to save. Click **Cancel** to cancel the changes.

Add Active Directory Group

A group cannot be created or removed from the Active Directory server, but access can be granted to an existing group in Active Directory.

A screenshot of the 'Create Group' dialog box. The title bar is blue with the text 'Create Group' and a close button. The dialog has three main sections: 'Name' with a text field containing 'test', 'Access Level' with a dropdown menu showing 'Administrator', and 'Active Directory Group' with a toggle switch that is turned on. At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'X' icon.

Once the group is added, all members of that group will have access to the DM-NAX-4ZSP.


1. Click the **Create Group** button.
2. In the **Create Group** dialog enter the following:
 - a. Enter the group name in the **Name** field, for example "Engineering Group". Note that group names are case sensitive; a space is a valid character that can be used in group names.

3. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is enabled.


4. Click **OK** to save. Click **Cancel** to cancel the changes.


Delete a Group

Click the trashcan button () in the **Actions** column to delete a group. Click **Yes** when prompted to delete the group or **No** to cancel the deletion.

When a group is deleted, users in the group are not removed from the device or Active Directory server. However, because a user's access level is inherited from a group(s), users within the deleted group will lose access rights associated with the group.

View Group Details

Click the information button () in the **Actions** column to view information for the selected group. The **Group Details** dialog lists the following information for the selected group.



The **Group Details** dialog box displays the following information:

Name	Administrators
Access Level	Administrator
Active Directory Group	No

At the bottom right, there is a blue button with a checkmark and the text **OK**.

- **Name:** Displays the name of the group.
- **Access Level:** Displays the access level of the group and its users.
- **Active Directory Group:** Displays whether the group is an Active Directory group.

Click **OK** to close the **Group Details** dialog and to return to the Groups tab.

802.1x Configuration

The DM-NAX-4ZSP has built-in support for the 802.1X standard (an IEEE network standard designed to enhance the security of wireless and Ethernet LANs. The standard relies on the exchange of messages between the device and the network's host, or authentication server), allowing communication with the authentication server and access to protected corporate networks.

StatusSettingsSecurity802.1x Configuration

802.1x Configuration

IEEE 802.1x Authentication

Authentication MethodEAP MSCHAP V2- password

Domainsecure12

Usernameadmin

Password*****

Enable Authentication Server Validation

Select Trusted Certificate Authority(s)

☐ AAA Certificate Services

☐ AC RAIZ FNMT-RCM

☐ ACCVRAIZ1

☐ Actalis Authentication Root CA

☒ AffirmTrust Commercial

☐ AffirmTrust Networking

☐ AffirmTrust Premium ECC

☒ AffirmTrust Premium

☐ Amazon Root CA 1

☐ Amazon Root CA 2

☒ Amazon Root CA 3

☐ Amazon Root CA 4

☐ Atos TrustedRoot 2011

☐ Autoridad de Certificacion Firmaprofesional CIF A62634068

☐ Baltimore CyberTrust Root

To Configure DM-NAX-4ZSP for 802.1X Authentication

1. Set the **IEEE 802.1X Authentication** toggle to enabled. This will enable all options on the 802.1X dialog.
2. Select the **Authentication method: EAP-TLS Certificate** or **EAP-MSCHAP V2 Password** according to the network administrator's requirement.
3. Do either one of the following:
 - Select **EAP-TLS Certificate**, click **Action/Manage Certificates** to upload the required machine certificate. The machine certificate is an encrypted file that will be supplied by the network administrator, along with the certificate password.
 - Select **EAP-MSCHAP V2 Password**, enter the username and password supplied by the network administrator into the **Username** and **Password** fields. This method does not require the use of a machine certificate, only the user name and password credentials.
4. If you enabled the **Enable Authentication Server Validation** option, this will enable the **Select Trusted Certificate Authoritie(s)** list box which contains signed Trusted Certificate Authorities (CAs) preloaded into the DM-NAX-4ZSP.

Select the check box next to each CA whose certificate can be used for server validation, as specified by the network administrator.

If the network does not use any of the listed certificates, the network administrator must provide a certificate, which must be uploaded manually via the **Manage Certificates** functionality.

5. If required, type the domain name of the network in the **Domain** field.
6. When the 802.1X settings are configured as desired, click **Save Changes** to save the changes to the device and reboot it. Click **Revert** to cancel any changes.

Access the Web Interface With the Crestron Toolbox™ Application

To access the web interface by opening a web browser within the Crestron Toolbox™ application, do the following:

1. Open the Crestron Toolbox application.
2. From the **Tools** menu, select **Device Discovery Tool**. You can also access the Device Discovery Tool by clicking the Device Discovery Tool button () in the Crestron Toolbox toolbar. The DM-NAX-4ZSP is discovered and listed in the device list on the left side of the screen. The associated host name, IP address, and firmware version are also displayed.

NOTE: If there is security software running on the computer, a security alert might be displayed when the Crestron Toolbox application attempts to connect to the network. Make sure to allow the connection, so that the Device Discovery Tool can be used.

3. In the Device Discovery Tool list, double-click your device.
4. Enter your credentials in the **Authentication Required** dialog that opens, and then click **Log In**.
5. Click the **Web Configuration** button in the Configuration page displayed on the left side of the Device Discovery Tool.

DM-NAX-16AIN

This section describes how to configure DM-NAX-16AIN.

Web Interface Configuration

The DM-NAX-16AIN web interface allows you to view status information and configure network and device settings.

Access the Web Interface

To access the web interface, do either of the following:

- [Access the Web Interface with a Web Browser on page 376](#)
- [Access the Web Interface With the Crestron Toolbox™ Application on page 406](#)

The web interface is accessed from a web browser. The following table lists operating systems and their corresponding supported web browsers.

Operating System and Supported Web Browsers


OPERATING SYSTEM	SUPPORTED WEB BROWSERS
Windows® operating system	Chrome™ web browser, version 31 and later
	Firefox® web browser, version 31 and later
	Internet Explorer web browser, version 11 and later
	Microsoft Edge web browser
macOS® operating system	Safari® web browser, version 6 and later
	Chrome web browser, version 31 and later
	Firefox web browser, version 31 and later

Access the Web Interface with a Web Browser

1. Enter the IP address of the DM-NAX-16AIN into a web browser.


NOTE: To obtain the IP address, use the **Device Discovery Tool** option in Crestron Toolbox™ application or an IP scanner application.

2. If you are creating a user account for the first time, do the following; otherwise, skip to step 3.
 - a. Enter a username in the **Username** field.
 - b. Enter a password in the **Password** field.
 - c. Re-enter the same password in the **Confirm Password** field.



The screenshot shows the Crestron logo at the top left. Below it, a yellow warning triangle icon is followed by the text "DEVICE FIRST BOOT". In the center, there is a white box titled "Device Administration". Inside this box, there are three input fields: "Username", "Password", and "Confirm Password". Below these fields is a green button with a white plus icon and the text "Create User". At the bottom of the white box, there is small text: "© 2021 Crestron Electronics, Inc.", "Privacy Statement", and "Crestron Software End-User License Agreement".

- d. Click **Create User**. The Device Administration page appears.




The screenshot shows the same Crestron logo at the top left. Below it, the "DEVICE FIRST BOOT" message is no longer present. The white box titled "Device Administration" still contains the "Username" and "Password" input fields. Below these fields is a blue button with a white magnifying glass icon and the text "Sign In". At the bottom of the white box, the same small text is present: "© 2021 Crestron Electronics, Inc.", "Privacy Statement", and "Crestron Software End-User License Agreement".

3. Enter the username in the **Username** field.
4. Enter the password in the **Password** field.
5. Click **Sign In**.

Action

The **Action** drop-down menu is displayed at the top right side of the interface and provides quick access to common device functions:

- Save Changes
- Revert
- Reboot
- Restore
- Update Firmware
- Download Logs
- Manage Certificates



Save Changes

Click **Save Changes** to save any changes made to the configuration settings.


Revert

Click **Revert** to revert the device back to the last saved configuration settings.

Reboot the DM-NAX-16AIN

Certain changes to the settings may require the DM-NAX-16AIN to be rebooted to take effect. To reboot the device, do the following:

1. Click **Reboot** in the **Actions** drop-down menu. The **Confirmation** message box appears.




2. Click **Yes, Reboot Now** to reboot the device. The **Reboot** message box appears. Wait for the device reboot to complete before attempting to reconnect to the device.

Restore to Factory Default Settings

1. Click **Restore** in the **Actions** drop-down menu to restore the settings of the DM-NAX-16AIN to factory defaults.

NOTE: When settings are restored, all settings, including the network settings, will revert to the factory default. If a static IP address is set, restoring the device to factory default settings will revert the IP address to the default DHCP mode.




2. Click **Yes** in the **Confirmation** dialog to restore the DM-NAX-16AIN to factory settings. Click **No** to cancel the restore operation.

A dialog is displayed again, indicating that the restore process was successful and that the device rebooted.

You can also restore to factory settings by pressing and holding the **SETUP** button on the rear panel of the device with power disconnected then connect the power supply and continue to hold **SETUP** button for 30 seconds.

Update Firmware

1. Click **Update Firmware** in the **Actions** drop-down menu.
2. In the **Firmware Upgrade** dialog, click **+ Browse**.



3. Locate and select the desired firmware file, and then click **Open**. The selected firmware file name is displayed in the **Firmware Upgrade** dialog.
4. Click **Load** and wait for the progress bar to complete and for the **OK** button in the message to become clickable.
5. Click **OK**. The device with new firmware can now be accessed.


Download Logs

1. Click **Download Logs** in the **Actions** drop-down menu to download the device message logs for diagnostic purposes.

The log file is downloaded to the Downloads folder of the PC.

Manage Certificates

Use the **Manage Certificates** dialog to add, remove, and manage certificates used in 802.1x and other protected networks.



1. Click **Manage Certificates** in the **Actions** drop-down menu. The following certificate tabs are displayed:
 - **Root:** The Root certificate is used by the DM-NAX-16AIN to validate the network's authentication server. The DM-NAX-16AIN has a variety of Root certificates, self-signed by trusted CAs (Certificate Authorities) preloaded into the device. Root certificates must be self-signed.
 - **Intermediate:** The Intermediate store holds non self-signed certificates that are used to validate the authentication server. These certificates will be provided by the network administrator if the network does not use self-signed Root certificates.
 - **Machine:** The machine certificate is an encrypted PFX file that is used by the authentication server to validate the identity of the DM-NAX-16AIN. The machine certificate will be provided by the network administrator, along with the certificate password. For 802.1x, only one machine certificate can reside on the device.
 - **Web Server:** The Web Server certificate is a digital file that contains information about the identity of the web server.


To Add Certificates

1. Click the corresponding certificate tab.
2. Click the **Add Root Certificate** button.
3. Click the **+ Browse** button.
4. Locate and select the file, and then click the **Open** button.

NOTE: If the certificate is a Machine Certificate, enter the password provided by the network administrator.

5. Click **OK**. This will add the certificate to the list box, displaying the file name and expiration date.
The certificate is now available for selection and can be loaded to the device.

To Delete Certificates

1. Click the corresponding certificate tab.
2. Click the trashcan button () in the **Actions** column to delete the certificate.
3. Click **Yes** when prompted to delete the certificate or **No** to cancel the deletion.

Status

The **Status** tab is the first page displayed when opening the interface of the DM-NAX-16AIN. It displays general information about the DM-NAX-16AIN (such as Model Name, Firmware Version, and Serial Number) and current network settings (such as Host Name and IP Address, etc.).


The Status tab can be accessed at any time by clicking the **Status** tab of the DM-NAX-16AIN interface.




Information displayed on the **Status** tab is organized into different sections.

Device

The **Device** section displays the **Model**, **Firmware Version**, and **Serial Number** of the DM-NAX-16AIN.




Click **+ More Details** to review additional information about the DM-NAX-16AIN.



Network

The **Network** section displays network-related information about the DM-NAX-16AIN, including the Hostname, Domain Name, and DNS Servers.




NOTE: By default, the host name of the DM-NAX-16AIN consists of the model name followed by the MAC address of the device. For example, DM-NAX-16AIN-00107FF41E53.

Click **+ Adapter 1** to display an expanded section that shows additional information. If **+ Adapter 1** is selected, click **- Less** details to collapse the section.

NOTE: The **+ Adapter 2** option appears when the dual Ethernet ports on the DM-NAX-16AIN are set to isolate traffic using the Port Selection feature.

Control System

The **Control System** section displays connection information, consisting of the following:



- **Encrypt Connection:** ON or OFF
- **IP ID:** Reports the currently used IP ID of the DM-NAX-16AIN
- **IP Address/Hostname:** The IP address of the control system
- **Room ID:** Displays the room ID
- **Status:** OFFLINE or ONLINE

Settings

The **Settings** tab enables you to configure the DM-NAX-16AIN settings. The Settings page can be accessed at any time by clicking the **Settings** tab of the DM-NAX-16AIN interface.



Settings available on the **Settings** tab are organized into different sections.

System Setup

The **System Setup** section contains settings for **Date/Time**, **Auto Update**, **Network**, and **Control System**.

Date/Time

Use the **Date/Time** section to configure the date and time settings of the DM-NAX-16AIN.

	Address	Port	Authentication Method	Authentication Key	Key ID
<input type="checkbox"/>	pool.ntp.org	123	None	*****	0

Time Synchronization

1. Set the **Time Synchronization** toggle to the right position to enable or left position to disable time synchronization. By default, time synchronization is enabled.
2. In the **NTP Time Servers** table, enter the URL of a NTP (Network Time Protocol) or SNTP (Simple Network Time Protocol) server. Up to three time servers can be added on a device.
3. Click **Synchronize Now** to perform time synchronization between the device's internal clock and the time server.

Time Configuration


1. Click on the **Time Zone** drop-down menu to select the applicable time zone.
2. In the **Date** field, enter the current date.
3. In the **Time (24hr Format)** field, enter the current time in 24-hour format.

Click the **Save Changes** button to save the settings.

Click **Revert** from the **Actions** drop-down menu to revert to the previous settings without saving.

Auto Update

The DM-NAX-16AIN can automatically check for and install firmware updates at scheduled intervals via the Auto Update feature.



The screenshot shows the 'Auto Update' configuration page. On the left, there is a 'Schedule' section. On the right, there are several settings: 'Auto Update' is a toggle switch turned on (blue); 'Custom URL' is a toggle switch turned off (grey); 'Custom URL Path' is a text box containing 'https://crestrondevicefiles.blob.core.winc'; 'Day of Week' is a dropdown menu set to 'Daily'; 'Time of Day' is a text box set to '02:13'; 'Poll Interval' is a text box set to '0' with 'Minutes' to its right; and an 'Update Now' button at the bottom right.

1. Set the **Auto Update** toggle to the right position to enable Auto Update.
2. Define the URL to download the updates by doing either of the following:
 - a. Use the default URL to download the updates from the Crestron server.
 - b. Use a custom URL. Set the **Custom URL** toggle to the right position to enable a custom URL. In the **Custom URL Path** text box, enter the path to a custom manifest file in the FTP or SFTP URL format. Use the Crestron Auto Update Tool to generate a custom manifest file, then store the file on an FTP (File Transfer Protocol) or SFTP (Secure File Transfer Protocol) server.
3. Set a schedule for the automatic firmware update by doing either of the following:
 - a. Select the desired **Day of Week** and **Time of Day** (24-hour format) values.
 - b. Set the **Poll Interval** by entering a value from **60** to **65535** minutes. A value of **0** disables the Poll Interval.
4. Click **Save Changes**.

Clicking **Update Now** causes the device to check for a firmware update immediately. If a schedule was set in step 4 above, that schedule still remains in effect.

Network

The **Network** section contains network-related settings for the DM-NAX-16AIN, including the Hostname, Domain, Primary Static DNS, and Secondary Static DNS.

The screenshot shows the 'Network' configuration interface. At the top, there's a 'Network' header with a minus icon. Below it, the 'Hostname' field is populated with 'DM-NAX-16AIN-00107FF41E53'. The 'Domain' field is empty. The 'Primary Static DNS' and 'Secondary Static DNS' fields are also empty. On the left, 'Adapter 1' is listed. To the right of 'Adapter 1', the 'DHCP' toggle is turned on (blue). Below the toggle, the 'IP Address' is '10.254.68.87', the 'Subnet Mask' is '255.255.0.0', and the 'Default Gateway' is '10.254.68.1'.

NOTE: By default, the hostname of the DM-NAX-16AIN consists of the model name followed by the MAC address of the device. For example, DM-NAX-16AIN-00107FB58088.

Adapter 1

The Adapter 1 subheading contains settings for DHCP, IP Address, Subnet Mask, and Default Gateway of Ethernet adapter 1 on the rear panel of the device.

NOTES:

- An **+ Adapter 2** option only appears when the dual Ethernet ports on the DM-NAX-8ZSA are set to isolate traffic using the Port Selection feature. The settings for Adapter 2 are identical to those available for Adapter 1.
- DM NAX devices' internal processes use IP addresses in the 10.10.10.xxx range. This IP range should be avoided when addressing DM NAX devices to prevent conflicts.

Set the **DHCP** toggle to enabled (right) or disabled (left) to specify whether the IP address of the DM-NAX-16AIN is to be assigned by a DHCP (Dynamic Host Configuration Protocol) server.

- **Enabled:** When DHCP is enabled (default setting), the IP address of the DM-NAX-16AIN is automatically assigned by a DHCP server on the local area network (LAN).
- **Disabled:** When DHCP is disabled, manually enter information in the following fields:
 - **Primary Static DNS:** Enter a primary DNS IP address.
 - **Secondary Static DNS:** Enter a secondary DNS IP address.
 - **IP Address:** Enter a unique IP address for the DM-NAX-16AIN.
 - **Subnet Mask:** Enter the subnet mask that is set on the network.
 - **Default Gateway:** Enter the IP address that is to be used as the network's gateway.

To save any new network entries, click **Save Changes**.

Control System

Control System

Encrypt Connection ☐

IP Table

IP ID	IP Address/Hostname	Room ID
No records found		

+ Add x Remove

1. Click the **Encrypt Connection** button to navigate to the **Security** tab to configure encryption settings.
2. Enter the username in the **Control System Username** field.
3. Enter the password in the **Control System Password** field.
4. Enter the Room ID in the **Room ID** field.
5. Enter the IP ID of the DM-NAX-16AIN in the **IP ID** field.
6. Enter the IP address or hostname of the control system in the **IP Address/Hostname** field.
7. Click the **Save Changes** button to save the new entries. The Control System Save message box appears, indicating that the control system settings were saved successfully. Click the **Revert** button to revert to the previous settings without saving.

Commissioning

The **Commissioning** section provides a quick way to automatically assign multicast addresses to all of the device's internal audio-over-IP stream transmitters.

Commissioning

Starting Multicast Address 239.8.3.5

Last Used Multicast Address 239.8.3.36

Assign Addresses

































Click **Assign Addresses** to give each DM NAX transmitter in the DM-NAX-16AIN a unique multicast address beginning with the specified **Starting Multicast Address**. The valid range for **Starting Multicast Address** is 239.8.0.0 to 239.255.255.239.

NOTE: This will begin transmitting multicast traffic on your network, refer to the [DM NAX Audio-over-IP System Design Guide](#) document for details.

Inputs

The **Inputs** menu is used to configure **Name**, **Compensation**, and **Mute** attributes of the available analog and digital inputs on the DM-NAX-16AIN.

Inputs (Autosaved)


Name	TOSLINK1	TOSLINK2	S/PDIF1	S/PDIF2	RCA1	RCA2	RCA3	RCA4
Gain (db)	 0	 0	 0	 0	 0	 0	 0	 0
Signal Present								
Clipping Detected	 Nominal	 Nominal	 Nominal	 Nominal	 Nominal	 Nominal	 Nominal	 Nominal
Mute								

Configure Inputs

1. If needed, enter a friendly name for each input in its **Name** field.
2. To set a level compensation adjustment for a given input, do one of the following:
 - Move the **Compensation** slider up to increase or down to decrease the compensation. Compensation increases the level of the incoming audio signal on any of the physical inputs on the device's rear panel.
 - Click the **db** arrows to increase or decrease the compensation. Values range from -10 dB to 10 dB, adjustable in increments of 1 dB.
 - Manually enter a value in the **Compensation** field.
3. To mute the signal from the corresponding input, click the **Mute** button. To disable the mute, click the **Muted** button. By default, **Mute** is disabled.

Monitor the device's input signals using the text indicators in the **Signal Present** and **Clipping Detected** columns:

- **Signal Presence** indicates whether or not a signal is detected in that zone.
- **Clipping Detected** indicates if the signal is **Clipping** or **Nominal** (non-clipping).

Use the **Global Filter** text field to filter specific inputs by name. Not all of the available inputs are shown on the first page in this section when no **Global Filter** is applied. Use  at the bottom of the table to view the next page of inputs.

DM NAX Streams

Each local input of the DM-NAX-8ZSA can be made available as a DM NAX audio-over-IP stream.

Click **NAX Streams** to display the following information.




























NAX Streams

Device is Master PTP Clock SourceNo

Master Clock Status00107ffffe.f4062b

PTP Priority254

Transmitters (Autosaved)

Input Name	Stream	Nax Stream Address	Nax Stream Name	Status	Actions
Analog1	Stream01	0.0.0.0	Analog1100.10.7ff4.1e.53	Stream Stopped	  
Analog2	Stream02	0.0.0.0	Analog2200.10.7ff4.1e.53	Stream Stopped	  
Analog3	Stream03	0.0.0.0	Analog3300.10.7ff4.1e.53	Stream Stopped	  
Analog4	Stream04	0.0.0.0	Analog4400.10.7ff4.1e.53	Stream Stopped	  
Analog5	Stream05	0.0.0.0	Analog5500.10.7ff4.1e.53	Stream Stopped	  
Analog6	Stream06	0.0.0.0	Analog6600.10.7ff4.1e.53	Stream Stopped	  
Analog7	Stream07	0.0.0.0	Analog7700.10.7ff4.1e.53	Stream Stopped	  
Analog8	Stream08	0.0.0.0	Analog8800.10.7ff4.1e.53	Stream Stopped	  
S/PDIF1	Stream09	0.0.0.0	S/PDIF1900.10.7ff4.1e.53	Stream Stopped	  

- **Device is Master PTP Clock Source** indicates whether the device is the master for PTP on the network. **Yes** will be displayed in green when the local DM-NAX-16AIN is the PTP clock master and **No** will be displayed in red when another PTP clock on the network is operating as the master clock.
- **Master Clock Status** displays the Master Clock ID of the device on the network that acts as the Master Clock.
- **PTP Priority:** This sets the priority of the local DM NAX device's PTP clock relative to other clocks on the network. The default setting is 254 (one increment higher than the lowest possible value) so that the DM-NAX-16AIN will only operate as clock master if no other PTP master is present on the network. Valid values range from 1 to 255.

Configure Transmitters

Transmitters (Autosaved)					
Input Name	Stream	Nax Stream Address	Nax Stream Name	Status	Actions
Analog1	Stream01	0.0.0.0	Analog1100.10.7f4.1e53	Stream Stopped	▶ ◻ ⚙
Analog2	Stream02	0.0.0.0	Analog2200.10.7f4.1e53	Stream Stopped	▶ ◻ ⚙
Analog3	Stream03	0.0.0.0	Analog3300.10.7f4.1e53	Stream Stopped	▶ ◻ ⚙
Analog4	Stream04	0.0.0.0	Analog4400.10.7f4.1e53	Stream Stopped	▶ ◻ ⚙
Analog5	Stream05	0.0.0.0	Analog5500.10.7f4.1e53	Stream Stopped	▶ ◻ ⚙
Analog6	Stream06	0.0.0.0	Analog6600.10.7f4.1e53	Stream Stopped	▶ ◻ ⚙
Analog7	Stream07	0.0.0.0	Analog7700.10.7f4.1e53	Stream Stopped	▶ ◻ ⚙
Analog8	Stream08	0.0.0.0	Analog8800.10.7f4.1e53	Stream Stopped	▶ ◻ ⚙
S/PDIF1	Stream09	0.0.0.0	S/PDIF1900.10.7f4.1e53	Stream Stopped	▶ ◻ ⚙
S/PDIF2	Stream10	0.0.0.0	S/PDIF21000.10.7f4.1e53	Stream Stopped	▶ ◻ ⚙

NOTE: To configure transmitters not shown on the current page of the table, click the ▶ icon to display the next page of eight transmitters.

To configure a DM NAX transmit stream, do the following.


1. Enter a valid multicast address in the **NAX Stream Address** field.
2. Enter a name in the **NAX Stream Name** field by which the stream can be identified. This stream name is associated with the DM NAX stream's multicast address by other DM NAX or AES67 devices, like a device hostname that resolves to a given IP address.
3. **Status** indicates whether a stream is transmitting or not. When the stream has started or stopped, the **Status** column will update accordingly.
4. Click the configure button (⚙) in the **Actions** column. The **Configure** dialog appears:

The image shows a 'Configure' dialog box with a blue header and a close button (X). Inside, there is a toggle switch for 'Auto Initiation' which is currently turned off. Below it is a 'Port' field with a dropdown arrow, showing the value '5004'. At the bottom, there are two buttons: 'OK' with a checkmark icon and 'CANCEL' with an X icon.

5. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled for a given stream, the stream will begin transmitting automatically and will be available as a multicast stream on your network at the specified multicast address.
 - If **Auto Initiation** is disabled for the input, the stream will not begin transmitting until it is manually initiated.
6. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number for DM NAX streams is 5004.
7. Click **OK** to save or click **Cancel** to cancel the changes.

Port Selection

The Port Selection feature allows the device's internal network traffic to be managed and segregated based on traffic type. Internal VLANs are used to segment device management and streaming service traffic to a separate physical device Ethernet port than audio-over-IP streaming traffic. With Port Selection enabled on all DM NAX devices on a network, DM NAX and AES67 network traffic can be physically separated from the control network onto a dedicated audio network.



To configure Port Selection:

1. Set the **Port Selection** toggle to the right position to enable Port Selection. Set the toggle to the left position to disable Port Selection. By default, **Port Selection** is disabled.

NOTE: Ports 1 and 2 correspond to the Ethernet adapters labeled **1** and **2** on the rear panel of the DM-NAX-16AIN, respectively.

2. With **Port Selection** enabled, select an Ethernet port from the **Management** drop-down menu to designate which Ethernet port on the rear panel of the device will handle network traffic relating to device configuration and the device's connection to a control system.


NOTE: The Management port controls your connection to the web interface. Changing the port value can result in losing your connection to the device via the web interface.

3. With **Port Selection** enabled, select an Ethernet port from the **Audio/NAX** drop-down menu to designate which Ethernet port on the rear panel of the device will handle audio-over-IP streaming network traffic.
4. Click **Save** changes to apply the new settings.

NOTE: Making changes to **Port Selection** settings will require a reboot.

Security


Click the **Security** tab to configure security for users and groups and to allow different levels of access to the DM-NAX-16AIN functions . By default, security is disabled.



Select **Encrypt and Validate**, **Encrypt**, or **OFF** in the **SSL Mode** drop-down menu, to specify whether to use encryption. By default, SSL Mode is set to **OFF**.

Current User

Click the **Current User** tab to view read-only information or to change the password for the current user.




The interface shows the 'Current User' tab selected. It displays the following information:

Name	admin
Access Level	Administrator
Active Directory User	No
Groups	Administrators

Below the information is a blue button labeled 'Change Current User Password'.

1. Click the **Change Current User Password** button to provide a new password for the current user.
2. In the **Change Password** dialog, enter the current password in the **Current Password** field, the new password in the **Password** field, and then re-enter the same new password in the **Confirm Password** field.



The 'Change Password' dialog box is shown. It has a title bar with a close button. The fields are:


- Current Password: [password masked with dots]
- Password: [password masked with dots]
- Confirm Password: [password masked with dots]

At the bottom right are two buttons: 'OK' (with a checkmark icon) and 'Cancel' (with an 'x' icon).

3. Click **OK** to save or click **Cancel** to cancel the changes.

Users

Click the **Users** tab to view and edit user settings. The **Users** tab can be used to add or remove local and Active Directory users and preview information about users.



Use the **Search Users** field to enter search term(s) and display users that match the search criteria.

If users listed in the **Users** table span across multiple pages, navigate through the list of users by clicking a page number or by using the left or right arrows at the bottom of the **Users** pane to move forward or backward through the pages.

Each page can be set to display 5, 10, or 20 users by using the drop-down menu to the right of the navigation arrows.

Information about existing users is displayed in table format and the following details are provided for each user.


- **Username:** Displays the name of the user.
- **AD User:** Displays whether the user requires authentication using Active Directory.

Click the corresponding button in the Actions column to view detailed user information or to delete the user.

To create a new user, click the **Create User** button.

Create a New Local User

1. Click the **Create User** button in the User tab.
2. In the **Create User** dialog, enter the following:



The screenshot shows a 'Create User' dialog box. The 'Name' field contains 'test'. The 'Active Directory User' toggle is disabled. The 'Password' and 'Confirm Password' fields are masked with dots. The 'Groups' dropdown is set to 'Administrators'. The 'OK' and 'Cancel' buttons are at the bottom right.

- a. Enter a user name in the **Name** field. A valid user name can consist of alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
- c. Assign the access level by selecting one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is disabled.

3. Click **OK** to save or click **Cancel** to cancel the changes.


Add an Active Directory User

Users cannot be created or removed from the Active Directory server, but access can be granted to an existing user in the Active Directory server.

To grant access to an Active Directory user, you can either add the user to a local group on the DM-NAX-16AIN, or add the Active Directory group(s) that they are a member of to the DM-NAX-16AIN.

To add an Active Directory user.

1. Click the **Create User** button.
2. In the **Create User** dialog, enter the following.




The screenshot shows a 'Create User' dialog box with a blue header. Inside, there is a 'Name' text field with the value 'Connects\test'. Below it is a toggle switch labeled 'Active Directory User' which is currently turned on (blue). Underneath the toggle is a 'Groups' dropdown menu showing 'Connects'. At the bottom right of the dialog are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'x' icon.

- a. Enter a user name in the **Name** field in the format "Domain\UserName", for example "crestronlabs.com\JohnSmith". Valid user names can contain alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Select one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is set to enabled.


3. Click **OK** to save or click **Cancel** to cancel the changes.

Delete User


Click the trashcan button () in the **Actions** column to delete the user. Click **Yes** when prompted to delete the user or **No** to cancel the deletion.

After a user is removed from a group, they lose any access rights associated with that group. Note that the user account is not deleted by the delete user operation.

View User Details

Click the information button () in the **Actions** column to view information for the selected user. The **User Details** dialog displays the following information for the selected user.


- **Name:** Displays the name of the selected user.
- **Active Directory User:** Displays whether the user is an Active Directory user.
- **Group:** Displays group(s) the selected user is part of.




The **User Details** dialog box has a blue title bar with the text "User Details" and a close button (X). The main area is white and contains three rows of information: "Name" with the value "admin1", "Active Directory User" with the value "No", and "Groups" with the value "Administrators". At the bottom right, there is a blue button with a checkmark and the text "OK".

Click **OK** to close the **User Details** dialog and to return to the **Users** tab.

Update User Details



The **Update User** dialog box has a blue title bar with the text "Update User" and a close button (X). The main area is white and contains several fields: "Name" with the value "admin1", "Active Directory User" with a toggle switch that is currently off, "Password" and "Confirm Password" fields both containing seven dots, and a "Groups" drop-down menu with "Administrators" selected. At the bottom right, there are two blue buttons: one with a checkmark and "OK", and another with an X and "Cancel".

1. Click the edit button () in the **Actions** column to update information for the selected user.
2. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
3. Select one or more groups to assign the user to from the **Groups** drop-down list.
4. Click **OK** to save or click **Cancel** to cancel the changes.

The **Update User** dialog also displays the following read-only information for the selected user.

- **Name:** Displays the name of the user.
- **Active Directory User:** Displays whether the user is an Active Directory user.











Groups

Click the **Groups** tab to view and edit group settings. The **Groups** tab can be used to add local and Active Directory groups, remove local and Active Directory groups, and preview information about a group.

Use the **Search Groups** field to enter search term(s) and display groups that match the search criteria.

Current UserUsersGroups

Search...

Group Name	AD Group	Access Level	Action
Administrators	No	Administrator	 
Connects	No	Connect	 
Operators	No	Operator	 
Programmers	No	Programmer	 
Users	No	User	 

1

10



Create Group

If groups listed in the **Groups** table span across multiple pages, navigate through the groups by clicking a page number or by using the left or right arrows at the bottom of the Groups pane to move forward or backward through the pages.

Additionally, each page can be set to display 5, 10, or 20 groups by using the drop-down menu to the right of the navigation arrows.


Existing groups are displayed in a table and the following information is provided for each group:

- **Group Name:** Displays the name of the group.
- **AD Group:** Displays whether the group requires authentication using Active Directory.
- **Access Level:** Displays the predefined access level assigned to the group (Administrator, Programmer, Operator, User, or Connect).

Click the corresponding button in the **Actions** column to view detailed group information () or to delete () selected group.

Click on the **Create Group** button in the **Groups** tab to create new group.

Create Local Group

The image shows a 'Create Group' dialog box with a blue header bar containing the title 'Create Group' and a close button. The dialog has three main input areas: a 'Name' text field with 'test12' entered, an 'Access Level' dropdown menu currently showing 'Programmer', and an 'Active Directory Group' toggle switch which is turned off (grey). At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'X' icon.


1. Click the **Create Group** button.
2. In the **Create Group** dialog, enter the following:
 - a. Enter the group name in the **Name** field.
 - b. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is disabled.

3. Click **OK** to save. Click **Cancel** to cancel the changes.

Add Active Directory Group

A group cannot be created or removed from the Active Directory server, but access can be granted to an existing group in Active Directory.

The image shows a 'Create Group' dialog box, similar to the one above but with the 'Active Directory Group' toggle switch turned on (blue). The 'Name' field contains 'test' and the 'Access Level' dropdown menu is set to 'Administrator'. The 'OK' and 'Cancel' buttons are at the bottom right.

Once the group is added, all members of that group will have access to the DM-NAX-16AIN.


1. Click the **Create Group** button.
2. In the **Create Group** dialog enter the following:
 - a. Enter the group name in the **Name** field, for example "Engineering Group". Note that group names are case sensitive; a space is a valid character that can be used in group names.

3. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is enabled.


4. Click **OK** to save. Click **Cancel** to cancel the changes.


Delete a Group

Click the trashcan button () in the **Actions** column to delete a group. Click **Yes** when prompted to delete the group or **No** to cancel the deletion.

When a group is deleted, users in the group are not removed from the device or Active Directory server. However, because a user's access level is inherited from a group(s), users within the deleted group will lose access rights associated with the group.

View Group Details

Click the information button () in the **Actions** column to view information for the selected group. The **Group Details** dialog lists the following information for the selected group.



The **Group Details** dialog box displays the following information for the selected group:

Name	Administrators
Access Level	Administrator
Active Directory Group	No

At the bottom right of the dialog is a blue button with a checkmark icon and the text **OK**.

- **Name:** Displays the name of the group.
- **Access Level:** Displays the access level of the group and its users.
- **Active Directory Group:** Displays whether the group is an Active Directory group.

Click **OK** to close the **Group Details** dialog and to return to the Groups tab.

802.1x Configuration

The DM-NAX-16AIN has built-in support for the 802.1X standard (an IEEE network standard designed to enhance the security of wireless and Ethernet LANs. The standard relies on the exchange of messages between the device and the network's host, or authentication server), allowing communication with the authentication server and access to protected corporate networks.

The screenshot shows the '802.1x Configuration' page in a web interface. At the top, there is a navigation bar with 'Status', 'Settings', 'Security', and '802.1x Configuration'. Below this, a blue header bar contains the text '802.1x Configuration'. The main configuration area includes a toggle for 'IEEE 802.1x Authentication' which is turned on. Below this is a dropdown for 'Authentication Method' set to 'EAP MSCHAP V2- password'. There are input fields for 'Domain' (containing 'secure12'), 'Username' (containing 'admin'), and 'Password' (masked with dots). Another toggle for 'Enable Authentication Server Validation' is also turned on. At the bottom, there is a section 'Select Trusted Certificate Authorities' with a search bar and a list of certificate authorities. The list includes 'AAA Certificate Services', 'AC RAIZ FNMT-RCM', 'ACCVRAIZ1', 'Actalis Authentication Root CA', 'AffirmTrust Commercial', 'AffirmTrust Networking', 'AffirmTrust Premium ECC', 'AffirmTrust Premium', 'Amazon Root CA 1', 'Amazon Root CA 2', 'Amazon Root CA 3', 'Amazon Root CA 4', 'Atos TrustedRoot 2011', 'Autoridad de Certificacion Firmaprofesional CIF A62634068', and 'Baltimore CyberTrust Root'. The first four items are checked.

IEEE 802.1x Authentication ☒

Authentication Method: EAP MSCHAP V2- password

Domain: secure12

Username: admin

Password:

Enable Authentication Server Validation ☒

Select Trusted Certificate Authorities)

- ☒ AAA Certificate Services
- ☐ AC RAIZ FNMT-RCM
- ☐ ACCVRAIZ1
- ☐ Actalis Authentication Root CA
- ☒ AffirmTrust Commercial
- ☐ AffirmTrust Networking
- ☐ AffirmTrust Premium ECC
- ☒ AffirmTrust Premium
- ☐ Amazon Root CA 1
- ☐ Amazon Root CA 2
- ☒ Amazon Root CA 3
- ☐ Amazon Root CA 4
- ☐ Atos TrustedRoot 2011
- ☐ Autoridad de Certificacion Firmaprofesional CIF A62634068
- ☐ Baltimore CyberTrust Root

To Configure DM-NAX-16AIN for 802.1X Authentication

1. Set the **IEEE 802.1X Authentication** toggle to enabled. This will enable all options on the 802.1X dialog.
2. Select the **Authentication method: EAP-TLS Certificate** or **EAP-MSCHAP V2 Password** according to the network administrator's requirement.
3. Do either one of the following:
 - Select **EAP-TLS Certificate**, click **Action/Manage Certificates** to upload the required machine certificate. The machine certificate is an encrypted file that will be supplied by the network administrator, along with the certificate password.
 - Select **EAP-MSCHAP V2 Password**, enter the username and password supplied by the network administrator into the **Username** and **Password** fields. This method does not require the use of a machine certificate, only the user name and password credentials.
4. If you enabled the **Enable Authentication Server Validation** option, this will enable the **Select Trusted Certificate Authoritie(s)** list box which contains signed Trusted Certificate Authorities (CAs) preloaded into the DM-NAX-16AIN.

Select the check box next to each CA whose certificate can be used for server validation, as specified by the network administrator.

If the network does not use any of the listed certificates, the network administrator must provide a certificate, which must be uploaded manually via the **Manage Certificates** functionality.

5. If required, type the domain name of the network in the **Domain** field.
6. When the 802.1X settings are configured as desired, click **Save Changes** to save the changes to the device and reboot it. Click **Revert** to cancel any changes.

Access the Web Interface With the Crestron Toolbox™ Application

To access the web interface by opening a web browser within the Crestron Toolbox™ application, do the following:

1. Open the Crestron Toolbox application.
2. From the **Tools** menu, select **Device Discovery Tool**. You can also access the Device Discovery Tool by clicking the Device Discovery Tool button () in the Crestron Toolbox toolbar. The DM-NAX-16AIN is discovered and listed in the device list on the left side of the screen. The associated host name, IP address, and firmware version are also displayed.

NOTE: If there is security software running on the computer, a security alert might be displayed when the Crestron Toolbox application attempts to connect to the network. Make sure to allow the connection, so that the Device Discovery Tool can be used.

3. In the Device Discovery Tool list, double-click your device.
4. Enter your credentials in the **Authentication Required** dialog that opens, and then click **Log In**.
5. Click the **Web Configuration** button in the Configuration page displayed on the left side of the Device Discovery Tool.

DM-NAX-AMP-X300

This section describes how to configure the DM-NAX-AMP-X300.

Web Interface Configuration

The DM-NAX-AMP-X300 web interface allows you to view status information and configure network and device settings.

NOTE: Throughout the web interface, values can be entered manually. When values entered manually fall out of the range, the value will be maximized or minimized or have no effect.

Access the Web Interface

To access the web interface, do either of the following:

- [Access the Web Interface with a Web Browser on page 408](#)
- [Access the Web Interface With the Crestron Toolbox™ Application on page 472](#)

The web interface is accessed from a web browser. The following table lists operating systems and their corresponding supported web browsers.

Operating System and Supported Web Browsers


OPERATING SYSTEM	SUPPORTED WEB BROWSERS
Windows® operating system	Chrome™ web browser, version 31 and later
	Firefox® web browser, version 31 and later
	Internet Explorer web browser, version 11 and later
	Microsoft Edge web browser
macOS® operating system	Safari® web browser, version 6 and later
	Chrome web browser, version 31 and later
	Firefox web browser, version 31 and later

Access the Web Interface with a Web Browser

1. Enter the IP address of the DM-NAX-AMP-X300 into a web browser.


NOTE: To obtain the IP address, use the **Device Discovery Tool** option in Crestron Toolbox™ application or an IP scanner application.

2. If you are creating a user account for the first time, do the following; otherwise, skip to step 3.
 - a. Enter a username in the **Username** field.
 - b. Enter a password in the **Password** field.
 - c. Re-enter the same password in the **Confirm Password** field.



The screenshot shows the Crestron logo at the top left. Below it, a yellow warning triangle icon is followed by the text "DEVICE FIRST BOOT". In the center, there is a white box titled "Device Administration". Inside this box, there are three input fields labeled "Username", "Password", and "Confirm Password". Below these fields is a green button with a white plus sign and the text "Create User". At the bottom of the white box, there is small text: "© 2021 Crestron Electronics, Inc.", "Privacy Statement", and "Crestron Software End-User License Agreement".

- d. Click **Create User**. The Device Administration page appears.




The screenshot shows the same Crestron logo at the top left. Below it, the "DEVICE FIRST BOOT" message is no longer present. The white box titled "Device Administration" still contains the "Username" and "Password" input fields. Below these fields is a blue button with a white magnifying glass icon and the text "Sign In". At the bottom of the white box, the same small text as in the previous screenshot is visible: "© 2021 Crestron Electronics, Inc.", "Privacy Statement", and "Crestron Software End-User License Agreement".

3. Enter the username in the **Username** field.
4. Enter the password in the **Password** field.
5. Click **Sign In**.

Action

The **Action** drop-down menu is displayed at the top right side of the interface and provides quick access to common device functions:

- Save Changes
- Revert
- Reboot
- Restore
- Update Firmware
- Download Logs
- Manage Certificates



Save Changes

Click **Save Changes** to save any changes made to the configuration settings.


Revert

Click **Revert** to revert the device back to the last saved configuration settings.

Reboot the DM-NAX-AMP-X300

Certain changes to the settings may require the DM-NAX-AMP-X300 to be rebooted to take effect. To reboot the device, do the following:

1. Click **Reboot** in the **Actions** drop-down menu. The **Confirmation** message box appears.




2. Click **Yes, Reboot Now** to reboot the device. The **Reboot** message box appears.
Wait for the device reboot to complete before attempting to reconnect to the device.

Restore to Factory Default Settings

1. Click **Restore** in the **Actions** drop-down menu to restore the settings of the DM-NAX-AMP-X300 to factory defaults.

NOTE: When settings are restored, all settings, including the network settings, will revert to the factory default. If a static IP address is set, restoring the device to factory default settings will revert the IP address to the default DHCP mode.




2. Click **Yes** in the **Confirmation** dialog to restore the DM-NAX-AMP-X300 to factory settings. Click **No** to cancel the restore operation.

A dialog is displayed again, indicating that the restore process was successful and that the device rebooted.

You can also restore the device by following the Reset procedures in the [DM-NAX-AMP-X300 Installation on page 105](#) section of this manual.

Update Firmware

1. Click **Update Firmware** in the **Actions** drop-down menu.
2. In the **Firmware Upgrade** dialog, click **+ Browse**.



3. Locate and select the desired firmware file, and then click **Open**. The selected firmware file name is displayed in the **Firmware Upgrade** dialog.
4. Click **Load** and wait for the progress bar to complete and for the **OK** button in the message to become clickable.
5. Click **OK**. The device with new firmware can now be accessed.


Download Logs

1. Click **Download Logs** in the **Actions** drop-down menu to download the device message logs for diagnostic purposes.

The log file is downloaded to the Downloads folder of the PC.

Manage Certificates

Use the **Manage Certificates** dialog to add, remove, and manage certificates used in 802.1x and other protected networks.



1. Click **Manage Certificates** in the **Actions** drop-down menu. The following certificate tabs are displayed:
 - **Root:** The Root certificate is used by the DM-NAX-AMP-X300 to validate the network's authentication server. The DM-NAX-AMP-X300 has a variety of Root certificates, self-signed by trusted CAs (Certificate Authorities) preloaded into the device. Root certificates must be self-signed.
 - **Intermediate:** The Intermediate store holds non self-signed certificates that are used to validate the authentication server. These certificates will be provided by the network administrator if the network does not use self-signed Root certificates.
 - **Machine:** The machine certificate is an encrypted PFX file that is used by the authentication server to validate the identity of the DM-NAX-AMP-X300. The machine certificate will be provided by the network administrator, along with the certificate password. For 802.1x, only one machine certificate can reside on the device.
 - **Web Server:** The Web Server certificate is a digital file that contains information about the identity of the web server.


To Add Certificates

1. Click the corresponding certificate tab.
2. Click the **Add Root Certificate** button.
3. Click the **+ Browse** button.
4. Locate and select the file, and then click the **Open** button.

NOTE: If the certificate is a Machine Certificate, enter the password provided by the network administrator.

5. Click **OK**. This will add the certificate to the list box, displaying the file name and expiration date.
The certificate is now available for selection and can be loaded to the device.


To Delete Certificates

1. Click the corresponding certificate tab.
2. Click the trashcan button () in the **Actions** column to delete the certificate.
3. Click **Yes** when prompted to delete the certificate or **No** to cancel the deletion.

Status

The **Status** tab is the first page displayed when opening the interface of the DM-NAX-AMP-X300. It displays general information about the DM-NAX-AMP-X300 (such as Model Name, Firmware Version, and Serial Number), current network settings (such as Host Name and IP Address, etc.), and input and output ports' current status.


The Status tab can be accessed at any time by clicking the **Status** tab of the DM-NAX-AMP-X300 interface.



Information displayed on the **Status** tab is organized into different sections.

Device

The **Device** section displays the **Model**, **Firmware Version**, and **Serial Number** of the DM-NAX-AMP-X300.



Click + **More Details** to review additional information about the DM-NAX-AMP-X300.

CRESTRON®

AMP-X300

▼ Action ▼

More Details

DM-NAX-AMP-X300

1.1.0082.22396

Build

Jan 24 2023 (490081)

Updater

1.1.0082.22396

Bootloader

1.00.00

CCUI Version

1.66.887159

XIOSDK

3.8.2

IoTSDK

1.9.1

Build time

22:39:41

Product ID

0x7A03

Revision ID

0x0200

ctrl-audio-dsp-0

FW v34 (Driver v3.11)

ctrl-extclkkin-pps

Driver v1.1

ctrl-prod-info

Driver v3.0

PUF


1.1.0082.22396

Forced Auth Mode

True

Network

The **Network** section displays network-related information about the DM-NAX-AMP-X300, including the Hostname, Domain Name, and DNS Servers.




NOTE: By default, the host name of the DM-NAX-AMP-X300 consists of the model name followed by the MAC address of the device. For example, DM-NAX-AMP-X300-00107FB58088.

Click **+ Adapter 1** to display an expanded section that shows additional information. If **+ Adapter 1** is selected, click **- Less** details to collapse the section.

NOTE: The **+ Adapter 2** option appears when the dual Ethernet ports on the DM-NAX-AMP-X300 are set to isolate traffic using the Port Selection feature.

Control System

The **Control System** section displays connection information, consisting of the following:



- **Encrypt Connection:** ON or OFF
- **IP ID:** Reports the currently used IP ID of the DM-NAX-AMP-X300
- **IP Address/Hostname:** The IP address of the control system
- **Room ID:** Displays the room ID
- **Status:** OFFLINE or ONLINE

Settings

The **Settings** tab enables configuration of the DM-NAX-AMP-X300 settings. The Settings page can be accessed at any time by clicking the **Settings** tab of the DM-NAX-AMP-X300 interface.

Many options in the Settings tab are exclusive to a specific device mode: Residential or Commercial. The DM-NAX-AMP-X300 is in Commercial mode by default.


This section provides the following information:

- [Commercial Mode on page 418](#)
- [Residential Mode on page 439](#)

Commercial Mode

This section provides the following information:

- [System Setup on page 419](#)
- [Commissioning on page 424](#)
- [Output Channels on page 424](#)
- [Input Channels on page 430](#)
- [DM NAX Streams on page 431](#)
- [Port Selection on page 434](#)
- [Mixing on page 435](#)



System Setup

The **System Setup** section contains settings for **Date/Time**, **Auto Update**, **Network**, **Control System**, **Cloud Settings**, and **Device Modes**.

Date/Time

Use the **Date/Time** section to configure the date and time settings of the DM-NAX-AMP-X300.

— Date/Time

Synchronization

Time Synchronization ☒

Synchronize Now

NTP Time Servers

<input type="checkbox"/>	Address	Port	Authentication Method	Authentication Key	Key ID
<input type="checkbox"/>	pool.ntp.org	123	None	*****	0

Add Remove

Configuration

Time Zone (UTC-05:00) Eastern Time (US & ...)

Date 01/26/2023

Time 08:37

Time Synchronization

1. Set the **Time Synchronization** toggle to the right position to enable or left position to disable time synchronization. By default, time synchronization is enabled.
2. In the **NTP Time Servers** table, enter the URL of a NTP (Network Time Protocol) or SNTP (Simple Network Time Protocol) server. Up to three time servers can be added on a device.
3. Click **Synchronize Now** to perform time synchronization between the device's internal clock and the time server.

Time Configuration

1. Click on the **Time Zone** drop-down menu to select the applicable time zone.
2. In the **Date** field, enter the current date.
3. In the **Time (24hr Format)** field, enter the current time in 24-hour format.

Click the **Save Changes** button to save the settings.

Click **Revert** from the **Actions** drop-down menu to revert to the previous settings without saving.

Auto Update

The DM-NAX-AMP-X300 can automatically check for and install firmware updates at scheduled intervals via the Auto Update feature.

— Auto Update

Auto Update ☒

Custom URL ☐

Custom URL Path

Schedule

Day of Week

Time of Day

Poll Interval Minutes

Update Now

1. Set the **Auto Update** toggle to the right position to enable Auto Update.
2. Define the URL to download the updates by doing either of the following:
 - a. Use the default URL to download the updates from the Crestron server.
 - b. Use a custom URL. Set the **Custom URL** toggle to the right position to enable a custom URL. In the **Custom URL Path** text box, enter the path to a custom manifest file in the FTP or SFTP URL format. Use the Crestron Auto Update Tool to generate a custom manifest file, then store the file on an FTP (File Transfer Protocol) or SFTP (Secure File Transfer Protocol) server.
3. Set a schedule for the automatic firmware update by doing either of the following:
 - a. Select the desired **Day of Week** and **Time of Day** (24-hour format) values.
 - b. Set the **Poll Interval** by entering a value from **60** to **65535** minutes. A value of **0** disables the Poll Interval.
4. Click **Save Changes**.

Clicking **Update Now** causes the device to check for a firmware update immediately. If a schedule was set in step 4 above, that schedule still remains in effect.

Network

The **Network** section contains network-related settings for the DM-NAX-AMP-X300, including the Hostname, Domain, Primary Static DNS, and Secondary Static DNS.

Network

Hostname * AMP-X300-TECH-DOCS

Domain 6vcrestrongelab.com

Primary Static DNS 10.253.31.12(DHCP)

Secondary Static DNS

Adapter 1

DHCP ☒

IP Address 10.253.46.147

Subnet Mask 255.255.255.0

Default Gateway 10.253.46.1

NOTE: By default, the hostname of the DM-NAX-AMP-X300 consists of the model name followed by the MAC address of the device. For example, DM-NAX-AMP-X300-00107FB58088.

Adapter 1

The Adapter 1 subheading contains settings for DHCP, IP Address, Subnet Mask, and Default Gateway of Ethernet adapter 1 on the rear panel of the device.

NOTES:

- An **+ Adapter 2** option only appears when the dual Ethernet ports on the DM-NAX-8ZSA are set to isolate traffic using the Port Selection feature. The settings for Adapter 2 are identical to those available for Adapter 1.
- DM NAX devices' internal processes use IP addresses in the 10.10.10.xxx range. This IP range should be avoided when addressing DM NAX devices to prevent conflicts with these internal addresses.

Set the **DHCP** toggle to enabled (right) or disabled (left) to specify whether the IP address of the DM-NAX-AMP-X300 is to be assigned by a DHCP (Dynamic Host Configuration Protocol) server.

- **Enabled:** When DHCP is enabled (default setting), the IP address of the DM-NAX-AMP-X300 is automatically assigned by a DHCP server on the local area network (LAN).
- **Disabled:** When DHCP is disabled, manually enter information in the following fields:
 - **Primary Static DNS:** Enter a primary DNS IP address.
 - **Secondary Static DNS:** Enter a secondary DNS IP address.
 - **IP Address:** Enter a unique IP address for the DM-NAX-8ZSA.
 - **Subnet Mask:** Enter the subnet mask that is set on the network.
 - **Default Gateway:** Enter the IP address that is to be used as the network's gateway.

To save any new network entries, click **Save Changes**.

Control System

Control System

Encrypt Connection

IP Table

	IP ID	IP Address/Hostname	Room ID
No records found			
+ Add		✖ Remove	

1. Click the **Encrypt Connection** button to navigate to the **Security** tab to configure encryption settings.
2. Enter a username in the **Control System Username** field.
3. Enter a password in the **Control System Password** field.
4. Enter the Room ID in the **Room ID** field.
5. Enter the IP ID of the DM-NAX-AMP-X300 in the **IP ID** field.
6. Enter the IP address or hostname of the control system in the **IP Address/Hostname** field.
7. Click the **Save Changes** button to save the new entries. The Control System Save message box appears, indicating that the control system settings were saved successfully. Click the **Revert** button to revert to the previous settings without saving.

Cloud Settings


Cloud Settings

Cloud Configuration Service Connection ☒


Set the **Cloud Settings** toggle to enabled (right) or disabled (left) to specify whether the DM-NAX-AMP-X300 can communicate with the XiO Cloud® platform.

Device Modes

Use the **Device Modes** section to configure the **Application Mode**, **Audio-Over-IP Mode**, and **Standby Mode**, as well as see a live status readout of the device's rear panel functionality.



- **Application Mode:** The Application Mode determines which options and controls are available.
 - Select **Residential (Standard)** or **Commercial (Advanced)**. A **Reboot** confirmation message box appears.




- Click **Yes, Reboot Now** to reboot the device into the selected mode. The **Reboot** message box appears.
 - Wait for the device reboot to complete before attempting to reconnect to the device.
- **Audio Over IP Mode:** Select **NAX (AES67)** or **Dante** to specify what type of audio-over-IP streams the DM-NAX-AMP-X300 will accept and transmit.

NOTE: In NAX (AES67) mode, the DM-NAX-AMP-X300 can still accept streams from Dante devices by way of the AES67 Compatibility Mode feature, which can be enabled on most Dante devices.

- **Rear Panel Lockout:** Set the **Rear Panel Lockout** toggle to specify whether the physical controls on the rear panel are locked (right) or functional (left). When locked, all device controls are handled through this menu.
- **Standby Mode:** Select the DM-NAX-AMP-X300's standby behavior.
 - **Always On:** The device's amplifier remains powered on at all times.
 - **Power Saver:** If no signal is detected for 25 minutes, the device enters a low power state by turning off the amplifier board. Upon detecting an audio signal, the amplifier will be turned back on.
- **Channel 1/2 Output Drive:** Set Channel 1/2 to **Standard** or **Bridged**. This option is only selectable when the **Output Mode** is set to **Lo-Z**.
- **Channel 3/4 Output Drive:** Set Channel 3/4 to **Standard** or **Bridged**. This option is only selectable when the **Output Mode** is set to **Lo-Z**.
- **Output Mode:** The DM-NAX-AMP-X300 can be configured to work with 4 Ω and 8 Ω (low impedance or "Lo-Z") loads or a distributed audio (high impedance or "Hi-Z") 70/100V system.
 - **Lo-Z:** Select **Lo-Z** to use the amplifier with 4 Ω or 8 Ω low impedance loudspeakers.
 - **70V:** Select **70V** to use the amplifier in a 70V distributed audio system.
 - **100V:** Select **100V** to use the amplifier in a 100V distributed audio system.

Commissioning

The **Commissioning** section provides a quick way to automatically assign multicast addresses to all of the device's internal audio-over-IP stream transmitters.




Click **Assign Addresses** to give each DM NAX transmitter in the DM-NAX-AMP-X300 a unique multicast address beginning with the specified **Starting Multicast Address**. The valid range for **Starting Multicast Address** is 239.8.0.0 to 239.127.255.255.

NOTE: This will begin transmitting multicast traffic on your network, refer to the [General Network Requirements](#) document for details.

Output Channels

The **Output Channels** section enables the viewing and configuration of Zone outputs.



Zones

In the **Zones** section, the properties of each zone can be viewed and configured.

Name	Amp1	Amp2	Amp3	Amp4	LineOut1	LineOut2	LineOut3	LineOut4	StreamOut1Ch	StreamOut2Ch	StreamOut3Ch
Volume (%)	30	30	30	30	30	30	30	30	30	30	30
Signal Presence	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗
Signal Level	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Mute	⏻	⏻	⏻	⏻	⏻	⏻	⏻	⏻	⏻	⏻	⏻
Action	Edit	Edit	Edit	Edit	Edit	Edit	Edit	Edit	Edit	Edit	Edit

Signal Presence indicates whether or not an audio signal is detected in that zone.

Signal Level indicates if the signal is **Clipping** or **Nominal** (non-clipping).

- **Nominal:** The signal level is within normal operating bounds and below the clipping threshold.
- **Clipping:** The signal level is clipping or above the -3 dB warning threshold and in danger of clipping.

Give each zone a friendly name using the **Name** row of the **Zones** table. If the device is paired with a control system, these names may be overwritten by the control system's program.

To configure the zone volume, do one of the following:

- Move the **Volume** slider up to increase or down to decrease the zone volume.
- Click the % arrows to increase or decrease the zone volume. Values range from 0 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Volume** field.


To mute all audio output from a zone, click its respective **Mute** button. To unmute the zone, click the **Muted** button.

Click **Edit** to view additional **Zone** and **Output** options.


Zone

To configure additional zone settings, click the Edit button. The **Edit Zone** window appears.

Click **Zone** to access the settings for **Tone** and **Delay**.




Tone



- **Bass:** To adjust the bass, do one of the following:
 - Move the **Bass** slider to the right to increase or to the left to decrease the bass db.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of .1 db.
 - Manually enter a value in the **Bass** field.
- **Treble:** To adjust the treble, do one of the following:
 - Move the **Treble** slider to the right to increase or to the left to decrease the treble db.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of .1 db.
 - Manually enter a value in the **Treble** field.

Delay




To set the delay, do one of the following:

- Move the **Delay Time(ms)** slider to the right to increase or to the left to decrease the delay time.
- Click the **ms** arrows to increase or decrease the delay. Values range from 0 ms to 250 ms, adjustable in increments of 1 ms.
- Manually enter a value in the **Delay Time(ms)** field.

Output

Click **Output** to access the settings for **Minimum/Maximum**, **Signal**, **Speaker Configuration**, **Speaker/Faults**, and **Equalizer Settings**.

Minimum/Maximum Volume



— Minimum / Maximum (Autosaved)

Minimum %

Maximum %

Default %


1. To set the minimum volume of the zone, do one of the following:
 - Move the **Minimum** slider to the right to increase or to the left to decrease the minimum volume.
 - Click the **%** arrows to increase or decrease the minimum volume. Values range from 0 to 50%, adjustable in increments of 1%.
 - Manually enter a value in the **Minimum** field.
2. To set the maximum volume of the zone, do one of the following:
 - Move the **Maximum** slider to the right to increase or to the left to decrease the maximum volume.
 - Click the **%** arrows to increase or decrease the maximum volume. Values range from 70 to 100%, adjustable in increments of 1%.
 - Manually enter a value in the **Maximum** field.

NOTE: When a **Minimum** and **Maximum** volume are set, the 1-100% range represented by the **Zone** and **Default** volume controls are scaled to the range set. For example, if a **Minimum** of 10% and a **Maximum** of 80% are set for a zone, the 1-100% range of the **Zone** volume control is scaled to the 10%-80% range set as the **Minimum** and **Maximum**.

3. To set the default volume of the zone, do one of the following:
 - Move the **Default** slider to the right to increase or to the left to decrease the default volume.
 - Click the **%** arrows to increase or decrease the default volume. Values range from 0 to 50%, adjustable in increments of 1%.
 - Manually enter a value in the **Default** field.

NOTE: The **Default** volume is applied as the **Zone** volume any time the zone receives a source route and no source was previously routed to that zone.

Signal




— Signal (Autosaved)

Signal	Not Present
Clipping	None

The **Signal** section is a read-only field that displays the **Signal** and **Clipping** status of the zone output.

- If an output signal is present but not clipping, **Signal** will display **Present** in green and **Clipping** will display **None** in green.
- If an output signal is present and clipping, **Signal** will display **Present** in green and **Clipping** will display **Present** in red.
- If no output signal is detected, **Signal** will display **Not Present** in red and **Clipping** will display **None** in green.

Speaker Configuration



— Speaker Configuration (Autosaved)


Enable Speaker Protect ☐

Speaker Wattage 40 Watts

Impedance

1. Set the **Enable Speaker Protect** toggle to the right position to enable speaker protection for the zone output. Set the toggle to the left position to disable speaker protection. By default, **Enable Speaker Protect** is set to the left position.
2. To set the maximum output wattage, do one of the following:
 - Move the **Speaker Wattage** slider to the right to increase or to the left to decrease the maximum peak amplifier wattage that can be output to the speaker.
 - Click the **Watts** arrows to increase or decrease the maximum peak amplifier wattage that can be output to the speaker. Values range from 5 W to 150 W, adjustable in increments of 1 W.
 - Manually enter a value in the **Speaker Wattage** field.
3. Select the impedance of the speaker on a selected zone from the **Impedance** drop-down menu. Values are **4 Ohms**, **8 Ohms**, and **Bridged**.

Speaker Faults



— Speaker / Faults (Autosaved)

DC Offset Fault	None
Over Current Fault	None
Clipping Detected	None
Over or Under Voltage	None
Over Temperature	None

The Speaker/Faults section is a read-only field that displays the status of the **DC Offset Fault**, **Over Current Fault**, **Clipping Detected**, **Over or Under Voltage**, and **Over Temperature** detectors for the zone output. If clipping or a given fault type is detected, then its corresponding readout displays **Fault Detected** in red. Otherwise, it displays **None** in blue.

Equalizer Settings

Band	Band01	Band02	Band03	Band04	Band05	Band06
Gain	0	0	0	0	0	0
Type	EQ	EQ	EQ	EQ	EQ	EQ
Frequency	32	64	125	250	500	1000
Bandwidth	0.33	0.33	0.33	0.33	0.33	0.33
Bypass	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Actions	Reset	Reset	Reset	Reset	Reset	Reset

Each zone output of the DM-NAX-AMP-X300 has a dedicated ten-band equalizer that can be fully customized to tune the zone output signal to the needs of an install. Each band can have a discrete gain, filter type, center frequency, and bandwidth set, and can also be bypassed. The equalizer itself can also be bypassed using the **Speaker EQ Enabled** toggle.

1. Set the **Speaker EQ Enabled** toggle to the right position to enable the equalizer. Set the toggle to the left position to bypass the equalizer.

NOTE: When **Speaker EQ Enabled** is disabled, all equalizer bands are bypassed. This is a quick way to perform A/B testing of the entire EQ curve.

2. With the **Speaker EQ Enabled** toggle in the right position, do the following to configure a given equalizer band:
 - a. To set a band's gain, do one of the following:
 - Move the **Gain** slider up to increase or down to decrease the gain.
 - Click the arrows to increase or decrease the gain. Values range from -40 dB to 20 dB, adjustable in increments of 0.1 dB.
 - Manually enter a value in the **Gain** field.





































- b. Select a filter type from the **Type** drop-down menu. By default, all bands are set to the **EQ** filter type. Some filter types will disable other settings in their respective band while enabled. For example, selecting the **LowPass** filter type for a band will disable that band's **Gain** and **Bandwidth** settings, since the **LowPass** filter applies a fixed roll-off slope at a set frequency. The available filter types are:
- **EQ:** a fully parametric filter that can boost or cut a range of frequencies.
 - **Notch:** a parametric filter designed to more precisely cut a frequency or range of frequencies. A notch filter can achieve a narrower bandwidth than the standard **EQ** parametric filter type.
 - **TrebleShelf:** a filter that boosts or cuts all frequencies above a set frequency by a set gain.
 - **BassShelf:** a filter that boosts or cuts all frequencies below a set frequency by a set gain.
 - **LowPass:** a filter that fully cuts all frequencies above a set frequency using a fixed roll-off slope of -12 dB per octave.
 - **HighPass:** a filter that fully cuts all frequencies below a set frequency using a fixed roll-off slope of -12 dB per octave.
- c. Set a center frequency for the equalizer band to tune a specific portion of the audible frequency spectrum. To set the center frequency, do one of the following:
- Click the arrows to increase or decrease the frequency. Values range from 20 Hz to 20 kHz, adjustable in increments of 1 Hz. Each band has a default center frequency that will be applied if the **Reset** button at the bottom of the band is clicked.
 - Manually enter a value in the **Frequency** field.
- d. Set a bandwidth to determine how wide of a frequency range is effected by the equalizer band. To set the bandwidth, do one of the following:
- Click the arrows to increase or decrease the bandwidth. Values range from 0.1 octaves to 4.0 octaves, adjustable in increments of 0.1 octave.
 - Manually enter a value in the **Bandwidth** field.
- e. The individual Bypass controls allow you to bypass a single band of equalization at a time for more granular A/B testing of a single filter. Set a band's **Bypass** toggle to the right position to bypass that band. Set the toggle to the left position to disable the bypass. By default, **Bypass** is disabled.
- f. Each equalizer band has a **Reset** button that will reapply the default settings for that band.

Click **Done** to return to the **Settings** tab of the web user interface.

Input Channels

The **Input Channels** section enables the viewing and configuration of **Analog Inputs**.

— Analog Inputs (Autosaved)

Name	LineIn1	LineIn2	LineIn3	LineIn4	StreamIn1Ch1	StreamIn1Ch2	StreamIn2Ch1	StreamIn2Ch2
Analog Gain (db)	17	17	17	17				
Compensation (db)								
Signal Present								
Signal Level	 Nominal	 Nominal	 Nominal	 Nominal	 Nominal	 Nominal	 Nominal	 Nominal
Mode	Line	Line	Line	Line				
Phantom Power								
Mute								

Signal Presence indicates whether or not a signal is detected in that zone.

Signal Level indicates if the signal is **Clipping** or **Nominal** (non-clipping).

- If needed, enter a friendly name for each input in its **Name** field.
- To set a level compensation adjustment for a given input, do one of the following:
 - Slide the **Compensation** slider up to increase or down to decrease the compensation. Compensation increases the level of the incoming audio signal on any of the physical inputs on the device's rear panel.
 - Click the **db** arrows to increase or decrease the compensation. Values range from -10 db to 10 db, adjustable in increments of .1 db.
 - Manually enter a value in the **Compensation** field.
- Use the Mode drop-down to select **Line** or **Mic**.
- If using **Mic Mode**, **Phantom Power** can be enabled by moving the **Phantom Power** toggle to the right. Disable **Phantom Power** by moving the toggle to the left.
- To mute the signal from the corresponding input, click the **Mute** button. To disable the mute, click the **Muted** button. By default, **Mute** is disabled.

DM NAX Streams

Each local input of the DM-NAX-AMP-X300 can be made available as a DM NAX audio-over-IP stream.

The DM-NAX-AMP-X300 also supports parallel DM NAX streams for each zone output, enabling an additional transmit stream per output to mirror all routes and DSP settings of its respective zone. These parallel streams enable control of the audio signal to third-party uncontrolled AES67 devices receiving audio from the DM-NAX-AMP-X300.

NOTES:

- Under the **Transmitters** section (see [Configure Transmitters](#)), the last two listed transmitters are dedicated to parallel zone outputs.
- To configure the DSP settings, see [Zone Settings](#).

Click **NAX Streams** to display the following information.

AMP-X300

▼ Status Settings Security 802.1x Configuration

System Setup

Commissioning

Output Channels

Input Channels

NAX Streams

Device is Master PTP Clock Source: No

Master Clock Status: 00107fffe.f40615

PTP Priority: 254

+ Transmitters (Autosaved)

+ Receivers (Autosaved)

- **Device is Master PTP Clock Source** indicates whether the device is the master for PTP on the network. **Yes** will be displayed in green when the local DM-NAX-AMP-X300 is the PTP clock master and **No** will be displayed in red when another PTP clock on the network is operating as the master clock.
- **Master Clock Status** displays the Master Clock ID of the device on the network that acts as the Master Clock.
- **PTP Priority**: This sets the priority of the local DM NAX device's PTP clock relative to other clocks on the network. The default setting is 254 (one increment higher than the lowest possible value) so that the DM-NAX-AMP-X300 will only operate as clock master if no other PTP master is present on the network. Valid values range from 1 to 255.

Configure Transmitters

Transmitters (Autosaved)

Audio Source	Stream	Nax Stream Address	Nax Stream Name	Status	Actions
IN1-IN2	Stream01	239.8.0.2	Stream01c4.42.68.18.54.47	Stream Started	▶ □ ⚙
IN3-IN4	Stream02	239.8.0.3	Stream02c4.42.68.18.54.47	Stream Started	▶ □ ⚙

To configure a DM NAX transmit stream, do the following.

1. Enter a valid multicast address in the **NAX Stream Address** field.
2. Enter a name in the **NAX Stream Name** field by which the stream can be identified. This stream name is associated with the DM NAX stream's multicast address by other DM NAX or AES67 devices, like a device hostname that resolves to a given IP address.

3. **Status** indicates whether a stream is transmitting or not. When the stream has started or stopped, the **Status** column will update accordingly.
4. Click the configure button (⚙️) in the **Actions** column. The **Configure** dialog appears:

The **Configure** dialog box has a blue header with a close button. It contains an **Auto Initiation** toggle switch, currently in the off position. Below it is a **Port** field with the value 5004 and a spinner control. At the bottom are **OK** and **CANCEL** buttons.

5. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled for a given stream, the stream will begin transmitting automatically and will be available as a multicast stream on your network at the specified multicast address.
 - If **Auto Initiation** is disabled for the input, the stream will not begin transmitting until it is manually initiated.
6. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number for DM NAX streams is 5004.
7. Click **OK** to save or click **Cancel** to cancel the changes.

Configure Receivers

Receivers (Autosaved)					
Zone Name	Stream	Current Stream Address	Requested Stream Address	Status	Actions
Zone_Amp1	Stream01	0.0.0.0	0.0.0.0	Stream Stopped	▶️ 📺 ⚙️
Zone_Amp2	Stream02	0.0.0.0	0.0.0.0	Stream Stopped	▶️ 📺 ⚙️


1. Enter the multicast address of a transmitting stream in the **Requested Stream Address** field to subscribe the receiver to the stream.
2. Click the configure button (⚙️) in the **Actions** column. The **Configure** dialog appears:

The **Configure** dialog box is identical to the one shown in step 4, with the **Auto Initiation** toggle off and the **Port** set to 5004.

3. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled, the stream will begin automatically when the receiver subscribes to the transmitter.
 - If **Auto Initiation** is disabled, the stream will not begin until it is manually initiated.
4. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number is 5004.
5. Click **OK** to save or click **Cancel** to cancel the changes.

Port Selection

The Port Selection feature allows the device's internal network traffic to be managed and segregated based on traffic type. Internal VLANs are used to segment device management and streaming service traffic to a separate physical device Ethernet port than audio-over-IP streaming traffic. With Port Selection enabled on all DM NAX devices on a network, DM NAX and AES67 network traffic can be physically separated from the control network onto a dedicated audio network.



To configure Port Selection:

1. Set the **Port Selection** toggle to the right position to enable Port Selection. Set the toggle to the left position to disable Port Selection. By default, **Port Selection** is disabled.

NOTE: Ports 1 and 2 correspond to the Ethernet adapters labeled **1** and **2** on the rear panel of the DM-NAX-AMP-X300, respectively.

2. With **Port Selection** enabled, select an Ethernet port from the **Management** drop-down menu to designate which Ethernet port on the rear panel of the device will handle network traffic relating to device configuration and the device's connection to a control system.


NOTE: The Management port determines your connection to the web interface. Changing the port value can result in losing your connection to the device via the web interface.

3. With **Port Selection** enabled, select an Ethernet port from the **Audio/NAX** drop-down menu to designate which Ethernet port on the rear panel of the device will handle audio-over-IP streaming network traffic.
4. Click **Save** changes to apply the new settings.

NOTE: Making changes to **Port Selection** settings will require a reboot.


Mixing

This section contains the **Mixing** and **Ducking** matrices.



Mixing

The **Mixing** matrix is used to route a local input or AES67 stream to an output on the DM-NAX-AMP-X300.




To route inputs to outputs on the device:

- Click the cells corresponding to the desired output that are to be paired for routing. Once a route is made, appears. The input that you have selected for a given row will route to the output corresponding to that row in the matrix.
- Use the arrows (or) at the top of the matrix to change pages to view all available inputs.
- To break a given route click or .
- Lock icons appear on any routes that are already configured in the **Ducking** matrix.


Each output can have any number of inputs routed to it. To adjust the mix setting for a route, click the **dB** value of the cell, then do one of the following:

- Move the slider up to increase or down to decrease the mix level.
- Click the arrows to increase or decrease the mix level.
- Manually enter a value in the field.





Ducking

The **Ducking** matrix is used to configure ducking routes. Audio signals on these routes will duck audio signals on the **Mixing** routes for a given output whenever the ducking signal exceeds the ducking threshold.





To assign inputs as ducking signals for zones on the device:


- Click the cells corresponding to the desired zone that are to be paired for ducking. Once a route is made,  appears. The input that you have selected for a given row will route to the zone corresponding to that row in the matrix, and will duck any other signals routed to that zone in the **Mixing** matrix.
- Use the arrows (◀ or ▶) at the top of the matrix to change pages to view all available inputs.
- To break a given route click  or ✕.
- Lock icons appear on any routes that are already configured in the **Mixing** matrix.

Each output can have any number of inputs routed to it. To adjust the mix setting for a route, click the **dB** value of the cell, then do one of the following:

- Move the slider up to increase or down to decrease the mix level.
- Click the arrows to increase or decrease the mix level.
- Manually enter a value in the field.



To configure the Ducker settings for a given output, select the configure button () below it.



Logic Out: This indicator turns blue when the ducker is active.

Bypass: Set the **Bypass** toggle to the right position to bypass the ducker. Set the toggle to the left to enable the ducker.

Threshold: Set the dB value at which the ducker engages. Use the arrows or enter a number to set the dB value for the **Threshold**. Values range from 0 dB to -60 dB.

Attenuation: Set the dB value by which the **Mixing** matrix output signals will be reduced when ducking is triggered. Use the arrows or enter a number to set the dB value for the **Attenuation**. Values range from 0 dB to -80 dB.

Attack: Set how quickly the ducking occurs once triggered. Use the arrows or enter a number to set value in ms for the **Attack**. Values range from 0.1 ms to 2000 ms.


Hold: Set the length of time for which the ducker will stay at full attenuation once the ducking signal passes the **Threshold**. Use the arrows or enter a number to set a value in seconds for the **Hold**. Values range from 0.1 s to 20 s.

Release: Set the time for the **Mixing** matrix output signal to return to its full level after the ducking signal falls below the threshold and the **Hold** time ends. Use the arrows or enter a number to set the value in ms for the **Release**. Values range from 10 ms to 4000 ms.

Residential Mode

This section provides the following information:

- [System Setup on page 440](#)
- [Commissioning on page 444](#)
- [Zones on page 445](#)
- [Bussing on page 457](#)
- [Inputs on page 458](#)
- [NAX Streams on page 458](#)
- [Routing on page 461](#)
- [Port Selection on page 461](#)



System Setup

The **System Setup** section displays information about the Date/Time, Auto Update, Network, Control System, Cloud Settings, and Device Modes.

Date/Time

Use the **Date/Time** section to configure the date and time settings of the DM-NAX-AMP-X300.

Date/Time

Synchronization

Time Synchronization ☒

[Synchronize Now](#)

NTP Time Servers

	Address	Port	Authentication Method	Authentication Key	Key ID
<input type="checkbox"/>	pool.ntp.org	123	None	*****	0

[+ Add](#) [- Remove](#)

Configuration

Time Zone: (UTC-05:00) Eastern Time (US & Canada)

Date: 01/26/2023

Time: 08:37

Time Synchronization

1. Set the **Time Synchronization** toggle to the right position to enable or left position to disable time synchronization. By default, time synchronization is enabled.
2. In the **NTP Time Servers** table, enter the URL of a NTP (Network Time Protocol) or SNTP (Simple Network Time Protocol) server. Up to three time servers can be added on a device.
3. Click **Synchronize Now** to perform time synchronization between the device's internal clock and the time server.

Time Configuration

1. Click on the **Time Zone** drop-down menu to select the applicable time zone.
2. In the **Date** field, enter the current date.
3. In the **Time (24hr Format)** field, enter the current time in 24-hour format.

Click the **Save Changes** button to save the settings.

Click **Revert** from the **Actions** drop-down menu to revert to the previous settings without saving.

Auto Update

The DM-NAX-AMP-X300 can automatically check for and install firmware updates at scheduled intervals via the Auto Update feature.

— Auto Update

Auto Update ☒

Custom URL ☐

Custom URL Path

Schedule

Day of Week

Time of Day

Poll Interval Minutes

Update Now

1. Set the **Auto Update** toggle to the right position to enable Auto Update.
2. Define the URL to download the updates by doing either of the following:
 - a. Use the default URL to download the updates from the Crestron server.
 - b. Use a custom URL. Set the **Custom URL** toggle to the right position to enable a custom URL. In the **Custom URL Path** text box, enter the path to a custom manifest file in the FTP or SFTP URL format. Use the Crestron Auto Update Tool to generate a custom manifest file, then store the file on an FTP (File Transfer Protocol) or SFTP (Secure File Transfer Protocol) server.
3. Set a schedule for the automatic firmware update by doing either of the following:
 - a. Select the desired **Day of Week** and **Time of Day** (24-hour format) values.
 - b. Set the **Poll Interval** by entering a value from **60** to **65535** minutes. A value of **0** disables the Poll Interval.
4. Click **Save Changes**.

Clicking **Update Now** causes the device to check for a firmware update immediately. If a schedule was set in step 4 above, that schedule still remains in effect.

Network

The **Network** section contains network-related settings for the DM-NAX-AMP-X300, including the Hostname, Domain, Primary Static DNS, and Secondary Static DNS.

Network

Hostname * AMP-X300-TECH-DOCS

Domain 6vcrestrongelab.com

Primary Static DNS 10.253.31.12(DHCP)

Secondary Static DNS

Adapter 1

DHCP ☒

IP Address 10.253.46.147

Subnet Mask 255.255.255.0

Default Gateway 10.253.46.1

NOTE: By default, the host name of the DM-NAX-AMP-X300 consists of the model name followed by the MAC address of the device. For example, DM-NAX-AMP-X300-00107FB58088.

Adapter 1

The Adapter 1 subheading contains settings for DHCP, IP Address, Subnet Mask, and Default Gateway of Ethernet adapter 1 on the rear panel of the device.

NOTES:


- An **+ Adapter 2** option only appears when the dual Ethernet ports on the DM-NAX-AMP-X300 are set to isolate traffic using the Port Selection feature. The settings for Adapter 2 are identical to those available for Adapter 1.
- DM NAX devices' internal processes use IP addresses in the 10.10.10.xxx range. This IP range should be avoided when addressing DM NAX devices to prevent conflicts.

Set the **DHCP** toggle to enabled (right) or disabled (left) to specify whether the IP address of the DM-NAX-AMP-X300 is to be assigned by a DHCP (Dynamic Host Configuration Protocol) server.

- **Enabled:** When DHCP is enabled (default setting), the IP address of the DM-NAX-AMP-X300 is automatically assigned by a DHCP server on the local area network (LAN).
- **Disabled:** When DHCP is disabled, manually enter information in the following fields:
 - **Primary Static DNS:** Enter a primary DNS IP address.
 - **Secondary Static DNS:** Enter a secondary DNS IP address.
 - **IP Address:** Enter a unique IP address for the DM-NAX-AMP-X300.
 - **Subnet Mask:** Enter the subnet mask that is set on the network.
 - **Default Gateway:** Enter the IP address that is to be used as the network's gateway.

To save any new network entries, click **Save Changes**.

Control System



Control System

Encrypt Connection

IP Table

	IP ID	IP Address/Hostname	Room ID
No records found			
+ Add		✕ Remove	

1. Click the **Encrypt Connection** button to navigate to the **Security** tab to configure encryption settings.
2. Enter the username in the **Control System Username** field.
3. Enter the password in the **Control System Password** field.
4. Enter the Room ID in the **Room ID** field.
5. Enter the IP ID of the DM-NAX-AMP-X300 in the **IP ID** field.
6. Enter the IP address or hostname of the control system in the **IP Address/Hostname** field.
7. Click the **Save Changes** button to save the new entries. The Control System Save message box appears, indicating that the control system settings were saved successfully. Click the **Revert** button to revert to the previous settings without saving.

Cloud Settings



Cloud Settings

Cloud Configuration Service Connection ☒

Set the **Cloud Settings** toggle to enabled (right) or disabled (left) to specify whether the DM-NAX-AMP-X300 can communicate with the XiO Cloud® platform.

Device Modes


Use the **Device Modes** section to configure the **Application Mode** and **Standby Mode**.

Device Modes (Autosaved)

Application Mode: Residential (Standard)

Standby Mode: Power Saver

- **Application Mode:** The Application Mode determines which options and controls are available.
 - Select **Residential (Standard)** or **Commercial (Advanced)**. A **Reboot** confirmation message box appears.



- Click **Yes, Reboot Now** to reboot the device into the selected mode. The **Reboot** message box appears.
 - Wait for the device reboot to complete before attempting to reconnect to the device.
- **Standby Mode:** Select the DM-NAX-AMP-X300's standby behavior.
 - **Always On:** The device's amplifier remains powered on at all times.
 - **Power Saver:** If no signal is detected for 25 minutes, the device enters a low power state by turning off the amplifier board. Upon detecting an audio signal, the amplifier will be turned back on.

Commissioning

The **Commissioning** section provides a quick way to automatically assign multicast addresses to all of the device's internal audio-over-IP stream transmitters.

CRESTRON

AMP-X300

✓ Status Settings Security 802.1x Configuration

System Setup

Commissioning

Starting Multicast Address: 239.8.0.2

Last Reserved Multicast Address: 239.8.0.9


Assign Addresses

Click **Assign Addresses** to give each DM NAX transmitter in the DM-NAX-AMP-X300 a unique multicast address beginning with the specified **Starting Multicast Address**. The valid range for **Starting Multicast Address** is 239.8.0.0 to 239.127.255.255.

NOTE: This will begin transmitting multicast traffic on your network, refer to the [General Network Requirements](#) document for details.

Zones

The **Zones** section contains the **Volume** and **Mute** settings for all zone outputs of the device, as well as a Configure option for more advanced settings within each zone.




Give each zone a friendly name using the **Name** column of the **Zones** table. If the device is paired with a control system, these names may be overwritten by the control system's program.

To configure the zone volume, do one of the following:

- Move the **Volume** slider to the right to increase or to the left to decrease the zone volume.
- Click the % arrows to increase or decrease the zone volume. Values range from 0 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Volume** field.


To mute all audio output from a zone, click its respective **Mute** button. To unmute the zone, click the **Muted** button.

Zone Settings


To configure zone settings, click the **Configure** button ( **Configure**). The **Edit Zone** window appears.

Zone

Click **Zone** to access the settings for **Tone**, **Balance**, and **Delay**.



Tone



The **Tone** section provides adjustments for the **Tone Profile**, **Bass**, **Treble**, **Loudness**, and **Night Mode** settings of the zone output.

NOTE: The Tone Profile, Bass, Treble, and Loudness settings in the Tone section are all applied separately from the Equalizer Settings for the zone. This means that any adjustments made in the Tone section will stack with those made in the Equalizer Settings section.

1. To select a tone profile preset for the zone, select an option from the **Tone Profile** drop-down menu. The available options are **Off**, **Classical**, **Jazz**, **Pop**, **Rock**, and **Spoken Word**. By default, **Off** is selected.
2. **Bass:** To adjust the bass, do one of the following:
 - Move the **Bass** slider to the right to increase or to the left to decrease the bass.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of 1 db.
 - Manually enter a value in the **Bass** field.
3. **Treble:** To adjust the treble, do one of the following:
 - Move the **Treble** slider to the right to increase or to the left to decrease the treble.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of 1 db.
 - Manually enter a value in the **Treble** field.
4. To enable the loudness setting on the zone output, slide the **Loudness** switch to the right. To disable loudness, slide the **Loudness** switch to the left.
5. The **Night Mode** feature applies subtle processing to restrict the dynamic range of the zone audio, to allow for lower listening levels at night or in rooms where higher listening levels would be disruptive. To select a dynamics processing level, select an option from the **Night Mode** drop-down menu. The available options are **Off**, **Low**, **Medium**, and **High**. By default, **Off** is selected.


Balance



To adjust the left/right balance of the stereo output signal, do one of the following:

- Move the **Balance** slider to the right to shift the stereo balance to the right channel or to the left to shift the balance to the left.
- Click the arrows to adjust the balance left or right. The up arrow shifts the balance to the right while the down arrow shifts the balance to the left.
- Manually enter a value in the **Balance** field. Values range from -50 to 50, adjustable in increments of 1. Positive values shift the balance to the right while negative values shift the balance to the left.

Delay



To set the delay, do one of the following:

- Move the **Delay Time(ms)** slider to the right to increase or to the left to decrease the delay time.
- Click the **ms** arrows to increase or decrease the delay. Values range from 0 ms to 250 ms, adjustable in increments of 1 ms.
- Manually enter a value in the **Delay Time(ms)** field.

Output

Click **Output** to access the settings for **Minimum/Maximum Volume**, **Stereo/Mono**, **Signal**, **Bussing Volume Offset**, **Speaker Configuration**, **Speaker/Faults**, **Line Out**, **Signal Generator**, and **Equalizer Settings**.

AMP-X300 > Zones
Zone_Amp1

▼ Output

- + Minimum / Maximum (Autosaved)
- + Stereo / Mono (Autosaved)
- + Signal (Autosaved)
- + Bussing Volume Offset (Autosaved)
- + Speaker Configuration (Autosaved)
- + Speaker / Faults (Autosaved)
- + Line Out (Autosaved)
- + Signal Generator (Autosaved)
- + Advanced Signal Generator (Autosaved)
- + Equalizer Settings (Autosaved)

Minimum/Maximum Volume

— Minimum / Maximum (Autosaved)

Minimum 0 %

Maximum 100 %

Default 30 %

- To set the minimum volume of the zone, do one of the following:
 - Move the **Minimum** slider to the right to increase or to the left to decrease the minimum volume.
 - Click the **%** arrows to increase or decrease the minimum volume. Values range from 0 to 50%, adjustable in increments of 1%.
 - Manually enter a value in the **Minimum** field.
- To set the maximum volume of the zone, do one of the following:
 - Move the **Maximum** slider to the right to increase or to the left to decrease the maximum volume.
 - Click the **%** arrows to increase or decrease the maximum volume. Values range from 70 to 100%, adjustable in increments of 1%.
 - Manually enter a value in the **Maximum** field.


NOTE: When a **Minimum** and **Maximum** volume are set, the 1-100% range represented by the **Zone** and **Default** volume controls are scaled to the range set. For example, if a **Minimum** of 10% and a **Maximum** of 80% are set for a zone, the 1-100% range of the **Zone** volume control is scaled to the 10%-80% range set as the **Minimum** and **Maximum**.

3. To set the default volume of the zone, do one of the following:

- Move the **Default** slider to the right to increase or to the left to decrease the default volume.
- Click the **%** arrows to increase or decrease the default volume. Values range from 0 to 50%, adjustable in increments of 1%.
- Manually enter a value in the **Default** field.

NOTE: The **Default** volume is applied as the **Zone** volume any time the zone receives a source route and no source was previously routed to that zone.


Stereo/Mono




1. Select either **Stereo** or **Mono** from the **Stereo/Mono** radio buttons.
2. Select the zone configuration from the **Zone Configuration** drop-down menu. The available values are **Standard**, **Bridged**, **Bridged Sub 2.1**, and **Bridged Mono**. See the diagrams below for the output signal flow applied in each configuration.

NOTE: The **Stereo/Mono** field is disabled for the Bridge Mono, and Bridged Sub 2.1 zone configurations.


Stereo - Standard




Stereo - Bridged




Mono - Standard




Mono - Bridged




Bridged Sub 2.1



Bridged Mono




Signal



The **Signal** section is a read-only field that displays the **Signal** and **Clipping** status of the zone output.

- If an output signal is present but not clipping, **Signal** will display **Present** in green and **Clipping** will display **None** in green.
- If an output signal is present and clipping, **Signal** will display **Present** in green and **Clipping** will display **Present** in red.
- If no output signal is detected, **Signal** will display **Not Present** in red and **Clipping** will display **None** in green.

Bussing Volume Offset




Bussing Volume Offset is an additional level compensation applied to the zone relative to any other zones it is grouped with via the **Bussing** feature.

To set the bussing volume offset, do one of the following:


- Move the **Bussing Volume Offset** slider to the right to increase or to the left to decrease the offset.
- Click the **db** arrows to increase or decrease the offset. Values range from -12 dB to 12 dB, adjustable in increments of 1 dB.
- Manually enter a value in the **Bussing Volume Offset** field.

Speaker Configuration




1. Set the **Enable Speaker Protect** toggle to the right position to enable speaker protection for the zone output. Set the toggle to the left position to disable speaker protection. By default, **Enable Speaker Protect** is set to the left position.
2. To set the maximum output wattage, do one of the following:
 - Move the **Speaker Wattage** slider to the right to increase or to the left to decrease the maximum peak amplifier wattage that can be output to the speaker.
 - Click the **Watts** arrows to increase or decrease the maximum peak amplifier wattage that can be output to the speaker. Values range from 5 W to 150 W, adjustable in increments of 1 W.
 - Manually enter a value in the **Speaker Wattage** field.
3. Select the impedance of the speaker on a selected zone from the **Impedance** drop-down menu. Values are **4 Ohms**, **8 Ohms**, and **Bridged**.

Speaker/Faults



The Speaker/Faults section is a read-only field that displays the status of the **DC Offset Fault**, **Over Current Fault**, **Clipping Detected**, **Over or Under Voltage**, and **Over Temperature** detectors for the zone output. If clipping or a given fault type is detected, then its corresponding readout displays **Fault Detected** in red. Otherwise, it displays **None** in blue.

Line Out




Line Out Volume controls the volume level of the corresponding line-level output on the DM NAX device. The Line Out Volume is only applied when **Line Out EQ Bypass** is enabled.

1. To set the line out volume, do one of the following:
 - Move the **Line Out Volume** slider to the right to increase or to the left to decrease the line out volume.
 - Click the arrows to increase or decrease the line out volume. Values range from 0 to 100, adjustable in increments of 1. This range in dB is -80 dB to 20 dB.
 - Manually enter a value in the **Line Out Volume** field.
2. Set the **Line Out EQ Bypass** toggle to the right position to have the line-level output signal bypass the zone's equalizer settings. Set the toggle to the left position to have the line-level output signal pass through the zone's equalizer. By default, **Line Out EQ Bypass** is disabled.

NOTE: When the **Line Out EQ Bypass** setting is disabled, the line-level output's level will mirror the speaker output's **Zone** volume control. This allows for a variable signal level in applications where the line-level output is connected to an uncontrolled device such as powered speakers. If the **Line Out EQ Bypass** setting is enabled, the **Line Out Volume** slider can be used to set a fixed level for the line-level output. This level will not be affected by the speaker output **Zone** volume controls, making this configuration better suited to applications where the line output is connected to a controlled amplifier with its own level adjustment.

Signal Generator



The DM-NAX-AMP-X300 has a built-in signal generator that allows an integrator to send an audio signal to any number of selected zones to test output functionality.


1. To route the signal generator to the zone output, click the **Signal Generator** button so that it displays **Active** and is highlighted in blue. To unroute the signal generator on the zone output, click the **Signal Generator** button so that it displays **Inactive** and is highlighted in grey. By default, the signal generator is not routed to the zone output.

NOTES:

- There is only one signal generator built-in to the DM NAX device. Each zone has its own button to enable or disable the signal generator from passing signal to that output. Setting the signal generator to **Inactive** on a given zone output only breaks the route for that output and does not stop it from playing back in other zones.
- The **Signal Generator Volume** control is a local control that does not affect the signal generator's volume on other zone outputs. Only the settings under **Advanced Signal Generator** are applied universally to all zones of the DM NAX device.

2. To adjust the signal generator's volume, do one of the following:
 - Move the **Signal Generator Volume** slider right to increase or left to decrease the volume.
 - Click the arrows to increase or decrease the signal generator volume. Values range from 0 to 100, adjustable in increments of 1.
 - Manually enter a value in the **Signal Generator Volume** field.

Advanced Signal Generator



The advanced signal generator settings control the built-in signal generator directly, and are applied universally to all output zones of the DM NAX device. The signal type for the generator can be set, and the left and right channels of the test signal can be individually enabled or disabled.

1. Set the **Left Channel** toggle to the right position to enable the left channel of the signal. Set the toggle to the left position to disable the left channel. By default, **Left Channel** is enabled.
2. Set the **Right Channel** toggle to the right position to enable the right channel of the signal. Set the toggle to the left position to disable the right channel. By default, **Right Channel** is enabled.
3. Select an audio test signal type from the **Signal Type** drop-down menu. The available signal types are:
 - **Tone**: Generates a 1 kHz sine wave tone.
 - **Pink Noise**: Generates pink noise.
 - **White Noise**: Generates white noise.

Equalizer Settings

Band	Band01	Band02	Band03	Band04	Band05	Band06
Gain						
Type	EQ	EQ	EQ	EQ	EQ	EQ
Frequency	32	64	125	250	500	1000
Bandwidth	0.33	0.33	0.33	0.33	0.33	0.33
Bypass	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Actions	Reset	Reset	Reset	Reset	Reset	Reset

Each zone output of the DM-NAX-AMP-X300 has a dedicated ten-band equalizer that can be fully customized to tune the zone output signal to the needs of an install. Each band can have a discrete gain, filter type, center frequency, and bandwidth set, and can also be bypassed. The equalizer itself can also be bypassed using the **Speaker EQ Enabled** toggle.

1. Set the **Speaker EQ Enabled** toggle to the right position to enable the equalizer. Set the toggle to the left position to bypass the equalizer.


NOTE: When **Speaker EQ Enabled** is disabled, all equalizer bands are bypassed. This is a quick way to perform A/B testing of the entire EQ curve.

2. With the **Speaker EQ Enabled** toggle in the right position, do the following to configure a given equalizer band:
 - a. To set a band's gain, do one of the following:
 - Move the **Gain** slider up to increase or down to decrease the gain.
 - Click the arrows to increase or decrease the gain. Values range from -40 dB to 20 dB, adjustable in increments of 0.1 dB.
 - Manually enter a value in the **Gain** field.

- b. Select a filter type from the **Type** drop-down menu. By default, all bands are set to the **EQ** filter type. Some filter types will disable other settings in their respective band while enabled. For example, selecting the **LowPass** filter type for a band will disable that band's **Gain** and **Bandwidth** settings, since the **LowPass** filter applies a fixed roll-off slope at a set frequency. The available filter types are:
 - **EQ:** a fully parametric filter that can boost or cut a range of frequencies.
 - **Notch:** a parametric filter designed to more precisely cut a frequency or range of frequencies. A notch filter can achieve a narrower bandwidth than the standard **EQ** parametric filter type.
 - **TrebleShelf:** a filter that boosts or cuts all frequencies above a set frequency by a set gain.
 - **BassShelf:** a filter that boosts or cuts all frequencies below a set frequency by a set gain.
 - **LowPass:** a filter that fully cuts all frequencies above a set frequency using a fixed roll-off slope of -12 dB per octave.
 - **HighPass:** a filter that fully cuts all frequencies below a set frequency using a fixed roll-off slope of -12 dB per octave.
- c. Set a center frequency for the equalizer band to tune a specific portion of the audible frequency spectrum. To set the center frequency, do one of the following:
 - Click the arrows to increase or decrease the frequency. Values range from 20 Hz to 20 kHz, adjustable in increments of 1 Hz. Each band has a default center frequency that will be applied if the **Reset** button at the bottom of the band is clicked.
 - Manually enter a value in the **Frequency** field.
- d. Set a bandwidth to determine how wide of a frequency range is effected by the equalizer band. To set the bandwidth, do one of the following:
 - Click the arrows to increase or decrease the bandwidth. Values range from 0.1 octaves to 4.0 octaves, adjustable in increments of 0.1 octave.
 - Manually enter a value in the **Bandwidth** field.
- e. The individual Bypass controls allow you to bypass a single band of equalization at a time for more granular A/B testing of a single filter. Set a band's **Bypass** toggle to the right position to bypass that band. Set the toggle to the left position to disable the bypass. By default, **Bypass** is disabled.
- f. Each equalizer band has a **Reset** button that will reapply the default settings for that band.

Click **Done** to return to the **Settings** tab of the web user interface.

Bussing



The screenshot shows a web interface titled "Bussing (Autosaved)". It features a search bar labeled "Global Filter" with a magnifying glass icon. Below the search bar is a table with three columns: "Name", "Bus Id", and "Included Zones". The table contains one row with the following data:

Name	Bus Id	Included Zones
Bus01	1	Choose Zones

The bussing feature on DM NAX devices allows an integrator to assign any number of selected zones to a fixed group of zones (bus). Zones in a bus track the other zones' volume and routing. For example,


when the source or volume for one zone in the bus is adjusted, all other zones in that bus receive the same adjustment. You can create a single output bus on the DM-NAX-AMP-X300.

Configure Bussing

1. If needed, enter a friendly name for each bus in its **Name** field.
2. Select any number of zones from the **Included Zones** drop-down menu.

Inputs

The **Inputs** section is used to configure the **Name**, **Compensation**, and **Mute** attributes of the available analog, digital, and media streaming inputs on the DM-NAX-AMP-X300.



1. If needed, enter a friendly name for each input in its **Name** field.
2. To set a level compensation adjustment for a given input, do one of the following:
 - Move the **Compensation** slider up to increase or down to decrease the compensation. Compensation increases or decreases the level of the incoming audio signal on any of the physical inputs on the device's rear panel.
 - Click the **db** arrows to increase or decrease the compensation. Values range from -10 dB to 10 dB, adjustable in increments of 1 dB.
 - Manually enter a value in the **Compensation** field.
3. To mute the signal from the corresponding input, click the **Mute** button. To disable the mute, click the **Muted** button. By default, **Mute** is disabled.

Monitor the device's input signals using the indicators in the **Signal Present** and **Clipping Detected** rows:

- **Signal Presence** indicates whether or not a signal is detected in that zone.
- **Clipping Detected** indicates if the signal is **Clipping** or **Nominal** (non-clipping).

NAX Streams

Each local input of the DM-NAX-AMP-X300 can be made available as a DM NAX audio-over-IP stream.

The DM-NAX-AMP-X300 also supports parallel DM NAX streams for each zone output, enabling an additional transmit stream per output to mirror all routes and DSP settings of its respective zone. These parallel streams enable control of the audio signal to third-party uncontrolled AES67 devices receiving audio from the DM-NAX-AMP-X300.

NOTES:

- Under the **Transmitters** section (see [Configure Transmitters](#)), the last two listed transmitters are dedicated to parallel zone outputs.
- To configure the DSP settings, see [Zone Settings](#).

Click **NAX Streams** to display the following information.

AMP-X300

▼ Status Settings Security 802.1x Configuration

System Setup

Commissioning

Output Channels

Input Channels

NAX Streams

Device is Master PTP Clock Source No

Master Clock Status 00107fffe.f40615

PTP Priority 254

+ Transmitters (Autosaved)

+ Receivers (Autosaved)

- **Device is Master PTP Clock Source** indicates whether the device is the master for PTP on the network. **Yes** will be displayed in green when the local DM-NAX-AMP-X300 is the PTP clock master and **No** will be displayed in red when another PTP clock on the network is operating as the master clock.
- **Master Clock Status** displays the Master Clock ID of the device on the network that acts as the Master Clock.
- **PTP Priority**: This sets the priority of the local DM NAX device's PTP clock relative to other clocks on the network. The default setting is 254 (one increment higher than the lowest possible value) so that the DM-NAX-AMP-X300 will only operate as clock master if no other PTP master is present on the network. Valid values range from 1 to 255.

Configure Transmitters

Transmitters (Autosaved)

Audio Source	Stream	Nax Stream Address	Nax Stream Name	Status	Actions
IN1-IN2	Stream01	239.8.0.2	Stream01c4.42.68.18.54.47	Stream Started	▶ ◻ ⚙
IN3-IN4	Stream02	239.8.0.3	Stream02c4.42.68.18.54.47	Stream Started	▶ ◻ ⚙

To configure a DM NAX transmit stream, do the following.

1. Enter a valid multicast address in the **NAX Stream Address** field.
2. Enter a name in the **NAX Stream Name** field by which the stream can be identified. This stream name is associated with the DM NAX stream's multicast address by other DM NAX or AES67 devices, like a device hostname that resolves to a given IP address.

3. **Status** indicates whether a stream is transmitting or not. When the stream has started or stopped, the **Status** column will update accordingly.
4. Click the configure button (⚙️) in the **Actions** column. The **Configure** dialog appears:

The **Configure** dialog box has a blue header with a close button. It contains an **Auto Initiation** toggle switch, currently in the off position. Below it is a **Port** field with the value 5004 and a spinner control. At the bottom are **OK** and **CANCEL** buttons.

5. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled for a given stream, the stream will begin transmitting automatically and will be available as a multicast stream on your network at the specified multicast address.
 - If **Auto Initiation** is disabled for the input, the stream will not begin transmitting until it is manually initiated.
6. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number for DM NAX streams is 5004.
7. Click **OK** to save or click **Cancel** to cancel the changes.

Configure Receivers

Receivers (Autosaved)					
Zone Name	Stream	Current Stream Address	Requested Stream Address	Status	Actions
Zone_Amp1	Stream01	0.0.0.0	0.0.0.0	Stream Stopped	▶️ 📺 ⚙️
Zone_Amp2	Stream02	0.0.0.0	0.0.0.0	Stream Stopped	▶️ 📺 ⚙️

1. Enter the multicast address of a transmitting stream in the **Requested Stream Address** field to subscribe the receiver to the stream.
2. Click the configure button (⚙️) in the **Actions** column. The **Configure** dialog appears:


The **Configure** dialog box for receivers is identical to the one shown earlier, with the **Auto Initiation** toggle and **Port** field (5004) and **OK**/**CANCEL** buttons.

3. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled, the stream will begin automatically when the receiver subscribes to the transmitter.
 - If **Auto Initiation** is disabled, the stream will not begin until it is manually initiated.
4. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number is 5004.
5. Click **OK** to save or click **Cancel** to cancel the changes.

Routing

The **Routing** section is used to route a local input or AES67 stream to a Zone on the DM-NAX-AMP-X300.

NOTE: To receive an AES67 stream from Dante devices, see [OLH 1001151](#).




To route an input to a zone, click the box in the routing matrix where the zone's row overlaps the corresponding input's column. Once a route is made, appears. To break a given route click or . To route a single input to all zones, click on the under the input's name.

Use the arrows (or) at the top of the matrix to change pages to view all available inputs.

Port Selection

The Port Selection feature allows the device's internal network traffic to be managed and segregated based on traffic type. Internal VLANs are used to segment device management and streaming service traffic to a separate physical device Ethernet port than audio-over-IP streaming traffic. With Port Selection enabled on all DM NAX devices on a network, DM NAX and AES67 network traffic can be physically separated from the control network onto a dedicated audio network.



To configure Port Selection:

1. Set the **Port Selection** toggle to the right position to enable Port Selection. Set the toggle to the left position to disable Port Selection. By default, **Port Selection** is disabled.

NOTE: Ports 1 and 2 correspond to the Ethernet adapters labeled **1** and **2** on the rear panel of the DM-NAX-AMP-X300, respectively.

2. With **Port Selection** enabled, select an Ethernet port from the **Management** drop-down menu to designate which Ethernet port on the rear panel of the device will handle network traffic relating to device configuration and the device's connection to a control system.

NOTE: The Management port determines your connection to the web interface. Changing the port value can result in losing your connection to the device via the web interface.

3. With **Port Selection** enabled, select an Ethernet port from the **Audio/NAX** drop-down menu to designate which Ethernet port on the rear panel of the device will handle audio-over-IP streaming network traffic.
4. Click **Save** changes to apply the new settings.

NOTE: Making changes to **Port Selection** settings will require a reboot.

Security

Click the **Security** tab to configure security for users and groups and to allow different levels of access to the DM-NAX-AMP-X300 functions. By default, security is disabled.

The screenshot shows the 'Security' tab selected in the top navigation bar. Below the navigation bar, there is a 'Security' section with a dropdown menu for 'SSL Mode' set to 'OFF'. Below this, there is a 'Current User' tab selected, showing user details: Name: admin1, Access Level: Administrator, Active Directory User: No, and Groups: Administrators. A blue button labeled 'Change Current User Password' is located at the bottom left of the 'Current User' section.


Select **Encrypt and Validate**, **Encrypt**, or **OFF** in the **SSL Mode** drop-down menu, to specify whether to use encryption. By default, SSL Mode is set to **OFF**.

Current User

Click the **Current User** tab to view read-only information or to change the password for the current user.

The screenshot shows the 'Current User' tab selected in the top navigation bar. Below the navigation bar, there is a 'Current User' section showing user details: Name: admin1, Access Level: Administrator, Active Directory User: No, and Groups: Administrators. A blue button labeled 'Change Current User Password' is located at the bottom left of the 'Current User' section.

1. Click the **Change Current User Password** button to provide a new password for the current user.
2. In the **Change Password** dialog, enter the current password in the **Current Password** field, the new password in the **Password** field, and then re-enter the same new password in the **Confirm Password** field.




A dialog box titled "Change Password" with a close button (X) in the top right corner. It contains three input fields: "Current Password" with 10 dots, "Password" with 8 dots, and "Confirm Password" with 8 dots and a cursor at the end. At the bottom right, there are two buttons: "OK" with a checkmark icon and "Cancel" with an X icon.




3. Click **OK** to save or click **Cancel** to cancel the changes.

Users

Click the **Users** tab to view and edit user settings. The **Users** tab can be used to add or remove local and Active Directory users and preview information about users.



The "Users" tab interface shows a table with columns: Username, AD User, and Action. The first row shows "admin1" as the username and "No" as the AD User status. The Action column contains three icons: a person, a pencil, and a trash can. Below the table is a navigation bar with left and right arrows, a page number "1", and a dropdown menu set to "10". A "Create User" button is located at the bottom left.

Username	AD User	Action
admin1	No	  

Use the **Search Users** field to enter search term(s) and display users that match the search criteria.

If users listed in the **Users** table span across multiple pages, navigate through the list of users by clicking a page number or by using the left or right arrows at the bottom of the **Users** pane to move forward or backward through the pages.

Each page can be set to display 5, 10, or 20 users by using the drop-down menu to the right of the navigation arrows.

Information about existing users is displayed in table format and the following details are provided for each user.

- **Username:** Displays the name of the user.
- **AD User:** Displays whether the user requires authentication using Active Directory.
Click the corresponding button in the Actions column to view detailed user information or to delete the user.

To create a new user, click the **Create User** button.

Create a New Local User

1. Click the **Create User** button in the User tab.
2. In the **Create User** dialog, enter the following:

Create User

Name: test

Active Directory User: ☐

Password:

Confirm Password:

Groups: Administrators

OK Cancel

- Enter a user name in the **Name** field. A valid user name can consist of alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
- Assign the access level by selecting one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is disabled.

- Click **OK** to save or click **Cancel** to cancel the changes.

Add an Active Directory User

Users cannot be created or removed from the Active Directory server, but access can be granted to an existing user in the Active Directory server.

To grant access to an Active Directory user, you can either add the user to a local group on the DM-NAX-AMP-X300, or add the Active Directory group(s) that they are a member of to the DM-NAX-AMP-X300.

To add an Active Directory user.

- Click the **Create User** button.
- In the **Create User** dialog, enter the following.

Create User

Name: Connects\test

Active Directory User: ☒

Groups: Connects


OK Cancel

- a. Enter a user name in the **Name** field in the format "Domain\UserName", for example "crestronlabs.com\JohnSmith". Valid user names can contain alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Select one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is set to enabled.


3. Click **OK** to save or click **Cancel** to cancel the changes.

Delete User


Click the trashcan button () in the **Actions** column to delete the user. Click **Yes** when prompted to delete the user or **No** to cancel the deletion.

After a user is removed from a group, they lose any access rights associated with that group. Note that the user account is not deleted by the delete user operation.

View User Details

Click the information button () in the **Actions** column to view information for the selected user. The **User Details** dialog displays the following information for the selected user.

- **Name:** Displays the name of the selected user.
- **Active Directory User:** Displays whether the user is an Active Directory user.
- **Group:** Displays group(s) the selected user is part of.



Click **OK** to close the **User Details** dialog and to return to the **Users** tab.

Update User Details

Update User

Name

admin1

Active Directory User

☐

Password


Confirm Password

Groups

Administrators

OK

Cancel

1. Click the edit button () in the **Actions** column to update information for the selected user.

2. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.

3. Select one or more groups to assign the user to from the **Groups** drop-down list.

4. Click **OK** to save or click **Cancel** to cancel the changes.

The **Update User** dialog also displays the following read-only information for the selected user.

- **Name:** Displays the name of the user.
- **Active Directory User:** Displays whether the user is an Active Directory user.











Groups

Click the **Groups** tab to view and edit group settings. The **Groups** tab can be used to add local and Active Directory groups, remove local and Active Directory groups, and preview information about a group.

Use the **Search Groups** field to enter search term(s) and display groups that match the search criteria.

Current UserUsersGroups

Search...

Group Name	AD Group	Access Level	Action
Administrators	No	Administrator	 
Connects	No	Connect	 
Operators	No	Operator	 
Programmers	No	Programmer	 
Users	No	User	 

1

10

Create Group

If groups listed in the **Groups** table span across multiple pages, navigate through the groups by clicking a page number or by using the left or right arrows at the bottom of the Groups pane to move forward or backward through the pages.

Additionally, each page can be set to display 5, 10, or 20 groups by using the drop-down menu to the right of the navigation arrows.


Existing groups are displayed in a table and the following information is provided for each group:

- **Group Name:** Displays the name of the group.
- **AD Group:** Displays whether the group requires authentication using Active Directory.
- **Access Level:** Displays the predefined access level assigned to the group (Administrator, Programmer, Operator, User, or Connect).

Click the corresponding button in the **Actions** column to view detailed group information (ⓘ) or to delete (🗑) selected group.

Click on the **Create Group** button in the **Groups** tab to create new group.

Create Local Group




1. Click the **Create Group** button.
2. In the **Create Group** dialog, enter the following:
 - a. Enter the group name in the **Name** field.
 - b. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is disabled.

3. Click **OK** to save. Click **Cancel** to cancel the changes.

Add Active Directory Group

A group cannot be created or removed from the Active Directory server, but access can be granted to an existing group in Active Directory.



The 'Create Group' dialog box has a blue header with the title 'Create Group' and a close button. It contains three fields: 'Name' with the value 'test', 'Access Level' with a dropdown menu showing 'Administrator', and 'Active Directory Group' with a toggle switch that is turned on. At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'X' icon.


Once the group is added, all members of that group will have access to the DM-NAX-AMP-X300.

1. Click the **Create Group** button.
2. In the **Create Group** dialog enter the following:
 - a. Enter the group name in the **Name** field, for example "Engineering Group". Note that group names are case sensitive; a space is a valid character that can be used in group names.
3. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is enabled.


4. Click **OK** to save. Click **Cancel** to cancel the changes.


Delete a Group

Click the trashcan button () in the **Actions** column to delete a group. Click **Yes** when prompted to delete the group or **No** to cancel the deletion.

When a group is deleted, users in the group are not removed from the device or Active Directory server. However, because a user's access level is inherited from a group(s), users within the deleted group will lose access rights associated with the group.

View Group Details

Click the information button () in the **Actions** column to view information for the selected group. The **Group Details** dialog lists the following information for the selected group.




The 'Group Details' dialog box has a blue header with the title 'Group Details' and a close button. It displays three pieces of information: 'Name' with the value 'Administrators', 'Access Level' with the value 'Administrator', and 'Active Directory Group' with the value 'No'. At the bottom right, there is a button labeled 'OK' with a checkmark icon.

- **Name:** Displays the name of the group.
- **Access Level:** Displays the access level of the group and its users.
- **Active Directory Group:** Displays whether the group is an Active Directory group.

Click **OK** to close the **Group Details** dialog and to return to the Groups tab.

802.1x Configuration

The DM-NAX-AMP-X300 has built-in support for the 802.1X standard (an IEEE network standard designed to enhance the security of wireless and Ethernet LANs. The standard relies on the exchange of messages between the device and the network's host, or authentication server), allowing communication with the authentication server and access to protected corporate networks.



To Configure 802.1X Authentication


1. Set the **IEEE 802.1X Authentication** toggle to enabled. This will enable all options on the 802.1X dialog.
2. Select the **Authentication method: EAP-TLS Certificate** or **EAP-MSCHAP V2 Password** according to the network administrator's requirement.
3. Do either one of the following:
 - Select **EAP-TLS Certificate**: Click **Action/Manage Certificates** to upload the required machine certificate. The machine certificate is an encrypted file that will be supplied by the network administrator, along with the certificate password.
 - Select **EAP-MSCHAP V2 Password**: Enter the username and password supplied by the network administrator into the **Username** and **Password** fields. This method does not require the use of a machine certificate, only the user name and password credentials.
4. Select the **OCSP State**: If using OCSP, select **All**, **Required**, or **Optional**. To disable OCSP, select **Off**.
5. If you enabled the **Enable Authentication Server Validation** option, this will enable the **Select Trusted Certificate Authority(ies)** list box which contains signed Trusted Certificate Authorities (CAs) preloaded into the DM-NAX-AMP-X300.

Select the check box next to each CA whose certificate can be used for server validation, as specified by the network administrator.

If the network does not use any of the listed certificates, the network administrator must provide a certificate, which must be uploaded manually via the **Manage Certificates** functionality.
6. If required, type the domain name of the network in the **Domain** field.
7. When the 802.1X settings are configured as desired, click **Save Changes** to save the changes to the device and reboot it. Click **Revert** to cancel any changes.

Access the Web Interface With the Crestron Toolbox™ Application

To access the web interface by opening a web browser within the Crestron Toolbox™ application, do the following:

1. Open the Crestron Toolbox application.
2. From the **Tools** menu, select **Device Discovery Tool**. You can also access the Device Discovery Tool by clicking the Device Discovery Tool button () in the Crestron Toolbox toolbar. The DM-NAX-AMP-X300 is discovered and listed in the device list on the left side of the screen. The associated host name, IP address, and firmware version are also displayed.

NOTE: If there is security software running on the computer, a security alert might be displayed when the Crestron Toolbox application attempts to connect to the network. Make sure to allow the connection, so that the Device Discovery Tool can be used.

3. In the Device Discovery Tool list, double-click your device.
4. Enter your credentials in the **Authentication Required** dialog that opens, and then click **Log In**.
5. Click the **Web Configuration** button in the Configuration page displayed on the left side of the Device Discovery Tool.

DM-NAX-AUD-IO

This section describes how to configure the DM-NAX-AUD-IO.

Web Interface Configuration

The DM-NAX-2XLRI-1G web interface allows you to view status information and configure network and device settings.

Access the Web Interface

To access the web interface, do either of the following:

- [Access the Web Interface with a Web Browser on page 474](#)
- [Access the Web Interface With the Crestron Toolbox™ Application on page 528](#)

The web interface is accessed from a web browser. The following table lists operating systems and their corresponding supported web browsers.

Operating System and Supported Web Browsers


OPERATING SYSTEM	SUPPORTED WEB BROWSERS
Windows® operating system	Chrome™ web browser, version 31 and later
	Firefox® web browser, version 31 and later
	Internet Explorer web browser, version 11 and later
	Microsoft Edge web browser
macOS® operating system	Safari® web browser, version 6 and later
	Chrome web browser, version 31 and later
	Firefox web browser, version 31 and later

Access the Web Interface with a Web Browser

1. Enter the IP address of the DM-NAX-AUD-IO into a web browser.


NOTE: To obtain the IP address, use the **Device Discovery Tool** option in Crestron Toolbox™ application or an IP scanner application.

2. If you are creating a user account for the first time, do the following; otherwise, skip to step 3.
 - a. Enter a username in the **Username** field.
 - b. Enter a password in the **Password** field.
 - c. Re-enter the same password in the **Confirm Password** field.



The screenshot shows the Crestron logo at the top left. Below it, a yellow warning triangle icon is followed by the text "DEVICE FIRST BOOT". In the center, there is a white box titled "Device Administration". Inside this box, there are three input fields: "Username", "Password", and "Confirm Password". Below these fields is a green button with a white plus sign and the text "Create User". At the bottom of the white box, there is small text: "© 2021 Crestron Electronics, Inc.", "Privacy Statement", and "Crestron Software End-User License Agreement".

- d. Click **Create User**. The Device Administration page appears.




The screenshot shows the same Crestron logo at the top left. Below it, the "DEVICE FIRST BOOT" warning is no longer present. The white box titled "Device Administration" still contains the "Username" and "Password" input fields. Below these fields is a blue button with a white magnifying glass icon and the text "Sign In". At the bottom of the white box, the same small text is present: "© 2021 Crestron Electronics, Inc.", "Privacy Statement", and "Crestron Software End-User License Agreement".

3. Enter the username in the **Username** field.
4. Enter the password in the **Password** field.
5. Click **Sign In**.

Action

The **Action** drop-down menu is displayed at the top right side of the interface and provides quick access to common device functions:

- Save Changes
- Revert
- Reboot
- Restore
- Update Firmware
- Download Logs
- Manage Certificates



Save Changes

Click **Save Changes** to save any changes made to the configuration settings.


Revert

Click **Revert** to revert the device back to the last saved configuration settings.

Reboot the DM-NAX-AUD-IO

Certain changes to the settings may require the DM-NAX-AUD-IO to be rebooted to take effect. To reboot the device, do the following:

1. Click **Reboot** in the **Actions** drop-down menu. The **Confirmation** message box appears.




2. Click **Yes, Reboot Now** to reboot the device. The **Reboot** message box appears. Wait for the device reboot to complete before attempting to reconnect to the device.

Restore to Factory Default Settings

1. Click **Restore** in the **Actions** drop-down menu to restore the settings of the DM-NAX-AUD-IO to factory defaults.

NOTE: When settings are restored, all settings, including the network settings, will revert to the factory default. If a static IP address is set, restoring the device to factory default settings will revert the IP address to the default DHCP mode.




2. Click **Yes** in the **Confirmation** dialog to restore the DM-NAX-AUD-IO to factory settings. Click **No** to cancel the restore operation.
A dialog is displayed again, indicating that the restore process was successful and that the device rebooted.

You can also restore to factory settings by pressing and holding the **SETUP** button on the rear panel of the device with power disconnected then connect the power supply and continue to hold **SETUP** button for 30 seconds.

Update Firmware

1. Click **Update Firmware** in the **Actions** drop-down menu.
2. In the **Firmware Upgrade** dialog, click **+ Browse**.



3. Locate and select the desired firmware file, and then click **Open**. The selected firmware file name is displayed in the **Firmware Upgrade** dialog.
4. Click **Load** and wait for the progress bar to complete and for the **OK** button in the message to become clickable.
5. Click **OK**. The device with new firmware can now be accessed.


Download Logs

1. Click **Download Logs** in the **Actions** drop-down menu to download the device message logs for diagnostic purposes.

The log file is downloaded to the Downloads folder of the PC.

Manage Certificates

Use the **Manage Certificates** dialog to add, remove, and manage certificates used in 802.1x and other protected networks.



1. Click **Manage Certificates** in the **Actions** drop-down menu. The following certificate tabs are displayed:
 - **Root:** The Root certificate is used by the DM-NAX-AUD-IO to validate the network's authentication server. The DM-NAX-AUD-IO has a variety of Root certificates, self-signed by trusted CAs (Certificate Authorities) preloaded into the device. Root certificates must be self-signed.
 - **Intermediate:** The Intermediate store holds non self-signed certificates that are used to validate the authentication server. These certificates will be provided by the network administrator if the network does not use self-signed Root certificates.
 - **Machine:** The machine certificate is an encrypted PFX file that is used by the authentication server to validate the identity of the DM-NAX-AUD-IO. The machine certificate will be provided by the network administrator, along with the certificate password. For 802.1x, only one machine certificate can reside on the device.
 - **Web Server:** The Web Server certificate is a digital file that contains information about the identity of the web server.

To Add Certificates

1. Click the corresponding certificate tab.
2. Click the **Add Root Certificate** button.
3. Click the **+ Browse** button.
4. Locate and select the file, and then click the **Open** button.

NOTE: If the certificate is a Machine Certificate, enter the password provided by the network administrator.

5. Click **OK**. This will add the certificate to the list box, displaying the file name and expiration date.
The certificate is now available for selection and can be loaded to the device.


To Delete Certificates

1. Click the corresponding certificate tab.
2. Click the trashcan button (🗑️) in the **Actions** column to delete the certificate.
3. Click **Yes** when prompted to delete the certificate or **No** to cancel the deletion.

Status

The **Status** tab is the first page displayed when opening the interface of the DM-NAX-AUD-IO. It displays general information about the DM-NAX-AUD-IO (such as Model Name, Firmware Version, and Serial Number), current network settings (such as Host Name and IP Address, etc.), and input and output ports' current status.


The Status tab can be accessed at any time by clicking the **Status** tab of the DM-NAX-AUD-IO interface.




Information displayed on the **Status** tab is organized into different sections.

Device

The **Device** section displays the **Model**, **Firmware Version**, and **Serial Number** of the DM-NAX-AUD-IO.



Click **+ More Details** to review additional information about the DM-NAX-AUD-IO.



Network

The **Network** section displays network-related information about the DM-NAX-AUD-IO, including the Hostname, Domain Name, and DNS Servers.

The screenshot shows the Windows Network settings window. The 'Adapter 1' tab is selected. The 'Status' section shows the network is connected. The 'IP Settings' section shows the IP address is 10.64.68.171, subnet mask is 255.255.255.0, and default gateway is 10.64.68.1. The 'DNS Settings' section shows the DNS server is 10.64.5.10 (DHCP). The 'Advanced' section shows the DHCP is On, Link Active is true, and the MAC address is c4:42:68:3f:d4:74.

Property	Value
Hostname	DM-NAX-AUD-IO-C442683FD474
Domain Name	CRESTRON.CRESTRON.com
DNS Servers	10.64.5.10(DHCP)
Adapter 1	
DHCP	On
IP Address	10.64.68.171
Subnet Mask	255.255.255.0
Default Gateway	10.64.68.1
Link Active	true
MAC Address	c4:42:68:3f:d4:74

NOTE: By default, the host name of the DM-NAX-AUD-IO consists of the model name followed by the MAC address of the device. For example, DM-NAX-AUD-IO-00107FB58088.

Click **+ Adapter 1** to display an expanded section that shows additional information. If **+ Adapter 1** is selected, click **- Less details** to collapse the section.

Control System

The **Control System** section displays connection information, consisting of the following:

Control System

Encrypt Connection ON

IP Table

IP ID	Room Id	IP Address/Hostname	Type	Server Port	Connection	Status
C		DIN-AP4-R-C442681A3F36	Peer	41796	Gway	ONLINE

- **Encrypt Connection:** ON or OFF
- **IP ID:** Reports the currently used IP ID of the DM-NAX-AUD-IO
- **IP Address/Hostname:** The IP address of the control system
- **Room ID:** Displays the room ID
- **Status:** OFFLINE or ONLINE

Settings

The **Settings** tab enables configuration of the DM-NAX-AUD-IO settings. The Settings page can be accessed at any time by clicking the **Settings** tab of the DM-NAX-AUD-IO interface.

Many options in the Settings tab are exclusive to a specific device mode: Residential or Commercial. The DM-NAX-AUD-IO is in Commercial mode by default.


This section provides the following information:

- [Commercial Mode on page 482](#)
- [Residential Mode on page 500](#)

Commercial Mode

This section provides the following information:

- [System Setup on page 482](#)
- [Commissioning on page 487](#)
- [Output Channels on page 488](#)
- [Input Channels on page 495](#)
- [DM NAX Streams on page 496](#)
- [Mixing on page 499](#)



System Setup

The **System Setup** section contains settings for **Date/Time**, **Auto Update**, **Network**, and **Control System**.

System Setup

Date/Time Auto Update Network Control System Cloud Settings Device Modes

— Date/Time

Synchronization

Time Synchronization ☒

[Synchronize Now](#)

NTP Time Servers

<input type="checkbox"/>	Address	Port	Authentication Method	Authentication Key	Key ID
<input type="checkbox"/>	pool.ntp.org	123	None	*****	0

[+ Add](#) [- Remove](#)

Configuration

Time Zone (UTC-05:00) Eastern Time (US & Can)

Date 02/27/2024

Time 17:14

Date/Time

Use the **Date/Time** tab to configure the date and time settings of the DM-NAX-AUD-IO.

— Date/Time

Synchronization

Time Synchronization ☒

[Synchronize Now](#)

NTP Time Servers

<input type="checkbox"/>	Address	Port	Authentication Method	Authentication Key	Key ID
<input type="checkbox"/>	pool.ntp.org	123	None	*****	0

[+ Add](#) [- Remove](#)

Configuration

Time Zone (UTC-05:00) Eastern Time (US & Can)

Date 02/21/2024

Time 12:40

Time Synchronization

1. Set the **Time Synchronization** toggle to the right position to enable or left position to disable time synchronization. By default, time synchronization is enabled.
2. In the **NTP Time Servers** table, enter the URL of a NTP (Network Time Protocol) or SNTP (Simple Network Time Protocol) server. Up to three time servers can be added on a device.
3. Click **Synchronize Now** to perform time synchronization between the device's internal clock and the time server.

Time Configuration


1. Click on the **Time Zone** drop-down menu to select the applicable time zone.
2. In the **Date** field, enter the current date.
3. In the **Time (24hr Format)** field, enter the current time in 24-hour format.

Click the **Save Changes** button to save the settings.

Click **Revert** from the **Actions** drop-down menu to revert to the previous settings without saving.

Auto Update

The DM-NAX-AUD-IO can automatically check for and install firmware updates at scheduled intervals via the Auto Update feature.



The screenshot shows the 'Auto Update' configuration page. On the left, there is a 'Schedule' section. On the right, there are several settings: 'Auto Update' and 'Custom URL' are toggle switches, both currently turned off. Below 'Custom URL' is a text box for 'Custom URL Path' containing the URL 'https://crestrondevicefiles.blob.core.win'. Further down are three input fields: 'Day of Week' with a dropdown menu showing 'Daily', 'Time of Day' with a text box showing '02:07', and 'Poll Interval' with a text box showing '0' and a 'Minutes' label. At the bottom right is a blue button labeled 'Update Now'.

1. Set the **Auto Update** toggle to the right position to enable Auto Update.
2. Define the URL to download the updates by doing either of the following:
 - a. Use the default URL to download the updates from the Crestron server.
 - b. Use a custom URL. Set the **Custom URL** toggle to the right position to enable a custom URL. In the **Custom URL Path** text box, enter the path to a custom manifest file in the FTP or SFTP URL format. Use the Crestron Auto Update Tool to generate a custom manifest file, then store the file on an FTP (File Transfer Protocol) or SFTP (Secure File Transfer Protocol) server.
3. Set a schedule for the automatic firmware update by doing either of the following:
 - a. Select the desired **Day of Week** and **Time of Day** (24-hour format) values.
 - b. Set the **Poll Interval** by entering a value from **60** to **65535** minutes. A value of **0** disables the Poll Interval.
4. Click **Save Changes**.

Clicking **Update Now** causes the device to check for a firmware update immediately. If a schedule was set in step 4 above, that schedule still remains in effect.

Network

The **Network** tab contains network-related settings for the DM-NAX-AUD-IO, including the Hostname, Domain, Primary Static DNS, and Secondary Static DNS.

The screenshot shows the 'System Setup' interface with the 'Network' tab selected. Under the 'Adapter 1' subheading, the following settings are visible:

- Hostname ***: DM-NAX-AUD-IO-C442683FD474
- Domain**: CRESTRON.CRESTRON.com
- Primary Static DNS**: 10.64.5.10(DHCP)
- Secondary Static DNS**: 192.168.200.133(DHCP)
- DHCP Enabled**: A toggle switch is currently turned on (blue).
- IP Address**: 10.64.68.171
- Subnet Mask**: 255.255.255.0
- Default Gateway**: 10.64.68.1

NOTE: By default, the hostname of the DM-NAX-AUD-IO consists of the model name followed by the MAC address of the device. For example, DM-NAX-AUD-IO-00107FB58088.

Adapter 1

The Adapter 1 subheading contains settings for DHCP, IP Address, Subnet Mask, and Default Gateway of Ethernet adapter 1 on the rear panel of the device.

NOTE: DM NAX devices' internal processes use IP addresses in the 10.10.10.xxx range. This IP range should be avoided when addressing DM NAX devices to prevent conflicts.

Set the **DHCP** toggle to enabled (right) or disabled (left) to specify whether the IP address of the DM-NAX-AUD-IO is to be assigned by a DHCP (Dynamic Host Configuration Protocol) server.

- **Enabled:** When DHCP is enabled (default setting), the IP address of the DM-NAX-AUD-IO is automatically assigned by a DHCP server on the local area network (LAN).
- **Disabled:** When DHCP is disabled, manually enter information in the following fields:
 - **Primary Static DNS:** Enter a primary DNS IP address.
 - **Secondary Static DNS:** Enter a secondary DNS IP address.
 - **IP Address:** Enter a unique IP address for the DM-NAX-AUD-IO.
 - **Subnet Mask:** Enter the subnet mask that is set on the network.
 - **Default Gateway:** Enter the IP address that is to be used as the network's gateway.

To save any new network entries, click **Save Changes**.

Control System

Control System

Control System Username

chdevice

Control System Password

Encrypt Connection

IP Table

<input type="checkbox"/>	IP ID	IP Address/Hostname	Room Id
<input type="checkbox"/>	C	DIN-AP4-R-C442681A3F36	Room Id

+ Add

× Remove

1. Click the **Encrypt Connection** button to navigate to the **Security** tab to configure encryption settings.
2. Enter the username in the **Control System Username** field.
3. Enter the password in the **Control System Password** field.
4. Enter the Room ID in the **Room ID** field.
5. Enter the IP ID of the DM-NAX-AUD-IO in the **IP ID** field.
6. Enter the IP address or hostname of the control system in the **IP Address/Hostname** field.
7. Click the **Save Changes** button to save the new entries. The Control System Save message box appears, indicating that the control system settings were saved successfully. Click the **Revert** button to revert to the previous settings without saving.

Cloud Settings

Date/Time

Auto Update

Network

Control System

Cloud Settings

Device Modes

Cloud Settings

Cloud Configuration Service Connection

Set the **Cloud Settings** toggle to enabled (right) or disabled (left) to specify whether the DM-NAX-AUD-IO can communicate with the XiO Cloud® platform.

Device Modes

Use the **Device Modes** tab to configure the **Application Mode** of the DM-NAX-AUD-IO.

Date/Time

Auto Update

Network

Control System

Cloud Settings

Device Modes


Device Modes (Autosaved)

Application Mode

Commercial (Advanced)

The Application Mode determines which options and controls are available.

- Select **Residential (Standard)** or **Commercial (Advanced)**. A **Reboot** confirmation message box appears.




- Click **Yes, Reboot Now** to reboot the device into the selected mode. The **Reboot** message box appears.
- Wait for the device reboot to complete before attempting to reconnect to the device.

By default, the DM-NAX-AUD-IO is set to **Commercial (Advanced)** mode.

Commissioning

The **Commissioning** section provides a quick way to automatically assign multicast addresses to the device's internal audio-over-IP stream transmitters.

A screenshot of the 'Commissioning' section in a web interface. The section has a blue header with a dropdown arrow and the text 'Commissioning'. Below the header, there are two labels: 'Starting Multicast Address' and 'Last Used Multicast Address'. The 'Starting Multicast Address' is followed by a text input field containing '239.8.0.0'. The 'Last Used Multicast Address' is followed by the text '239.8.0.8'. At the bottom right, there is a blue button labeled 'Assign Addresses'.

Click **Assign Addresses** to give each DM NAX transmitter in the DM-NAX-AUD-IO a unique multicast address beginning with the specified **Starting Multicast Address**. The valid range for **Starting Multicast Address** is 239.8.0.0 to 239.255.255.254.

NOTE: This will begin transmitting multicast traffic on your network, refer to the [DM NAX Audio-over-IP System Design Guide](#) document for details.

Output Channels

The **Zones** section contains the **Volume** and **Mute** settings for all zone outputs of the device, as well as an **Edit** option for more advanced settings within each zone.

Output Channels

Zones (Autosaved)

Global Filter

Name	LineOutLeft	LineOutRight	StreamOut1Ch1	StreamOut1Ch2
Volume (%)	 30	 30	 80	 80
Signal Presence				
Signal Level	 Nominal	 Nominal	 Nominal	 Nominal
Mute				
Action	Edit	Edit	Edit	Edit

Signal Presence indicates whether or not an audio signal is detected in that zone.

Signal Level indicates if the signal is **Clipping** or **Nominal** (non-clipping).

- **Nominal:** The signal level is within normal operating bounds and below the clipping threshold.
- **Clipping:** The signal level is clipping or above the -3 dB warning threshold and in danger of clipping.

Give each zone a friendly name using the **Name** column of the **Zones** table. If the device is paired with a control system, these names may be overwritten by the control system's program.

To configure the zone volume, do one of the following:

- Move the **Volume** slider up to increase or down to decrease the zone volume.
- Click the % arrows to increase or decrease the zone volume. Values range from 0 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Volume** field.

To mute all audio output from a zone, click its respective **Mute** button. To unmute the zone, click the **Muted** button.

Click **Edit** to view additional **Zone** and **Output** options.

Zone Settings

To configure the settings for an output channel, click the **Edit** button. The **Edit Zone** window appears.

DM-NAX-AUD-IO-C442683FD474 > Zones

LineOutLeft

Zone

Tone (Autosaved)

Bass

0

db

Treble

0

db

Delay (Autosaved)

Delay Time(ms)

0

ms

Output

Zone

Click **Zone** to access the settings for **Tone** and **Delay**.

DM-NAX-AUD-IO-C442683FD474 > Zones

LineOutLeft

Zone

Tone (Autosaved)

Bass

0

db

Treble

0

db

Delay (Autosaved)

Delay Time(ms)

0

ms

Output

Tone

Tone (Autosaved)

Bass

-1.7

db

Treble

0.5

db

- **Bass:** To adjust the bass, do one of the following:
 - Move the **Bass** slider to the right to increase or to the left to decrease the bass db.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of .1 db.
 - Manually enter a value in the **Bass** field.
- **Treble:** To adjust the treble, do one of the following:
 - Move the **Treble** slider to the right to increase or to the left to decrease the treble db.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of .1 db.
 - Manually enter a value in the **Treble** field.

Delay

Delay (Autosaved)

Delay Time(ms)

0

ms


To set the delay, do one of the following:

- Move the **Delay Time(ms)** slider to the right to increase or to the left to decrease the delay time.
- Click the **ms** arrows to increase or decrease the delay. Values range from 0 ms to 85 ms, adjustable in increments of 1 ms.
- Manually enter a value in the **Delay Time(ms)** field.

NOTE: The Delay feature is only available on the line level output channels.

Output

Click **Output** to access the settings for **Minimum/Maximum Volume**, **Signal**, and the output Equalizer.



Output

Minimum / Maximum (Autosaved)

Minimum 0 %

Maximum 100 %


Default 30 %

Signal (Autosaved)

Signal Not Present

Clipping None

Minimum/Maximum Volume



Minimum / Maximum (Autosaved)

Minimum 0 %

Maximum 100 %

Default 30 %

1. To set the minimum volume of the zone, do one of the following:

- Move the **Minimum** slider to the right to increase or to the left to decrease the minimum volume.
- Click the **%** arrows to increase or decrease the minimum volume. Values range from 0 to 50%, adjustable in increments of 1%.
- Manually enter a value in the **Minimum** field.

2. To set the maximum volume of the zone, do one of the following:

- Move the **Maximum** slider to the right to increase or to the left to decrease the maximum volume.
- Click the **%** arrows to increase or decrease the maximum volume. Values range from 70 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Maximum** field.


NOTE: When a **Minimum** and **Maximum** volume are set, the 1-100% range represented by the **Zone** and **Default** volume controls are scaled to the range set. For example, if a **Minimum** of 10% and a **Maximum** of 80% are set for a zone, the 1-100% range of the **Zone** volume control is scaled to the 10%-80% range set as the **Minimum** and **Maximum**.

3. To set the default volume of the zone, do one of the following:

- Move the **Default** slider to the right to increase or to the left to decrease the default volume.
- Click the **%** arrows to increase or decrease the default volume. Values range from 0 to 50%, adjustable in increments of 1%.
- Manually enter a value in the **Default** field.

NOTE: The **Default** volume is applied as the **Zone** volume any time the zone receives a source route and no source was previously routed to that zone.

Signal























The **Signal** section is a read-only field that displays the **Signal** and **Clipping** status of the zone output.

- If an output signal is present but not clipping, **Signal** will display **Present** in green and **Clipping** will display **None** in green.
- If an output signal is present and clipping, **Signal** will display **Present** in green and **Clipping** will display **Present** in red.
- If no output signal is detected, **Signal** will display **Not Present** in red and **Clipping** will display **None** in green.

Equalizer Settings

Equalizer Settings (Autosaved)

Speaker EQ Enabled ☒

Band	Band01	Band02	Band03	Band04	Band05	Band06	Band07	Band08	Band09	Band10
Gain	 0	 0	 0	 0	 0	 0	 0	 0	 0	 0
Type	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ
Frequency	32	64	125	250	500	1000	2000	4000	8000	16000
Bandwidth	0.33	0.33	0.33	0.33	0.33	0.33	0.33	0.33	0.33	0.33
Bypass	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Actions	 Reset	 Reset	 Reset	 Reset	 Reset	 Reset	 Reset	 Reset	 Reset	 Reset

Each output channel of the DM-NAX-AUD-IO has a dedicated ten-band equalizer that can be fully customized to tune the zone output signal to the needs of an install. Each band can have a discrete gain, filter type, center frequency, and bandwidth set, and can also be bypassed. The equalizer itself can also be bypassed using the **Speaker EQ Enabled** toggle.

1. Set the **Speaker EQ Enabled** toggle to the right position to enable the equalizer. Set the toggle to the left position to bypass the equalizer.

NOTE: When **Speaker EQ Enabled** is disabled, all equalizer bands are bypassed. This is a quick way to perform A/B testing of the entire EQ curve.

2. With the **Speaker EQ Enabled** toggle in the right position, do the following to configure a given equalizer band:
 - a. To set a band's gain, do one of the following:
 - Move the **Gain** slider up to increase or down to decrease the gain.
 - Click the arrows to increase or decrease the gain. Values range from -40 dB to 20 dB, adjustable in increments of 0.1 dB.
 - Manually enter a value in the **Gain** field.

- b. Select a filter type from the **Type** drop-down menu. By default, all bands are set to the **EQ** filter type. Some filter types will disable other settings in their respective band while enabled. For example, selecting the **LowPass** filter type for a band will disable that band's **Gain** and **Bandwidth** settings, since the **LowPass** filter applies a fixed roll-off slope at a set frequency. The available filter types are:
- **EQ:** a fully parametric filter that can boost or cut a range of frequencies.
 - **Notch:** a parametric filter designed to more precisely cut a frequency or range of frequencies. A notch filter can achieve a narrower bandwidth than the standard **EQ** parametric filter type.
 - **TrebleShelf:** a filter that boosts or cuts all frequencies above a set frequency by a set gain.
 - **BassShelf:** a filter that boosts or cuts all frequencies below a set frequency by a set gain.
 - **LowPass:** a filter that fully cuts all frequencies above a set frequency using a fixed roll-off slope of -12 dB per octave.
 - **HighPass:** a filter that fully cuts all frequencies below a set frequency using a fixed roll-off slope of -12 dB per octave.
- c. Set a center frequency for the equalizer band to tune a specific portion of the audible frequency spectrum. To set the center frequency, do one of the following:
- Click the arrows to increase or decrease the frequency. Values range from 20 Hz to 20 kHz, adjustable in increments of 1 Hz. Each band has a default center frequency that will be applied if the **Reset** button at the bottom of the band is clicked.
 - Manually enter a value in the **Frequency** field.
- d. Set a bandwidth to determine how wide of a frequency range is effected by the equalizer band. To set the bandwidth, do one of the following:
- Click the arrows to increase or decrease the bandwidth. Values range from 0.1 octaves to 4.0 octaves, adjustable in increments of 0.1 octave.
 - Manually enter a value in the **Bandwidth** field.
- e. The individual Bypass controls allow you to bypass a single band of equalization at a time for more granular A/B testing of a single filter. Set a band's **Bypass** toggle to the right position to bypass that band. Set the toggle to the left position to disable the bypass. By default, **Bypass** is disabled.
- f. Each equalizer band has a **Reset** button that will reapply the default settings for that band.

Click **Done** to return to the **Settings** tab of the web user interface.

Input Channels

The **Input Channels** section is used to configure the **Name**, **Compensation**, and **Mute** attributes of the front panel line inputs on the DM-NAX-AUD-IO.

The screenshot shows the 'Input Channels' configuration window. It has a title bar 'Input Channels' with a dropdown arrow. Below it is a section 'Analog Inputs (Autosaved)' with a green line indicator. The main area is a table with 4 columns and 7 rows. The columns are 'LineInLeft', 'LineInRight', 'StreamIn1Ch1', and 'StreamIn1Ch2'. The rows are 'Name', 'Analog Gain (db)', 'Compensation (db)', 'Signal Present', 'Signal Level', and 'Mute'. The 'Compensation (db)' row has a slider and a numeric field for each input. The 'Signal Present' row has green checkmarks for StreamIn1Ch1 and StreamIn1Ch2. The 'Signal Level' row has green checkmarks and the word 'Nominal' for all inputs. The 'Mute' row has toggle switches for all inputs.

Name	LineInLeft	LineInRight	StreamIn1Ch1	StreamIn1Ch2
Analog Gain (db)	17	17		
Compensation (db)				
Signal Present			✓	✓
Signal Level	✓ Nominal	✓ Nominal	✓ Nominal	✓ Nominal
Mute	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Configure Inputs

1. If needed, enter a friendly name for each input in its **Name** field.
2. To set an analog gain value for a given input, click the **db** arrows to increase or decrease the compensation. Values range from 0 dB to 60 dB, adjustable in increments of 1 dB.
3. To set a level compensation adjustment for a given input, do one of the following:
 - Move the **Compensation** slider up to increase or down to decrease the level compensation. Compensation increases or decreases the level of the incoming audio signal on any of the physical inputs on the device's rear panel.
 - Click the **db** arrows to increase or decrease the compensation. Values range from -10 dB to 10 dB, adjustable in increments of 1 dB.
 - Manually enter a value in the **Compensation** field.
4. To mute the signal from the corresponding input, set the **Mute** toggle to the right. To disable the mute, set the **Mute** toggle to the left. By default, **Mute** is disabled.

Monitor the device's input signals using the text indicators in the **Signal Present** and **Clipping Detected** columns:

- ## DM NAX Streams

Click **NAX Streams** to expand the tab and display the following information.

▼ NAX Streams

This Device is the Leader PTP Clock Source

No

PTP Clock Leader MAC Address

00:10:71:9c:1fe9

PTP Priority

254

⬆️⬇️⬆️

— Transmitters (Autosaved)

Audio Source	Stream	Nax Stream Address	Nax Stream Name	Status	Actions
StreamOut1Ch1	Stream01	0.0.0.0	Stream01c4.42.68.3fb8.ac	Stream Stopped	▶️ ◻️ ⚙️

— Receivers (Autosaved)


Zone Name	Stream	Current Stream Address	Requested Stream Address	Status	Actions
StreamIn1Ch1	Stream01	0.0.0.0	0.0.0.0 🔍	Stream Stopped	▶️ ◻️ ⚙️

- **Device is Master PTP Clock Source** indicates whether the DM NAX device's PTP clock is the master clock on the network. **Yes** will be displayed in green when the local DM-NAX-AUD-IO's clock is the PTP master clock and **No** will be displayed in red when another PTP clock on the network is operating as the master clock.
- **Master Clock Status** displays the Master Clock ID of the device on the network that is currently acting as the master clock.
- **PTP Priority**: This sets the priority of the local DM NAX device's PTP clock relative to other clocks on the network. The default setting is 254 (one increment higher than the lowest possible value) so that the DM-NAX-AUD-IO will only operate as clock master if no other PTP master is present on the network. Valid values range from 1 to 255.

Configure Transmitters

To configure the DM NAX transmit stream, do the following.

1. Enter a valid multicast address in the **NAX Stream Address** field.
2. Enter a name in the **NAX Stream Name** field by which the stream can be identified. This stream name is associated with the DM NAX stream's multicast address by other DM NAX or AES67 devices, like a device hostname that resolves to a given IP address.
3. **Status** indicates whether a stream is transmitting or not. When the stream has started or stopped, the **Status** column will update accordingly.
4. Click the configure button (⚙️) in the **Actions** column. The **Configure** dialog appears:




5. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled for a given stream, the stream will begin transmitting automatically and will be available as a multicast stream on your network at the specified multicast address.
 - If **Auto Initiation** is disabled for the input, the stream will not begin transmitting until it is manually initiated.
6. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number for DM NAX streams is 5004.
7. Click **OK** to save or click **Cancel** to cancel the changes.

Configure Receivers

1. Enter the multicast address of a transmitting stream in the **Requested Stream Address** field to subscribe the receiver to the stream.

2. Click the configure button (⚙️) in the **Actions** column. The **Configure** dialog appears:




The screenshot shows a 'Configure' dialog box. It features a blue header bar with the title 'Configure' and a close button (X). The main content area is white and contains a toggle switch labeled 'Auto Initiation' which is currently in the 'off' position. Below the toggle is a 'Port' field with a text input displaying '5004' and a spinner control with up and down arrows. At the bottom of the dialog, there are two buttons: 'OK' (with a checkmark icon) and 'CANCEL' (with an 'X' icon).

3. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled, the stream will begin automatically when the receiver subscribes to the transmitter.
 - If **Auto Initiation** is disabled, the stream will not begin until it is manually initiated.
4. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number is 5004.
5. Click **OK** to save or click **Cancel** to cancel the changes.

Mixing

The **Mixing** matrix is used to route a local input or AES67 stream to an output on the DM-NAX-AUD-IO.

NOTE: To receive an AES67 stream from Dante devices, see [OLH 1001151](#).




To route inputs to outputs on the device:

- Click the cells corresponding to the desired output that are to be paired for routing. Once a route is made, 🔊 appears. The input that you have selected for a given row will route to the output corresponding to that row in the matrix.
- To break a given route click 🔊 or ✖.

Each output can have any number of inputs routed to it. To adjust the mix setting for a route, click the **dB** value of the cell, then do one of the following:


- Move the slider up to increase or down to decrease the mix level.
- Click the arrows to increase or decrease the mix level.
- Manually enter a value in the field.



Residential Mode

This section provides the following information:

- [System Setup on page 501](#)
- [Commissioning on page 505](#)
- [Output Channels on page 506](#)
- [Inputs on page 513](#)
- [NAX Streams on page 514](#)
- [Routing on page 517](#)



System Setup

The **System Setup** section displays information about the Date/Time, Auto Update, Network, Control System, Cloud Settings, and Device Modes.

Date/Time

Use the **Date/Time** section to configure the date and time settings of the DM-NAX-AUD-IO.

System Setup

Date/Time Auto Update Network Control System Cloud Settings Device Modes

— Date/Time

Synchronization

Time Synchronization ☒

[Synchronize Now](#)

NTP Time Servers

<input type="checkbox"/>	Address	Port	Authentication Method	Authentication Key	Key ID
<input type="checkbox"/>	pool.ntp.org	123	None	*****	0

[+ Add](#) [- Remove](#)

Configuration

Time Zone: (UTC-05:00) Eastern Time (US & Can) ▼

Date: 02/21/2024

Time: 11:49

Time Synchronization

1. Set the **Time Synchronization** toggle to the right position to enable or left position to disable time synchronization. By default, time synchronization is enabled.

2. In the **NTP Time Servers** table, enter the URL of a NTP (Network Time Protocol) or SNTP (Simple Network Time Protocol) server. Up to three time servers can be added on a device.
3. Click **Synchronize Now** to perform time synchronization between the device's internal clock and the time server.

Time Configuration

1. Click on the **Time Zone** drop-down menu to select the applicable time zone.
2. In the **Date** field, enter the current date.
3. In the **Time (24hr Format)** field, enter the current time in 24-hour format.

Click the **Save Changes** button to save the settings.

Click **Revert** from the **Actions** drop-down menu to revert to the previous settings without saving.

Auto Update

The DM-NAX-AUD-IO can automatically check for and install firmware updates at scheduled intervals via the Auto Update feature.

The screenshot shows the 'System Setup' menu with 'Auto Update' selected. The 'Auto Update' toggle is turned on. The 'Custom URL' toggle is turned off. The 'Custom URL Path' text box contains the URL 'https://crestrondevicefiles.blob.core.winc'. The 'Schedule' section shows 'Day of Week' set to 'Daily', 'Time of Day' set to '02:25', and 'Poll Interval' set to '0' minutes. An 'Update Now' button is at the bottom right.

1. Set the **Auto Update** toggle to the right position to enable Auto Update.
2. Define the URL to download the updates by doing either of the following:
 - a. Use the default URL to download the updates from the Crestron server.
 - b. Use a custom URL. Set the **Custom URL** toggle to the right position to enable a custom URL. In the **Custom URL Path** text box, enter the path to a custom manifest file in the FTP or SFTP URL format. Use the Crestron Auto Update Tool to generate a custom manifest file, then store the file on an FTP (File Transfer Protocol) or SFTP (Secure File Transfer Protocol) server.
3. Set a schedule for the automatic firmware update by doing either of the following:

- a. Select the desired **Day of Week** and **Time of Day** (24-hour format) values.
 - b. Set the **Poll Interval** by entering a value from **60** to **65535** minutes. A value of **0** disables the Poll Interval.
4. Click **Save Changes**.

Clicking **Update Now** causes the device to check for a firmware update immediately. If a schedule was set in step 4 above, that schedule still remains in effect.

Network

The **Network** section contains network-related settings for the DM-NAX-AUD-IO, including the Hostname, Domain, Primary Static DNS, and Secondary Static DNS.

The screenshot shows the 'System Setup' menu with the 'Network' tab selected. The 'Network' section is expanded, showing settings for 'Adapter 1'. The settings are as follows:

Setting	Value
Hostname *	DM-NAX-AUD-IO-C442683FD474
Domain	CRESTRON.CRESTRON.com
Primary Static DNS	10.64.5.10(DHCP)
Secondary Static DNS	192.168.200.133(DHCP)
DHCP Enabled	<input checked="" type="checkbox"/>
IP Address	10.64.68.171
Subnet Mask	255.255.255.0
Default Gateway	10.64.68.1

NOTE: By default, the host name of the DM-NAX-AUD-IO consists of the model name followed by the MAC address of the device. For example, DM-NAX-AUD-IO-00107FB58088.

Adapter 1

The Adapter 1 subheading contains settings for DHCP, IP Address, Subnet Mask, and Default Gateway of Ethernet adapter 1 on the rear panel of the device.

NOTE: DM NAX devices' internal processes use IP addresses in the 10.10.10.xxx range. This IP range should be avoided when addressing DM NAX devices to prevent conflicts.

Set the **DHCP** toggle to enabled (right) or disabled (left) to specify whether the IP address of the DM-NAX-AUD-IO is to be assigned by a DHCP (Dynamic Host Configuration Protocol) server.

- **Enabled:** When DHCP is enabled (default setting), the IP address of the DM-NAX-AUD-IO is automatically assigned by a DHCP server on the local area network (LAN).
- **Disabled:** When DHCP is disabled, manually enter information in the following fields:
 - **Primary Static DNS:** Enter a primary DNS IP address.
 - **Secondary Static DNS:** Enter a secondary DNS IP address.
 - **IP Address:** Enter a unique IP address for the DM-NAX-AUD-IO.
 - **Subnet Mask:** Enter the subnet mask that is set on the network.
 - **Default Gateway:** Enter the IP address that is to be used as the network's gateway.

To save any new network entries, click **Save Changes**.

Control System

The screenshot shows the 'Control System' configuration page. At the top, there's a 'System Setup' header with tabs for 'Date/Time', 'Auto Update', 'Network', 'Control System' (selected), 'Cloud Settings', and 'Device Modes'. Below the tabs, there's a section titled 'Control System'. It features an 'Encrypt Connection' button. Below this is an 'IP Table' section with a table header containing 'IP ID', 'IP Address/Hostname', and 'Room Id'. The table currently shows 'No records found'. At the bottom of the table, there are '+ Add' and 'x Remove' buttons.

1. Click the **Encrypt Connection** button to navigate to the **Security** tab to configure encryption settings.
2. Enter the username in the **Control System Username** field.
3. Enter the password in the **Control System Password** field.
4. Enter the Room ID in the **Room ID** field.
5. Enter the IP ID of the DM-NAX-AUD-IO in the **IP ID** field.
6. Enter the IP address or hostname of the control system in the **IP Address/Hostname** field.
7. Click the **Save Changes** button to save the new entries. The Control System Save message box appears, indicating that the control system settings were saved successfully. Click the **Revert** button to revert to the previous settings without saving.

Cloud Settings

The screenshot shows the 'Cloud Settings' configuration page. It features a toggle switch labeled 'Cloud Configuration Service Connection'. The toggle is currently turned on (green).

Set the **Cloud Settings** toggle to enabled (right) or disabled (left) to specify whether the DM-NAX-AUD-IO can communicate with the XiO Cloud® platform.

Device Modes

Use the **Device Modes** section to configure the **Application Mode**.

- **Application Mode:** The Application Mode determines which options and controls are available.
 - Select **Residential (Standard)** or **Commercial (Advanced)**. A **Reboot** confirmation message box appears.

- Click **Yes, Reboot Now** to reboot the device into the selected mode. The **Reboot** message box appears.
- Wait for the device reboot to complete before attempting to reconnect to the device.

Commissioning


The **Commissioning** section provides a quick way to automatically assign multicast addresses to the device's internal audio-over-IP stream transmitters.

Click **Assign Addresses** to give each DM NAX transmitter in the DM-NAX-AUD-IO a unique multicast address beginning with the specified **Starting Multicast Address**. The valid range for **Starting Multicast Address** is 239.8.0.0 to 239.127.255.254.

NOTE: This will begin transmitting multicast traffic on your network, refer to the [General Network Requirements](#) document for details.

Output Channels

The **Zones** section contains the **Volume** and **Mute** settings for all zone outputs of the device, as well as a Configure option for more advanced settings within each zone.




Give each zone a friendly name using the **Name** column of the **Zones** table. If the device is paired with a control system, these names may be overwritten by the control system's program.

To configure the zone volume, do one of the following:

- Move the **Volume** slider to the right to increase or to the left to decrease the zone volume.
- Click the % arrows to increase or decrease the zone volume. Values range from 0 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Volume** field.

To mute all audio output from a zone, click its respective **Mute** button. To unmute the zone, click the **Muted** button.

Zone Settings

To configure zone settings, click the **Configure** button ( **Configure**). The **Edit Zone** window appears.

Zone

Click **Zone** to access the settings for **Tone**, **Balance**, and **Delay**.

DM-NAX-AUD-IO-C442683FD474 > Zones

LineOut

Zone

Tone (Autosaved)

Tone Profile

Off

Bass

0

db

Treble

0

db

Night Mode

Off

Balance (Autosaved)

Left / Right

0

%

The **Tone** section provides adjustments for the **Tone Profile**, **Bass**, **Treble**, **Loudness**, and **Night Mode** settings of the zone output.

NOTE: The Tone Profile, Bass, Treble, and Loudness settings in the Tone section are all applied separately from the Equalizer Settings for the zone. This means that any adjustments made in the Tone section will stack with those made in the Equalizer Settings section.

- To select a tone profile preset for the zone, select an option from the **Tone Profile** drop-down menu. The available options are **Off**, **Classical**, **Jazz**, **Pop**, **Rock**, and **Spoken Word**. By default, **Off** is selected.
- Bass:** To adjust the bass, do one of the following:
 - Move the **Bass** slider to the right to increase or to the left to decrease the bass.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of 1 db.
 - Manually enter a value in the **Bass** field.
- Treble:** To adjust the treble, do one of the following:
 - Move the **Treble** slider to the right to increase or to the left to decrease the treble.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of 1 db.
 - Manually enter a value in the **Treble** field.
- To enable the loudness setting on the zone output, slide the **Loudness** switch to the right. To disable loudness, slide the **Loudness** switch to the left.

5. The **Night Mode** feature applies subtle processing to restrict the dynamic range of the zone audio, to allow for lower listening levels at night or in rooms where higher listening levels would be disruptive. To select a dynamics processing level, select an option from the **Night Mode** drop-down menu. The available options are **Off**, **Low**, **Medium**, and **High**. By default, **Off** is selected.

Balance

To adjust the left/right balance of the stereo output signal, do one of the following:

- Move the **Balance** slider to the right to shift the stereo balance to the right channel or to the left to shift the balance to the left.
- Click the arrows to adjust the balance left or right. The up arrow shifts the balance to the right while the down arrow shifts the balance to the left.
- Manually enter a value in the **Balance** field. Values range from -50 to 50, adjustable in increments of 1. Positive values shift the balance to the right while negative values shift the balance to the left.

Delay

To set the delay, do one of the following:

- Move the **Delay Time(ms)** slider to the right to increase or to the left to decrease the delay time.
- Click the **ms** arrows to increase or decrease the delay. Values range from 0 ms to 85 ms, adjustable in increments of 1 ms.
- Manually enter a value in the **Delay Time(ms)** field.

Output

Click **Output** to access the settings for **Minimum/Maximum Volume**, **Stereo/Mono**, **Signal**, **Bussing**, **Volume Offset**, **Signal Generator**, and **Equalizer Settings**.

Output

Minimum / Maximum (Autosaved)

Minimum

0

%

Maximum

100

%

Default

30

%

Stereo / Mono (Autosaved)

Stereo / Mono

Stereo

Mono

Zone Configuration

Standard

Signal (Autosaved)

Signal

Not Present

Minimum/Maximum Volume

Minimum / Maximum (Autosaved)

Minimum

0

%

Maximum

100

%

Default

30

%

1. To set the minimum volume of the zone, do one of the following:

- Move the **Minimum** slider to the right to increase or to the left to decrease the minimum volume.
- Click the **%** arrows to increase or decrease the minimum volume. Values range from 0 to 50%, adjustable in increments of 1%.
- Manually enter a value in the **Minimum** field.

2. To set the maximum volume of the zone, do one of the following:

- Move the **Maximum** slider to the right to increase or to the left to decrease the maximum volume.
- Click the **%** arrows to increase or decrease the maximum volume. Values range from 70 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Maximum** field.


NOTE: When a **Minimum** and **Maximum** volume are set, the 1-100% range represented by the **Zone** and **Default** volume controls are scaled to the range set. For example, if a **Minimum** of 10% and a **Maximum** of 80% are set for a zone, the 1-100% range of the **Zone** volume control is scaled to the 10%-80% range set as the **Minimum** and **Maximum**.

3. To set the default volume of the zone, do one of the following:

- Move the **Default** slider to the right to increase or to the left to decrease the default volume.
- Click the **%** arrows to increase or decrease the default volume. Values range from 0 to 50%, adjustable in increments of 1%.
- Manually enter a value in the **Default** field.

NOTE: The **Default** volume is applied as the **Zone** volume any time the zone receives a source route and no source was previously routed to that zone.

Stereo/Mono




— Stereo / Mono (Autosaved)

Stereo / Mono ☒ Stereo ☐ Mono

Zone Configuration Standard

Select either **Stereo** or **Mono** from the **Stereo/Mono** radio buttons. If **Stereo** is selected, both output channels can have independent audio content. If **Mono** is selected, both output channels receive the same audio content.

Signal



— Signal (Autosaved)


Signal Not Present

Clipping None

The **Signal** section is a read-only field that displays the **Signal** and **Clipping** status of the zone output.

- If an output signal is present but not clipping, **Signal** will display **Present** in green and **Clipping** will display **None** in green.
- If an output signal is present and clipping, **Signal** will display **Present** in green and **Clipping** will display **Present** in red.
- If no output signal is detected, **Signal** will display **Not Present** in red and **Clipping** will display **None** in green.

Bussing Volume Offset




Bussing Volume Offset is an additional level compensation applied to the zone relative to any other zones it is grouped with via the **Bussing** feature.

To set the bussing volume offset, do one of the following:

- Move the **Bussing Volume Offset** slider to the right to increase or to the left to decrease the offset.
- Click the **db** arrows to increase or decrease the offset. Values range from -12 dB to 12 dB, adjustable in increments of 1 dB.
- Manually enter a value in the **Bussing Volume Offset** field.

Signal Generator













The DM-NAX-AUD-IO has a built-in signal generator that allows an integrator to send an audio signal to the output for testing purposes.

1. To route the signal generator to the zone output, click the **Signal Generator** button so that it displays **Active** and is highlighted in blue. To unroute the signal generator on the zone output, click the **Signal Generator** button so that it displays **Inactive** and is highlighted in grey. By default, the signal generator is not routed to the zone output.
2. To adjust the signal generator's volume, do one of the following:
 - Move the **Signal Generator Volume** slider right to increase or left to decrease the volume.
 - Click the arrows to increase or decrease the signal generator volume. Values range from 0 to 100, adjustable in increments of 1.
 - Manually enter a value in the **Signal Generator Volume** field.

Equalizer Settings

Equalizer Settings (Autosaved)

Speaker EQ Enabled ☒

Band	Band01	Band02	Band03	Band04	Band05	Band06	Band07	Band08	Band09	Band10
Gain										
	0	0	0	0	0	0	0	0	0	0
Type	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ
Frequency	32	64	125	250	500	1000	2000	4000	8000	16000
Bandwidth	0.33	0.33	0.33	0.33	0.33	0.33	0.33	0.33	0.33	0.33
Bypass	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Actions	Reset	Reset	Reset	Reset	Reset	Reset	Reset	Reset	Reset	Reset

The zone output of the DM-NAX-AUD-IO has a dedicated ten-band equalizer that can be fully customized to tune the zone output signal to the needs of an install. Each band can have a discrete gain, filter type, center frequency, and bandwidth set, and can also be bypassed. The equalizer itself can also be bypassed using the **Speaker EQ Enabled** toggle.

1. Set the **Speaker EQ Enabled** toggle to the right position to enable the equalizer. Set the toggle to the left position to bypass the equalizer.

NOTE: When **Speaker EQ Enabled** is disabled, all equalizer bands are bypassed. This is a quick way to perform A/B testing of the entire EQ curve.

2. With the **Speaker EQ Enabled** toggle in the right position, do the following to configure a given equalizer band:
 - a. To set a band's gain, do one of the following:
 - Move the **Gain** slider up to increase or down to decrease the gain.
 - Click the arrows to increase or decrease the gain. Values range from -40 dB to 20 dB, adjustable in increments of 0.1 dB.
 - Manually enter a value in the **Gain** field.

- b. Select a filter type from the **Type** drop-down menu. By default, all bands are set to the **EQ** filter type. Some filter types will disable other settings in their respective band while enabled. For example, selecting the **LowPass** filter type for a band will disable that band's **Gain** and **Bandwidth** settings, since the **LowPass** filter applies a fixed roll-off slope at a set frequency. The available filter types are:
- **EQ:** a fully parametric filter that can boost or cut a range of frequencies.
 - **Notch:** a parametric filter designed to more precisely cut a frequency or range of frequencies. A notch filter can achieve a narrower bandwidth than the standard **EQ** parametric filter type.
 - **TrebleShelf:** a filter that boosts or cuts all frequencies above a set frequency by a set gain.
 - **BassShelf:** a filter that boosts or cuts all frequencies below a set frequency by a set gain.
 - **LowPass:** a filter that fully cuts all frequencies above a set frequency using a fixed roll-off slope of -12 dB per octave.
 - **HighPass:** a filter that fully cuts all frequencies below a set frequency using a fixed roll-off slope of -12 dB per octave.
- c. Set a center frequency for the equalizer band to tune a specific portion of the audible frequency spectrum. To set the center frequency, do one of the following:
- Click the arrows to increase or decrease the frequency. Values range from 20 Hz to 20 kHz, adjustable in increments of 1 Hz. Each band has a default center frequency that will be applied if the **Reset** button at the bottom of the band is clicked.
 - Manually enter a value in the **Frequency** field.
- d. Set a bandwidth to determine how wide of a frequency range is effected by the equalizer band. To set the bandwidth, do one of the following:
- Click the arrows to increase or decrease the bandwidth. Values range from 0.1 octaves to 4.0 octaves, adjustable in increments of 0.1 octave.
 - Manually enter a value in the **Bandwidth** field.
- e. The individual Bypass controls allow you to bypass a single band of equalization at a time for more granular A/B testing of a single filter. Set a band's **Bypass** toggle to the right position to bypass that band. Set the toggle to the left position to disable the bypass. By default, **Bypass** is disabled.
- f. Each equalizer band has a **Reset** button that will reapply the default settings for that band.

Click **Done** to return to the **Settings** tab of the web user interface.

Inputs

The **Inputs** section is used to configure the **Name**, **Compensation**, and **Mute** attributes of the available analog, digital, and media streaming inputs on the DM-NAX-AUD-IO.

The screenshot shows a configuration window titled 'Inputs' with a sub-section 'Analog Inputs (Autosaved)'. Inside, there's a table-like structure for the 'LineIn' input. The 'Gain (db)' row features a vertical slider from -10 to 10 and a numeric input field set to 0. The 'Signal Present' row shows a green checkmark. The 'Clipping Detected' row shows a green checkmark and the word 'Nominal'. The 'Mute' row has a toggle switch currently turned off.

Configure Inputs

1. If needed, enter a friendly name for each input in its **Name** field.
2. To set a level compensation adjustment for a given input, do one of the following:
 - Move the **Compensation** slider up to increase or down to decrease the level compensation. Compensation increases or decreases the level of the incoming audio signal on any of the physical inputs on the device's rear panel.
 - Click the **db** arrows to increase or decrease the compensation. Values range from -10 dB to 10 dB, adjustable in increments of 1 dB.
 - Manually enter a value in the **Compensation** field.
3. To mute the signal from the corresponding input, set the **Mute** toggle to the right. To disable the mute, set the **Mute** toggle to the left. By default, **Mute** is disabled.

Monitor the device's input signals using the text indicators in the **Signal Present** and **Clipping Detected** columns:

- **Signal Presence** indicates whether or not a signal is detected in that zone.
- **Clipping Detected** indicates if the signal is **Clipping** or **Nominal** (non-clipping).

NAX Streams

The two local line level input channels of the DM-NAX-AUD-IO can be made available as a DM NAX audio-over-IP stream.

Click **NAX Streams** to expand the tab and display the following information.

▼ NAX Streams

This Device is the Leader PTP Clock Source

No

PTP Clock Leader MAC Address

00:1d:c1:12:16:68

PTP Priority

254


⬇️

— Transmitters (Autosaved)

Audio Source	Stream	Nax Stream Address	Nax Stream Name	Status	Actions
LineIn	Stream01	239.69.19.1	Stream01-AUD-I/O	Stream Started	▶️ ◻️ ⚙️

— Receivers (Autosaved)


Zone Name	Stream	Current Stream Address	Requested Stream Address	Status	Actions
LineOut	Stream01	239.69.190.168	239.69.190.168 🔍	Stream Started	▶️ ◻️ ⚙️



5. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled for a given stream, the stream will begin transmitting automatically and will be available as a multicast stream on your network at the specified multicast address.
 - If **Auto Initiation** is disabled for the input, the stream will not begin transmitting until it is manually initiated.
6. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number for DM NAX streams is 5004.
7. Click **OK** to save or click **Cancel** to cancel the changes.

Configure Receivers

1. Enter the multicast address of a transmitting stream in the **Requested Stream Address** field to subscribe the receiver to the stream.
2. Click the configure button (⚙️) in the **Actions** column. The **Configure** dialog appears:




3. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled, the stream will begin automatically when the receiver subscribes to the transmitter.
 - If **Auto Initiation** is disabled, the stream will not begin until it is manually initiated.

4. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number is 5004.
5. Click **OK** to save or click **Cancel** to cancel the changes.

Routing

The **Routing** section is used to route a local input or AES67 stream to a Zone on the DM-NAX-AUD-IO.

NOTE: To receive an AES67 stream from Dante devices, see [OLH 1001151](#).



To route an input to a zone, click the box in the routing matrix where the zone's row overlaps the corresponding input's column. Once a route is made, appears. To break a given route click or . To route a single input to all zones, click on the icon under the input's name.

Security

Click the **Security** tab to configure security for users and groups and to allow different levels of access to the DM-NAX-AUD-IO functions. By default, security is disabled.

✓ Status

⚙ Settings

🔒 Security

⚙ 802.1x Configuration

▼ Security

SSL Mode

Encrypt

▼

SSL Authentication

Username *

chdevice

Password *

Confirm Password *

Current User

Users

Groups

Name

admin

Access Level

Administrator

Active Directory User

No

Groups

Administrators

Change Current User Password

Select **Encrypt and Validate**, **Encrypt**, or **OFF** in the **SSL Mode** drop-down menu, to specify whether to use encryption. By default, SSL Mode is set to **OFF**.

Current User

Click the **Current User** tab to view read-only information or to change the password for the current user.

Current User

Users

Groups

Name

admin

Access Level

Administrator

Active Directory User

No

Groups

Administrators

Change Current User Password

1. Click the **Change Current User Password** button to provide a new password for the current user.
2. In the **Change Password** dialog, enter the current password in the **Current Password** field, the new password in the **Password** field, and then re-enter the same new password in the **Confirm Password** field.

Change Password

Current Password

.....

Password

.....

Confirm Password

.....|


✓ OK

✕ Cancel

3. Click **OK** to save or click **Cancel** to cancel the changes.

Users

Click the **Users** tab to view and edit user settings. The **Users** tab can be used to add or remove local and Active Directory users and preview information about users.



Use the **Search Users** field to enter search term(s) and display users that match the search criteria.

If users listed in the **Users** table span across multiple pages, navigate through the list of users by clicking a page number or by using the left or right arrows at the bottom of the **Users** pane to move forward or backward through the pages.

Each page can be set to display 5, 10, or 20 users by using the drop-down menu to the right of the navigation arrows.

Information about existing users is displayed in table format and the following details are provided for each user.


- **Username:** Displays the name of the user.
- **AD User:** Displays whether the user requires authentication using Active Directory.

Click the corresponding button in the Actions column to view detailed user information or to delete the user.

To create a new user, click the **Create User** button.

Create a New Local User

1. Click the **Create User** button in the User tab.
2. In the **Create User** dialog, enter the following:



The screenshot shows a 'Create User' dialog box. The 'Name' field contains 'test'. The 'Active Directory User' toggle is disabled. The 'Password' and 'Confirm Password' fields are masked with dots. The 'Groups' dropdown is set to 'Administrators'. The 'OK' and 'Cancel' buttons are at the bottom right.

- a. Enter a user name in the **Name** field. A valid user name can consist of alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
- c. Assign the access level by selecting one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is disabled.

3. Click **OK** to save or click **Cancel** to cancel the changes.


Add an Active Directory User

Users cannot be created or removed from the Active Directory server, but access can be granted to an existing user in the Active Directory server.

To grant access to an Active Directory user, you can either add the user to a local group on the DM-NAX-AUD-IO, or add the Active Directory group(s) that they are a member of to the DM-NAX-AUD-IO.

To add an Active Directory user.

1. Click the **Create User** button.
2. In the **Create User** dialog, enter the following.




The screenshot shows a 'Create User' dialog box with a blue header. It contains three main fields: 'Name' with the text 'Connects\test', 'Active Directory User' with a blue toggle switch turned on, and 'Groups' with a dropdown menu showing 'Connects'. At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'x' icon.

- a. Enter a user name in the **Name** field in the format "Domain\UserName", for example "crestronlabs.com\JohnSmith". Valid user names can contain alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Select one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is set to enabled.


3. Click **OK** to save or click **Cancel** to cancel the changes.

Delete User


Click the trashcan button () in the **Actions** column to delete the user. Click **Yes** when prompted to delete the user or **No** to cancel the deletion.

After a user is removed from a group, they lose any access rights associated with that group. Note that the user account is not deleted by the delete user operation.

View User Details

Click the information button () in the **Actions** column to view information for the selected user. The **User Details** dialog displays the following information for the selected user.


- **Name:** Displays the name of the selected user.
- **Active Directory User:** Displays whether the user is an Active Directory user.
- **Group:** Displays group(s) the selected user is part of.




The **User Details** dialog box has a blue title bar with the text "User Details" and a close button (X). The main area is white and contains three rows of information: "Name" with the value "admin1", "Active Directory User" with the value "No", and "Groups" with the value "Administrators". At the bottom right, there is a blue button with a checkmark and the text "OK".

Click **OK** to close the **User Details** dialog and to return to the **Users** tab.

Update User Details



The **Update User** dialog box has a blue title bar with the text "Update User" and a close button (X). The main area is white and contains several fields: "Name" with the value "admin1", "Active Directory User" with a toggle switch that is currently off, "Password" and "Confirm Password" fields both containing seven dots, and a "Groups" drop-down menu with "Administrators" selected. At the bottom right, there are two blue buttons: one with a checkmark and "OK", and another with an X and "Cancel".

1. Click the edit button () in the **Actions** column to update information for the selected user.
2. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
3. Select one or more groups to assign the user to from the **Groups** drop-down list.
4. Click **OK** to save or click **Cancel** to cancel the changes.

The **Update User** dialog also displays the following read-only information for the selected user.

- **Name:** Displays the name of the user.
- **Active Directory User:** Displays whether the user is an Active Directory user.











Groups

Click the **Groups** tab to view and edit group settings. The **Groups** tab can be used to add local and Active Directory groups, remove local and Active Directory groups, and preview information about a group.

Use the **Search Groups** field to enter search term(s) and display groups that match the search criteria.

Current UserUsersGroups

Search...

Group Name	AD Group	Access Level	Actions
Administrators	No	Administrator	 
Connects	No	Connect	 
Operators	No	Operator	 
Programmers	No	Programmer	 
Users	No	User	 

<<<1>>>

10



Create Group

If groups listed in the **Groups** table span across multiple pages, navigate through the groups by clicking a page number or by using the left or right arrows at the bottom of the Groups pane to move forward or backward through the pages.

Additionally, each page can be set to display 5, 10, or 20 groups by using the drop-down menu to the right of the navigation arrows.


Existing groups are displayed in a table and the following information is provided for each group:

- **Group Name:** Displays the name of the group.
- **AD Group:** Displays whether the group requires authentication using Active Directory.
- **Access Level:** Displays the predefined access level assigned to the group (Administrator, Programmer, Operator, User, or Connect).

Click the corresponding button in the **Actions** column to view detailed group information () or to delete () selected group.

Click on the **Create Group** button in the **Groups** tab to create new group.

Create Local Group



The screenshot shows a 'Create Group' dialog box with a blue header. It contains three main fields: 'Name' with the text 'test12', 'Access Level' with a dropdown menu showing 'Programmer', and 'Active Directory Group' with a toggle switch that is currently turned off. At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'X' icon.


1. Click the **Create Group** button.
2. In the **Create Group** dialog, enter the following:
 - a. Enter the group name in the **Name** field.
 - b. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is disabled.

3. Click **OK** to save. Click **Cancel** to cancel the changes.

Add Active Directory Group

A group cannot be created or removed from the Active Directory server, but access can be granted to an existing group in Active Directory.



The screenshot shows a 'Create Group' dialog box with a blue header. It contains three main fields: 'Name' with the text 'test', 'Access Level' with a dropdown menu showing 'Administrator', and 'Active Directory Group' with a toggle switch that is currently turned on. At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'X' icon.

Once the group is added, all members of that group will have access to the DM-NAX-AUD-IO.


1. Click the **Create Group** button.
2. In the **Create Group** dialog enter the following:
 - a. Enter the group name in the **Name** field, for example "Engineering Group". Note that group names are case sensitive; a space is a valid character that can be used in group names.

3. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is enabled.


4. Click **OK** to save. Click **Cancel** to cancel the changes.


Delete a Group

Click the trashcan button () in the **Actions** column to delete a group. Click **Yes** when prompted to delete the group or **No** to cancel the deletion.

When a group is deleted, users in the group are not removed from the device or Active Directory server. However, because a user's access level is inherited from a group(s), users within the deleted group will lose access rights associated with the group.

View Group Details

Click the information button () in the **Actions** column to view information for the selected group. The **Group Details** dialog lists the following information for the selected group.



The **Group Details** dialog box displays the following information:

Name	Administrators
Access Level	Administrator
Active Directory Group	No

At the bottom right, there is a blue button with a checkmark and the text **OK**.

- **Name:** Displays the name of the group.
- **Access Level:** Displays the access level of the group and its users.
- **Active Directory Group:** Displays whether the group is an Active Directory group.

Click **OK** to close the **Group Details** dialog and to return to the Groups tab.

802.1x Configuration

The DM-NAX-AUD-IO has built-in support for the 802.1X standard (an IEEE network standard designed to enhance the security of wireless and Ethernet LANs. The standard relies on the exchange of messages between the device and the network's host, or authentication server), allowing communication with the authentication server and access to protected corporate networks.

StatusSettingsSecurity802.1x Configuration

802.1x Configuration

IEEE 802.1x Authentication

Authentication MethodEAP MSCHAP V2- password

Domainsecure12

Usernameadmin

Password

Enable Authentication Server Validation

Select Trusted Certificate Authorities()

Q

☒ AAA Certificate Services

☐ AC RAIZ FNMT-RCM

☐ ACCVRAIZ1

☐ Actalis Authentication Root CA

☒ AffirmTrust Commercial

☐ AffirmTrust Networking

☐ AffirmTrust Premium ECC

☒ AffirmTrust Premium

☐ Amazon Root CA 1

☐ Amazon Root CA 2

☒ Amazon Root CA 3

☐ Amazon Root CA 4

☐ Atos TrustedRoot 2011

☐ Autoridad de Certificacion Firmaprofesional CIF A62634068

☐ Baltimore CyberTrust Root

To Configure DM-NAX-AUD-IO for 802.1X Authentication

1. Set the **IEEE 802.1X Authentication** toggle to enabled. This will enable all options on the 802.1X dialog.
2. Select the **Authentication method: EAP-TLS Certificate** or **EAP-MSCHAP V2 Password** according to the network administrator's requirement.
3. Do either one of the following:
 - Select **EAP-TLS Certificate**, click **Action/Manage Certificates** to upload the required machine certificate. The machine certificate is an encrypted file that will be supplied by the network administrator, along with the certificate password.
 - Select **EAP-MSCHAP V2 Password**, enter the username and password supplied by the network administrator into the **Username** and **Password** fields. This method does not require the use of a machine certificate, only the user name and password credentials.
4. If you enabled the **Enable Authentication Server Validation** option, this will enable the **Select Trusted Certificate Authority(ies)** list box which contains signed Trusted Certificate Authorities (CAs) preloaded into the DM-NAX-AUD-IO.

Select the check box next to each CA whose certificate can be used for server validation, as specified by the network administrator.

If the network does not use any of the listed certificates, the network administrator must provide a certificate, which must be uploaded manually via the **Manage Certificates** functionality.
5. If required, type the domain name of the network in the **Domain** field.
6. When the 802.1X settings are configured as desired, click **Save Changes** to save the changes to the device and reboot it. Click **Revert** to cancel any changes.

Access the Web Interface With the Crestron Toolbox™ Application

To access the web interface by opening a web browser within the Crestron Toolbox™ application, do the following:

1. Open the Crestron Toolbox application.
2. From the **Tools** menu, select **Device Discovery Tool**. You can also access the Device Discovery Tool by clicking the Device Discovery Tool button () in the Crestron Toolbox toolbar. The DM-NAX-AUD-IO is discovered and listed in the device list on the left side of the screen. The associated host name, IP address, and firmware version are also displayed.

NOTE: If there is security software running on the computer, a security alert might be displayed when the Crestron Toolbox application attempts to connect to the network. Make sure to allow the connection, so that the Device Discovery Tool can be used.

3. In the Device Discovery Tool list, double-click your device.
4. Enter your credentials in the **Authentication Required** dialog that opens, and then click **Log In**.
5. Click the **Web Configuration** button in the Configuration page displayed on the left side of the Device Discovery Tool.

DM-NAX-AUD-USB

This section describes how to configure the DM-NAX-AUD-USB.

Web Interface Configuration

The DM-NAX-2XLRI-1G web interface allows you to view status information and configure network and device settings.

Access the Web Interface

To access the web interface, do either of the following:

- [Access the Web Interface with a Web Browser on page 530](#)
- [Access the Web Interface With the Crestron Toolbox™ Application on page 584](#)

The web interface is accessed from a web browser. The following table lists operating systems and their corresponding supported web browsers.

Operating System and Supported Web Browsers


OPERATING SYSTEM	SUPPORTED WEB BROWSERS
Windows® operating system	Chrome™ web browser, version 31 and later
	Firefox® web browser, version 31 and later
	Internet Explorer web browser, version 11 and later
	Microsoft Edge web browser
macOS® operating system	Safari® web browser, version 6 and later
	Chrome web browser, version 31 and later
	Firefox web browser, version 31 and later

Access the Web Interface with a Web Browser

1. Enter the IP address of the DM-NAX-AUD-USB into a web browser.


NOTE: To obtain the IP address, use the **Device Discovery Tool** option in Crestron Toolbox™ application or an IP scanner application.

2. If you are creating a user account for the first time, do the following; otherwise, skip to step 3.
 - a. Enter a username in the **Username** field.
 - b. Enter a password in the **Password** field.
 - c. Re-enter the same password in the **Confirm Password** field.



The screenshot shows the Crestron logo at the top left. Below it, a yellow warning triangle icon is followed by the text "DEVICE FIRST BOOT". In the center, there is a white box titled "Device Administration". Inside this box, there are three input fields: "Username", "Password", and "Confirm Password". Below these fields is a green button with a white plus icon and the text "Create User". At the bottom of the white box, there is small text: "© 2021 Crestron Electronics, Inc.", "Privacy Statement", and "Crestron Software End-User License Agreement".

- d. Click **Create User**. The Device Administration page appears.




The screenshot shows the same Crestron logo at the top left. Below it, the "DEVICE FIRST BOOT" message is no longer present. The white box titled "Device Administration" still contains the "Username" and "Password" input fields. Below these fields is a blue button with a white magnifying glass icon and the text "Sign In". At the bottom of the white box, the same small text is present: "© 2021 Crestron Electronics, Inc.", "Privacy Statement", and "Crestron Software End-User License Agreement".

3. Enter the username in the **Username** field.
4. Enter the password in the **Password** field.
5. Click **Sign In**.

Action

The **Action** drop-down menu is displayed at the top right side of the interface and provides quick access to common device functions:

- Save Changes
- Revert
- Reboot
- Restore
- Update Firmware
- Download Logs
- Manage Certificates



Save Changes

Click **Save Changes** to save any changes made to the configuration settings.


Revert

Click **Revert** to revert the device back to the last saved configuration settings.

Reboot the DM-NAX-AUD-USB

Certain changes to the settings may require the DM-NAX-AUD-USB to be rebooted to take effect. To reboot the device, do the following:

1. Click **Reboot** in the **Actions** drop-down menu. The **Confirmation** message box appears.




2. Click **Yes, Reboot Now** to reboot the device. The **Reboot** message box appears. Wait for the device reboot to complete before attempting to reconnect to the device.

Restore to Factory Default Settings

1. Click **Restore** in the **Actions** drop-down menu to restore the settings of the DM-NAX-AUD-USB to factory defaults.

NOTE: When settings are restored, all settings, including the network settings, will revert to the factory default. If a static IP address is set, restoring the device to factory default settings will revert the IP address to the default DHCP mode.




2. Click **Yes** in the **Confirmation** dialog to restore the DM-NAX-AUD-USB to factory settings. Click **No** to cancel the restore operation.

A dialog is displayed again, indicating that the restore process was successful and that the device rebooted.

You can also restore to factory settings by pressing and holding the **SETUP** button on the rear panel of the device with power disconnected then connect the power supply and continue to hold **SETUP** button for 30 seconds.

Update Firmware

1. Click **Update Firmware** in the **Actions** drop-down menu.
2. In the **Firmware Upgrade** dialog, click **+ Browse**.



3. Locate and select the desired firmware file, and then click **Open**. The selected firmware file name is displayed in the **Firmware Upgrade** dialog.
4. Click **Load** and wait for the progress bar to complete and for the **OK** button in the message to become clickable.
5. Click **OK**. The device with new firmware can now be accessed.


Download Logs

1. Click **Download Logs** in the **Actions** drop-down menu to download the device message logs for diagnostic purposes.

The log file is downloaded to the Downloads folder of the PC.

Manage Certificates

Use the **Manage Certificates** dialog to add, remove, and manage certificates used in 802.1x and other protected networks.



1. Click **Manage Certificates** in the **Actions** drop-down menu. The following certificate tabs are displayed:
 - **Root:** The Root certificate is used by the DM-NAX-AUD-USB to validate the network's authentication server. The DM-NAX-AUD-USB has a variety of Root certificates, self-signed by trusted CAs (Certificate Authorities) preloaded into the device. Root certificates must be self-signed.
 - **Intermediate:** The Intermediate store holds non self-signed certificates that are used to validate the authentication server. These certificates will be provided by the network administrator if the network does not use self-signed Root certificates.
 - **Machine:** The machine certificate is an encrypted PFX file that is used by the authentication server to validate the identity of the DM-NAX-AUD-USB. The machine certificate will be provided by the network administrator, along with the certificate password. For 802.1x, only one machine certificate can reside on the device.
 - **Web Server:** The Web Server certificate is a digital file that contains information about the identity of the web server.

To Add Certificates

1. Click the corresponding certificate tab.
2. Click the **Add Root Certificate** button.
3. Click the **+ Browse** button.
4. Locate and select the file, and then click the **Open** button.

NOTE: If the certificate is a Machine Certificate, enter the password provided by the network administrator.

5. Click **OK**. This will add the certificate to the list box, displaying the file name and expiration date.
The certificate is now available for selection and can be loaded to the device.


To Delete Certificates

1. Click the corresponding certificate tab.
2. Click the trashcan button (🗑️) in the **Actions** column to delete the certificate.
3. Click **Yes** when prompted to delete the certificate or **No** to cancel the deletion.

Status

The **Status** tab is the first page displayed when opening the interface of the DM-NAX-AUD-USB. It displays general information about the DM-NAX-AUD-USB (such as Model Name, Firmware Version, and Serial Number), current network settings (such as Host Name and IP Address, etc.), and input and output ports' current status.


The Status tab can be accessed at any time by clicking the **Status** tab of the DM-NAX-AUD-USB interface.




Information displayed on the **Status** tab is organized into different sections.

Device

The **Device** section displays the **Model**, **Firmware Version**, and **Serial Number** of the DM-NAX-AUD-USB.



Click **+ More Details** to review additional information about the DM-NAX-AUD-USB.



Network

The **Network** section displays network-related information about the DM-NAX-AUD-USB, including the Hostname, Domain Name, and DNS Servers.

▼ Network

Hostname DM-NAX-AUD-USB-C442683FD459

Domain Name CRESTRON.CRESTRON.com

DNS Servers 10.64.5.10(DHCP)

— Adapter 1

DHCP	On
IP Address	10.64.68.176
Subnet Mask	255.255.255.0
Default Gateway	10.64.68.1
Link Active	true
MAC Address	c4.42.68.3f.d4.59

NOTE: By default, the host name of the DM-NAX-AUD-USB consists of the model name followed by the MAC address of the device. For example, DM-NAX-AUD-USB-00107FB58088.

Click **+ Adapter 1** to display an expanded section that shows additional information. If **+ Adapter 1** is selected, click **- Less details** to collapse the section.

Control System

The **Control System** section displays connection information, consisting of the following:

Control System						
Encrypt Connection ON						
— IP Table						
IP ID	Room Id	IP Address/Hostname	Type	Server Port	Connection	Status
C		DIN-AP4-R-C442681A3F36	Peer	41796	Gway	ONLINE

- **Encrypt Connection:** ON or OFF
- **IP ID:** Reports the currently used IP ID of the DM-NAX-AUD-USB
- **IP Address/Hostname:** The IP address of the control system
- **Room ID:** Displays the room ID
- **Status:** OFFLINE or ONLINE

Settings

The **Settings** tab enables configuration of the DM-NAX-AUD-USB settings. The Settings page can be accessed at any time by clicking the **Settings** tab of the DM-NAX-AUD-USB interface.


Many options in the Settings tab are exclusive to a specific device mode: Residential or Commercial. The DM-NAX-AUD-USB is in Commercial mode by default.

This section provides the following information:

- [Commercial Mode on page 538](#)
- [Residential Mode on page 556](#)

Commercial Mode


The **Settings** tab enables you to configure the DM-NAX-AUD-USB settings. The Settings page can be accessed at any time by clicking the **Settings** tab of the DM-NAX-AUD-USB interface.



Settings available on the **Settings** page are organized into different sections.

System Setup

The **System Setup** section contains settings for **Date/Time**, **Auto Update**, **Network**, and **Control System**.



Date/Time

Use the **Date/Time** tab to configure the date and time settings of the DM-NAX-AUD-USB.

Date/Time

Synchronization

Time Synchronization

Synchronize Now

NTP Time Servers

	Address	Port	Authentication Method	Authentication Key	Key ID
	pool.ntp.org	123	None	*****	0

+ Add

- Remove

Configuration

Time Zone

(UTC-05:00) Eastern Time (US & Can)

Date

02/21/2024

Time

12:40

Time Synchronization

- 1. Set the **Time Synchronization** toggle to the right position to enable or left position to disable time synchronization. By default, time synchronization is enabled.
- 2. In the **NTP Time Servers** table, enter the URL of a NTP (Network Time Protocol) or SNTP (Simple Network Time Protocol) server. Up to three time servers can be added on a device.
- 3. Click **Synchronize Now** to perform time synchronization between the device's internal clock and the time server.

Time Configuration

- 1. Click on the **Time Zone** drop-down menu to select the applicable time zone.
- 2. In the **Date** field, enter the current date.
- 3. In the **Time (24hr Format)** field, enter the current time in 24-hour format.

Click the **Save Changes** button to save the settings.

Click **Revert** from the **Actions** drop-down menu to revert to the previous settings without saving.

Auto Update

The DM-NAX-AUD-USB can automatically check for and install firmware updates at scheduled intervals via the Auto Update feature.

The screenshot shows the 'Auto Update' configuration window. It includes a 'Schedule' sidebar and a main configuration area. The 'Auto Update' toggle is currently off. The 'Custom URL' toggle is also off. The 'Custom URL Path' is set to 'https://crestrondevicefiles.blob.core.win...'. The 'Day of Week' is set to 'Daily'. The 'Time of Day' is set to '02:07'. The 'Poll Interval' is set to '0' minutes. An 'Update Now' button is at the bottom right.

1. Set the **Auto Update** toggle to the right position to enable Auto Update.
2. Define the URL to download the updates by doing either of the following:
 - a. Use the default URL to download the updates from the Crestron server.
 - b. Use a custom URL. Set the **Custom URL** toggle to the right position to enable a custom URL. In the **Custom URL Path** text box, enter the path to a custom manifest file in the FTP or SFTP URL format. Use the Crestron Auto Update Tool to generate a custom manifest file, then store the file on an FTP (File Transfer Protocol) or SFTP (Secure File Transfer Protocol) server.
3. Set a schedule for the automatic firmware update by doing either of the following:
 - a. Select the desired **Day of Week** and **Time of Day** (24-hour format) values.
 - b. Set the **Poll Interval** by entering a value from **60** to **65535** minutes. A value of **0** disables the Poll Interval.
4. Click **Save Changes**.

Clicking **Update Now** causes the device to check for a firmware update immediately. If a schedule was set in step 4 above, that schedule still remains in effect.

Network

The **Network** tab contains network-related settings for the DM-NAX-AUD-USB, including the Hostname, Domain, Primary Static DNS, and Secondary Static DNS.

System Setup

Date/Time Auto Update **Network** Control System Cloud Settings Device Modes

Network

Adapter 1

Hostname *	DM-NAX-AUD-USB-C442683FD459
Domain	CRESTRON.CRESTRON.com
Primary Static DNS	10.64.5.10(DHCP)
Secondary Static DNS	192.168.200.133(DHCP)
DHCP Enabled	<input checked="" type="checkbox"/>
IP Address	10.64.68.176
Subnet Mask	255.255.255.0
Default Gateway	10.64.68.1

NOTE: By default, the hostname of the DM-NAX-AUD-USB consists of the model name followed by the MAC address of the device. For example, DM-NAX-AUD-USB-00107FB58088.

Adapter 1

The Adapter 1 subheading contains settings for DHCP, IP Address, Subnet Mask, and Default Gateway of Ethernet adapter 1 on the rear panel of the device.

NOTE: DM NAX devices' internal processes use IP addresses in the 10.10.10.xxx range. This IP range should be avoided when addressing DM NAX devices to prevent conflicts.

Set the **DHCP** toggle to enabled (right) or disabled (left) to specify whether the IP address of the DM-NAX-AUD-USB is to be assigned by a DHCP (Dynamic Host Configuration Protocol) server.

- **Enabled:** When DHCP is enabled (default setting), the IP address of the DM-NAX-AUD-USB is automatically assigned by a DHCP server on the local area network (LAN).
- **Disabled:** When DHCP is disabled, manually enter information in the following fields:
 - **Primary Static DNS:** Enter a primary DNS IP address.
 - **Secondary Static DNS:** Enter a secondary DNS IP address.
 - **IP Address:** Enter a unique IP address for the DM-NAX-AUD-USB.
 - **Subnet Mask:** Enter the subnet mask that is set on the network.
 - **Default Gateway:** Enter the IP address that is to be used as the network's gateway.

To save any new network entries, click **Save Changes**.

Control System

Control System

Control System Username

chdevice

Control System Password

Encrypt Connection

IP Table

<input type="checkbox"/>	IP ID	IP Address/Hostname	Room Id
<input type="checkbox"/>	C	DIN-AP4-R-C442681A3F36	Room Id

+ Add

× Remove

1. Click the **Encrypt Connection** button to navigate to the **Security** tab to configure encryption settings.
2. Enter the username in the **Control System Username** field.
3. Enter the password in the **Control System Password** field.
4. Enter the Room ID in the **Room ID** field.
5. Enter the IP ID of the DM-NAX-AUD-USB in the **IP ID** field.
6. Enter the IP address or hostname of the control system in the **IP Address/Hostname** field.
7. Click the **Save Changes** button to save the new entries. The Control System Save message box appears, indicating that the control system settings were saved successfully. Click the **Revert** button to revert to the previous settings without saving.

Cloud Settings

Date/Time

Auto Update

Network

Control System

Cloud Settings

Device Modes

Cloud Settings

Cloud Configuration Service Connection

Set the **Cloud Settings** toggle to enabled (right) or disabled (left) to specify whether the DM-NAX-AUD-USB can communicate with the XiO Cloud® platform.

Device Modes

Use the **Device Modes** tab to configure the **Application Mode** of the DM-NAX-AUD-USB.

Date/Time

Auto Update

Network

Control System

Cloud Settings

Device Modes


Device Modes (Autosaved)

Application Mode

Commercial (Advanced)

The Application Mode determines which options and controls are available.

- Select **Residential (Standard)** or **Commercial (Advanced)**. A **Reboot** confirmation message box appears.




- Click **Yes, Reboot Now** to reboot the device into the selected mode. The **Reboot** message box appears.
- Wait for the device reboot to complete before attempting to reconnect to the device.

By default, the DM-NAX-AUD-USB is set to **Commercial (Advanced)** mode.

Commissioning

The **Commissioning** section provides a quick way to automatically assign multicast addresses to the device's internal audio-over-IP stream transmitters.


A screenshot of the 'Commissioning' section in a software interface. It has a light blue header with a dropdown arrow and the text 'Commissioning'. Below the header, there are two labels: 'Starting Multicast Address' and 'Last Used Multicast Address'. The 'Starting Multicast Address' is next to a text input field containing '239.8.0.0'. The 'Last Used Multicast Address' is next to the text '239.8.0.8'. At the bottom right, there is a blue button labeled 'Assign Addresses'.

Click **Assign Addresses** to give each DM NAX transmitter in the DM-NAX-AUD-USB a unique multicast address beginning with the specified **Starting Multicast Address**. The valid range for **Starting Multicast Address** is 239.8.0.0 to 239.255.255.254.

NOTE: This will begin transmitting multicast traffic on your network, refer to the [DM NAX Audio-over-IP System Design Guide](#) document for details.

Output Channels

The **Zones** section contains the **Volume** and **Mute** settings for all zone outputs of the device, as well as an **Edit** option for more advanced settings within each zone.



The screenshot shows the 'Output Channels' section of a software interface. It features a table with 8 columns representing different audio output channels. Each column has a volume slider, a signal presence indicator, a signal level indicator, a mute toggle, and an edit button. The volume sliders are currently set to 79% for most channels and 80% for StreamOut1Ch1 and StreamOut1Ch2. All signal levels are 'Nominal' and all mute toggles are turned off.

Name	LineOutLeft	LineOutRight	USBOutLeft	USBOutRight	StreamOut1Ch1	StreamOut1Ch2	StreamOut2Ch1	StreamOut2Ch2
Volume (%)								
Signal Presence								
Signal Level	Nominal	Nominal	Nominal	Nominal	Nominal	Nominal	Nominal	Nominal
Mute	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Action	Edit	Edit	Edit	Edit	Edit	Edit	Edit	Edit

Signal Presence indicates whether or not an audio signal is detected in that zone.

Signal Level indicates if the signal is **Clipping** or **Nominal** (non-clipping).

- **Nominal:** The signal level is within normal operating bounds and below the clipping threshold.
- **Clipping:** The signal level is clipping or above the -3 dB warning threshold and in danger of clipping.

Give each zone a friendly name using the **Name** column of the **Zones** table. If the device is paired with a control system, these names may be overwritten by the control system's program.

To configure the zone volume, do one of the following:

- Move the **Volume** slider up to increase or down to decrease the zone volume.
- Click the % arrows to increase or decrease the zone volume. Values range from 0 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Volume** field.

To mute all audio output from a zone, click its respective **Mute** button. To unmute the zone, click the **Muted** button.


Click **Edit** to view additional **Zone** and **Output** options.

Zone Settings

To configure the settings for an output channel, click the **Edit** button. The **Edit Zone** window appears.

- **Bass:** To adjust the bass, do one of the following:
 - Move the **Bass** slider to the right to increase or to the left to decrease the bass db.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of .1 db.
 - Manually enter a value in the **Bass** field.
- **Treble:** To adjust the treble, do one of the following:
 - Move the **Treble** slider to the right to increase or to the left to decrease the treble db.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of .1 db.
 - Manually enter a value in the **Treble** field.

Delay



To set the delay, do one of the following:

- Move the **Delay Time(ms)** slider to the right to increase or to the left to decrease the delay time.
- Click the **ms** arrows to increase or decrease the delay. Values range from 0 ms to 85 ms, adjustable in increments of 1 ms.
- Manually enter a value in the **Delay Time(ms)** field.

NOTE: The Delay feature is only available on the line level output channels.

Output

Click **Output** to access the settings for **Minimum/Maximum Volume**, **Signal**, and the output **Equalizer**.

Output

Minimum / Maximum (Autosaved)

Minimum

0 %

Maximum

100 %

Default

79 %

Signal (Autosaved)

Signal

Not Present

Clipping

None

Equalizer Settings (Autosaved)

Speaker EQ Enabled

Minimum/Maximum Volume

Minimum / Maximum (Autosaved)

Minimum

0 %

Maximum

100 %

Default

30 %

1. To set the minimum volume of the zone, do one of the following:

- Move the **Minimum** slider to the right to increase or to the left to decrease the minimum volume.
- Click the **%** arrows to increase or decrease the minimum volume. Values range from 0 to 50%, adjustable in increments of 1%.
- Manually enter a value in the **Minimum** field.

2. To set the maximum volume of the zone, do one of the following:

- Move the **Maximum** slider to the right to increase or to the left to decrease the maximum volume.
- Click the **%** arrows to increase or decrease the maximum volume. Values range from 70 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Maximum** field.


NOTE: When a **Minimum** and **Maximum** volume are set, the 1-100% range represented by the **Zone** and **Default** volume controls are scaled to the range set. For example, if a **Minimum** of 10% and a **Maximum** of 80% are set for a zone, the 1-100% range of the **Zone** volume control is scaled to the 10%-80% range set as the **Minimum** and **Maximum**.

3. To set the default volume of the zone, do one of the following:

- Move the **Default** slider to the right to increase or to the left to decrease the default volume.
- Click the **%** arrows to increase or decrease the default volume. Values range from 0 to 50%, adjustable in increments of 1%.
- Manually enter a value in the **Default** field.

NOTE: The **Default** volume is applied as the **Zone** volume any time the zone receives a source route and no source was previously routed to that zone.

Signal













The **Signal** section is a read-only field that displays the **Signal** and **Clipping** status of the zone output.

- If an output signal is present but not clipping, **Signal** will display **Present** in green and **Clipping** will display **None** in green.
- If an output signal is present and clipping, **Signal** will display **Present** in green and **Clipping** will display **Present** in red.
- If no output signal is detected, **Signal** will display **Not Present** in red and **Clipping** will display **None** in green.

Equalizer Settings

Equalizer Settings (Autosaved)

Speaker EQ Enabled ☒

Band	Band01	Band02	Band03	Band04	Band05	Band06	Band07	Band08	Band09	Band10
Gain	 0	 0	 0	 0	 0	 0	 0	 0	 0	 0
Type	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ
Frequency	32	64	125	250	500	1000	2000	4000	8000	16000
Bandwidth	0.33	0.33	0.33	0.33	0.33	0.33	0.33	0.33	0.33	0.33
Bypass	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Actions	Reset	Reset	Reset	Reset	Reset	Reset	Reset	Reset	Reset	Reset

Each output channel of the DM-NAX-AUD-USB has a dedicated ten-band equalizer that can be fully customized to tune the zone output signal to the needs of an install. Each band can have a discrete gain, filter type, center frequency, and bandwidth set, and can also be bypassed. The equalizer itself can also be bypassed using the **Speaker EQ Enabled** toggle.

1. Set the **Speaker EQ Enabled** toggle to the right position to enable the equalizer. Set the toggle to the left position to bypass the equalizer.

NOTE: When **Speaker EQ Enabled** is disabled, all equalizer bands are bypassed. This is a quick way to perform A/B testing of the entire EQ curve.


2. With the **Speaker EQ Enabled** toggle in the right position, do the following to configure a given equalizer band:
 - a. To set a band's gain, do one of the following:
 - Move the **Gain** slider up to increase or down to decrease the gain.
 - Click the arrows to increase or decrease the gain. Values range from -40 dB to 20 dB, adjustable in increments of 0.1 dB.
 - Manually enter a value in the **Gain** field.

- b. Select a filter type from the **Type** drop-down menu. By default, all bands are set to the **EQ** filter type. Some filter types will disable other settings in their respective band while enabled. For example, selecting the **LowPass** filter type for a band will disable that band's **Gain** and **Bandwidth** settings, since the **LowPass** filter applies a fixed roll-off slope at a set frequency. The available filter types are:
- **EQ:** a fully parametric filter that can boost or cut a range of frequencies.
 - **Notch:** a parametric filter designed to more precisely cut a frequency or range of frequencies. A notch filter can achieve a narrower bandwidth than the standard **EQ** parametric filter type.
 - **TrebleShelf:** a filter that boosts or cuts all frequencies above a set frequency by a set gain.
 - **BassShelf:** a filter that boosts or cuts all frequencies below a set frequency by a set gain.
 - **LowPass:** a filter that fully cuts all frequencies above a set frequency using a fixed roll-off slope of -12 dB per octave.
 - **HighPass:** a filter that fully cuts all frequencies below a set frequency using a fixed roll-off slope of -12 dB per octave.
- c. Set a center frequency for the equalizer band to tune a specific portion of the audible frequency spectrum. To set the center frequency, do one of the following:
- Click the arrows to increase or decrease the frequency. Values range from 20 Hz to 20 kHz, adjustable in increments of 1 Hz. Each band has a default center frequency that will be applied if the **Reset** button at the bottom of the band is clicked.
 - Manually enter a value in the **Frequency** field.
- d. Set a bandwidth to determine how wide of a frequency range is effected by the equalizer band. To set the bandwidth, do one of the following:
- Click the arrows to increase or decrease the bandwidth. Values range from 0.1 octaves to 4.0 octaves, adjustable in increments of 0.1 octave.
 - Manually enter a value in the **Bandwidth** field.
- e. The individual Bypass controls allow you to bypass a single band of equalization at a time for more granular A/B testing of a single filter. Set a band's **Bypass** toggle to the right position to bypass that band. Set the toggle to the left position to disable the bypass. By default, **Bypass** is disabled.
- f. Each equalizer band has a **Reset** button that will reapply the default settings for that band.

Click **Done** to return to the **Settings** tab of the web user interface.

Input Channels

The **Input Channels** section is used to configure the **Name**, **Compensation**, and **Mute** attributes of the front panel inputs on the DM-NAX-AUD-USB.



Name	LineInLeft	LineInRight	USBInLeft	USBInRight	StreamIn1Ch1	StreamIn1Ch2	StreamIn2Ch1	StreamIn2Ch2
Compensation (db)								
Signal Present								
Signal Level	Nominal	Nominal	Nominal	Nominal	Nominal	Nominal	Nominal	Nominal
Mute								

Configure Inputs

1. If needed, enter a friendly name for each input in its **Name** field.
2. To set a level compensation adjustment for a given input, do one of the following:
 - Move the **Compensation** slider up to increase or down to decrease the level compensation. Compensation increases or decreases the level of the incoming audio signal on any of the physical inputs on the device's rear panel.
 - Click the **db** arrows to increase or decrease the compensation. Values range from -10 dB to 10 dB, adjustable in increments of 1 dB.
 - Manually enter a value in the **Compensation** field.
3. To mute the signal from the corresponding input, set the **Mute** toggle to the right. To disable the mute, set the **Mute** toggle to the left. By default, **Mute** is disabled.

Monitor the device's input signals using the text indicators in the **Signal Present** and **Clipping Detected** columns:

- **Signal Presence** indicates whether or not a signal is detected in that zone.
- **Clipping Detected** indicates if the signal is **Clipping** or **Nominal** (non-clipping).

DM NAX Streams

The local inputs of the DM-NAX-AUD-USB can be made available as DM NAX audio-over-IP streams. Two network stream transmitters are available on the device. One transmitter will encode the local unbalanced line level input, and the other will encode the USB input audio.

Click **NAX Streams** to expand the tab and display the following information.

NAX Streams

This Device is the Leader PTP Clock Source

No

PTP Clock Leader MAC Address

00:1d:c1:12:16:68

PTP Priority

254

Transmitters (Autosaved)

Audio Source	Stream	Nax Stream Address	Nax Stream Name	Status	Actions
StreamOut1Ch1	Stream01	<div>239.69.18.1</div>	<div>Stream01-AUD-USB</div>	Stream Started	<div><div></div><div></div><div></div></div>
StreamOut2Ch1	Stream02	<div>239.69.18.2</div>	<div>Stream02-AUD-USB</div>	Stream Started	<div><div></div><div></div><div></div></div>


Receivers (Autosaved)

Zone Name	Stream	Current Stream Address	Requested Stream Address	Status	Actions
StreamIn1Ch1	Stream01	239.69.2.1	<div>239.69.2.1</div> <div></div>	Stream Started	<div><div></div><div></div><div></div></div>
StreamIn2Ch1	Stream02	239.69.61.139	<div>239.69.61.139</div> <div></div>	Stream Started	<div><div></div><div></div><div></div></div>

Configure Transmitters

To configure the DM NAX transmit stream, do the following.

1. Enter a valid multicast address in the **NAX Stream Address** field.
2. Enter a name in the **NAX Stream Name** field by which the stream can be identified. This stream name is associated with the DM NAX stream's multicast address by other DM NAX or AES67 devices, like a device hostname that resolves to a given IP address.
3. **Status** indicates whether a stream is transmitting or not. When the stream has started or stopped, the **Status** column will update accordingly.
4. Click the configure button (⚙️) in the **Actions** column. The **Configure** dialog appears:




5. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled for a given stream, the stream will begin transmitting automatically and will be available as a multicast stream on your network at the specified multicast address.
 - If **Auto Initiation** is disabled for the input, the stream will not begin transmitting until it is manually initiated.
6. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number for DM NAX streams is 5004.
7. Click **OK** to save or click **Cancel** to cancel the changes.

Configure Receivers

1. Enter the multicast address of a transmitting stream in the **Requested Stream Address** field to subscribe the receiver to the stream.

2. Click the configure button (⚙️) in the **Actions** column. The **Configure** dialog appears:


A screenshot of a 'Configure' dialog box. The dialog has a blue title bar with the text 'Configure' and a close button (X). The main area is white and contains a toggle switch labeled 'Auto Initiation' which is currently turned off. Below the toggle is a 'Port' field with a text input showing '5004' and a spinner control with up and down arrows. At the bottom of the dialog, there are two buttons: 'OK' with a checkmark icon and 'CANCEL' with an X icon.

3. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled, the stream will begin automatically when the receiver subscribes to the transmitter.
 - If **Auto Initiation** is disabled, the stream will not begin until it is manually initiated.
4. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number is 5004.
5. Click **OK** to save or click **Cancel** to cancel the changes.

Mixing

The **Mixing** matrix is used to route a local input or AES67 stream to an output on the DM-NAX-AUD-USB.

NOTE: To receive an AES67 stream from Dante devices, see [OLH 1001151](#).




To route inputs to outputs on the device:

- Click the cells corresponding to the desired output that are to be paired for routing. Once a route is made, appears. The input that you have selected for a given row will route to the output corresponding to that row in the matrix.
- Use the arrows (or) at the left of the matrix to change pages to view all available inputs.
- To break a given route click or .

Each output can have any number of inputs routed to it. To adjust the mix setting for a route, click the **dB** value of the cell, then do one of the following:


- Move the slider up to increase or down to decrease the mix level.
- Click the arrows to increase or decrease the mix level.
- Manually enter a value in the field.



Residential Mode

This section provides the following information:

- [System Setup on page 557](#)
- [Commissioning on page 561](#)
- [Output Channels on page 562](#)
- [Inputs on page 569](#)
- [NAX Streams on page 570](#)
- [Routing on page 573](#)



System Setup

The **System Setup** section displays information about the Date/Time, Auto Update, Network, Control System, Cloud Settings, and Device Modes.

Date/Time

Use the **Date/Time** section to configure the date and time settings of the DM-NAX-AUD-USB.

System Setup

[Date/Time](#) [Auto Update](#) [Network](#) [Control System](#) [Cloud Settings](#) [Device Modes](#)

— Date/Time

Synchronization

Time Synchronization ☒

[Synchronize Now](#)

NTP Time Servers

<input type="checkbox"/>	Address	Port	Authentication Method	Authentication Key	Key ID
<input type="checkbox"/>	poolntp.org	123	None	*****	0

[+ Add](#) [- Remove](#)

Configuration

Time Zone: (UTC-05:00) Eastern Time (US & Can) ▼

Date: 02/21/2024

Time: 11:49

Time Synchronization

1. Set the **Time Synchronization** toggle to the right position to enable or left position to disable time synchronization. By default, time synchronization is enabled.

2. In the **NTP Time Servers** table, enter the URL of a NTP (Network Time Protocol) or SNTP (Simple Network Time Protocol) server. Up to three time servers can be added on a device.
3. Click **Synchronize Now** to perform time synchronization between the device's internal clock and the time server.

Time Configuration

1. Click on the **Time Zone** drop-down menu to select the applicable time zone.
2. In the **Date** field, enter the current date.
3. In the **Time (24hr Format)** field, enter the current time in 24-hour format.

Click the **Save Changes** button to save the settings.

Click **Revert** from the **Actions** drop-down menu to revert to the previous settings without saving.

Auto Update

The DM-NAX-AUD-USB can automatically check for and install firmware updates at scheduled intervals via the Auto Update feature.

The screenshot shows the 'Auto Update' configuration page within the 'System Setup' menu. The page has a light blue header with 'System Setup' and a sub-header with tabs: 'Date/Time', 'Auto Update' (selected), 'Network', 'Control System', 'Cloud Settings', and 'Device Modes'. The 'Auto Update' section is titled 'Auto Update' and contains several settings: 'Auto Update' toggle (turned on), 'Custom URL' toggle (turned off), 'Custom URL Path' text box (containing 'https://crestrondevicefiles.blob.core.win...'), 'Schedule' section with 'Day of Week' (Daily), 'Time of Day' (02:25), and 'Poll Interval' (0 Minutes). An 'Update Now' button is at the bottom right.

1. Set the **Auto Update** toggle to the right position to enable Auto Update.
2. Define the URL to download the updates by doing either of the following:
 - a. Use the default URL to download the updates from the Crestron server.
 - b. Use a custom URL. Set the **Custom URL** toggle to the right position to enable a custom URL. In the **Custom URL Path** text box, enter the path to a custom manifest file in the FTP or SFTP URL format. Use the Crestron Auto Update Tool to generate a custom manifest file, then store the file on an FTP (File Transfer Protocol) or SFTP (Secure File Transfer Protocol) server.
3. Set a schedule for the automatic firmware update by doing either of the following:

- a. Select the desired **Day of Week** and **Time of Day** (24-hour format) values.
 - b. Set the **Poll Interval** by entering a value from **60** to **65535** minutes. A value of **0** disables the Poll Interval.
4. Click **Save Changes**.

Clicking **Update Now** causes the device to check for a firmware update immediately. If a schedule was set in step 4 above, that schedule still remains in effect.

Network

The **Network** section contains network-related settings for the DM-NAX-AUD-USB, including the Hostname, Domain, Primary Static DNS, and Secondary Static DNS.

The screenshot shows the 'System Setup' menu with the 'Network' tab selected. The 'Network' section is expanded, showing settings for 'Adapter 1'. The settings are as follows:

Setting	Value
Hostname *	DM-NAX-AUD-USB-C442683FD459
Domain	CRESTRON.CRESTRON.com
Primary Static DNS	10.64.5.10(DHCP)
Secondary Static DNS	192.168.200.133(DHCP)
DHCP Enabled	<input checked="" type="checkbox"/>
IP Address	10.64.68.176
Subnet Mask	255.255.255.0
Default Gateway	10.64.68.1

NOTE: By default, the host name of the DM-NAX-AUD-USB consists of the model name followed by the MAC address of the device. For example, DM-NAX-AUD-USB-00107FB58088.

Adapter 1

The Adapter 1 subheading contains settings for DHCP, IP Address, Subnet Mask, and Default Gateway of Ethernet adapter 1 on the rear panel of the device.

NOTE: DM NAX devices' internal processes use IP addresses in the 10.10.10.xxx range. This IP range should be avoided when addressing DM NAX devices to prevent conflicts.

Set the **DHCP** toggle to enabled (right) or disabled (left) to specify whether the IP address of the DM-NAX-AUD-USB is to be assigned by a DHCP (Dynamic Host Configuration Protocol) server.

- **Enabled:** When DHCP is enabled (default setting), the IP address of the DM-NAX-AUD-USB is automatically assigned by a DHCP server on the local area network (LAN).
- **Disabled:** When DHCP is disabled, manually enter information in the following fields:
 - **Primary Static DNS:** Enter a primary DNS IP address.
 - **Secondary Static DNS:** Enter a secondary DNS IP address.
 - **IP Address:** Enter a unique IP address for the DM-NAX-AUD-USB.
 - **Subnet Mask:** Enter the subnet mask that is set on the network.
 - **Default Gateway:** Enter the IP address that is to be used as the network's gateway.

To save any new network entries, click **Save Changes**.

Control System

System Setup

Date/Time Auto Update Network **Control System** Cloud Settings Device Modes

Control System

Encrypt Connection

IP Table

<input type="checkbox"/>	IP ID	IP Address/Hostname	Room Id
No records found			

+ Add x Remove

1. Click the **Encrypt Connection** button to navigate to the **Security** tab to configure encryption settings.
2. Enter the username in the **Control System Username** field.
3. Enter the password in the **Control System Password** field.
4. Enter the Room ID in the **Room ID** field.
5. Enter the IP ID of the DM-NAX-AUD-USB in the **IP ID** field.
6. Enter the IP address or hostname of the control system in the **IP Address/Hostname** field.
7. Click the **Save Changes** button to save the new entries. The Control System Save message box appears, indicating that the control system settings were saved successfully. Click the **Revert** button to revert to the previous settings without saving.

Cloud Settings

System Setup

Date/Time Auto Update Network Control System **Cloud Settings** Device Modes

Cloud Settings

Cloud Configuration Service Connection ☒

Set the **Cloud Settings** toggle to enabled (right) or disabled (left) to specify whether the DM-NAX-AUD-USB can communicate with the XiO Cloud® platform.

Device Modes

Use the **Device Modes** section to configure the **Application Mode**.

- **Application Mode:** The Application Mode determines which options and controls are available.
 - Select **Residential (Standard)** or **Commercial (Advanced)**. A **Reboot** confirmation message box appears.

- Click **Yes, Reboot Now** to reboot the device into the selected mode. The **Reboot** message box appears.
- Wait for the device reboot to complete before attempting to reconnect to the device.

Commissioning


The **Commissioning** section provides a quick way to automatically assign multicast addresses to the device's internal audio-over-IP stream transmitters.

Click **Assign Addresses** to give each DM NAX transmitter in the DM-NAX-AUD-USB a unique multicast address beginning with the specified **Starting Multicast Address**. The valid range for **Starting Multicast Address** is 239.8.0.0 to 239.127.255.254.

NOTE: This will begin transmitting multicast traffic on your network, refer to the [General Network Requirements](#) document for details.

Output Channels

The **Zones** section contains the **Volume** and **Mute** settings for all zone outputs of the device, as well as a Configure option for more advanced settings within each zone.




Give each zone a friendly name using the **Name** column of the **Zones** table. If the device is paired with a control system, these names may be overwritten by the control system's program.

To configure the zone volume, do one of the following:

- Move the **Volume** slider to the right to increase or to the left to decrease the zone volume.
- Click the % arrows to increase or decrease the zone volume. Values range from 0 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Volume** field.

To mute all audio output from a zone, click its respective **Mute** button. To unmute the zone, click the **Muted** button.

Zone Settings

To configure zone settings, click the **Configure** button ( **Configure**). The **Edit Zone** window appears.

Zone

Click **Zone** to access the settings for **Tone**, **Balance**, and **Delay**.

DM-NAX-AUD-IO-C442683FD474 > Zones

LineOut

Zone

Tone (Autosaved)

Tone Profile

Off

Bass

0

db

Treble

0

db

Night Mode

Off

Balance (Autosaved)

Left / Right

0

%

The **Tone** section provides adjustments for the **Tone Profile**, **Bass**, **Treble**, **Loudness**, and **Night Mode** settings of the zone output.

NOTE: The Tone Profile, Bass, Treble, and Loudness settings in the Tone section are all applied separately from the Equalizer Settings for the zone. This means that any adjustments made in the Tone section will stack with those made in the Equalizer Settings section.

- To select a tone profile preset for the zone, select an option from the **Tone Profile** drop-down menu. The available options are **Off**, **Classical**, **Jazz**, **Pop**, **Rock**, and **Spoken Word**. By default, **Off** is selected.
- Bass:** To adjust the bass, do one of the following:
 - Move the **Bass** slider to the right to increase or to the left to decrease the bass.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of 1 db.
 - Manually enter a value in the **Bass** field.
- Treble:** To adjust the treble, do one of the following:
 - Move the **Treble** slider to the right to increase or to the left to decrease the treble.
 - Click the **db** arrows to increase or decrease the db. Values range from -12 db to 12 db, adjustable in increments of 1 db.
 - Manually enter a value in the **Treble** field.
- To enable the loudness setting on the zone output, slide the **Loudness** switch to the right. To disable loudness, slide the **Loudness** switch to the left.

5. The **Night Mode** feature applies subtle processing to restrict the dynamic range of the zone audio, to allow for lower listening levels at night or in rooms where higher listening levels would be disruptive. To select a dynamics processing level, select an option from the **Night Mode** drop-down menu. The available options are **Off**, **Low**, **Medium**, and **High**. By default, **Off** is selected.

Balance

To adjust the left/right balance of the stereo output signal, do one of the following:

- Move the **Balance** slider to the right to shift the stereo balance to the right channel or to the left to shift the balance to the left.
- Click the arrows to adjust the balance left or right. The up arrow shifts the balance to the right while the down arrow shifts the balance to the left.
- Manually enter a value in the **Balance** field. Values range from -50 to 50, adjustable in increments of 1. Positive values shift the balance to the right while negative values shift the balance to the left.

Delay

To set the delay, do one of the following:

- Move the **Delay Time(ms)** slider to the right to increase or to the left to decrease the delay time.
- Click the **ms** arrows to increase or decrease the delay. Values range from 0 ms to 85 ms, adjustable in increments of 1 ms.
- Manually enter a value in the **Delay Time(ms)** field.

NOTE: The Delay feature is only available on the line level output channels.

Output

Click **Output** to access the settings for **Minimum/Maximum Volume**, **Stereo/Mono**, **Signal**, **Bussing**, **Volume Offset**, **Signal Generator**, and **Equalizer Settings**.

Output

Minimum / Maximum (Autosaved)

Minimum

0

%

Maximum

100

%

Default

30

%

Stereo / Mono (Autosaved)

Stereo / Mono

Stereo

Mono

Zone Configuration

Standard

Signal (Autosaved)

Signal

Not Present

Minimum/Maximum Volume

Minimum / Maximum (Autosaved)

Minimum

0

%

Maximum

100

%

Default

30

%

1. To set the minimum volume of the zone, do one of the following:

- Move the **Minimum** slider to the right to increase or to the left to decrease the minimum volume.
- Click the **%** arrows to increase or decrease the minimum volume. Values range from 0 to 50%, adjustable in increments of 1%.
- Manually enter a value in the **Minimum** field.

2. To set the maximum volume of the zone, do one of the following:

- Move the **Maximum** slider to the right to increase or to the left to decrease the maximum volume.
- Click the **%** arrows to increase or decrease the maximum volume. Values range from 70 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Maximum** field.


NOTE: When a **Minimum** and **Maximum** volume are set, the 1-100% range represented by the **Zone** and **Default** volume controls are scaled to the range set. For example, if a **Minimum** of 10% and a **Maximum** of 80% are set for a zone, the 1-100% range of the **Zone** volume control is scaled to the 10%-80% range set as the **Minimum** and **Maximum**.

3. To set the default volume of the zone, do one of the following:

- Move the **Default** slider to the right to increase or to the left to decrease the default volume.
- Click the **%** arrows to increase or decrease the default volume. Values range from 0 to 50%, adjustable in increments of 1%.
- Manually enter a value in the **Default** field.

NOTE: The **Default** volume is applied as the **Zone** volume any time the zone receives a source route and no source was previously routed to that zone.

Stereo/Mono




— Stereo / Mono (Autosaved)

Stereo / Mono ☒ Stereo ☐ Mono

Zone Configuration Standard

Select either **Stereo** or **Mono** from the **Stereo/Mono** radio buttons. If **Stereo** is selected, both output channels can have independent audio content. If **Mono** is selected, both output channels receive the same audio content.

Signal



— Signal (Autosaved)


Signal Not Present

Clipping None

The **Signal** section is a read-only field that displays the **Signal** and **Clipping** status of the zone output.

- If an output signal is present but not clipping, **Signal** will display **Present** in green and **Clipping** will display **None** in green.
- If an output signal is present and clipping, **Signal** will display **Present** in green and **Clipping** will display **Present** in red.
- If no output signal is detected, **Signal** will display **Not Present** in red and **Clipping** will display **None** in green.

Bussing Volume Offset




Bussing Volume Offset is an additional level compensation applied to the zone relative to any other zones it is grouped with via the **Bussing** feature.

To set the bussing volume offset, do one of the following:

- Move the **Bussing Volume Offset** slider to the right to increase or to the left to decrease the offset.
- Click the **db** arrows to increase or decrease the offset. Values range from -12 dB to 12 dB, adjustable in increments of 1 dB.
- Manually enter a value in the **Bussing Volume Offset** field.

Signal Generator



The DM-NAX-AUD-USB has a built-in signal generator that allows an integrator to send an audio signal to the output for testing purposes.

1. To route the signal generator to the zone output, click the **Signal Generator** button so that it displays **Active** and is highlighted in blue. To unroute the signal generator on the zone output, click the **Signal Generator** button so that it displays **Inactive** and is highlighted in grey. By default, the signal generator is not routed to the zone output.
2. To adjust the signal generator's volume, do one of the following:
 - Move the **Signal Generator Volume** slider right to increase or left to decrease the volume.
 - Click the arrows to increase or decrease the signal generator volume. Values range from 0 to 100, adjustable in increments of 1.
 - Manually enter a value in the **Signal Generator Volume** field.

Equalizer Settings

Equalizer Settings (Autosaved)

Speaker EQ Enabled ☒

Band	Band01	Band02	Band03	Band04	Band05	Band06	Band07	Band08	Band09	Band10
Gain										
	0	0	0	0	0	0	0	0	0	0
Type	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ	EQ
Frequency	32	64	125	250	500	1000	2000	4000	8000	16000
Bandwidth	0.33	0.33	0.33	0.33	0.33	0.33	0.33	0.33	0.33	0.33
Bypass	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Actions	Reset	Reset	Reset	Reset	Reset	Reset	Reset	Reset	Reset	Reset

The zone output of the DM-NAX-AUD-USB has a dedicated ten-band equalizer that can be fully customized to tune the zone output signal to the needs of an install. Each band can have a discrete gain, filter type, center frequency, and bandwidth set, and can also be bypassed. The equalizer itself can also be bypassed using the **Speaker EQ Enabled** toggle.

1. Set the **Speaker EQ Enabled** toggle to the right position to enable the equalizer. Set the toggle to the left position to bypass the equalizer.

NOTE: When **Speaker EQ Enabled** is disabled, all equalizer bands are bypassed. This is a quick way to perform A/B testing of the entire EQ curve.

2. With the **Speaker EQ Enabled** toggle in the right position, do the following to configure a given equalizer band:
 - a. To set a band's gain, do one of the following:
 - Move the **Gain** slider up to increase or down to decrease the gain.
 - Click the arrows to increase or decrease the gain. Values range from -40 dB to 20 dB, adjustable in increments of 0.1 dB.
 - Manually enter a value in the **Gain** field.

- b. Select a filter type from the **Type** drop-down menu. By default, all bands are set to the **EQ** filter type. Some filter types will disable other settings in their respective band while enabled. For example, selecting the **LowPass** filter type for a band will disable that band's **Gain** and **Bandwidth** settings, since the **LowPass** filter applies a fixed roll-off slope at a set frequency. The available filter types are:
- **EQ:** a fully parametric filter that can boost or cut a range of frequencies.
 - **Notch:** a parametric filter designed to more precisely cut a frequency or range of frequencies. A notch filter can achieve a narrower bandwidth than the standard **EQ** parametric filter type.
 - **TrebleShelf:** a filter that boosts or cuts all frequencies above a set frequency by a set gain.
 - **BassShelf:** a filter that boosts or cuts all frequencies below a set frequency by a set gain.
 - **LowPass:** a filter that fully cuts all frequencies above a set frequency using a fixed roll-off slope of -12 dB per octave.
 - **HighPass:** a filter that fully cuts all frequencies below a set frequency using a fixed roll-off slope of -12 dB per octave.
- c. Set a center frequency for the equalizer band to tune a specific portion of the audible frequency spectrum. To set the center frequency, do one of the following:
- Click the arrows to increase or decrease the frequency. Values range from 20 Hz to 20 kHz, adjustable in increments of 1 Hz. Each band has a default center frequency that will be applied if the **Reset** button at the bottom of the band is clicked.
 - Manually enter a value in the **Frequency** field.
- d. Set a bandwidth to determine how wide of a frequency range is effected by the equalizer band. To set the bandwidth, do one of the following:
- Click the arrows to increase or decrease the bandwidth. Values range from 0.1 octaves to 4.0 octaves, adjustable in increments of 0.1 octave.
 - Manually enter a value in the **Bandwidth** field.
- e. The individual Bypass controls allow you to bypass a single band of equalization at a time for more granular A/B testing of a single filter. Set a band's **Bypass** toggle to the right position to bypass that band. Set the toggle to the left position to disable the bypass. By default, **Bypass** is disabled.
- f. Each equalizer band has a **Reset** button that will reapply the default settings for that band.

Click **Done** to return to the **Settings** tab of the web user interface.

Inputs

The **Inputs** section is used to configure the **Name**, **Compensation**, and **Mute** attributes of the available analog, digital, and media streaming inputs on the DM-NAX-AUD-USB.

Inputs	
Analog Inputs (Autosaved)	
Name	LineIn USBIn
Gain (db)	<div> <div>10</div> <div>5</div> <div>0</div> <div>-5</div> <div>-10</div> </div> <div>0</div>
Signal Present	
Clipping Detected	<div>✓</div> <div>Nominal</div>
Mute	<div>○</div>

Configure Inputs

1. If needed, enter a friendly name for each input in its **Name** field.
2. To set a level compensation adjustment for a given input, do one of the following:
 - Move the **Compensation** slider up to increase or down to decrease the level compensation. Compensation increases or decreases the level of the incoming audio signal on any of the physical inputs on the device's rear panel.
 - Click the **db** arrows to increase or decrease the compensation. Values range from -10 dB to 10 dB, adjustable in increments of 1 dB.
 - Manually enter a value in the **Compensation** field.
3. To mute the signal from the corresponding input, set the **Mute** toggle to the right. To disable the mute, set the **Mute** toggle to the left. By default, **Mute** is disabled.

Monitor the device's input signals using the text indicators in the **Signal Present** and **Clipping Detected** columns:

- **Signal Presence** indicates whether or not a signal is detected in that zone.
- **Clipping Detected** indicates if the signal is **Clipping** or **Nominal** (non-clipping).

NAX Streams

The two local inputs of the DM-NAX-AUD-USB can be made available as DM NAX audio-over-IP streams.

Click **NAX Streams** to expand the tab and display the following information.

NAX Streams

This Device is the Leader PTP Clock Source
PTP Clock Leader MAC Address
PTP Priority

No
00:1d:c1:12:16:68

Transmitters (Autosaved)

Audio Source	Stream	Nax Stream Address	Nax Stream Name	Status	Actions
LineIn	Stream01	<input type="text" value="239.69.18.1"/>	<input type="text" value="Stream01-AUD-USB"/>	Stream Started	▶ ■ ⚙️
USBIn	Stream02	<input type="text" value="239.69.18.2"/>	<input type="text" value="Stream02-AUD-USB"/>	Stream Started	▶ ■ ⚙️

Receivers (Autosaved)

Zone Name	Stream	Current Stream Address	Requested Stream Address	Status	Actions
LineOut	Stream01	239.69.2.1	<input type="text" value="239.69.2.1"/> 🔍	Stream Started	▶ ■ ⚙️
USBOut	Stream02	239.69.61.139	<input type="text" value="239.69.61.139"/> 🔍	Stream Started	▶ ■ ⚙️

5. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled for a given stream, the stream will begin transmitting automatically and will be available as a multicast stream on your network at the specified multicast address.
 - If **Auto Initiation** is disabled for the input, the stream will not begin transmitting until it is manually initiated.
6. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number for DM NAX streams is 5004.
7. Click **OK** to save or click **Cancel** to cancel the changes.

Configure Receivers

1. Enter the multicast address of a transmitting stream in the **Requested Stream Address** field to subscribe the receiver to the stream.
2. Click the configure button (⚙️) in the **Actions** column. The **Configure** dialog appears:

3. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled, the stream will begin automatically when the receiver subscribes to the transmitter.
 - If **Auto Initiation** is disabled, the stream will not begin until it is manually initiated.

4. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number is 5004.
5. Click **OK** to save or click **Cancel** to cancel the changes.

Routing

The **Routing** section is used to route a local input or AES67 stream to a Zone on the DM-NAX-AUD-USB.

NOTE: To receive an AES67 stream from Dante devices, see [OLH 1001151](#).



To route an input to a zone, click the box in the routing matrix where the zone's row overlaps the corresponding input's column. Once a route is made, appears. To break a given route click or . To route a single input to all zones, click on the under the input's name.

Security

Click the **Security** tab to configure security for users and groups and to allow different levels of access to the DM-NAX-AUD-USB functions. By default, security is disabled.

✓ Status

⚙ Settings

🔒 Security

⚙ 802.1x Configuration

▼ Security

SSL Mode

Encrypt ▼

SSL Authentication

Username *

chdevice

Password *

Confirm Password *

Current User

Users

Groups

Name

admin

Access Level

Administrator

Active Directory User

No

Groups

Administrators

Change Current User Password

Select **Encrypt and Validate**, **Encrypt**, or **OFF** in the **SSL Mode** drop-down menu, to specify whether to use encryption. By default, SSL Mode is set to **OFF**.

Current User

Click the **Current User** tab to view read-only information or to change the password for the current user.

Current User

Users

Groups

Name

admin

Access Level

Administrator

Active Directory User

No

Groups

Administrators

Change Current User Password

1. Click the **Change Current User Password** button to provide a new password for the current user.
2. In the **Change Password** dialog, enter the current password in the **Current Password** field, the new password in the **Password** field, and then re-enter the same new password in the **Confirm Password** field.

Change Password

Current Password

.....

Password

.....

Confirm Password

.....|


✓ OK

✕ Cancel

3. Click **OK** to save or click **Cancel** to cancel the changes.

Users

Click the **Users** tab to view and edit user settings. The **Users** tab can be used to add or remove local and Active Directory users and preview information about users.



Use the **Search Users** field to enter search term(s) and display users that match the search criteria.

If users listed in the **Users** table span across multiple pages, navigate through the list of users by clicking a page number or by using the left or right arrows at the bottom of the **Users** pane to move forward or backward through the pages.

Each page can be set to display 5, 10, or 20 users by using the drop-down menu to the right of the navigation arrows.

Information about existing users is displayed in table format and the following details are provided for each user.


- **Username:** Displays the name of the user.
- **AD User:** Displays whether the user requires authentication using Active Directory.

Click the corresponding button in the Actions column to view detailed user information or to delete the user.

To create a new user, click the **Create User** button.

Create a New Local User

1. Click the **Create User** button in the User tab.
2. In the **Create User** dialog, enter the following:



The screenshot shows a 'Create User' dialog box. The 'Name' field contains the text 'test'. The 'Active Directory User' toggle switch is turned off. The 'Password' and 'Confirm Password' fields are both filled with dots, indicating they are masked. The 'Groups' dropdown menu is set to 'Administrators'. At the bottom right, there are 'OK' and 'Cancel' buttons.

- a. Enter a user name in the **Name** field. A valid user name can consist of alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
- c. Assign the access level by selecting one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is disabled.

3. Click **OK** to save or click **Cancel** to cancel the changes.


Add an Active Directory User

Users cannot be created or removed from the Active Directory server, but access can be granted to an existing user in the Active Directory server.

To grant access to an Active Directory user, you can either add the user to a local group on the DM-NAX-AUD-USB, or add the Active Directory group(s) that they are a member of to the DM-NAX-AUD-USB.

To add an Active Directory user.

1. Click the **Create User** button.
2. In the **Create User** dialog, enter the following.




The screenshot shows a 'Create User' dialog box with a blue header. It contains three main fields: 'Name' with the text 'Connects\test', 'Active Directory User' with a blue toggle switch turned on, and 'Groups' with a dropdown menu showing 'Connects'. At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'x' icon.

- a. Enter a user name in the **Name** field in the format "Domain\UserName", for example "crestronlabs.com\JohnSmith". Valid user names can contain alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Select one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is set to enabled.


3. Click **OK** to save or click **Cancel** to cancel the changes.

Delete User


Click the trashcan button () in the **Actions** column to delete the user. Click **Yes** when prompted to delete the user or **No** to cancel the deletion.

After a user is removed from a group, they lose any access rights associated with that group. Note that the user account is not deleted by the delete user operation.

View User Details

Click the information button () in the **Actions** column to view information for the selected user. The **User Details** dialog displays the following information for the selected user.


- **Name:** Displays the name of the selected user.
- **Active Directory User:** Displays whether the user is an Active Directory user.
- **Group:** Displays group(s) the selected user is part of.




The **User Details** dialog box has a blue title bar with the text "User Details" and a close button (X). The main area is white and contains three rows of information: "Name" with the value "admin1", "Active Directory User" with the value "No", and "Groups" with the value "Administrators". At the bottom right, there is a blue button with a checkmark and the text "OK".

Click **OK** to close the **User Details** dialog and to return to the **Users** tab.

Update User Details



The **Update User** dialog box has a blue title bar with the text "Update User" and a close button (X). The main area is white and contains several fields: "Name" with the value "admin1", "Active Directory User" with a toggle switch that is currently off, "Password" and "Confirm Password" fields both containing seven dots, and a "Groups" drop-down menu with "Administrators" selected. At the bottom right, there are two blue buttons: one with a checkmark and "OK", and another with an X and "Cancel".

1. Click the edit button () in the **Actions** column to update information for the selected user.
2. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
3. Select one or more groups to assign the user to from the **Groups** drop-down list.
4. Click **OK** to save or click **Cancel** to cancel the changes.

The **Update User** dialog also displays the following read-only information for the selected user.

- **Name:** Displays the name of the user.
- **Active Directory User:** Displays whether the user is an Active Directory user.











Groups

Click the **Groups** tab to view and edit group settings. The **Groups** tab can be used to add local and Active Directory groups, remove local and Active Directory groups, and preview information about a group.

Use the **Search Groups** field to enter search term(s) and display groups that match the search criteria.

Current UserUsersGroups

Search...

Group Name	AD Group	Access Level	Actions
Administrators	No	Administrator	 
Connects	No	Connect	 
Operators	No	Operator	 
Programmers	No	Programmer	 
Users	No	User	 

<<<1>>>

10



Create Group

If groups listed in the **Groups** table span across multiple pages, navigate through the groups by clicking a page number or by using the left or right arrows at the bottom of the Groups pane to move forward or backward through the pages.

Additionally, each page can be set to display 5, 10, or 20 groups by using the drop-down menu to the right of the navigation arrows.


Existing groups are displayed in a table and the following information is provided for each group:

- **Group Name:** Displays the name of the group.
- **AD Group:** Displays whether the group requires authentication using Active Directory.
- **Access Level:** Displays the predefined access level assigned to the group (Administrator, Programmer, Operator, User, or Connect).

Click the corresponding button in the **Actions** column to view detailed group information () or to delete () selected group.

Click on the **Create Group** button in the **Groups** tab to create new group.

Create Local Group



The screenshot shows a 'Create Group' dialog box with a blue header. It contains three main fields: 'Name' with the text 'test12', 'Access Level' with a dropdown menu showing 'Programmer', and 'Active Directory Group' with a toggle switch that is currently off. At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'X' icon.


1. Click the **Create Group** button.
2. In the **Create Group** dialog, enter the following:
 - a. Enter the group name in the **Name** field.
 - b. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is disabled.

3. Click **OK** to save. Click **Cancel** to cancel the changes.

Add Active Directory Group

A group cannot be created or removed from the Active Directory server, but access can be granted to an existing group in Active Directory.



The screenshot shows a 'Create Group' dialog box with a blue header. It contains three main fields: 'Name' with the text 'test', 'Access Level' with a dropdown menu showing 'Administrator', and 'Active Directory Group' with a toggle switch that is currently on. At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'X' icon.

Once the group is added, all members of that group will have access to the DM-NAX-AUD-USB.


1. Click the **Create Group** button.
2. In the **Create Group** dialog enter the following:
 - a. Enter the group name in the **Name** field, for example "Engineering Group". Note that group names are case sensitive; a space is a valid character that can be used in group names.

3. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is enabled.


4. Click **OK** to save. Click **Cancel** to cancel the changes.


Delete a Group

Click the trashcan button () in the **Actions** column to delete a group. Click **Yes** when prompted to delete the group or **No** to cancel the deletion.

When a group is deleted, users in the group are not removed from the device or Active Directory server. However, because a user's access level is inherited from a group(s), users within the deleted group will lose access rights associated with the group.

View Group Details

Click the information button () in the **Actions** column to view information for the selected group. The **Group Details** dialog lists the following information for the selected group.



The **Group Details** dialog box displays the following information:

Name	Administrators
Access Level	Administrator
Active Directory Group	No

At the bottom right, there is a blue button with a checkmark and the text **OK**.

- **Name:** Displays the name of the group.
- **Access Level:** Displays the access level of the group and its users.
- **Active Directory Group:** Displays whether the group is an Active Directory group.

Click **OK** to close the **Group Details** dialog and to return to the Groups tab.

802.1x Configuration

The DM-NAX-AUD-USB has built-in support for the 802.1X standard (an IEEE network standard designed to enhance the security of wireless and Ethernet LANs. The standard relies on the exchange of messages between the device and the network's host, or authentication server), allowing communication with the authentication server and access to protected corporate networks.

StatusSettingsSecurity802.1x Configuration

802.1x Configuration

IEEE 802.1x Authentication

Authentication MethodEAP MSCHAP V2- password

Domainsecure12

Usernameadmin

Password*****

Enable Authentication Server Validation

Select Trusted Certificate Authority(ies)

☐

AAA Certificate Services

☐

AC RAIZ FNMT-RCM

☐

ACCVRAIZ1

☐

Actalis Authentication Root CA

☒

AffirmTrust Commercial

☐

AffirmTrust Networking

☐

AffirmTrust Premium ECC

☒

AffirmTrust Premium

☐

Amazon Root CA 1

☐

Amazon Root CA 2

☒

Amazon Root CA 3

☐

Amazon Root CA 4

☐

Atos TrustedRoot 2011

☐

Autoridad de Certificacion Firmaprofesional CIF A62634068

☐

Baltimore CyberTrust Root

To Configure DM-NAX-AUD-USB for 802.1X Authentication

1. Set the **IEEE 802.1X Authentication** toggle to enabled. This will enable all options on the 802.1X dialog.
2. Select the **Authentication method: EAP-TLS Certificate** or **EAP-MSCHAP V2 Password** according to the network administrator's requirement.
3. Do either one of the following:
 - Select **EAP-TLS Certificate**, click **Action/Manage Certificates** to upload the required machine certificate. The machine certificate is an encrypted file that will be supplied by the network administrator, along with the certificate password.
 - Select **EAP-MSCHAP V2 Password**, enter the username and password supplied by the network administrator into the **Username** and **Password** fields. This method does not require the use of a machine certificate, only the user name and password credentials.
4. If you enabled the **Enable Authentication Server Validation** option, this will enable the **Select Trusted Certificate Authority(ies)** list box which contains signed Trusted Certificate Authorities (CAs) preloaded into the DM-NAX-AUD-USB.

Select the check box next to each CA whose certificate can be used for server validation, as specified by the network administrator.

If the network does not use any of the listed certificates, the network administrator must provide a certificate, which must be uploaded manually via the **Manage Certificates** functionality.
5. If required, type the domain name of the network in the **Domain** field.
6. When the 802.1X settings are configured as desired, click **Save Changes** to save the changes to the device and reboot it. Click **Revert** to cancel any changes.

Access the Web Interface With the Crestron Toolbox™ Application

To access the web interface by opening a web browser within the Crestron Toolbox™ application, do the following:

1. Open the Crestron Toolbox application.
2. From the **Tools** menu, select **Device Discovery Tool**. You can also access the Device Discovery Tool by clicking the Device Discovery Tool button () in the Crestron Toolbox toolbar. The DM-NAX-AUD-USB is discovered and listed in the device list on the left side of the screen. The associated host name, IP address, and firmware version are also displayed.

NOTE: If there is security software running on the computer, a security alert might be displayed when the Crestron Toolbox application attempts to connect to the network. Make sure to allow the connection, so that the Device Discovery Tool can be used.

3. In the Device Discovery Tool list, double-click your device.
4. Enter your credentials in the **Authentication Required** dialog that opens, and then click **Log In**.
5. Click the **Web Configuration** button in the Configuration page displayed on the left side of the Device Discovery Tool.

DM-NAX-BTIO-1G

This section describes how to configure the DM-NAX-BTIO-1G.

Web Interface Configuration

The DM-NAX-2XLRI-1G web interface allows you to view status information and configure network and device settings.

Access the Web Interface

To access the web interface, do either of the following:

- [Access the Web Interface with a Web Browser on page 586](#)
- [Access the Web Interface With the Crestron Toolbox™ Application on page 640](#)

The web interface is accessed from a web browser. The following table lists operating systems and their corresponding supported web browsers.

Operating System and Supported Web Browsers


OPERATING SYSTEM	SUPPORTED WEB BROWSERS
Windows® operating system	Chrome™ web browser, version 31 and later
	Firefox® web browser, version 31 and later
	Internet Explorer web browser, version 11 and later
	Microsoft Edge web browser
macOS® operating system	Safari® web browser, version 6 and later
	Chrome web browser, version 31 and later
	Firefox web browser, version 31 and later

Access the Web Interface with a Web Browser

1. Enter the IP address of the DM-NAX-BTIO-1G into a web browser.


NOTE: To obtain the IP address, use the **Device Discovery Tool** option in Crestron Toolbox™ application or an IP scanner application.

2. If you are creating a user account for the first time, do the following; otherwise, skip to step 3.
 - a. Enter a username in the **Username** field.
 - b. Enter a password in the **Password** field.
 - c. Re-enter the same password in the **Confirm Password** field.



The screenshot shows the Crestron logo at the top left. Below it, a yellow warning triangle icon is followed by the text "DEVICE FIRST BOOT". In the center, there is a white box titled "Device Administration". Inside this box, there are three input fields: "Username", "Password", and "Confirm Password". Below these fields is a green button with a white plus sign and the text "Create User". At the bottom of the white box, there is small text: "© 2021 Crestron Electronics, Inc.", "Privacy Statement", and "Crestron Software End-User License Agreement".

- d. Click **Create User**. The Device Administration page appears.




The screenshot shows the same Crestron logo at the top left. Below it, the "DEVICE FIRST BOOT" message is no longer present. The white box titled "Device Administration" still contains the "Username" and "Password" input fields. Below these fields is a blue button with a white magnifying glass icon and the text "Sign In". At the bottom of the white box, the same small text is present: "© 2021 Crestron Electronics, Inc.", "Privacy Statement", and "Crestron Software End-User License Agreement".

3. Enter the username in the **Username** field.
4. Enter the password in the **Password** field.
5. Click **Sign In**.

Action

The **Action** drop-down menu is displayed at the top right side of the interface and provides quick access to common device functions:

- Save Changes
- Revert
- Reboot
- Restore
- Update Firmware
- Download Logs
- Manage Certificates



Save Changes

Click **Save Changes** to save any changes made to the configuration settings.


Revert

Click **Revert** to revert the device back to the last saved configuration settings.

Reboot the DM-NAX-BTIO-1G

Certain changes to the settings may require the DM-NAX-BTIO-1G to be rebooted to take effect. To reboot the device, do the following:

1. Click **Reboot** in the **Actions** drop-down menu. The **Confirmation** message box appears.




2. Click **Yes, Reboot Now** to reboot the device. The **Reboot** message box appears. Wait for the device reboot to complete before attempting to reconnect to the device.

Restore to Factory Default Settings

1. Click **Restore** in the **Actions** drop-down menu to restore the settings of the DM-NAX-BTIO-1G to factory defaults.

NOTE: When settings are restored, all settings, including the network settings, will revert to the factory default. If a static IP address is set, restoring the device to factory default settings will revert the IP address to the default DHCP mode.




2. Click **Yes** in the **Confirmation** dialog to restore the DM-NAX-BTIO-1G to factory settings. Click **No** to cancel the restore operation.

A dialog is displayed again, indicating that the restore process was successful and that the device rebooted.

You can also restore to factory settings by pressing and holding the **SETUP** button on the rear panel of the device with power disconnected then connect the power supply and continue to hold **SETUP** button for 30 seconds.

Update Firmware

1. Click **Update Firmware** in the **Actions** drop-down menu.
2. In the **Firmware Upgrade** dialog, click **+ Browse**.



3. Locate and select the desired firmware file, and then click **Open**. The selected firmware file name is displayed in the **Firmware Upgrade** dialog.
4. Click **Load** and wait for the progress bar to complete and for the **OK** button in the message to become clickable.
5. Click **OK**. The device with new firmware can now be accessed.


Download Logs

1. Click **Download Logs** in the **Actions** drop-down menu to download the device message logs for diagnostic purposes.

The log file is downloaded to the Downloads folder of the PC.

Manage Certificates

Use the **Manage Certificates** dialog to add, remove, and manage certificates used in 802.1x and other protected networks.



1. Click **Manage Certificates** in the **Actions** drop-down menu. The following certificate tabs are displayed:
 - **Root:** The Root certificate is used by the DM-NAX-BTIO-1G to validate the network's authentication server. The DM-NAX-BTIO-1G has a variety of Root certificates, self-signed by trusted CAs (Certificate Authorities) preloaded into the device. Root certificates must be self-signed.
 - **Intermediate:** The Intermediate store holds non self-signed certificates that are used to validate the authentication server. These certificates will be provided by the network administrator if the network does not use self-signed Root certificates.
 - **Machine:** The machine certificate is an encrypted PFX file that is used by the authentication server to validate the identity of the DM-NAX-BTIO-1G. The machine certificate will be provided by the network administrator, along with the certificate password. For 802.1x, only one machine certificate can reside on the device.
 - **Web Server:** The Web Server certificate is a digital file that contains information about the identity of the web server.

To Add Certificates

1. Click the corresponding certificate tab.
2. Click the **Add Root Certificate** button.
3. Click the **+ Browse** button.
4. Locate and select the file, and then click the **Open** button.

NOTE: If the certificate is a Machine Certificate, enter the password provided by the network administrator.

5. Click **OK**. This will add the certificate to the list box, displaying the file name and expiration date.
The certificate is now available for selection and can be loaded to the device.


To Delete Certificates

1. Click the corresponding certificate tab.
2. Click the trashcan button (🗑️) in the **Actions** column to delete the certificate.
3. Click **Yes** when prompted to delete the certificate or **No** to cancel the deletion.

Status

The **Status** tab is the first page displayed when opening the interface of the DM-NAX-BTIO-1G. It displays general information about the DM-NAX-BTIO-1G (such as Model Name, Firmware Version, and Serial Number), current network settings (such as Host Name and IP Address, etc.), and input and output ports' current status.

The Status tab can be accessed at any time by clicking the **Status** tab of the DM-NAX-BTIO-1G interface.



Information displayed on the **Status** tab is organized into different sections.

Device

The **Device** section displays the **Model**, **Firmware Version**, and **Serial Number** of the DM-NAX-BTIO-1G.

Device

Model

DM-NAX-BTIO-1G

Firmware Version

1.0.0033.11191

Serial Number

2346CRX00386

+ More Details

Click **+ More Details** to review additional information about the DM-NAX-BTIO-1G.

More Details

DM-NAX-BTIO-1G

1.0.0033.11191

Build

Feb 13 2024 (531246)

Updater

1.0.0033.11191

Bootloader

1.00.00

CCUI Version

1.1327.1

XIOSDK

3.8.2

IoTSDK

1.11.0

Build time

11:19:07

Product ID

0x7A09

Revision ID

0x0200

HDCP2X-SKE

HDCP2X-SKE [v9.0000.00000,#FFFFFFFFF]

PRE-BOOT

[v9.0000.00000]

BOOTLOADER

[v9.0000.00000]

ctrl-extclkin-pps

Driver v1.1

ctrl-prod-info

Driver v3.0

ctrl-io-bt

FW v2.0.98

PUF

1.0.0033.11191

Forced Auth Mode

True

Network

The **Network** section displays network-related information about the DM-NAX-BTIO-1G, including the Hostname, Domain Name, and DNS Servers.

Network

Hostname

DM-NAX-BTIO-1G-C442683FC7EA

Domain Name

CRESTRON.CRESTRON.com

DNS Servers

10.64.5.10(DHCP)

Adapter 1

DHCP

On

IP Address

10.64.68.175

Subnet Mask

255.255.255.0

Default Gateway

10.64.68.1

Link Active

true

MAC Address

c4.42.68.3f.c7.ea

NOTE: By default, the host name of the DM-NAX-BTIO-1G consists of the model name followed by the MAC address of the device. For example, DM-NAX-BTIO-1G-00107FB58088.

Click **+ Adapter 1** to display an expanded section that shows additional information. If **+ Adapter 1** is selected, click **- Less** details to collapse the section.

Control System

The **Control System** section displays connection information, consisting of the following:

Control System

Encrypt Connection

ON

IP Table

IP ID	Room Id	IP Address/Hostname	Type	Server Port	Connection	Status
C		DIN-AP4-R-C442681A3F36	Peer	41796	Gway	ONLINE

- **Encrypt Connection:** ON or OFF
- **IP ID:** Reports the currently used IP ID of the DM-NAX-BTIO-1G
- **IP Address/Hostname:** The IP address of the control system
- **Room ID:** Displays the room ID
- **Status:** OFFLINE or ONLINE

Settings

The **Settings** tab enables configuration of the DM-NAX-BTIO-1G settings. The Settings page can be accessed at any time by clicking the **Settings** tab of the DM-NAX-BTIO-1G interface.


Many options in the Settings tab are exclusive to a specific device mode: Residential or Commercial. The DM-NAX-BTIO-1G is in Commercial mode by default.

This section provides the following information:

- [Commercial Mode on page 594](#)
- [Residential Mode on page 612](#)

Commercial Mode

The **Settings** tab enables you to configure the DM-NAX-BTIO-1G settings. The Settings page can be accessed at any time by clicking the **Settings** tab of the DM-NAX-BTIO-1G interface.



Settings available on the **Settings** page are organized into different sections.

System Setup

The **System Setup** section contains settings for **Date/Time**, **Auto Update**, **Network**, and **Control System**.

System Setup

Date/Time Auto Update Network Control System Cloud Settings Device Modes

— Date/Time

Synchronization

Time Synchronization ☒

[Synchronize Now](#)

NTP Time Servers

<input type="checkbox"/>	Address	Port	Authentication Method	Authentication Key	Key ID
<input type="checkbox"/>	pool.ntp.org	123	None	*****	0

[+ Add](#) [- Remove](#)

Configuration

Time Zone (UTC-05:00) Eastern Time (US & Can) ▼

Date 02/27/2024

Time 17:14

Date/Time

Use the **Date/Time** tab to configure the date and time settings of the DM-NAX-BTIO-1G.

— Date/Time

Synchronization

Time Synchronization ☒

[Synchronize Now](#)

NTP Time Servers

<input type="checkbox"/>	Address	Port	Authentication Method	Authentication Key	Key ID
<input type="checkbox"/>	pool.ntp.org	123	None	*****	0

[+ Add](#) [- Remove](#)

Configuration

Time Zone (UTC-05:00) Eastern Time (US & Can) ▼

Date 02/21/2024

Time 12:40

Time Synchronization

1. Set the **Time Synchronization** toggle to the right position to enable or left position to disable time synchronization. By default, time synchronization is enabled.
2. In the **NTP Time Servers** table, enter the URL of a NTP (Network Time Protocol) or SNTP (Simple Network Time Protocol) server. Up to three time servers can be added on a device.
3. Click **Synchronize Now** to perform time synchronization between the device's internal clock and the time server.

Time Configuration

1. Click on the **Time Zone** drop-down menu to select the applicable time zone.
2. In the **Date** field, enter the current date.
3. In the **Time (24hr Format)** field, enter the current time in 24-hour format.

Click the **Save Changes** button to save the settings.

Click **Revert** from the **Actions** drop-down menu to revert to the previous settings without saving.

Auto Update

The DM-NAX-BTIO-1G can automatically check for and install firmware updates at scheduled intervals via the Auto Update feature.

Auto Update

Auto Update ☒

Custom URL ☒

Custom URL Path

Schedule

Day of Week

Time of Day

Poll Interval Minutes

Update Now

1. Set the **Auto Update** toggle to the right position to enable Auto Update.
2. Define the URL to download the updates by doing either of the following:
 - a. Use the default URL to download the updates from the Crestron server.
 - b. Use a custom URL. Set the **Custom URL** toggle to the right position to enable a custom URL. In the **Custom URL Path** text box, enter the path to a custom manifest file in the FTP or SFTP URL format. Use the Crestron Auto Update Tool to generate a custom manifest file, then store the file on an FTP (File Transfer Protocol) or SFTP (Secure File Transfer Protocol) server.
3. Set a schedule for the automatic firmware update by doing either of the following:
 - a. Select the desired **Day of Week** and **Time of Day** (24-hour format) values.
 - b. Set the **Poll Interval** by entering a value from **60** to **65535** minutes. A value of **0** disables the Poll Interval.
4. Click **Save Changes**.

Clicking **Update Now** causes the device to check for a firmware update immediately. If a schedule was set in step 4 above, that schedule still remains in effect.

Network

The **Network** tab contains network-related settings for the DM-NAX-BTIO-1G, including the Hostname, Domain, Primary Static DNS, and Secondary Static DNS.

Date/Time

Auto Update

Network

Control System

Cloud Settings

Device Modes

— Network

Adapter 1

Hostname *

DM-NAX-BTIO-1G-C442683FC7EA

Domain

CRESTRON.CRESTRON.com

Primary Static DNS

10.64.5.10(DHCP)

Secondary Static DNS

192.168.200.133(DHCP)

DHCP Enabled

☒

IP Address

10.64.68.175

Subnet Mask

255.255.255.0

Default Gateway

10.64.68.1

NOTE: By default, the hostname of the DM-NAX-BTIO-1G consists of the model name followed by the MAC address of the device. For example, DM-NAX-BTIO-1G-00107FB58088.

Adapter 1

The Adapter 1 subheading contains settings for DHCP, IP Address, Subnet Mask, and Default Gateway of Ethernet adapter 1 on the rear panel of the device.

NOTE: DM NAX devices' internal processes use IP addresses in the 10.10.10.xxx range. This IP range should be avoided when addressing DM NAX devices to prevent conflicts.

Set the **DHCP** toggle to enabled (right) or disabled (left) to specify whether the IP address of the DM-NAX-BTIO-1G is to be assigned by a DHCP (Dynamic Host Configuration Protocol) server.

- **Enabled:** When DHCP is enabled (default setting), the IP address of the DM-NAX-BTIO-1G is automatically assigned by a DHCP server on the local area network (LAN).
- **Disabled:** When DHCP is disabled, manually enter information in the following fields:
 - **Primary Static DNS:** Enter a primary DNS IP address.
 - **Secondary Static DNS:** Enter a secondary DNS IP address.
 - **IP Address:** Enter a unique IP address for the DM-NAX-BTIO-1G.
 - **Subnet Mask:** Enter the subnet mask that is set on the network.
 - **Default Gateway:** Enter the IP address that is to be used as the network's gateway.

To save any new network entries, click **Save Changes**.

Control System

Control System

Control System Username

chdevice

Control System Password

Encrypt Connection

IP Table

<input type="checkbox"/>	IP ID	IP Address/Hostname	Room Id
<input type="checkbox"/>	C	DIN-AP4-R-C442681A3F36	Room Id

+ Add

× Remove

1. Click the **Encrypt Connection** button to navigate to the **Security** tab to configure encryption settings.
2. Enter the username in the **Control System Username** field.
3. Enter the password in the **Control System Password** field.
4. Enter the Room ID in the **Room ID** field.
5. Enter the IP ID of the DM-NAX-BTIO-1G in the **IP ID** field.
6. Enter the IP address or hostname of the control system in the **IP Address/Hostname** field.
7. Click the **Save Changes** button to save the new entries. The Control System Save message box appears, indicating that the control system settings were saved successfully. Click the **Revert** button to revert to the previous settings without saving.

Cloud Settings

Date/Time

Auto Update

Network

Control System

Cloud Settings

Device Modes

Cloud Settings

Cloud Configuration Service Connection ☒

Set the **Cloud Settings** toggle to enabled (right) or disabled (left) to specify whether the DM-NAX-BTIO-1G can communicate with the XiO Cloud® platform.

Device Modes

Use the **Device Modes** tab to configure the **Application Mode** of the DM-NAX-BTIO-1G.

Date/Time

Auto Update

Network

Control System

Cloud Settings

Device Modes


Device Modes (Autosaved)

Application Mode

Commercial (Advanced) ▼

The Application Mode determines which options and controls are available.

- Select **Residential (Standard)** or **Commercial (Advanced)**. A **Reboot** confirmation message box appears.




- Click **Yes, Reboot Now** to reboot the device into the selected mode. The **Reboot** message box appears.
- Wait for the device reboot to complete before attempting to reconnect to the device.

By default, the DM-NAX-BTIO-1G is set to **Commercial (Advanced)** mode.

Commissioning

The **Commissioning** section provides a quick way to automatically assign multicast addresses to the device's internal audio-over-IP stream transmitters.

A screenshot of the 'Commissioning' section in a web interface. The section has a blue header with a dropdown arrow and the text 'Commissioning'. Below the header, there are two labels: 'Starting Multicast Address' and 'Last Used Multicast Address'. The 'Starting Multicast Address' is followed by a text input field containing '239.8.0.0'. The 'Last Used Multicast Address' is followed by the text '239.8.0.8'. At the bottom right, there is a blue button labeled 'Assign Addresses'.

Click **Assign Addresses** to give each DM NAX transmitter in the DM-NAX-BTIO-1G a unique multicast address beginning with the specified **Starting Multicast Address**. The valid range for **Starting Multicast Address** is 239.8.0.0 to 239.255.255.254.

NOTE: This will begin transmitting multicast traffic on your network, refer to the [DM NAX Audio-over-IP System Design Guide](#) document for details.

Bluetooth Settings

The **Bluetooth** section provides settings for the internal Bluetooth radio of the DM-NAX-BTIO-1G. These settings are divided up into two tabs, labeled **Main** and **Advanced**.

Main Bluetooth Settings

Bluetooth

Main Advanced





Main (Autosaved)

Bluetooth Name IP: 10.64.68.175

Bluetooth Enable ☒

Pairing Active ☐



Paired Devices

Name	Status	Actions
Galaxy S22	Connected	 
APX227328	Disconnected	 


To configure the settings on the **Main** tab of the Bluetooth settings section:

- Enter a custom name for the DM-NAX-BTIO-1G in the **Bluetooth Name** text field. This is the name that will be displayed on source devices (such as smartphones) that discover the DM-NAX-BTIO-1G as a casting destination.
- Set the **Bluetooth Enable** toggle to the right to allow Bluetooth wireless audio casting to the DM-NAX-BTIO-1G. Set the **Bluetooth Enable** toggle to the left to disable Bluetooth wireless audio.

NOTE: While Bluetooth audio is disabled on the device, some applications that scan for Bluetooth devices may still be able to detect the DM-NAX-BTIO-1G. These applications will not be able to connect to the DM-NAX-BTIO-1G or cast audio to it while Bluetooth audio is disabled.

- Set the **Pairing Active** toggle to the right to enable pairing mode, allowing Bluetooth devices to pair to the DM-NAX-BTIO-1G. Set the **Pairing Active** toggle to the left to disable pairing mode.
- The **Paired Devices** table displays the name and status of all remembered Bluetooth devices that were previously paired with the DM-NAX-BTIO-1G.
 - The DM-NAX-BTIO-1G can remember up to seven previously paired devices.
 - Only one paired Bluetooth device can have a **Connected** status at a time. All other paired devices will display a **Disconnected** status. The **Connected** status indicates which device is currently able to actively cast media to the wall plate.
 - To disconnect a connected device, click the  button.
 - To forget a remembered device from the **Paired Devices** table, click the  button.

Advanced Bluetooth Settings




Bluetooth

Main [Advanced](#)

— Advanced (Autosaved) —

Connection Management Exclusive

Reconnect Behavior Manual

 Paired Device Options

Pairing Code Enabled ☐

Connect Chime Enable ☒

Disconnect Chime Enable ☒

To configure the settings on the **Advanced** tab of the Bluetooth settings section:

- Select a **Connection Management** option from the drop-down.
 - In **Interrupt** mode, remembered paired devices can reconnect to the DM-NAX-BTIO-1G from their Bluetooth connections list, and will interrupt any currently playing audio. The most recent casting device to select the DM-NAX-BTIO-1G from its Bluetooth list will show a **Connected** status in the **Paired Devices** table, and all other devices will revert to **Disconnected**.
 - In **Exclusive** mode, remembered paired devices cannot be reconnected to the DM-NAX-BTIO-1G from their Bluetooth connections list until the currently **Connected** device is disconnected. The device that is listed as **Connected** in the **Paired Devices** table will remain as the **Connected** device until it is disconnected by programming, from the web interface, or by the casting device itself.
 - **TransientExclusive** mode is the same as Exclusive mode, with the added behavior that the DM-NAX-BTIO-1G will forget the currently connected device once it is disconnected.
- Select a Reconnect Behavior option from the drop-down.
 - **Manual** reconnection means that any time the Bluetooth casting device is disconnected from the DM-NAX-BTIO-1G, it can only be reconnected by selecting the casting device from the DM NAX device's list of paired devices.
 - **Automatic** reconnection means that any remembered paired Bluetooth casting device will reconnect to the DM-NAX-BTIO-1G when it is within the wireless range of the DM NAX device.

- Click the **Paired Device Options** button to open a **Paired Device Options** window. Select a command from the drop-down menu, then click the **Send** button to issue the command to the DM NAX device.
 - **Release All Paired Devices** will disconnect all currently paired devices from the DM-NAX-BTIO-1G.
 - **Release Inactive Paired Devices** will disconnect any paired device that is not actively playing any media.
 - **Forget All Paired Devices** will delete all currently paired devices from the **Paired Devices** table of the DM-NAX-BTIO-1G.
 - **Forget Inactive Paired Devices** will disconnect and forget any paired device that is not actively playing any media.
 - **Forget Connected Devices** will disconnect and forget only the current **Connected** device.
- Set the **Pairing Code Enabled** toggle to the right to enable the pairing code. When this is enabled, a pairing code string will populate on both the casting device and the OLED display of the DM-NAX-BTIO-1G during pairing. Confirm that the code matches on each device to complete the pairing process. Set the toggle to the left to disable the pairing code.
- Set the **Connect Chime Enable** toggle to the right to hear a short chime whenever a device successfully pairs to the DM-NAX-BTIO-1G. This chime is played back on the Bluetooth audio input path. Any outputs that receive the Bluetooth audio input signal will receive the chime audio. Set the **Connect Chime Enable** toggle to the left to disable the connect chime.
- Set the **Disconnect Chime Enable** toggle to the right to hear a short chime whenever a device is disconnected from the DM-NAX-BTIO-1G. This chime is played back on the Bluetooth audio input path. Any outputs that receive the Bluetooth audio input signal will receive the chime audio. Set the **Disconnect Chime Enable** toggle to the left to disable the disconnect chime.

Display

The screenshot shows a settings menu with a light blue header bar containing a dropdown arrow and the text "Display". Below the header, there are three settings:

- Brightness**: A slider set to 37, with up and down arrows and a percentage sign (%) to its right.
- Standby Timeout**: A dropdown menu set to 1, with up and down arrows and the word "Minutes" to its right.
- Button Lockout**: A toggle switch that is currently turned off (to the left).

The **Display** section contains settings that affect the front panel OLED display of the DM-NAX-BTIO-1G.

- To adjust the display brightness:
 - Click the **%** arrows to increase or decrease the brightness. Values range from 0 to 100%, adjustable in increments of 1%.
 - Manually enter a percentage value in the **Brightness** text field.
- To adjust the display standby timeout:
 - Click the **Minutes** arrows to increase or decrease the brightness. The default timeout value is one minute.
 - Manually enter a value in the **Standby Timeout** text field.

- Set the **Button Lockout** toggle to the right to lock out the front panel buttons on the DM-NAX-BTIO-1G. Set the **Button Lockout** toggle to the left to disable the lockout.

Output Channels

The **Zones** section contains the **Volume** and **Mute** settings for all zone outputs of the device, as well as an **Edit** option for more advanced settings within each zone.

Output Channels								
Zones (Autosaved)								
Global Filter								
Name	LineOutLeft	LineOutRight	BTOutLeft	BTOutRight	StreamOut1Ch1	StreamOut1Ch2	StreamOut2Ch1	StreamOut2Ch2
Volume (%)								
Signal Presence								
Signal Level	Nominal	Nominal	Nominal	Nominal	Nominal	Nominal	Nominal	Nominal
Mute	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Action								

Signal Presence indicates whether or not an audio signal is detected in that zone.

Signal Level indicates if the signal is **Clipping** or **Nominal** (non-clipping).

- **Nominal:** The signal level is within normal operating bounds and below the clipping threshold.
- **Clipping:** The signal level is clipping or above the -3 dB warning threshold and in danger of clipping.

Give each zone a friendly name using the **Name** column of the **Zones** table. If the device is paired with a control system, these names may be overwritten by the control system's program.

To configure the zone volume, do one of the following:


- Move the **Volume** slider up to increase or down to decrease the zone volume.
- Click the % arrows to increase or decrease the zone volume. Values range from 0 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Volume** field.

To mute all audio output from a zone, click its respective **Mute** button. To unmute the zone, click the **Muted** button.

Click **Edit** to view additional **Zone** and **Output** options.


Zone Settings

To configure the settings for an output channel, click the **Edit** button. The **Edit Zone** window appears.




Zone

Click **Zone** to access the settings for **Delay**.



Delay



To set the delay, do one of the following:

- Move the **Delay Time(ms)** slider to the right to increase or to the left to decrease the delay time.
- Click the **ms** arrows to increase or decrease the delay. Values range from 0 ms to 85 ms, adjustable in increments of 1 ms.
- Manually enter a value in the **Delay Time(ms)** field.

NOTE: The Delay feature is only available on the line level output channels.

Output

Click **Output** to access the settings for **Minimum/Maximum Volume** and **Signal**.

> Output

Minimum / Maximum (Autosaved)

Minimum

0 %

Maximum

100 %

Default

80 %

Signal (Autosaved)

Signal

Not Present

Clipping

None

Minimum/Maximum Volume

Minimum / Maximum (Autosaved)

Minimum

0 %

Maximum

100 %

Default

30 %


- To set the minimum volume of the zone, do one of the following:
 - Move the **Minimum** slider to the right to increase or to the left to decrease the minimum volume.
 - Click the **%** arrows to increase or decrease the minimum volume. Values range from 0 to 50%, adjustable in increments of 1%.
 - Manually enter a value in the **Minimum** field.
- To set the maximum volume of the zone, do one of the following:
 - Move the **Maximum** slider to the right to increase or to the left to decrease the maximum volume.
 - Click the **%** arrows to increase or decrease the maximum volume. Values range from 70 to 100%, adjustable in increments of 1%.
 - Manually enter a value in the **Maximum** field.

NOTE: When a **Minimum** and **Maximum** volume are set, the 1-100% range represented by the **Zone** and **Default** volume controls are scaled to the range set. For example, if a **Minimum** of 10% and a **Maximum** of 80% are set for a zone, the 1-100% range of the **Zone** volume control is scaled to the 10%-80% range set as the **Minimum** and **Maximum**.

3. To set the default volume of the zone, do one of the following:
- Move the **Default** slider to the right to increase or to the left to decrease the default volume.
 - Click the **%** arrows to increase or decrease the default volume. Values range from 0 to 50%, adjustable in increments of 1%.
 - Manually enter a value in the **Default** field.

NOTE: The **Default** volume is applied as the **Zone** volume any time the zone receives a source route and no source was previously routed to that zone.

Signal



— Signal (Autosaved)

Signal	Not Present
Clipping	None

The **Signal** section is a read-only field that displays the **Signal** and **Clipping** status of the zone output.

- If an output signal is present but not clipping, **Signal** will display **Present** in green and **Clipping** will display **None** in green.
- If an output signal is present and clipping, **Signal** will display **Present** in green and **Clipping** will display **Present** in red.
- If no output signal is detected, **Signal** will display **Not Present** in red and **Clipping** will display **None** in green.

Input Channels

The **Input Channels** section is used to configure the **Name**, **Compensation**, and **Mute** attributes of the audio inputs of the DM-NAX-BTIO-1G.

Name	LineInLeft	LineInRight	BTInLeft	BTInRight	StreamIn1Ch1	StreamIn1Ch2	StreamIn2Ch1	StreamIn2Ch2
Compensation (db)								
Signal Present					✓	✓		
Signal Level	✓ Nominal	✓ Nominal	✓ Nominal	✓ Nominal	✓ Nominal	✓ Nominal	✓ Nominal	✓ Nominal
Mute	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Configure Inputs

1. If needed, enter a friendly name for each input in its **Name** field.
2. To set a level compensation adjustment for a given input, do one of the following:
 - Move the **Compensation** slider up to increase or down to decrease the level compensation. Compensation increases or decreases the level of the incoming audio signal on any of the physical inputs on the device's rear panel.
 - Click the **db** arrows to increase or decrease the compensation. Values range from -10 dB to 10 dB, adjustable in increments of 1 dB.
 - Manually enter a value in the **Compensation** field.
3. To mute the signal from the corresponding input, set the **Mute** toggle to the right. To disable the mute, set the **Mute** toggle to the left. By default, **Mute** is disabled.

Monitor the device's input signals using the text indicators in the **Signal Present** and **Clipping Detected** columns:

- **Signal Presence** indicates whether or not a signal is detected in that zone.
- **Clipping Detected** indicates if the signal is **Clipping** or **Nominal** (non-clipping).

DM NAX Streams

The local inputs of the DM-NAX-BTIO-1G can be made available as DM NAX audio-over-IP streams. Two network stream transmitters are available on the device. One transmitter will encode the local unbalanced line level input, and the other will encode the Bluetooth input audio.

Click **NAX Streams** to expand the tab and display the following information.

NAX Streams

This Device is the Leader PTP Clock SourceNo
PTP Clock Leader MAC Address00:1d:c1:12:16:68
PTP Priority254

Transmitters (Autosaved)

Audio Source	Stream	Nax Stream Address	Nax Stream Name	Status	Actions
StreamOut1Ch1	Stream01	239.69.18.1	Stream01-AUD-USB	Stream Started	▶ □ ⚙️
StreamOut2Ch1	Stream02	239.69.18.2	Stream02-AUD-USB	Stream Started	▶ □ ⚙️


Receivers (Autosaved)

Zone Name	Stream	Current Stream Address	Requested Stream Address	Status	Actions
StreamIn1Ch1	Stream01	239.69.2.1	239.69.2.1 🔍	Stream Started	▶ □ ⚙️
StreamIn2Ch1	Stream02	239.69.61.139	239.69.61.139 🔍	Stream Started	▶ □ ⚙️

Configure Transmitters

To configure the DM NAX transmit stream, do the following.

1. Enter a valid multicast address in the **NAX Stream Address** field.
2. Enter a name in the **NAX Stream Name** field by which the stream can be identified. This stream name is associated with the DM NAX stream's multicast address by other DM NAX or AES67 devices, like a device hostname that resolves to a given IP address.
3. **Status** indicates whether a stream is transmitting or not. When the stream has started or stopped, the **Status** column will update accordingly.
4. Click the configure button (⚙️) in the **Actions** column. The **Configure** dialog appears:




5. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled for a given stream, the stream will begin transmitting automatically and will be available as a multicast stream on your network at the specified multicast address.
 - If **Auto Initiation** is disabled for the input, the stream will not begin transmitting until it is manually initiated.
6. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number for DM NAX streams is 5004.
7. Click **OK** to save or click **Cancel** to cancel the changes.

Configure Receivers

1. Enter the multicast address of a transmitting stream in the **Requested Stream Address** field to subscribe the receiver to the stream.

2. Click the configure button (⚙️) in the **Actions** column. The **Configure** dialog appears:


A screenshot of a 'Configure' dialog box. The dialog has a blue title bar with the text 'Configure' and a close button (X). The main area is white and contains a toggle switch labeled 'Auto Initiation' which is currently turned off. Below the toggle is a 'Port' field with a text input showing '5004' and a spinner control with up and down arrows. At the bottom of the dialog, there are two buttons: 'OK' with a checkmark icon and 'CANCEL' with an X icon.

3. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled, the stream will begin automatically when the receiver subscribes to the transmitter.
 - If **Auto Initiation** is disabled, the stream will not begin until it is manually initiated.
4. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number is 5004.
5. Click **OK** to save or click **Cancel** to cancel the changes.




Mixing

The **Mixing** matrix is used to route a local input or AES67 stream to an output on the DM-NAX-BTIO-1G.

NOTE: To receive an AES67 stream from Dante devices, see [OLH 1001151](#).




To route inputs to outputs on the device:

- Click the cells corresponding to the desired output that are to be paired for routing. Once a route is made,  appears. The input that you have selected for a given row will route to the output corresponding to that row in the matrix.
- Use the arrows (◀ or ▶) at the left of the matrix to change pages to view all available inputs.
- To break a given route click  or .

Each output can have any number of inputs routed to it. To adjust the mix setting for a route, click the **dB** value of the cell, then do one of the following:


- Move the slider up to increase or down to decrease the mix level.
- Click the arrows to increase or decrease the mix level.
- Manually enter a value in the field.



Residential Mode

This section provides the following information:

- [System Setup on page 613](#)
- [Commissioning on page 618](#)
- [Bluetooth on page 619](#)
- [Display on page 621](#)
- [Output Channels on page 622](#)
- [Inputs on page 626](#)
- [NAX Streams on page 627](#)
- [Routing on page 629](#)



System Setup

The **System Setup** section displays information about the Date/Time, Auto Update, Network, Control System, Cloud Settings, and Device Modes.

Date/Time

Use the **Date/Time** section to configure the date and time settings of the DM-NAX-BTIO-1G.

System Setup

Date/Time Auto Update Network Control System Cloud Settings Device Modes

Date/Time

Synchronization

Time Synchronization ☒

[Synchronize Now](#)

NTP Time Servers

<input type="checkbox"/>	Address	Port	Authentication Method	Authentication Key	Key ID
<input type="checkbox"/>	pool.ntp.org	123	None	*****	0

[+ Add](#) [- Remove](#)

Configuration

Time Zone: (UTC-05:00) Eastern Time (US & Can)

Date: 02/21/2024

Time: 11:49

Time Synchronization

1. Set the **Time Synchronization** toggle to the right position to enable or left position to disable time synchronization. By default, time synchronization is enabled.
2. In the **NTP Time Servers** table, enter the URL of a NTP (Network Time Protocol) or SNTP (Simple Network Time Protocol) server. Up to three time servers can be added on a device.
3. Click **Synchronize Now** to perform time synchronization between the device's internal clock and the time server.

Time Configuration

1. Click on the **Time Zone** drop-down menu to select the applicable time zone.
2. In the **Date** field, enter the current date.
3. In the **Time (24hr Format)** field, enter the current time in 24-hour format.

Click the **Save Changes** button to save the settings.

Click **Revert** from the **Actions** drop-down menu to revert to the previous settings without saving.

Auto Update

The DM-NAX-BTIO-1G can automatically check for and install firmware updates at scheduled intervals via the Auto Update feature.

The screenshot shows the 'System Setup' interface with the 'Auto Update' tab selected. The 'Auto Update' toggle is turned on. The 'Custom URL' toggle is turned off. The 'Custom URL Path' text box contains the URL 'https://crestrondevicefiles.blob.core.win'. The 'Day of Week' dropdown is set to 'Daily'. The 'Time of Day' text box contains '02:25'. The 'Poll Interval' text box contains '0' with a 'Minutes' label. An 'Update Now' button is at the bottom right.

1. Set the **Auto Update** toggle to the right position to enable Auto Update.
2. Define the URL to download the updates by doing either of the following:
 - a. Use the default URL to download the updates from the Crestron server.
 - b. Use a custom URL. Set the **Custom URL** toggle to the right position to enable a custom URL. In the **Custom URL Path** text box, enter the path to a custom manifest file in the FTP or SFTP URL format. Use the Crestron Auto Update Tool to generate a custom manifest file, then store the file on an FTP (File Transfer Protocol) or SFTP (Secure File Transfer Protocol) server.
3. Set a schedule for the automatic firmware update by doing either of the following:
 - a. Select the desired **Day of Week** and **Time of Day** (24-hour format) values.
 - b. Set the **Poll Interval** by entering a value from **60** to **65535** minutes. A value of **0** disables the Poll Interval.
4. Click **Save Changes**.

Clicking **Update Now** causes the device to check for a firmware update immediately. If a schedule was set in step 4 above, that schedule still remains in effect.

Network

The **Network** section contains network-related settings for the DM-NAX-BTIO-1G, including the Hostname, Domain, Primary Static DNS, and Secondary Static DNS.

10.64.68.1

Control System

System Setup

Date/Time Auto Update Network **Control System** Cloud Settings Device Modes

Control System

Encrypt Connection

IP Table

<input type="checkbox"/>	IP ID	IP Address/Hostname	Room Id
No records found			

+ Add X Remove

1. Click the **Encrypt Connection** button to navigate to the **Security** tab to configure encryption settings.
2. Enter the username in the **Control System Username** field.
3. Enter the password in the **Control System Password** field.
4. Enter the Room ID in the **Room ID** field.
5. Enter the IP ID of the DM-NAX-BTIO-1G in the **IP ID** field.
6. Enter the IP address or hostname of the control system in the **IP Address/Hostname** field.
7. Click the **Save Changes** button to save the new entries. The Control System Save message box appears, indicating that the control system settings were saved successfully. Click the **Revert** button to revert to the previous settings without saving.

Cloud Settings

Cloud Settings

Cloud Configuration Service Connection ☒

Set the **Cloud Settings** toggle to enabled (right) or disabled (left) to specify whether the DM-NAX-BTIO-1G can communicate with the XiO Cloud® platform.

Device Modes

Use the **Device Modes** section to configure the **Application Mode**.

- **Application Mode:** The Application Mode determines which options and controls are available.
 - Select **Residential (Standard)** or **Commercial (Advanced)**. A **Reboot** confirmation message box appears.

- Click **Yes, Reboot Now** to reboot the device into the selected mode. The **Reboot** message box appears.
- Wait for the device reboot to complete before attempting to reconnect to the device.

Commissioning

The **Commissioning** section provides a quick way to automatically assign multicast addresses to the device's internal audio-over-IP stream transmitters.


Click **Assign Addresses** to give each DM NAX transmitter in the DM-NAX-BTIO-1G a unique multicast address beginning with the specified **Starting Multicast Address**. The valid range for **Starting Multicast Address** is 239.8.0.0 to 239.127.255.254.

NOTE: This will begin transmitting multicast traffic on your network, refer to the [General Network Requirements](#) document for details.

Bluetooth

The **Bluetooth** section provides settings for the internal Bluetooth radio of the DM-NAX-BTIO-1G. These settings are divided up into two tabs, labeled **Main** and **Advanced**.

Main Bluetooth Settings




To configure the settings on the **Main** tab of the Bluetooth settings section:

- Enter a custom name for the DM-NAX-BTIO-1G in the **Bluetooth Name** text field. This is the name that will be displayed on source devices (such as smartphones) that discover the DM-NAX-BTIO-1G as a casting destination.
- Set the **Bluetooth Enable** toggle to the right to allow Bluetooth wireless audio casting to the DM-NAX-BTIO-1G. Set the **Bluetooth Enable** toggle to the left to disable Bluetooth wireless audio.

NOTE: While Bluetooth audio is disabled on the device, some applications that scan for Bluetooth devices may still be able to detect the DM-NAX-BTIO-1G. These devices will not be able to connect to the DM-NAX-BTIO-1G or cast audio to it while Bluetooth audio is disabled.

- Set the **Pairing Active** toggle to the right to enable pairing mode, allowing Bluetooth devices to pair to the DM-NAX-BTIO-1G. Set the **Pairing Active** toggle to the left to disable pairing mode.
- The **Paired Devices** table displays the name and status of all remembered Bluetooth devices that have previously paired with the DM-NAX-BTIO-1G.
 - The DM-NAX-BTIO-1G can remember up to seven previously paired devices.
 - Only one paired Bluetooth device can have a **Connected** at a time. All other paired devices will display a **Disconnected** status.
 - To disconnect a connected device, click the button.
 - To forget a remembered device from the **Paired Devices** table, click the button.

Advanced Bluetooth Settings




Bluetooth

Main [Advanced](#)

— Advanced (Autosaved) —

Connection Management Exclusive

Reconnect Behavior Manual

 Paired Device Options

Pairing Code Enabled ☐

Connect Chime Enable ☒


Disconnect Chime Enable ☒

To configure the settings on the **Advanced** tab of the Bluetooth settings section:

- Select a **Connection Management** option from the drop-down.
 - **Interrupt** connection management means that remembered paired devices can reconnect to the DM-NAX-BTIO-1G from their Bluetooth connections list, and will interrupt any currently playing audio when they do so. The most recent device to select the DM-NAX-BTIO-1G from its Bluetooth list will have a **Connected** status in the **Paired Devices** table, and all other devices will revert to **Disconnected**.
 - **Exclusive** connection management means that remembered paired devices can reconnect to the DM-NAX-BTIO-1G from their Bluetooth connections list, but they will not be able to play audio until the currently **Connected** device is disconnected. Whichever device was already listed as **Connected** in the **Paired Devices** table will remain as the **Connected** device until it is disconnected by programming, from the web interface, or by the casting device itself.
- Select a Reconnect Behavior option from the drop-down.
 - Manual reconnection means that the Bluetooth casting device must be reconnected to the DM-NAX-BTIO-1G by selecting the DM NAX device from the casting device's Bluetooth menu after a casting session ends or the device goes out of range of the DM NAX device.
 - Automatic reconnection means that the Bluetooth casting device reconnects to the DM-NAX-BTIO-1G when it re-enters the wireless range of the DM NAX device.

- Click the **Paired Device Options** button to open a **Paired Device Options** window with a drop-down menu and a **Send** button. Select a command from the drop-down menu, then click the Send button to issue the command to the DM NAX device.
 - **Release All Paired Devices** will disconnect all currently paired devices from the DM-NAX-BTIO-1G.
 - **Release Inactive Paired Devices** will disconnect any paired device that is out of range of the DM-NAX-BTIO-1G.
 - **Forget All Paired Devices** will delete all currently paired devices from the **Paired Devices** table of the DM-NAX-BTIO-1G.
 - **Forget Inactive Paired Devices** will delete any paired devices from the **Paired Devices** table that are out of range of the DM-NAX-BTIO-1G.
 - **Forget Connected Devices** will delete any device from the **Paired Devices** table that has a **Connected** status.
- **Pairing Code Enabled** is reserved for future use.
- Set the **Connect Chime Enable** toggle to the right to hear a short chime audio file whenever a device successfully pairs to the DM-NAX-BTIO-1G. This chime is played back on the Bluetooth audio input path. Any outputs that receive the Bluetooth audio input signal will receive the chime audio. Set the **Connect Chime Enable** toggle to the left to disable the connect chime.
- Set the **Disconnect Chime Enable** toggle to the right to hear a short chime audio file whenever a device is disconnected from the DM-NAX-BTIO-1G. This chime is played back on the Bluetooth audio input path. Any outputs that receive the Bluetooth audio input signal will receive the chime audio. Set the **Disconnect Chime Enable** toggle to the left to disable the disconnect chime.

Display



Display

Brightness 37 %

Standby Timeout 1 Minutes


Button Lockout ☐

The **Display** section contains settings that affect the front panel OLED display of the DM-NAX-BTIO-1G.

- To adjust the display brightness:
 - Click the **%** arrows to increase or decrease the brightness. Values range from 0 to 100%, adjustable in increments of 1%.
 - Manually enter a percentage value in the **Brightness** text field.
- To adjust the display standby timeout:
 - Click the **Minutes** arrows to increase or decrease the brightness. The default timeout value is one minute.
 - Manually enter a value in the **Standby Timeout** text field.
- Set the **Button Lockout** toggle to the right to lock out the front panel buttons on the DM-NAX-BTIO-1G. Set the **Button Lockout** toggle to the left to disable the lockout.

Output Channels

The **Zones** section contains the **Volume** and **Mute** settings for all zone outputs of the device, as well as a Configure option for more advanced settings within each zone.




Give each zone a friendly name using the **Name** column of the **Zones** table. If the device is paired with a control system, these names may be overwritten by the control system's program.

To configure the zone volume, do one of the following:

- Move the **Volume** slider to the right to increase or to the left to decrease the zone volume.
- Click the % arrows to increase or decrease the zone volume. Values range from 0 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Volume** field.


To mute all audio output from a zone, click its respective **Mute** button. To unmute the zone, click the **Muted** button.

Zone Settings

To configure zone settings, click the **Configure** button ( **Configure**). The **Edit Zone** window appears.

Zone

Click **Zone** to access the settings for **Balance** and **Delay**.



Balance

To adjust the left/right balance of the stereo output signal, do one of the following:

- Move the **Balance** slider to the right to shift the stereo balance to the right channel or to the left to shift the balance to the left.
- Click the arrows to adjust the balance left or right. The up arrow shifts the balance to the right while the down arrow shifts the balance to the left.
- Manually enter a value in the **Balance** field. Values range from -50 to 50, adjustable in increments of 1. Positive values shift the balance to the right while negative values shift the balance to the left.

Delay

To set the delay, do one of the following:

- Move the **Delay Time(ms)** slider to the right to increase or to the left to decrease the delay time.
- Click the **ms** arrows to increase or decrease the delay. Values range from 0 ms to 85 ms, adjustable in increments of 1 ms.
- Manually enter a value in the **Delay Time(ms)** field.

NOTE: The Delay feature is only available on the line level output channels.

Output

Click **Output** to access the settings for **Minimum/Maximum Volume**, **Stereo/Mono**, and **Signal**.

Output

Minimum / Maximum (Autosaved)

Minimum

0

%

Maximum

100

%

Default

30

%

Stereo / Mono (Autosaved)

Stereo / Mono

Stereo

Mono

Zone Configuration

Standard

Signal (Autosaved)

Signal

Not Present

Minimum/Maximum Volume

Minimum / Maximum (Autosaved)

Minimum

0

%

Maximum

100

%

Default

30

%

1. To set the minimum volume of the zone, do one of the following:

- Move the **Minimum** slider to the right to increase or to the left to decrease the minimum volume.
- Click the **%** arrows to increase or decrease the minimum volume. Values range from 0 to 50%, adjustable in increments of 1%.
- Manually enter a value in the **Minimum** field.

2. To set the maximum volume of the zone, do one of the following:

- Move the **Maximum** slider to the right to increase or to the left to decrease the maximum volume.
- Click the **%** arrows to increase or decrease the maximum volume. Values range from 70 to 100%, adjustable in increments of 1%.
- Manually enter a value in the **Maximum** field.

NOTE: When a **Minimum** and **Maximum** volume are set, the 1-100% range represented by the **Zone** and **Default** volume controls are scaled to the range set. For example, if a **Minimum** of 10% and a **Maximum** of 80% are set for a zone, the 1-100% range of the **Zone** volume control is scaled to the 10%-80% range set as the **Minimum** and **Maximum**.

3. To set the default volume of the zone, do one of the following:

- Move the **Default** slider to the right to increase or to the left to decrease the default volume.
- Click the **%** arrows to increase or decrease the default volume. Values range from 0 to 50%, adjustable in increments of 1%.
- Manually enter a value in the **Default** field.

NOTE: The **Default** volume is applied as the **Zone** volume any time the zone receives a source route and no source was previously routed to that zone.

Stereo/Mono

Stereo / Mono (Autosaved)

Stereo / Mono ☒ Stereo ☐ Mono

Zone Configuration Standard

Select either **Stereo** or **Mono** from the **Stereo/Mono** radio buttons. If **Stereo** is selected, both output channels can have independent audio content. If **Mono** is selected, both output channels receive the same audio content.

Signal

Signal (Autosaved)

Signal Not Present

Clipping None

The **Signal** section is a read-only field that displays the **Signal** and **Clipping** status of the zone output.

- If an output signal is present but not clipping, **Signal** will display **Present** in green and **Clipping** will display **None** in green.
- If an output signal is present and clipping, **Signal** will display **Present** in green and **Clipping** will display **Present** in red.
- If no output signal is detected, **Signal** will display **Not Present** in red and **Clipping** will display **None** in green.

Click **Done** to return to the **Settings** tab of the web user interface.

Inputs

The **Inputs** section is used to configure the **Name**, **Compensation**, and **Mute** attributes of the available analog, digital, and media streaming inputs on the DM-NAX-BTIO-1G.

	LineIn	BTIn
Name	LineIn	BTIn
Gain (db)	0	0
Signal Present		
Clipping Detected	Nominal	Nominal
Mute	<input type="checkbox"/>	<input type="checkbox"/>

Configure Inputs

1. If needed, enter a friendly name for each input in its **Name** field.
2. To set a level compensation adjustment for a given input, do one of the following:
 - Move the **Compensation** slider up to increase or down to decrease the level compensation. Compensation increases or decreases the level of the incoming audio signal on any of the physical inputs on the device's rear panel.
 - Click the **db** arrows to increase or decrease the compensation. Values range from -10 dB to 10 dB, adjustable in increments of 1 dB.
 - Manually enter a value in the **Compensation** field.

5. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled for a given stream, the stream will begin transmitting automatically and will be available as a multicast stream on your network at the specified multicast address.
 - If **Auto Initiation** is disabled for the input, the stream will not begin transmitting until it is manually initiated.
6. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number for DM NAX streams is 5004.
7. Click **OK** to save or click **Cancel** to cancel the changes.

Configure Receivers

1. Enter the multicast address of a transmitting stream in the **Requested Stream Address** field to subscribe the receiver to the stream.
2. Click the configure button (⚙️) in the **Actions** column. The **Configure** dialog appears:


3. Set the **Auto Initiation** toggle to the right position to enable auto initiation. Set the toggle to the left position to disable auto initiation.
 - If **Auto Initiation** is enabled, the stream will begin automatically when the receiver subscribes to the transmitter.
 - If **Auto Initiation** is disabled, the stream will not begin until it is manually initiated.

4. To set the port number, do one of the following:
 - Click the arrows to increase or decrease the port number by increments of 1.
 - Manually enter a port number in the **Port** field. The default port number is 5004.
5. Click **OK** to save or click **Cancel** to cancel the changes.

Routing

The **Routing** section is used to route a local input or AES67 stream to a Zone on the DM-NAX-BTIO-1G.

NOTE: To receive an AES67 stream from Dante devices, see [OLH 1001151](#).



To route an input to a zone, click the box in the routing matrix where the zone's row overlaps the corresponding input's column. Once a route is made, appears. To break a given route click or . To route a single input to all zones, click on the icon under the input's name.

Security

Click the **Security** tab to configure security for users and groups and to allow different levels of access to the DM-NAX-BTIO-1G functions. By default, security is disabled.

✓ Status

⚙ Settings

🔒 Security

⚙ 802.1x Configuration

▼ Security

SSL Mode

Encrypt

▼

SSL Authentication

Username *

chdevice

Password *

Confirm Password *

Current User

Users

Groups

Name

admin

Access Level

Administrator

Active Directory User

No

Groups

Administrators

Change Current User Password

Select **Encrypt and Validate**, **Encrypt**, or **OFF** in the **SSL Mode** drop-down menu, to specify whether to use encryption. By default, SSL Mode is set to **OFF**.

Current User

Click the **Current User** tab to view read-only information or to change the password for the current user.

Current User

Users

Groups

Name

admin

Access Level

Administrator

Active Directory User

No

Groups

Administrators

Change Current User Password

1. Click the **Change Current User Password** button to provide a new password for the current user.
2. In the **Change Password** dialog, enter the current password in the **Current Password** field, the new password in the **Password** field, and then re-enter the same new password in the **Confirm Password** field.

Change Password

Current Password

.....

Password

.....

Confirm Password

.....|


✓ OK

✕ Cancel

3. Click **OK** to save or click **Cancel** to cancel the changes.

Users

Click the **Users** tab to view and edit user settings. The **Users** tab can be used to add or remove local and Active Directory users and preview information about users.



Use the **Search Users** field to enter search term(s) and display users that match the search criteria.

If users listed in the **Users** table span across multiple pages, navigate through the list of users by clicking a page number or by using the left or right arrows at the bottom of the **Users** pane to move forward or backward through the pages.

Each page can be set to display 5, 10, or 20 users by using the drop-down menu to the right of the navigation arrows.

Information about existing users is displayed in table format and the following details are provided for each user.


- **Username:** Displays the name of the user.
- **AD User:** Displays whether the user requires authentication using Active Directory.

Click the corresponding button in the Actions column to view detailed user information or to delete the user.

To create a new user, click the **Create User** button.

Create a New Local User

1. Click the **Create User** button in the User tab.
2. In the **Create User** dialog, enter the following:



The screenshot shows a 'Create User' dialog box. The 'Name' field contains the text 'test'. The 'Active Directory User' toggle switch is turned off. The 'Password' and 'Confirm Password' fields are both filled with dots, indicating they are masked. The 'Groups' dropdown menu is set to 'Administrators'. At the bottom right, there are two buttons: 'OK' and 'Cancel'.

- a. Enter a user name in the **Name** field. A valid user name can consist of alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
- c. Assign the access level by selecting one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is disabled.

3. Click **OK** to save or click **Cancel** to cancel the changes.


Add an Active Directory User

Users cannot be created or removed from the Active Directory server, but access can be granted to an existing user in the Active Directory server.

To grant access to an Active Directory user, you can either add the user to a local group on the DM-NAX-BTIO-1G, or add the Active Directory group(s) that they are a member of to the DM-NAX-BTIO-1G.

To add an Active Directory user.

1. Click the **Create User** button.
2. In the **Create User** dialog, enter the following.




The screenshot shows a 'Create User' dialog box with a blue header. It contains three main fields: 'Name' with the text 'Connects\test', 'Active Directory User' with a blue toggle switch turned on, and 'Groups' with a dropdown menu showing 'Connects'. At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'x' icon.

- a. Enter a user name in the **Name** field in the format "Domain\UserName", for example "crestronlabs.com\JohnSmith". Valid user names can contain alphanumeric characters (letters a-z, A-Z, numbers 0-9) and the underscore "_" character.
- b. Select one or more groups from the **Groups** drop-down list.

NOTE: Make sure that the **Active Directory User** toggle is set to enabled.


3. Click **OK** to save or click **Cancel** to cancel the changes.

Delete User


Click the trashcan button () in the **Actions** column to delete the user. Click **Yes** when prompted to delete the user or **No** to cancel the deletion.

After a user is removed from a group, they lose any access rights associated with that group. Note that the user account is not deleted by the delete user operation.

View User Details

Click the information button () in the **Actions** column to view information for the selected user. The **User Details** dialog displays the following information for the selected user.

- **Name:** Displays the name of the selected user.
- **Active Directory User:** Displays whether the user is an Active Directory user.
- **Group:** Displays group(s) the selected user is part of.




The **User Details** dialog box shows the following information for the selected user:

Name	admin1
Active Directory User	No
Groups	Administrators

At the bottom right, there is a blue button with a checkmark and the text **OK**.

Click **OK** to close the **User Details** dialog and to return to the **Users** tab.


Update User Details



The **Update User** dialog box shows the following information for the selected user:

Name	admin1
Active Directory User	<input type="checkbox"/>
Password	<input type="password"/>
Confirm Password	<input type="password"/>
Groups	Administrators

At the bottom right, there are two blue buttons: one with a checkmark and the text **OK**, and another with an 'X' and the text **Cancel**.

1. Click the edit button () in the **Actions** column to update information for the selected user.
2. Enter a password in the **Password** field; re-enter the same password in the **Confirm Password** field.
3. Select one or more groups to assign the user to from the **Groups** drop-down list.
4. Click **OK** to save or click **Cancel** to cancel the changes.

The **Update User** dialog also displays the following read-only information for the selected user.

- **Name:** Displays the name of the user.
- **Active Directory User:** Displays whether the user is an Active Directory user.











Groups

Click the **Groups** tab to view and edit group settings. The **Groups** tab can be used to add local and Active Directory groups, remove local and Active Directory groups, and preview information about a group.

Use the **Search Groups** field to enter search term(s) and display groups that match the search criteria.

Current UserUsersGroups

Search...

Group Name	AD Group	Access Level	Actions
Administrators	No	Administrator	 
Connects	No	Connect	 
Operators	No	Operator	 
Programmers	No	Programmer	 
Users	No	User	 

<<<1>>>

10



Create Group

If groups listed in the **Groups** table span across multiple pages, navigate through the groups by clicking a page number or by using the left or right arrows at the bottom of the Groups pane to move forward or backward through the pages.

Additionally, each page can be set to display 5, 10, or 20 groups by using the drop-down menu to the right of the navigation arrows.


Existing groups are displayed in a table and the following information is provided for each group:

- **Group Name:** Displays the name of the group.
- **AD Group:** Displays whether the group requires authentication using Active Directory.
- **Access Level:** Displays the predefined access level assigned to the group (Administrator, Programmer, Operator, User, or Connect).

Click the corresponding button in the **Actions** column to view detailed group information () or to delete () selected group.

Click on the **Create Group** button in the **Groups** tab to create new group.

Create Local Group



The screenshot shows a 'Create Group' dialog box with a blue header. It contains three main fields: 'Name' with the text 'test12', 'Access Level' with a dropdown menu showing 'Programmer', and 'Active Directory Group' with a toggle switch that is currently turned off. At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'X' icon.


1. Click the **Create Group** button.
2. In the **Create Group** dialog, enter the following:
 - a. Enter the group name in the **Name** field.
 - b. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is disabled.

3. Click **OK** to save. Click **Cancel** to cancel the changes.

Add Active Directory Group

A group cannot be created or removed from the Active Directory server, but access can be granted to an existing group in Active Directory.



The screenshot shows a 'Create Group' dialog box with a blue header. It contains three main fields: 'Name' with the text 'test', 'Access Level' with a dropdown menu showing 'Administrator', and 'Active Directory Group' with a toggle switch that is currently turned on. At the bottom right, there are two buttons: 'OK' with a checkmark icon and 'Cancel' with an 'X' icon.

Once the group is added, all members of that group will have access to the DM-NAX-BTIO-1G.


1. Click the **Create Group** button.
2. In the **Create Group** dialog enter the following:
 - a. Enter the group name in the **Name** field, for example "Engineering Group". Note that group names are case sensitive; a space is a valid character that can be used in group names.

3. Assign the group access level by selecting a predefined access level (Administrator, Connect, Operator, Programmer, User) from the **Access Level** drop-down list.

NOTE: Make sure that the **Active Directory Group** toggle is enabled.


4. Click **OK** to save. Click **Cancel** to cancel the changes.


Delete a Group

Click the trashcan button () in the **Actions** column to delete a group. Click **Yes** when prompted to delete the group or **No** to cancel the deletion.

When a group is deleted, users in the group are not removed from the device or Active Directory server. However, because a user's access level is inherited from a group(s), users within the deleted group will lose access rights associated with the group.

View Group Details

Click the information button () in the **Actions** column to view information for the selected group. The **Group Details** dialog lists the following information for the selected group.



The Group Details dialog box displays the following information:

Name	Administrators
Access Level	Administrator
Active Directory Group	No

At the bottom right, there is a blue button with a checkmark and the text **OK**.

- **Name:** Displays the name of the group.
- **Access Level:** Displays the access level of the group and its users.
- **Active Directory Group:** Displays whether the group is an Active Directory group.

Click **OK** to close the **Group Details** dialog and to return to the Groups tab.

802.1x Configuration

The DM-NAX-BTIO-1G has built-in support for the 802.1X standard (an IEEE network standard designed to enhance the security of wireless and Ethernet LANs. The standard relies on the exchange of messages between the device and the network's host, or authentication server), allowing communication with the authentication server and access to protected corporate networks.

StatusSettingsSecurity802.1x Configuration

802.1x Configuration

IEEE 802.1x Authentication

Authentication Method

EAP MSCHAP V2- password

Domain

secure12

Username

admin

Password

Enable Authentication Server Validation

Select Trusted Certificate Authorities

Q

☒ AAA Certificate Services

☐ AC RAIZ FNMT-RCM

☐ ACCVRAIZ1

☐ Actalis Authentication Root CA

☒ AffirmTrust Commercial

☐ AffirmTrust Networking

☐ AffirmTrust Premium ECC

☒ AffirmTrust Premium

☐ Amazon Root CA 1

☐ Amazon Root CA 2

☒ Amazon Root CA 3

☐ Amazon Root CA 4

☐ Atos TrustedRoot 2011

☐ Autoridad de Certificacion Firmaprofesional CIF A62634068

☐ Baltimore CyberTrust Root

To Configure DM-NAX-BTIO-1G for 802.1X Authentication

1. Set the **IEEE 802.1X Authentication** toggle to enabled. This will enable all options on the 802.1X dialog.
2. Select the **Authentication method: EAP-TLS Certificate** or **EAP-MSCHAP V2 Password** according to the network administrator's requirement.
3. Do either one of the following:
 - Select **EAP-TLS Certificate**, click **Action/Manage Certificates** to upload the required machine certificate. The machine certificate is an encrypted file that will be supplied by the network administrator, along with the certificate password.
 - Select **EAP-MSCHAP V2 Password**, enter the username and password supplied by the network administrator into the **Username** and **Password** fields. This method does not require the use of a machine certificate, only the user name and password credentials.
4. If you enabled the **Enable Authentication Server Validation** option, this will enable the **Select Trusted Certificate Authority(ies)** list box which contains signed Trusted Certificate Authorities (CAs) preloaded into the DM-NAX-BTIO-1G.

Select the check box next to each CA whose certificate can be used for server validation, as specified by the network administrator.

If the network does not use any of the listed certificates, the network administrator must provide a certificate, which must be uploaded manually via the **Manage Certificates** functionality.
5. If required, type the domain name of the network in the **Domain** field.
6. When the 802.1X settings are configured as desired, click **Save Changes** to save the changes to the device and reboot it. Click **Revert** to cancel any changes.

Access the Web Interface With the Crestron Toolbox™ Application

To access the web interface by opening a web browser within the Crestron Toolbox™ application, do the following:

1. Open the Crestron Toolbox application.
2. From the **Tools** menu, select **Device Discovery Tool**. You can also access the Device Discovery Tool by clicking the Device Discovery Tool button () in the Crestron Toolbox toolbar. The DM-NAX-BTIO-1G is discovered and listed in the device list on the left side of the screen. The associated host name, IP address, and firmware version are also displayed.

NOTE: If there is security software running on the computer, a security alert might be displayed when the Crestron Toolbox application attempts to connect to the network. Make sure to allow the connection, so that the Device Discovery Tool can be used.

3. In the Device Discovery Tool list, double-click your device.
4. Enter your credentials in the **Authentication Required** dialog that opens, and then click **Log In**.
5. Click the **Web Configuration** button in the Configuration page displayed on the left side of the Device Discovery Tool.

Resources

The following resources are provided for DM NAX®.

NOTE: You may need to provide your Crestron.com web account credentials when prompted to access some of the following resources.

Crestron Support and Training

- [Crestron True Blue Support](#)
- [Crestron Resource Library](#)
- [Crestron Online Help \(OLH\)](#)
- [Crestron Training Institute \(CTI\) Portal](#)

Programmer and Developer Resources

- help.crestron.com: Provides help files for Crestron programming tools such as SIMPL, SIMPL#, and Crestron Toolbox™ software
- developer.crestron.com: Provides developer documentation for Crestron APIs, SDKs, and other development tools

Product Certificates

To search for product certificates, refer to support.crestron.com/app/certificates.

