

**Name:**

Intercom IVDS GUI Interface

**Summary:**

This module handles routing an IVDS input to an IVDS output.

**General Notes:**

This module is part of a set of modules available to simplify Intercom programming. The other modules in the set are:

- Intercom Manager
- Intercom IADS GUI Interface
- Intercom TPS-12 (Ethernet) GUI Interface
- Intercom TPMC-8X GUI Interface
- Intercom TPMC-8L GUI Interface
- Intercom TPMC-3X GUI Interface
- Intercom TPMC-4SM GUI Interface
- Intercom DGE-1 (Ethernet) GUI Interface
- Intercom TPS-6L (Ethernet) GUI Interface
- Intercom C2N-IIF GUI Interface
- Barix GUI Interface

**Inputs/Outputs/Parameters:**

**Inputs:**

<p>&lt;IVDS_Info_In&gt;</p>	<p>Connect this signal to the &lt;Video_Switcher_Info_Out&gt; feedback signal on the <i>Intercom Manager</i>.</p> <p>This signal will be used to receive all information from the <i>Intercom Manager</i>.</p>
<p>&lt;Src-For-Out-1&gt; - &lt;Src-For-Out-24&gt;</p>	<p>Specifies the IVDS input to be routed to the output.</p> <p>Range = 0d to 24d</p> <p>0d – No Input 1d – Input 1 2d – Input 2 3d – Input 3 4d – Input 4 5d – Input 5 6d – Input 6 7d – Input 7 8d – Input 8 9d – Input 9</p>

	10d – Input 10 11d – Input 11 12d – Input 12 13d – Input 13 14d – Input 14 15d – Input 15 16d – Input 16 17d – Input 17 18d – Input 18 19d – Input 19 20d – Input 20 21d – Input 21 22d – Input 22 23d – Input 23 24d – Input 24
--	--

**Outputs:**

<IVDS_Info_In>	<p>Connect this signal to the &lt;Audio_Switcher_Info_In&gt; signal on the <i>Intercom Manager</i>.</p> <p>This signal will be used to receive all information from the <i>Intercom Manager</i>.</p>
----------------	--

**Parameters:**

IVDS Input 1– IVDS Input 24	<p>Specify the UI location index that is connected physically to the corresponding IVDS input. The Index is directly similar to which of the &lt;UI_1_Information_IN&gt; - &lt;UI_24_Information_IN&gt; signals on the <i>Intercom Manager</i>, the location is connected to.</p> <p>Example: For a UI connected to &lt;UI_1_Information_IN&gt; on the <i>Intercom Manager</i> and physically to IVDS input 4, this parameter for IVDS input 4 (&lt;IVDS Input 4&gt;) should be specified as 1d.</p>
IVDS Output 1 – IVDS Output 24	<p>Specify the UI location index or device that is connected physically to the corresponding IVDS output. The Index is directly similar to which of &lt;UI_1_Information_IN&gt; - &lt;UI_24_Information_IN&gt; signals on the <i>Intercom Manager</i>, the location is connected to.</p> <p>Example: For a UI connected to &lt;UI_4_Information_IN&gt; on the <i>Intercom Manager</i> and physically to IVDS output 1, this parameter for IVDS output 1 (&lt;IVDS Output 1&gt;) should</p>

	be specified as 4d. For a NVS-100 connected to the output, select NVS-100 instead of the UI location index.
--	--

**Revision History:**

Version 1.0.0 – Initial Release