DMF-RMC-4K-SFP
## DigitalMedia™ SFP+ 4K Fiber Receiver

DO Install the Device

The Crestron® DMF-RMC-4K-SFP can be mounted onto a flat surface or onto a rack rail.

Mounting onto a Flat Surface

Using four mounting screws (not included), mount the device onto a flat surface such as a wall.

Mounting onto a Wall

Mounting onto a Rack Rail

Using two mounting screws (not included), mount the left or right mounting flange of the device onto the front or rear rail of a rack.

Mounting onto a Rack Rail

DO Check the Box

QTY	PRODUCT	PART NUM.
1	Cable, RJ-45 Male - DB9 Female, 6' (1.83 m)	2043246
1	Connector, 4-Pin	2003576
2	Connector, 5-Pin	2003577
1	Power Cord, 5' 10" (1.78 m)	2042043
1	Power Pack, 24 Vdc, 2.5 A, 100-240 Vac	2045873

DO Connect the Device

Connect the device as required for the application.

Top View

To/from serial port on PC (cable included)

To/from USB port on PC

To IR controllable devices

To/from RS-232 device

Ground

24 Vdc from power pack (included)

Bottom View

10BASE-T/ 100BASE-TX/ 1000BASE-T Ethernet to LAN or local network device*

From DM OUT port of DigitalMedia™ SFP+ transmitter†

To HDMI® display

From HDMI audio/video source

Balanced/ unbalanced stereo line level audio output

*To connect to the LAN, use either the LAN port of the DMF-RMC-4K-SFP or the LAN port of the DigitalMedia SFP+ transmitter (DMF-TX-4K-SFP or DMCF-TX-4K-SFP)—do not connect the receiver and transmitter LAN ports to the LAN simultaneously.

†Use Crestron® SFP+ transceiver modules only. Refer to the SFP-10G Series DO Guide (Doc. 7862) for additional information.

DO Configure the Device

NOTE: If the HDMI® output of the DMF-RMC-4K-SFP connects to a DigitalMedia™ switcher, the switcher automatically configures the IP table of the DigitalMedia SFP+ transmitter (DMF-TX-4K-SFP or DMCF-TX-4K-SFP) according to the SIMPL program. The transmitter hosts the configuration settings of the DMF-RMC-4K-SFP.

If the DMF-RMC-4K-SFP connects to a DigitalMedia SFP+ transmitter (DMF-TX-4K-SFP or DMCF-TX-4K-SFP) in a stand-alone configuration, do the following:

- Configure the routing, input, and output settings of the DMF-RMC-4K-SFP when configuring the DigitalMedia SFP+ transmitter. The transmitter hosts the configuration of the settings for the DMF-RMC-4K-SFP.

- Configure network and device settings of the DMF-RMC-4K-SFP by using the web interface of the DMF-RMC-4K-SFP. To access the web interface, open a web browser and then go to the IP address of the device.

  NOTE: By default, DHCP is enabled. To display the IP address on the connected display, press the **SETUP** button on the top panel of the DMF-RMC-4K-SFP.

  To log in to the web interface, enter the user name and password. The default user name is *admin*, and the default password is *admin*.

DO Learn More

Visit the website for additional information and the latest firmware updates. To learn more about this product, use a QR reader application on your mobile device to scan the QR image.

Crestron Electronics
15 Volvo Drive, Rockleigh, NJ 07647
888.CRESTRON | www.crestron.com

CRESTRON. DO GUIDE

DOC. 7903B (2046657) 09.16
Specifications subject to change without notice.